Connect sensors (camera, Lidar) to Jetson Nano Rapider Jetson Nano O 40 GND O 38 37 40 GND 0 O GND 35 Fan 34 33 0 32 31 0 0 0 GND 29 28 27 0 26 GND 0 0 0 24 23 Rapider Driver Board 22 21 0 0 0 GND 19 0 Raspberry Pi Camera 18 3V3 0 0 0 16 15 GND 13 0 12 11 0 10 GND 0 8 7 GND 5 Pi OLED 5V 3 5V 3V3 000 Ethemet **HDMI** USB USB Jake USB

Connect Jetson Nano to motor control board

Motor Control Board

