# **SIEMENS**

# HiPath 4000 ComWin 300

Programmers Guide / Reference

Guide



1P P30357-B9800-B10-101 EN

The information in this document contains only general descriptions or general features, which may not be available as described for actual application and/or which can change due to further product development.

The desired features are therefore only binding if formally specified at the closing of the contract.



The device conforms to the EU directive 1999/5/EG, as attested by the CE mark



This device has been manufactured in accordance with our certified environmental management system (ISO 14001). This process ensures that energy consumption and the use of primary raw materials are kept to a minimum, thus reducing waste production.

# **Content**

1	ComWin 300 Architecture	5
	The CBL Language	
	1 Syntax description	
	2.1.1 program	
	2.1.2 statement	
	2.1.3 assign_stmt	9
	2.1.4 call_stmt	
	2.1.5 syn_stmt	10
	2.1.6 enum_stmt	
	2.1.7 set_stmt	12
	2.1.8 text_table_stmt	
	2.1.9 signature_stmt	
	2.1.10 empty_stmt	
	2.1.11 include_stmt	13
	2.1.12 import_stmt	
	2.1.13 function_stmt	15
	2.1.14 function_parameters	
	2.1.15 declaration_stmt	
	2.1.16 class_stmt	
	2.1.17 class_member	
	2.1.18 ole/dll_cls_member	
	2.1.19 ole_type	24
	2.1.20 if_stmt	
	2.1.21 for_stmt	
	2.1.22 while_stmt	28
	2.1.23 do_while_stmt	
	2.1.24 try_catch_stmt	
	2.1.25 throw_stmt	30
	2.1.26 with_stmt	31
	2.1.27 return_stmt	
	2.1.28 break_stmt	33
	2.1.29 block	33
	2.1.30 expression	35
	2.1.31 binop	36
	2.1.32 type_identifier	41
	2.1.33 identifier	42
	2.1.34 alpha	43
	2.1.35 digit	43
	2.1.36 number	
	2.1.37 hex	43

2.1.38 quotstring	44
	45
2.1.40 comment (single line)	45
2.2 Summary of keywords	46
2.3 Advanced topics	47
	47
2.3.2 Working with reference variables	48
	53
	56
<u> </u>	58
3 CBL - Programmer's Reference	
3.1.1 Command line parameters: Args	
3.1.2 Interpreter functions	
3.2 General functions	
	63
	75
\ = /	76
3.2.4 cbllniFile (ole_class)	
3.2.5 cblZipFile (ole_class)	
3.2.6 cbl_dialogs (ole_class)	
3.2.7 cblXmlFile (ole_class)	
· ·	82
3.3.1 Comedit (ole_class)	
3.3.2 ComwinControl (ole_class)	
3.3.3 ComwinFrame (ole_class)	109
3.3.4 ComwinCBL (ole_class)	113
3.3.5 ComWinFT (ole_class)	114
3.3.6 ComWinPPP (ole_class)	120
3.3.7 ComWinAccessServer (ole_class)	122
	122
3.3.9 ComWinAccessFileman (ole_class)	123
3.3.10 ComWinAccessDatabase (ole_class)	124
· · · · · · · · · · · · · · · · · · ·	125
·	128
· ·	130
	130
	131
	136
	147
	148
· ·	152
· · · · · · · · · · · · · · · · · · ·	153
	153
	154


4 Introduction into CBL Programming	155
4.1 Preface	155
4.1.1 What is CBL?	155
4.1.2 What do we need to start?	156
4.2 Data types, variables and operators	158
4.2.1 Primitive data types	
4.2.2 Operators	
4.3 Statement and Expression	175
4.3.1 Expression	
4.3.2 Statement flow control	
4.4 Object and Class	
4.4.1 What is an object?	
4.4.2 Object instantiation	
4.4.3 Class	
4.5 Programming with GUI-Builder	
4.6 ComWin Interoperation	
·	
1 HiPath 4000 Expert Access Architecture	
2 Latest Enhancements	
2.1 Integration of the SOAP Interface	
2.2 Import of XML Schema Files (XSD)	
2.3 Import of ASN.1 specifications	9
3 The CBL Language	. 10
3 The CBL Language	
	. 10
3.1 Syntax description	. 10 . 10
3.1 Syntax description	. 10 . 10 . 11
3.1 Syntax description	. 10 . 10 . 11 . 13
3.1 Syntax description3.1.1 program3.1.2 statement3.1.3 assign_stmt3.1.4 call_stmt	. 10 . 10 . 11 . 13
3.1 Syntax description	. 10 . 10 . 11 . 13 . 14
3.1 Syntax description         3.1.1 program         3.1.2 statement         3.1.3 assign_stmt         3.1.4 call_stmt         3.1.5 syn_stmt	. 10 . 11 . 13 . 14 . 14
3.1 Syntax description 3.1.1 program. 3.1.2 statement 3.1.3 assign_stmt 3.1.4 call_stmt 3.1.5 syn_stmt 3.1.6 enum_stmt	. 10 . 11 . 13 . 14 . 14
3.1 Syntax description 3.1.1 program. 3.1.2 statement 3.1.3 assign_stmt 3.1.4 call_stmt 3.1.5 syn_stmt 3.1.5 syn_stmt 3.1.6 enum_stmt 3.1.7 set_stmt. 3.1.8 text_table_stmt	. 10 . 10 . 11 . 13 . 14 . 15 . 16
3.1 Syntax description 3.1.1 program 3.1.2 statement 3.1.3 assign_stmt 3.1.4 call_stmt 3.1.5 syn_stmt 3.1.6 enum_stmt 3.1.7 set_stmt. 3.1.8 text_table_stmt 3.1.9 signature_stmt.	. 10 . 10 . 11 . 13 . 14 . 15 . 16 . 16
3.1 Syntax description 3.1.1 program 3.1.2 statement 3.1.3 assign_stmt 3.1.4 call_stmt 3.1.5 syn_stmt 3.1.6 enum_stmt 3.1.7 set_stmt 3.1.8 text_table_stmt 3.1.9 signature_stmt 3.1.10 empty_stmt	. 10 . 10 . 11 . 13 . 14 . 15 . 16 . 16
3.1 Syntax description 3.1.1 program 3.1.2 statement 3.1.3 assign_stmt 3.1.4 call_stmt 3.1.5 syn_stmt 3.1.6 enum_stmt 3.1.7 set_stmt 3.1.8 text_table_stmt 3.1.9 signature_stmt 3.1.10 empty_stmt 3.1.11 include_stmt	. 10 . 10 . 11 . 13 . 14 . 15 . 16 . 17 . 17
3.1 Syntax description 3.1.1 program. 3.1.2 statement 3.1.3 assign_stmt 3.1.4 call_stmt 3.1.5 syn_stmt 3.1.6 enum_stmt 3.1.7 set_stmt. 3.1.8 text_table_stmt 3.1.9 signature_stmt 3.1.10 empty_stmt 3.1.11 include_stmt 3.1.12 import_stmt	. 10 . 10 . 11 . 13 . 14 . 15 . 16 . 16 . 17 . 17
3.1 Syntax description         3.1.1 program.         3.1.2 statement         3.1.3 assign_stmt.         3.1.4 call_stmt         3.1.5 syn_stmt.         3.1.6 enum_stmt         3.1.7 set_stmt.         3.1.8 text_table_stmt         3.1.9 signature_stmt.         3.1.10 empty_stmt         3.1.11 include_stmt         3.1.12 import_stmt         3.1.13 function_stmt.	. 10 . 10 . 11 . 13 . 14 . 15 . 16 . 17 . 17 . 17
3.1 Syntax description 3.1.1 program. 3.1.2 statement 3.1.3 assign_stmt. 3.1.4 call_stmt 3.1.5 syn_stmt. 3.1.6 enum_stmt 3.1.7 set_stmt. 3.1.8 text_table_stmt 3.1.9 signature_stmt. 3.1.10 empty_stmt 3.1.11 include_stmt 3.1.12 import_stmt 3.1.13 function_stmt. 3.1.14 function_parameters	. 10 . 10 . 11 . 13 . 14 . 15 . 16 . 17 . 17 . 17 . 19 . 20
3.1 Syntax description 3.1.1 program. 3.1.2 statement 3.1.3 assign_stmt 3.1.4 call_stmt 3.1.5 syn_stmt 3.1.6 enum_stmt 3.1.7 set_stmt. 3.1.8 text_table_stmt 3.1.9 signature_stmt. 3.1.10 empty_stmt 3.1.11 include_stmt 3.1.12 import_stmt 3.1.13 function_stmt. 3.1.14 function_parameters 3.1.15 declaration_stmt	. 10 . 10 . 11 . 13 . 14 . 15 . 16 . 17 . 17 . 17 . 18 . 19 . 20
3.1 Syntax description 3.1.1 program. 3.1.2 statement 3.1.3 assign_stmt 3.1.4 call_stmt 3.1.5 syn_stmt 3.1.6 enum_stmt 3.1.7 set_stmt. 3.1.8 text_table_stmt 3.1.9 signature_stmt 3.1.10 empty_stmt 3.1.11 include_stmt 3.1.12 import_stmt 3.1.13 function_stmt 3.1.14 function_parameters 3.1.15 declaration_stmt 3.1.16 class_stmt	. 10 . 10 . 11 . 13 . 14 . 15 . 16 . 17 . 17 . 17 . 18 . 19 . 20 . 22 . 25
3.1 Syntax description 3.1.1 program. 3.1.2 statement 3.1.3 assign_stmt 3.1.4 call_stmt 3.1.5 syn_stmt 3.1.6 enum_stmt 3.1.7 set_stmt. 3.1.8 text_table_stmt 3.1.9 signature_stmt 3.1.10 empty_stmt 3.1.11 include_stmt 3.1.12 import_stmt 3.1.13 function_stmt 3.1.14 function_parameters 3.1.15 declaration_stmt 3.1.16 class_stmt 3.1.17 class_member	. 10 . 10 . 11 . 13 . 14 . 15 . 16 . 17 . 17 . 17 . 19 . 20 . 22 . 25 . 26
3.1 Syntax description 3.1.1 program. 3.1.2 statement 3.1.3 assign_stmt 3.1.4 call_stmt 3.1.5 syn_stmt 3.1.6 enum_stmt 3.1.7 set_stmt. 3.1.8 text_table_stmt 3.1.9 signature_stmt 3.1.10 empty_stmt 3.1.11 include_stmt 3.1.12 import_stmt 3.1.13 function_stmt 3.1.14 function_parameters 3.1.15 declaration_stmt 3.1.16 class_stmt	. 10 . 10 . 11 . 13 . 14 . 15 . 16 . 17 . 17 . 17 . 18 . 20 . 22 . 25 . 26

3.1.21 for_stmt	31
3.1.22 while_stmt	32
	33
<b>,</b>	34
	34
	35
3.1.27 return_stmt	36
	37
3.1.29 .try_catch_stmt	38
	38
3.1.31 expression	39
3.1.32 binop	40
3.1.33 type_identifier	45
	46
3.1.35 alpha	47
3.1.36 digit	47
3.1.37 number	47
	47
3.1.39 quotstring	48
	49
	49
, <del>-</del>	50
	51
	51
	53
	57
	60
3.3.5 Working with the SOAP Interface	62
	64
	67
·	
	71
4.1 Interface to the Interpreter	
·	71
	72
	76
	76
= \ = /	89
\	90
$\langle \cdot \rangle = \cdot /$	92
$\mathbf{I}$	93
= 0 \ = /	93
\ = /	94
·	96
4.3.1 Comedit (ole class)	96

4.3.2 ComwinControl (ole_class)		. 114
4.3.3 (mode =2: application handles wrong password, open returns immediate	ely; mod	e =4:
deactivate autologon.)ComwinFrame (ole_class)		. 125
4.3.4 ComwinCBL (ole_class)		
4.3.5 ComWinFT (ole_class)		
4.3.6 ComWinPPP (ole_class)		. 136
4.3.7 ComWinAccessServer (ole_class)		. 138
4.3.8 ComWinAccessSession (ole_class)		. 138
4.3.9 ComWinAccessFileman (ole_class)		. 139
4.3.10 ComWinAccessDatabase (ole_class)		. 140
4.3.11 ComWinAccessQuery (ole_class)		. 141
4.3.12 ComWinFM (ole_class)		. 144
4.4 Designing forms		. 146
4.4.1 Form Layout		
4.4.2 The form class cblForm		. 148
4.4.3 Form controls		. 152
4.4.4 Definition of menus		. 168
4.4.5 Form examples		. 169
4.4.6 Modal dialog example		. 173
4.5 CBL - National Language Support		. 174
4.5.1 CBL-intrinsic text tables		. 174
4.5.2 NLS texts from H.O.T		. 175
5 Introduction into CBL Programming		176
5.1 Preface		
5.1.1 What is CBL?		
5.1.2 What do we need to start?		
5.2 Data types, variables and operators		
5.2.1 Primitive data types		
5.2.2 Operators		
5.3 Statement and Expression		
5.3.1 Expression		
5.3.2 Statement flow control		. 197
		. 197
5.4 Object and Class		202
DATE WORKER AD ODIECTA		
		. 203
5.4.2 Object instantiation		. 203 . 204
5.4.2 Object instantiation		. 203 . 204 . 205
5.4.2 Object instantiation		. 203 . 204 . 205

# 1 HiPath 4000 Expert Access Architecture

This chapter gives a brief overview of the HiPath 4000 Expert Access architecture.



The HiPath 4000 Expert Access architecture is characterized by several program components which communicate via the OLE automation interface. This interface makes it possible to execute a procedure or access a property contained in another program. The other program must offer this procedure or property.

The main components of the HiPath 4000 Expert Access Framework are:

- HiPath 4000 Expert Access CBL Interpreter: An interpreter and debugger for the new programming language "CBL" as an alternative to the MACRO language of PC-Comtes.
- HiPath 4000 Expert Access Connect: The program controlling and keeping connections to one or more switches. Complete (and of course enhanced) functionality of PC-Comtes
- HiPath 4000 Expert Access MML Editor: The MML command editor. ("Comedit-Window of PC-Comtes")

#### **HiPath 4000 Expert Access Architecture**

- HiPath 4000 Expert Access Frame: A frame application which can be seen as HiPath 4000 Expert Access-entry point for applications which want use HiPath 4000 Expert Access as Server (via OLE or HTTP-interface).
- HiPath 4000 Expert Access FileTransfer: An OLE server application with which files can be transported using various protocols.
- HiPath 4000 Expert Access GuiBuilder: The prototype of a tool to support the creation of CBL programs, see "Designing forms" on page 146.

The CBL intrinsic OLE interface can be used to contact 3rd Party or owner written programs as well (e. g. Microsoft Word, Excel, Netscape Navigator).

The HTTP-Server which is part of the CBL frame is not in the focus of this document. It offers the opportunity to communicate between Java applets and CBL programs.

Focus for this document is the description of the CBL language, the description of the interfaces and the usage of the CBL Interpreter/Debugger.

## 2 Latest Enhancements

## 2.1 Integration of the SOAP Interface

By means of an enhancement of the import statement (see "import\_stmt" on page 18) WSDL files (WebServiceDescriptionLangauge) can be imported directly into CBL programs. This can be done either as file or via HTTP. The methods that are implemented in the WebService can be called like "ordinary" CBL functions. Please refer to chapter 3.3.5, "Working with the SOAP Interface" for more information.

## 2.2 Import of XML Schema Files (XSD)

Due to another enhancment of the import statement (see "import\_stmt" on page 18) XSD files (XML Schema Definitions) can be imported directly into CBL programs. All contained data structure definitions get corresponding CBL data types. Additionally each generated class gets the methods ToString and FromString. These functions can be used to serialize the current object into a XML string and vice versa. By this means a validating XML parser got integrated into CBL.

See chapter 3.3.6, "Import of XSD Files" for details.

The most complex XSD files that have been imported til now were the ECMA standardized CSTA-XML schema files.

# 2.3 Import of ASN.1 specifications

One further enhancement of the import statement (see "import\_stmt" on page 18) allows to import ASN.1 modules into CBL. In this case an enhanced version of the freeware tool "snacc" is called in background to generate termporary CBL modules. These modules contain the BER decoders and encoders. They are linked to the current CBL project automatically.

The different ASN.1 variants and its functionality limit the possibilities of that feature. However, ASN.1 specificactions for ACSE, CSTA and ACL-C+ (HiPath 4000) have been imported successfully.

Please refer to chapter 3.3.7, "Import of ASN.1-Modules" for details.

Syntax description

# 3 The CBL Language


- > chapter 3.1, "Syntax description"
- > chapter 3.2, "Summary of keywords"
- > chapter 3.3, "Advanced topics"

## 3.1 Syntax description

This chapter describes the syntax of the CBL language.


See also chapter 3.2, "Summary of keywords".


## 3.1.1 program



A CBL program consists of one or more statements. However, there is also the possibility that the program is empty without any statement.


## 3.1.2 statement





## 3.1.3 assign\_stmt

(assign statement)



This is the general form of an assignment. The first expression denotes a memory location, e. g. may be the name of a variable. The second expression may be as simple as a single literal, or as complex as required. Please see "Operator =" on page 43 for implicit type conversion.

#### **Example:**

```
x = 10;

str.f = x + 13;
```

The operator += increments the left expression by the value of the right expression.

Operator -= subtracts the value of the right expression from the left expression and stores it at the variable defined by the left expression.

The operators \*= (multiplication and assignment), /= (division and assignment) and %= (modulo operation and assignment) work equivalent.

The operator ++ increments the value of the left expression (must be a variable) by 1. The operator -- decrements the value of the left expression.

If += is used for string expressions the right string is concatenated to the left string variable.


Syntax description

#### **Example:**

```
i++;
z--;
string s="Hello ";
s+="world ";
k+=5;
```

## 3.1.4 call\_stmt

(function call command)




Defines the syntax of a function call, where the result is ignored or the result type is defined as void. For information about type compatibility of parameters see the description of function\_stmt.

## **Example:**

```
triangle(a, b, c);
set_length(l);
```

# 3.1.5 syn\_stmt

(syn statement)



Using the keyword syn you can define an alias name for an identifier, e. g. a class name.

#### **Example:**

```
syn CForm = cblForm;
syn maxCnt = 4;
syn hello = "Hello World!";
```

After this declaration the identifier CForm can be used equivalent to the identifier cblForm. Due to readability considerations of programs this statement should be used very restrictively!

The last syntax has been introduced especially for access of NLS-Texts for project H.O.T. where the first quotstring specifies the catalogue to be opened, the quotstring in brackets is the key of the text to be fetched from this catalogue.


## **Example:**

```
syn Catalog = "messages.txt";
syn msg1 = Catalog [ "MSG1" ];
```

In the example msg1 is a synonym for the quotstring which has been retrieved from the catalogue messages.txt with key "MSG1" by the H.O.T.-OLE-Component HOT.NLS.1.

## 3.1.6 enum\_stmt

(enum statement)



Using the keyword enum you can define the enumeration of constants. The numeric values are automatically incremented starting at 0. Alternatively, a specific value can also be set.

## Example:


```
enum { mtWarning, mtError, mtInformation, mtConfirmation, mtCustom };
enum { FTProto_RmxScsi=1,
    FTProto FTP=3,
```

Syntax description

```
FTProto_FJAM=4,
FTProto_DispaList=6 };
```

## 3.1.7 set stmt

(set statement)




Using the keyword set you can define the enumeration of constants. The numeric values are automatically doubled starting at 1. The first identifier is assigned the value 1, the second the value 2, the third the value 4, the fourth the value 8, etc.

#### Example:

## 3.1.8 text\_table\_stmt

(text\_table statement)



Text tables can be used to implement language independent CBL applications (see "CBL - National Language Support" on page 174 for further details).

## 3.1.9 signature\_stmt

(signature statement)



Signatures are used to protect cbl files against unlicensed use and modifications. Signatures are generated by the CBL Interpreter itself and appended to a file, depending on the current user profile.


In the first release of HiPath 4000 Expert Access this mechanism will just be used to protect files against modification. It **could** be used to limit the capabilities to develop own CBL applications.

**Do not modify system files secured with signatures!** These files will be unusable and will not compile.

Signatures are appended automatically to the CBL source file. There may be more than on statements per file.

## 3.1.10 empty\_stmt

(empty statement)



The *empty\_statement* is provided for convenience only. It allows additional semicolons between statements.

## 3.1.11 include\_stmt

(include statement)



Syntax description

The *include\_stmt* instructs the interpreter to read another source file in addition to the one that contains the *include\_stmt*. The name of the file must be enclosed between double quotes. You can use both slash ("/") and backslash ("\") to separate directories. As always in quoted strings, if you use backslash you have to double every occurrence of backslash ("\\"). Example:

```
include "source_b.cbl";
```

You can use an absolute (e.g. C:/rootdir/subdir/inc.cbl) or a relative file path (e.g. source\_b.cbl, subdir/source\_c.cbl, ./subdir/source\_c.cbl, ../subdir/source\_d.cbl) to specify the file. It is recommended to use relative file paths wherever possible. Thereby it's easy to move a CBL application to another directory or drive, as long as the relative position of the source files retains intact.


If you use an relative path, the file is searched in the following order:

- The file is first searched in the system include directory. This path is determined during installation of HiPath 4000 Expert Access and can be checked in HiPath 4000 Expert Access-Options
- 2. Next the directory relative to the directory of the current source file is searched.

After determining the full path of the include file, the CBL Interpreter first checks, if this file already has been included previously. If this is the case, the second include statement is ignored and thereby problems due to duplicate definition of classes etc. are avoided. So this feature supports modular development of subsystems.

## 3.1.12 import\_stmt

(import statement)



Using the import statement the complete OLE interface of an OLE automation server can be imported. The import keyword either follows the class string under which the OLE server is registered or the absolute file name of its type library (.tlb file).

If the passed name ends with "wsdl" the name is interpreted as URL or file name of a WSDL description of a WebService. See section 3.3.5, "Working with the SOAP Interface", on page 62 for details.

If the passed name has the suffix "xsd" it is interpreted as file name of a XML Schema Definition File. Please refer to section 3.3.6, "Import of XSD Files", on page 64 for details.

If the passed name ends with "asn", it is interpreted as file name of a ASN.1 module. If the suffix is "zip", the CBL interpreter unpacks this file an expects a file with suffix "lst" (with the same filename as the .zip-File) that should give the order for reading the ASN.1 modules. See section 3.3.7, "Import of ASN.1-Modules", on page 67 for details.

By specifying the optional "namespace", the relevant prefix can be assigned to each OLE class published by the OLE server.

The classes, functions and property attributes that were made available with the import statement can be displayed in the CBL Interpreter's data inspector. A description of meaning and action is provided in the documentation provided with the relevant application.

The following example shows how the OLE interface can be imported and used by MS Excel:

```
import "Excel.Sheet" namespace Excel_
Excel_Application excel;

Excel_Workbooks workbooks;

workbooks=excel.Workbooks;

workbooks.Add();

excel_Range("Al").Formula="Hello World";

Excel_Workbook workbook=excel.ActiveWorkbook;


workbook.SaveAs("c:\\temp\\hello.xls");

workbook.Close();
```

## 3.1.13 function\_stmt


(function declaration)

Syntax description



## 3.1.14 function\_parameters

(function parameters)



The *type-identifier* specifies the type of data the function returns. It can be defined by a class or be of the type <code>int</code>, <code>string</code>, <code>variant</code> or <code>void</code> if no value is returned. It is also allowed to return an array. The type <code>variant</code> is used only in the context of OLE automation.

The second *identifier* is the name of the function. It is followed by a parameter list, which is a comma separated list of variable names (*identifier*) and their associated types (*type identifier*) that receive the values of the arguments when the function is called.

By default parameters are passed by value, i. e. the function gets a local copy of the parameters. Modifications of the parameters within the function are not seen by the caller. In contrast, the @ sign denotes a reference parameter. Reference parameters don't receive copies of the arguments, but use the same memory location as the arguments. Modifications of the parameters within the function are therefore seen by the caller. Also, the current argument for a reference parameter must always denote a memory location, e. g. be a variable, and must not be an arbitrary expression.

For compatibility of actual and formal parameters the same rules are valid as for assignment (see there). Therefore it is possible to pass an int variable to a string parameter and vice versa. This is even true for reference parameters!

The parameter list of a function is optional, but the parentheses are required. The *block* is the body of the function, which consists of the code. A function's code cannot be accessed by any statement in any other function except through a call to that function. Unless the function uses global variables or data, the code of its body can neither affect nor be affected by other parts of the program.



Although it is possible to define functions within functions this feature is not available in the interpreter.

#### **Example:**

```
int sqr(int x)
{
    x = x * x;
    return (x);
}
int a;
int b;
a = 3;
b = sqr(a);
// b is 9; a still is 3
b = sqr(4);
// b is 16
```

## **Example:**

```
string concat(string a, string b)
{
   return a + b;
}
```

# Example:

```
void func_call()
{
    int a;
    a = 10;
    z = sqr(a);
}
```

# **Example:** Call by reference


```
void append(string[] @list,string txt)
{ int cnt=list.count;
   list[cnt]=txt;
}
```

Syntax description

```
string [] list;
append(list, "aaa");
append(list, "bbb");
append(list, "ccc");
```

## 3.1.15 declaration\_stmt

(Variable statement)



Variables are declared in four different places:

- inside blocks (inside or outside of a function)
- in the definition of function parameters
- inside a class, but outside of functions
- outside of all classes and functions.

These are termed local variables, formal parameters, member variables and global variables respectively.

With the *declaration\_stmt* you are declaring local variables, member variables and global variables (It depends if the declaration statement is inside a block, or outside of all blocks). Local variables may be referenced only by statements that are inside the block in which the variables are declared or in a block, nested within that block.

The *type-identifier* defines the type of the variable. The *identifier* is the name of the variable. Variables, class members and array elements are automatically initialized according to their type: Integer variables with 0, string variables with an empty string (""), reference variables with the predefined constant null.

A '@' in front of the *type-identifier* can be used to define a reference variable. This is a variable that does not contain a value itself but it "points" to another variable/object. See Section 3.3.1 on page 3-51 for further details.

To declare an array the variable name has to be followed by brackets.

There are two different methods to define arrays (with/without upper bound) as well as two different types to access array elements (string indexed, integer indexed). Memory allocation for an array is always done when a new array element is accessed, not when the array is defined. If one tries to access an element by an index and there is not yet an element, an "empty" element is created automatically.

string list[10]; defines an array with a maximum of 10 elements. This **boundary** is checked with every access to this array. Note, that the expression in brackets need not be an constant expression! It is evaluated once, when the array declaration statement is executed. The array may be either string indexed or integer indexed.

string list[]; without an expression in brackets defines a **dynamic array** of strings. Dynamic means, that there is practically no maximum number of elements. The array may be either string indexed or integer indexed.

The first access to an array defines the type of indexing. If the first access was done with an **integer index**, this array can *only* be accessed with integer indices. It is allowed to have gaps within the index values, the elements in-between are allocated automatically. Integer indices always start with 0. The following example creates two strings in the array called list.

```
list[3]="Gerry";
list[6]="Bernd";
```

The index range is from 0 to 99999.

Syntax description

If the first access to an array (e.g. string[]) was done with a string index, this array gets string indexed. The elements of a string indexed array are automatically sorted alphabetically due to performance reasons. Example:

```
string phone[];
phone["Erich"]="18492";
phone["Roland"]="34928";
phone["Alexandra"]="23049";
```

String indexed arrays can be accessed both with string or integer indices, however you cannot allocate an additional array element using an integer index for an array that uses string type indices.

Each array variable has a property *count*, which holds the number of array elements currently allocated, i.e. the array elements can be accessed using indexes 0..count-1. Example:

```
int i;
for i=0 to phone.count-1 // will loop 3 times in the example above
{
    system.ConsolePrint(phone[i]);
}
```

This example prints the values "23049", "18492" and "34928" in the console window (sorted alphabetically by *string index*).

```
int i;
for i=0 to list.count-1 // will loop 7 times in the example above
{
   system.ConsolePrint(list[i]);
}
```

This example prints the values "", "", "", "Gerry", "", "Bernd" in the console window.

Currently only one-dimensional arrays are supported. If you absolutely need multi-dimensional arrays, you can embed an array into a class and build an array of this class.

The optional = expression clause is used to define an initial value for a variable or symbolic constant. It is a shorthand notation for definition of a variable and a subsequent assignment.

The initialization of member variables is effective whenever a new object instance of the class is created: Every new object's data variables are initialized with the values specified in the class declaration (see class\_member below).


Note that class members of type reference cannot be initialized in the class declaration with a value other than null.

The const modifier is used to define symbolic constants, i. e. you define a variable who's cannot be modified later on. For const variables you *must* specify a initialization expression, because there is no other way to assign a value to a const variable.

## **Example:**

#### 

(class statement)



Syntax description


A class declaration defines a new type that links code and data. Classes are created using the keyword class. The *identifier* specifies the name of the class. The code and data of classes are enclosed in braces.

A class can be derived from a base class using the keyword extends. The new class inherits all members (attributes and methods) of the base class. If a method/attribute has the same name as a base class member, only the member of the derived class will be accessible (overriding).

OLE classes are described in chapter 3.3.3, "Using the OLE interface".

DLL classes are described in chapter 3.3.4, "Using the DLL interface".

#### 3.1.17 class member



A class member can either be a function\_stmt or a declaration\_stmt.

#### **Example:**

```
class book {
  string author;
  string title;
  string keywords[];
  int number;
}
```

In the case above, the class consists only of declarations. The data members of a class or object are called *attributes* in CBL.

This example below is more complex. The class consists of declarations and a function. *employee* is a simple class, which is used to store a name and an address. The function *tax* is used to compute an employee's wage. In this special case *wage* will be 3000.

```
class employee {
  string name;
  string address;
  int tax(int pay)
  {
    return pay - 2000;
  }
}
```

```
void foo()
{ employee fred;
  int wage;
  fred.name = "Frederick";
  fred.address = "Munich";
  wage = fred.tax(5000);
  ...
}
```

In the example below, an initialization for data members is given:

```
class Point
{  int top = -1;
  int left = -1;
}

Point p1; // p1.top now is -1 and p1.left is -1
Point p2 = {left: 10}; // p2.top now is -1 and p2.left=10;
```

#### **Example for class hierarchy:**

```
class base
  string a;
   int
         b;
   int
          Сi
   int
          f()
                  return b+c; }
  void
                    system.ConsolePrint("base::g called"); }
         g()
}
class subclass extends base
{ string c;
  string d;
                { system.ConsolePrint("subclass::g called"); }
  void
        q()
                { system.ConsolePrint("subclass::h called"); }
  void
}
base A;
subclass B;
A.f();
A.g();
B.f();
B.g();
B.h();
```

In this example a base class "base" and a derived class "subclass" is defined. The subsequent calls of the methods produce the following output in the console window:

Syntax description

base::g called subclass::g called subclass::h called


The function f() is inherited by the subclass. Please note that f always accesses the attributes b and c of class "base".

Function g() is overridden by the derived class, so the function g() of the subclass will be executed for objects of type subclass.

Function h() is an additional method defined by the subclass.

The member c of the base class cannot be accessed directly by a method of subclass because it is hidden by "string c". It can be accessed using the predefined "pointer to base class" called super.

## 3.1.18 ole/dll\_cls\_member




# 3.1.19 ole\_type



OLE classes can additionally contain "externally" implemented functions and properties. The types for parameters, return value and properties is limited to int and string. The quotstring behind the colon specifies the name of the OLE procedure, function or property as published by the OLE server application.

## 3.1.20 if\_stmt

(if statement)



If the *if-expression* is true (anything other than 0), the corresponding block will be executed. Otherwise the *elseif-expressions* are tested one after the other until one is found which yields true. Then the corresponding block is executed. If none yields true, the block which is the target of *else* will be executed, if it exists.

Please note that the condition expressions can be as complex as you want using the boolean operators "and" (&&), or ( $|\cdot|$ ) and not (!).

## **Example:**

```
x = 10;
if (x < y)
{
    x = y;
}
elseif (x > y)
{
    y = x;
}
else
{
    x = x + 1;
    y = y + 1;
}
```

Syntax description

#### **Example:**

```
x = 22;
y = i;
if (x == y)
{
   y = y + 1;
}
```

Expression must yield an integer result. Here if (x == y) means: If x is equal y the following block (in the braces) will be executed. x = y would be an assignment, which does not return an value and therefore would cause an runtime error.

Hint: Could/Should be detected at compile time!


#### **Example:**

```
if (x)
{
    ...
}
```

If  $\mathbf{x}$  is anything other than 0, the block will be executed.

## 3.1.21 for\_stmt

(for statement)



The keyword for is followed by three expressions - each of them is optional - enclosed in parentheses. In general the first expression is an assignment statement that is used to set the loop control variable, but may also be e. g. a function call. The second is a relational expression that determines when the loop exists. The third is an increment that defines how the loop control variable changes each time the loop is repeated. These three sections are separated by semicolons. The *for-loop* continues to execute the block as long as the condition is true. Due to performance reasons there is also a second possibility to express a *for\_stmt*. This form of the *for\_stmt* consists of an assignment and a limitation. Therefore the first expression has to be a variable, the second and third expression have to be numerical. The increment is always 1 (see example above).

Syntax description

#### Example: for loop 1

```
for (x = 7; x < 2; x = x - 1)
{
   sum = sum * x;
}</pre>
```

#### Example: for loop 2

```
for i = 1 to 10 do {....}
```

## Example: for loop 3

```
for (;;) {...}
```

This loop will run forever. (Actually this is not guaranteed, because a break statement inside in the block, causes immediate termination.)

#### Example: for loop 4

```
x = 6;
for ( ; x < 10; )
{ x = x + 1; }
```

The initialization section has been left blank, and x is initialized before the loop is entered.

## 3.1.22 while stmt

(while statement)



The expression enclosed by the parentheses after the keyword while must be a condition. True is represented by any nonzero value. The *block* is iterated while the condition is true. When the condition becomes false (==0), the program passes to the statement after the block.

## **Example:**

```
string answer;
string text;
answer = "N";
while (answer != "Y")
{
```

```
answer=question(text);
}
```


The function question (text) (which must be defined anywhere in the program code) will be iterated as long as "Y" will be returned.

The next example has the same effect:

```
string answer;
while (question(answer) != "Y") { }
...
```

## 3.1.23 do\_while\_stmt

(do\_while statement)



Unlike for and while loops, which test the loop condition at the top of the loop, the *do\_while\_stmt* checks its condition (the expression enclosed by the parentheses) at the bottom of the loop. That means that the block is always executed at least once. The *do\_while\_stmt* iterates until the condition becomes false.

## **Example:**


```
string answer;
string text;
answer = "Y";
do {
   answer=question(text);
} while (answer != "Y")
```

Although answer is "Y" the *block* after do is executed. It depends on the return value of the function question(text) if it is repeated or not, no matter which value answer has before the *do\_while\_stmt*. (In contrast to the *while\_stmt*.)

Syntax description

## 3.1.24 try\_catch\_stmt

(try\_catch statement)



Using the try\_catch statement in conjunction with the throw statement you can implement exception handling as in C++ or Java.

If an exception object is "thrown" to a random call hierarchy within the try block, then it can be "caught" via subsequent catch instructions. An exception object is caught if its type, i.e. the exception class, matches; in other words, the thrown object contains the class to be caught in its class hierarchy (see "class\_stmt" on page 25, see keyword extends).

The identifiers that follow the keyword catch specify an exception class and the name of the exception object under the following block.

For an example of exception handling see "throw\_stmt" on page 34.

## 3.1.25 throw\_stmt

(throw statement)



Exception handling can be triggered with the throw instruction.

The keyword throw follows the name of an object that is derived from the predefined "Exception" base class (see "class\_stmt" on page 25, see keyword extends).

All statements following the throw statement are ignored until the object is "caught" by a suitable catch statement (see "try\_catch\_stmt" on page 34).

If a suitable catch statement was not found, the CBL program is terminated with an "Unhandled Exception" runtime error.

The base class of all exceptions is predefined in the system and is called "Exception". Moreover, an OleException exception class that is triggered as soon as a runtime error occurs in response to OLE problems is predefined:

```
class Exception
{
  string File;
  int Line;

  string Message;
}
class OleException extends Exception
{
}
```

The properties File and Line are automatically set by the CBL Interpreter on the execution position of the throw statement. The origin of the exception can thus be determined later.

## **Example: Exception handling**

```
try
{
   for i=1 to 100 do
   {
      comwinFrame.ConsolePrint(_string(i));
      if (i==10)
      {
        Exception e1;
        e1.Message="Abrupt cancellation";
        throw e1;
      }
   }
}
catch(Exception e)
{
   comwinFrame.ConsolePrint(e.Message);
}
```

The loop is quit after the 10th run. Information on the exception can be passed on via the exception object.

# 3.1.26 with\_stmt

(with statement)

Syntax description



The *with\_stmt* has to be followed by an expression enclosed by the parentheses and a block. The expression must denote a memory location. This statement makes it easier to access data and functions of a class.

## **Example:**

```
class xyz
{
    int a
    int b
    void m()
    {...}
    ...
}
xyz ABC
...
with (ABC)
{
    funct(a);
    b = 5
    m();
    ...
}
```

Without the with\_stmt the code after the "..." had to be:

```
funct(ABC.a)
ABC.b = 5;
ABC.m()
```

# 3.1.27 return\_stmt

(return statement)



The *return\_stmt* was already used in some examples above.

This statement is used to return from a function. It "jumps" back to the point at which the call of the function was made. If return has a value associated with it, the value of expression becomes the return value of the function. A non-void function must return a value.

You can use as many return statements as you like within a function. However, the function will stop executing as soon as it encounters the first return. The } that ends a function also causes the function to return. It is the same as a return without any specified value.

#### 3.1.28 break\_stmt

(break statement)




The break\_stmt is used to terminate a loop (for-loop, while-loop, do-while-loop) immediately, bypassing the normal loop conditional test. When the break statement is encountered inside a loop the program resumes at the next statement following the loop. A break causes an exit only from the innermost loop.

## **Example:**

```
for (t = 0; t < 100; t = t + 1)
{
    count = 1;
    for (;;)
    {
        count = count + 1;
        if (count == 10)
        {
            break;
        }
    }
}</pre>
```

Syntax description

# 3.1.29 .try\_catch\_stmt




The try-catch-statement can be used to catch exception objects that have been thrown by means of the throw statement. The first identifier specifies the exception class, the second the exception object). If there is no exception the exception block is ignored.

## Example:

```
try
{
   g();
}
catch (Exception e)
{
   comwinFrame.ConsolePrint("exception catched");
}
```


# 3.1.30 block

(block)




A block consists of none, one or more statements. A block begins with an opening curly brace and ends with a closing curly brace.

# 3.1.31 expression



# 3.1.32 binop



There are some restrictions concerning the operand types allowed for the different operators:

Arithmetic, logical and bitwise operators are defined for int operands only. The plus sign is also used for string concatenation (see table below).

The comparison operators ==, <, >, <=, >=, != are defined for the basic types int and string.

The following tables give you an overview about the possibilities of combinations with the four operators "+", "-", "in" and "=".

(If there is a "-" in a cell, it means that this combination is not defined.)

#### Operator +

+	right operand				
		int	string	class	[]
left operand	int	arithmetic addition	-	-	-
	string	-	string concatenation (1)	-	-
	class	-	-	-	-
	[]	-	-	-	-

(1) concatenates one string onto the end of another

## Example:

```
string s1;
string s2;
string hello;
s1 = "Hi";
s2 = " there!";
hello = s1 + "," + s2;
```

The string hello will be: "Hi, there!".

Syntax description

## Operator -

_			right operar	nd	
		int	string	class	[]
р	int	arithmetic subtraction	-	-	-
left operand	string	-	-	-	-
left c	class	-	-	-	-
	[]	-	-	-	-

# Operator in

in	right operand				
		int	string	class	[]
7	int	-	-	-	-
left operand	string	-	checking occurrence (1)	-	searching element in string[](2)
off o	class	-	-	-	
<b>9</b>	[]	-	-	-	-

# (1) Example:

```
string hello;
...
if ("he" in hello)
{...}
```

If "he" occurs in the string hello, the <code>expression</code> ("he" in hello) is true and the block  $\{\ldots\}$  will be executed.

# (2) Example:

```
string hello;
string Text[];
...
if (hello in Text)
{...}
```

If the string in variable hello is an element of the array Text, the expression (hello in Text) is true and the block  $\{\dots\}$  will be executed.

## Operator =

=	right operand				
		int	string	class	[]
left operand	int	assignment	string - int conversion (2)	-	-
	string	int - string conversion (1)	assignment	serialization for storage (3)	
	class	-	serialization for storage (3)	assignment	-
	[]	-		-	assignment

(1) converts an integer into a string. Example:

```
string hello;
int x;
x = 10;
hello = x;
```

The 'result' of hello will be the string "10".

(2) converts a string into an integer. The conversion stops at the first non-interpretable character.

## Example:

```
string hello;
int x;
hello = "10A";
x = hello;
```

The 'result' of x will be the integer 10.

Syntax description

(3) see later

Some examples referring to *expression*:

```
x = -3

x == -3 \mid \mid x >= 0

x * -23 + 44 / 2

x = 5 / 2
```

x will be 2, because all numeric variables are integer (the remainder will be truncated)

```
x = 5 % 2
```

x will be 1, the remainder of the integer division. The semantics of modulo is the same as in C.

```
hello = Text
```

The precedence of all operators is:

## **Examples for expression lists:**

```
class complex
{  int re;
  int im;
}
// tagged expression list:
z={ im:18, re:1 };
x={ im:99 }; // x.re is set to it's default value (0)
// expression list:
int list[] ={ 10 , 25, 30 };
```

An integer indexed array is initialized/assigned with an non-tagged expression list, e.g.

```
list={"Erich","Bernd","Roland"};
```

A String indexed array can be initialized/assigned a value with the tagged-expression-list .Example:


```
string phone[]={"Erich":"18492", "Roland":34928", "Alexandra":"23049"};
```

In general, a tag can be either the identifier of a data member of a class or a string, which is used as index in an string indexed array.

Basically using an expression list in an assignment is simply a short-hand notation for multiple assignments.

An assignment to a class sets the fields which are named by the tags where the remaining fields get their initial value.

## 3.1.33 type\_identifier



The *type-identifier* defines the type of a variable or function. You cannot define a variable of type void. The type void is used only as return type of functions, which do not return a result and as possible base type of references.

There is an additional predefined type variant, which is used only in the context of OLE automation.

#### **Example:**


```
int i;
void func();
string Text[];
string book(string title) {...}
```

An identifier which is defined by a *class\_stmt*:

Syntax description

```
class myclass {
...
}
myclass data;
```

## 3.1.34 identifier



The names of variables, functions, and other user-defined items are *identifiers*. These *identifiers* can vary from one to several characters. The first characters must be a letter or an underscore, and subsequent characters must be either letters, digits, or underscores. In an identifier, upper- and lowercase are treated as distinct. Hence, x and x would be two separate identifiers.



All names starting with an underscore are reserved for the CBL system and should therefore not be used in applications.

## **Example:**

Correct:

test1


list\_book

Incorrect: 1x


hello!you

list...book


# 3.1.35 alpha




# 3.1.36 digit



# 3.1.37 **number**




# 3.1.38 hex



Syntax description

#### **Example:**

# 3.1.39 quotstring



A *quotstring* is a set of (printable) characters enclosed in double quotes.

## **Example:**

```
"This is a 'simple' test"
```


An exception is the backslash character (\). This character is used to include special codes in a string.

The backslash codes are:

\n	new line
\t	horizontal tab
\r	carriage return
\"	double quote
	backslash itself
\x	The following two characters are interpreted as hex digits. The corresponding ASCII character is inserted into the string (e. g. $\xspace \xspace \xs$

If a single backslash followed by any other character occurs in a string, the backslash will be ignored.

# 3.1.40 comment (structured)



Structured *comments* begin with the character pair /\* and end with \*/. There must be no spaces between the asterisk and the slash. The interpreter ignores any text between the beginning and ending comment symbols. Comments can be anywhere in a program, as long as they do not appear in the middle of a keyword or identifier or quoted string.

#### **Example:**


```
x = 10;
/* this is a comment */
x = x + /* add a number */ 5;
```

Comments may not be nested. That is, one comment cannot contain another comment.

## **Example:**

```
/* This is /* not allowed */ and causes an error */
```

# 3.1.41 comment (single line)



A *single line comment* begins with // and it ends at the end of the line. Whatever follows the // is ignored by the interpreter until the end of the line is reached.

Summary of keywords

#### **Example:**

```
x = 10;
//this is a single line comment
x = x + 5; //add a number
```

# 3.2 Summary of keywords

break used to quit a for/do/while loop
catch see "try\_catch\_stmt" on page 34
class see "class\_stmt" on page 25

const used to define constants; see "declaration\_stmt" on page 22

corba\_class reserved

count used to determine the size of an array; see "expression" on page 39

dll\_class see "Using the DLL interface" on page 60

do see "do\_while\_stmt" on page 33, see "for\_stmt" on page 31

else see "if\_stmt" on page 29
elseif see "if\_stmt" on page 29

enum see "enum\_stmt" on page 15

extends defines the base class; see "class stmt" on page 25

for see "for\_stmt" on page 31
if see "if\_stmt" on page 29

in binary operator; see "expression" on page 39

import see "import\_stmt" on page 18
include see "include\_stmt" on page 17

index is the index value of an string indexed array element; see "Working with ar-

rays" on page 51

int predefined integer type; see "type\_identifier" on page 45

namespace see "import\_stmt" on page 18

null predefined reference to "no object"; see "Working with reference variables"

on page 53

ole\_class see "class\_stmt" on page 25

return leaves a function and returns a value to the caller; see "return\_stmt" on page

36

set see "set\_stmt" on page 16

string predefined string type; see "type\_identifier" on page 45

super predefined variable, available in functions of derived classes, pointing to the

members of the base class

syn see "syn\_stmt" on page 14

text\_table see "text\_table\_stmt" on page 16

this predefined variable, available in functions of a class; used to pass the refer-

ence to the current object to a function etc.

throw see "throw\_stmt" on page 34

to see "for\_stmt" on page 31

try see "try\_catch\_stmt" on page 34

variant see "Definition of OLE interfaces in CBL" on page 57

virtual reserved

void predefined type; wused if a function returns no value or if a reference to an

unknown type should be defined; see "type\_identifier" on page 45

while see "while\_stmt" on page 32; see "do\_while\_stmt" on page 33

with see "with\_stmt" on page 35

# 3.3 Advanced topics

- > chapter 3.3.1, "Working with arrays"
- > chapter 3.3.2, "Working with reference variables"
- chapter 3.3.3, "Using the OLE interface"
- > chapter 3.3.4, "Using the DLL interface"
- > chapter 3.3.5, "Working with the SOAP Interface"
- > chapter 3.3.6, "Import of XSD Files"
- > chapter 3.3.7, "Import of ASN.1-Modules"

# 3.3.1 Working with arrays

This section summarizes the CBL features regarding arrays.

Array with "unlimited" size:

```
int array[];
```

Advanced topics

Array with limited size:

```
int array[10];
```

Integer indexed array (unlimited):

```
string array[];
array[1]="Hugo";
```

Initialization of a integer indexed array:

```
string array[]={ "Hans", "Bernd", "Roland" };
```

String indexed array (unlimited):

```
string array[];
array["Erich"]="1234";
```

Initialization of a string indexed array:

```
string strarray[]={"Erich":"1234", "Bernd":"4321", "Roland":"1111" };
```

• An array can be set to 'empty' using the trivial form of expression list assignment:

```
strarray={};
```

- String indexed arrays are always sorted by increasing alphanumerical index string.
- Getting the size of an array:

```
strarray.count
```

- A string indexed array can also be accessed with integer indices from 0 to count-1.
- Getting the index-string of an string indexed array element:

```
string name=strarray[2].index; /* name becomes "Roland" */
```

Checking, if there is an array element with the specified string index in a string indexed array:

If the first parameter is not a string indexed array, a runtime error occurs.

 ArrayRemoveAt can be used to delete one specific element from an array identified by it's string index or sort order:

```
ArrayRemoveAt(strarray, "Roland");
ArrayRemoveAt(strarray, 1);
```

## 3.3.2 Working with reference variables

For efficient working with reference variables you must know how initialization of types and objects as well as assignment are handled within the interpreter.

A "type" or class is a template object. Some template objects are predefined (int, string). The definition of a class (see "class stmt" on page 25) causes a template object to be generated:

```
class complex
{ int re;
 int im;
}

"complex"

re
 im
```

Therefore you can also initialize the members in a class declaration to define other initial values than the default 0 values:

```
class point
{ int x = 1;
 int y = 9;
}

"point"


x 1
y 9
```

A structured variable (e. g. an array or class variable) is a pointer to its elements.


The definition of a variable causes the template object to be "cloned" (copied) and the definition of a reference to this new object to be stored in the variable. Therefore the newly defined variable has the same initial values as the template object for the class:

```
complex Z;
complex X;
point P; // P.x is 1 and P.y is 9
```

Advanced topics



When a structured variable is assigned to another structured variable as a whole, the value object of the source variable is cloned and assigned to the destination variable (Btw.: This is not the way the interpreter really works, but this description shows it from the users view):



As shown, the previous value object still exists but without any reference to it. Value objects without any reference will be removed by a process called "Garbage Collection".

However, when an expression list is assigned to a structured variable, the assignment occurs elementwise. Therefore, no object is cloned and the memory used by the object remains the same!


**Reference variables** allow a named data element to be referred multiply. If a reference variable is created, it first points to no value object. This value is called "null".

The reference variable cannot be accessed until it has been assigned a variable.

The only thing you can do here, is to test if the reference variable is null:

```
if (Ref == null) ...
if (Ref != null) ...
```


When you assign a variable to a reference variable which is null, a reference to the right side of the assignment is stored in the reference variable:



Ref is now a synonym for Z. If Ref is assigned a new value the value of the referred variable changes too:

```
Ref=X;
Z=X;  // both assignments have the same effect!
```

Advanced topics





A reference variable can be reset to it's original value using Ref=null.

Memory management by garbage collection assures, that a non-null reference is always referring to valid data.

However, you have to be careful when storing references to array elements or class members. If the array variable as a whole is assigned a new value the reference variable will still point to the old array element!

The same happens, if a reference variable points to a class member and the complete object is assigned a new value.





Now Ref doesn't point to the current array[1] anymore!

The grayed value objects will be deleted at next garbage collection.

# 3.3.3 Using the OLE interface

From the CBL syntax perspective the definition see "class\_stmt" on page 25.

With the OLE interface you can access either existing 3rd party programs like MS-Word, Netscape Browser, etc. or self written OLE servers. The following sections show how to program your own OLE server and the ways to access 1st and 3rd party OLE servers.

#### 3.3.3.1 Definition of OLE interfaces in CBL

To be able to access an OLE object from CBL the object must be modeled with the CBL language. The definition for the above OLE object looks like this:

```
ole_class cblFile : "cblsys1.file"
{
    string open(string name, string mode) : "open"
    string readln() : "readln"
    int write(string txt) : "write"
    void close() : "close"
    int eof : "eof"
}
```

Advanced topics

The information which is important for the logical link between OLE and CBL is printed bold.

In the current version of the interpreter only the types int and string are allowed for parameters, return values and properties. Only Call-By-Value is supported.

The function parameters, return values and property types must be consistent between OLE and CBL.

If you want to access 3rd party applications you must try to get the interface from the vendors help files or documentation.

Examples: (works only for German MS Word 7.0)

```
ole_class MS_Word : "Word.Basic"
 void FileNew(string type)
                                       : "DateiNeu"
 void Insert(string text)
                                        : "Einfügen"
 void FileSaveAs(string param)
                                       : "DateiSpeichernUnter"
 void FormatTabulator(string pos) : "FormatTabulator"
ole_class Netscape : "Netscape.Network.1"
  int Open(string pURL, int iMethod, string pPostData,
                 int lPostDataSize, string pPostHeaders) : "Open"
  int GetStatus()
                                                      : "GetStatus"
 void Close()
                                                       : "Close"
  int BytesReady()
                                                      : "BytesReady"
  int GetContentLength()
                                      : "GetContentLength"
                                      : "GetContentType"
  string GetContentType()
  int Read(string pbuffer, int iAmount) : "Read"
```

## 3.3.3.2 Using immediate OLE functions

Some 3rd party OLE servers use very complicated interfaces that cannot be modeled by means of CBL. Therefore the Interpreter offers some low level functions for communication with arbitrary OLE servers.

#### Example:

```
class Variant
{
  variant obj;
  void CreateObject(string name)
  { _OleCreateObject(obj,name); }
  variant OlePropertyGet(string name,variant i1, variant i2)
```

```
{ variant value;
    _OlePropertyGet(obj,name,value,i1,i2);
    return value; }
  void OlePropertySet(string name, variant value, variant i1, variant i2)
  { _OlePropertySet(obj,name,value,i1,i2); }
         OleProcedure(string name, variant p1, variant p2, variant p3)
  { _OleProcedure(obj,name,p1,p2,p3); }
  variant OleFunction(string name, variant p1, variant p2, variant p3)
  { variant value;
    _OleFunction(obj,name,value,p1,p2,p3);
    return value; }
Variant sheet;
sheet.CreateObject("Excel.Sheet");
Variant app;
app.obj=sheet.OlePropertyGet("Anwendung",empty,empy);
int visible=app.OlePropertyGet("Sichtbar", empty, empty);
app.OlePropertySet("Sichtbar", "Wahr", empty, empty);
Variant cell;
cell.obj=app.OlePropertyGet("AktiveZelle",empty,empty);
cell.OlePropertySet("Z1S1Formel", "11", empty,empty);
Variant range;
range.obj = sheet.OlePropertyGet("Bereich", "A2", empty);
range.OleProcedure("Auswählen", empty, empty, empty);
cell.obj=app.OlePropertyGet("AktiveZelle",empty,empty);
cell.OlePropertySet("Z1S1Formel", "222",empty,empty);
range.obj=sheet.OlePropertyGet("Bereich","A3",empty);
range.OlePropertySet("Z1S1Formel",
                      "=SUMME(Z(-2)S:Z(-1)S)", empty, empty);
```

The Functions \_OleCreateObject, \_OlePropertyGet, \_OlePropertySet, \_OleFunction and \_OleProcedure offer a C-like procedure interface to OLE. In this example these function have been wrapped by a class "Variant" which will be offered in a CBL include file. "variant" is the CBL value type that can either be an int, a string or an OLE object.

CreateObject(string name) is called to create an interface object to the OLE server. The object is stored in obj. name is the name of the OLE class as stored in the Windows registry database (e. g. "Netscape.Network").

variant OlePropertyGet(string name, variant i1, variant i2) returns the value of property name of the OLE object obj. If the property is an array i1 and i2 are used as index values to this array. The result can be a string, int or an OLE object.

Advanced topics

void OlePropertySet(string name, variant value, variant i1, variant i2) sets the value of property name of OLE object obj to value. If the property is an array i1 and i2 are used as index values to this array.

OleProcedure(string name, variant p1, variant p2, variant p3) calls the OLE procedure name. p1, p2 and p3 are parameters for this procedure call.

variant OleFunction(string name, variant p1, variant p2, variant p3) calls the OLE function name. p1, p2 and p3 are parameters for this procedure call. It returns the result of the function call.

# 3.3.4 Using the DLL interface

For a definition from the perspective of CBL syntax, see "class\_stmt" on page 25.

Defining a DLL class means that functions that are implemented in a DLL library can be called up directly from a CBL script. Understandably, this interface is subject to various restrictions. These are:

- The DLL function must be declared to be a WINAPI (due to the parameter transfer sequence)
- The only parameter types allowed are int (corresponds to 32-bit long in C/C++), int@ (corresponds to long & in C/C++) and string (converted into char \* in C/C++). Unfortunately, Unicode strings are not supported.
- Memory blocks can be administered via the new CBL-internal data type \_memblock and the associated access routines \_MemBlockGetPtr, \_MemBlockSetPtr, \_MemBlockAlloc, \_MemBlockFree, \_MemBlockGetInt, \_MemBlockSetInt, \_MemBlockGetString and \_MemBlockSetString. These functions can be encapsulated with the following "wrapper" class:

```
class cblMemblock
  _memblock mb;
                            { return _MemBlockGetPtr(mb); }
  int
        GetPtr()
                            { _MemBlockSetPtr(mb,ptr); }
 void
        SetPtr(int ptr)
                            { _MemBlockAlloc(mb,size); }
 void
        Alloc(int size)
 void
        Free()
                            { MemBlockFree(mb); }
  int
        GetInt(int offset, int size)
                          { return _MemBlockGetInt(mb,offset,size); }
 void
        SetInt(int offset, int size, int value)
                          { _MemBlockSetInt(mb,offset,size,value); }
  string GetString(int offset, int size)
                          { return
```

#### Meaning of the functions:

GetPtr	Returns the address of the memory block as an int value
SetPtr	An int value which represents a memory block address must be included as ptr. Otherwise, unforeseen program reactions can occur (e.g. access violations)
Alloc	Seizes a memory block of the specified size
Free	Frees the current memory block
GetInt	Interprets size bytes from the offset address offset (relative to the memory block start) as an int value and supplies this value as return.
SetInt	Interprets size bytes from the offset address offset (relative to the memory block start) as an int value and sets this to value.
GetString	Interprets size bytes from the offset address offset (relative to the memory block start) as a null-terminated character string and supplies it as a return value.
SetString	Copies maximum size bytes from the character string s to the address offset (relative to the memory block start) and terminates this, where applicable, with ' $\0$ '.

Only void, int or string are allowed as return values for functions.

## **Example: Calling functions from USER32.DLL:**

## 3.3.5 Working with the SOAP Interface

Precondition for this feature is an installation of Microsoft SOAP Toolkit SDK 3.0. In later Com-Win version this toolkit will be installed with ComWin.

The interface to WebServices can be read using the import statement (see "import\_stmt" on page 18).

## **Example:** Import of a WSDL via HTTP

```
import "http://localhost/XAWS/XA.asmx?WSDL" namespace XA;
```

If the WSDL is stored in a local file it can be imported immediately as well:

#### **Example:** Import of a WSDL file

```
import "xa.wsdl" namespace XA;
```

If the server requires authentification with user and password the CBL Interpreter intrinsic function \_Import can be called.:

## Example: Import of a WSDL using function \_Import

```
try
{
    __Import("http://"+ServerIP+"/HiT/"+ws+".asmx?WSDL",ns,User,Password);
}
catch(SoapException e)
{
    print_SoapException(e);
}
```

As shown in the example above the URL can be constructed at runtime. Exceptions can be caught using the CBL excaption handling. The second paramter of the \_Import function is the namespace.

If a WebService could be imported successfully there will be a class with the name of the Web-Service and methods for each WebMethod. These types and objects can be visualized using the data inspector of the CBL interpreter.

These imported objects contain predefined properties like \_url, \_keepconnection and \_http. They are used to control the execution of the methods of that WebService.

\_url is a text string. It tells the CBL interpreter where to execut the WebMethod. Therfor the \_url must be set in advance to the execution of the first method. Setting \_url is ablolutely necessary if the WSDL was read from a file.

\_keepconnection tells the CBL interpreter if the HTTP connection should be reset (0) or kept (1) for each call of an WebMethod. Default value of \_keepconnection is 1.

By means of the string array \_http additional parameters can be passed to the HTTP connector component (see description of MS-SOAP-Toolkit for details).

Methods that are defined in the WebService can be called like ordinary CBL functions::

## **Example:** Call to a WebMethod:

```
XA::XA xa;
xa._url="http://localhost/XAWS/XA.asmx";
string result=xa.SetPhoneState("31562","Online","2003-10-15 12:00");
```

## 3.3.6 Import of XSD Files

XSD files are XML schema descriptions. These files describe valid syntax of XML files.

Such files can be included by means of the import statement. (see "import\_stmt" on page 18). Due to the suffix ".xsd" the CBL Interpreter recognizes these files as XML schema files.

#### **Example:** Import of a XSD file:

```
import "C:\\localdata\\fe31562\\ECMA\\make-call.xsd" namespace CSTA
```

XSD files may contain references to further XSD files. These will be read and interpreted as well.

#### This shows an example of a XSD file:

```
<?xml version="1.0" encoding="UTF-8"?>
<!-- edited with XMLSPY v5 U (http://www.xmlspy.com) by tom miller (self) -->
<xsd:schema targetNamespace="http://www.ecma.ch/standards/ecma-323/csta/ed2"</pre>
xmlns:csta="http://www.ecma.ch/standards/ecma-323/csta/ed2" xmlns:xsd="http://www.w3.org/2001/
XMLSchema" elementFormDefault="qualified" attributeFormDefault="unqualified">
  <xsd:annotation>
    <xsd:documentation>CSTA-make-call</xsd:documentation>
  </xsd:annotation>
  <xsd:include schemaLocation="device-identifiers.xsd"/>
  <xsd:include schemaLocation="call-connection-identifiers.xsd"/>
  <xsd:include schemaLocation="device-feature-types.xsd"/>
  <xsd:include schemaLocation="extension-types.xsd"/>
  <xsd:include schemaLocation="call-control.xsd"/>
  <xsd:include schemaLocation="media-services.xsd"/>
  <xsd:element name="MakeCall">
    <xsd:complexType>
      <xsd:sequence>
        <xsd:element name="callingDevice" type="csta:DeviceID"/>
        <xsd:element name="calledDirectoryNumber" type="csta:DeviceID"/>
        <xsd:element ref="csta:accountCode" minOccurs="0"/>
        <xsd:element ref="csta:authCode" minOccurs="0"/>
        <xsd:element name="autoOriginate" type="csta:AutoOriginate" default="prompt"</pre>
minOccurs="0"/>
        <xsd:element ref="csta:correlatorData" minOccurs="0"/>
        <xsd:element ref="csta:userData" minOccurs="0"/>
        <xsd:element ref="csta:callCharacteristics" minOccurs="0"/>
        <xsd:element ref="csta:mediaCallCharacteristics" minOccurs="0"/>
        <xsd:element name="callingConnectionInfo" type="csta:ConnectionInformation"</pre>
minOccurs="0"/>
        <xsd:element ref="csta:subjectOfCall" minOccurs="0"/>
        <xsd:element ref="csta:languagePreferences" minOccurs="0"/>
        <xsd:element ref="csta:extensions" minOccurs="0"/>
      </xsd:sequence>
    </xsd:complexType>
  </xsd:element>
  <xsd:element name="MakeCallResponse">
    <xsd:complexType>
      <xsd:sequence>
        <xsd:element name="callingDevice" type="csta:ConnectionID"/>
```

The elements defined in this file lead to definition of corresponding data structures in the symbol table of the CBL interpreter. These types can then be inspected using the data inspector. With the data inspector you can also navigate to the XSD file where the data structure has been defined. This is a very helpful function when exploring complex schemas.

If a XML string is to be created - matching the XML description shown above - an object of this data type can be instanceated like this:

```
CSTA::MakeCall makecall;
```

The properties of this object can be accessed like with any other CBL defined object:

Each class that has been generated by a XSD import has the methods string ToString() and void FromString(string s).

Using <code>ToString()</code> a XML string will be generated from the current objects content. Default values will be taken into consideration when genering the XML string: only values that differ from the default values will be visible in the string.

```
string s=makecall.ToString();
comwinFrame.ConsolePrint( BeautifyXML(s));
```

The function \_BeautifyXML can be used to "beautify" a XML string to enhance its readabilty.

The object shown above results in this XML string:

```
<MakeCall>
    <callingDevice>31562</callingDevice>
    <calledDirectoryNumber>39153</calledDirectoryNumber>
</MakeCall>
```

The method FromString is used for parsing a XML string in the other direction. The object will be filled with data provided in the XML string:

Advanced topics

```
CSTA::MakeCall mc;
mc.FromString(s);
```

The the data can be accessed using ordinary CBL functionionality. By this means the CBL interpreter got a validating XML parser.

## 3.3.7 Import of ASN.1-Modules

By means of the import statement (see "import\_stmt" on page 18) ASN.1-Modules can be "imported" into a CBL project.

Therefor the desired module or a sum of zip packed modules will be given to the ASN.1 compiler "snacc". This freeware tool was enanced to generate CBL code. "snacc" is called in the background in a way that the generated CBL files are placed into a temporary directory and added to the current CBL project.

The imported class definitions are visible in the data inspector, the generated modules are visible in the module list of the CBL Interpreter.

Unfortunately not all ASN.1 dialects can be interpreted using snacc (version 1.3); ASN.1 had some evolution steps in its past. But the functionality is enought to interpret the complex spectifications of the ECMA CSTA III protocol.

The usage of the BER encoding, decoding and printing routines is analoy to the generated C++ code. The advantage of CBL code is that you do not have to care about memory management. This is done automatically by the CBL garbage collector.

This small example shows generation and analysis of ASN.1 coded messages from CSTA "SystemStatusRequest":

## **Example: Code generation of ASN.1-Code**

```
import "csta.zip" namespace CSTA
CSTA::ROSEapdus rose_apdu;
CSTA::ROSEapdus rose res;
int bytesDecoded=0;
int bytesEncoded=0;
AsnBuf b;
string os;
void HandleMessage(string hex)
  os="";
  b.InstallDataFromHex(hex);
  rose_apdu.Init();
  int ok=rose_apdu.BDecPdu(b,bytesDecoded,os);
  if (ok)
    os << endl;
    rose_apdu.Print(os);
    comwinFrame.ConsolePrint("\nReceived ROSE:\n");
    comwinFrame.ConsolePrintStyle(os,cpsFixed);
    with (rose_apdu)
      if (!_IsNull(roiv_apdu))
        with (roiv_apdu)
```

Advanced topics

```
int send_response=0;
      (operation_value.value==211)
  // Received SystemStatus-Request --> Send SystemStatusRes
with (rose_res)
    choiceId=CSTA::ROSEapdus::rors_apduCid;
    rors_apdu=CSTA::RORSapdu::New();
    with (rors_apdu)
      invokeID.value=rose_apdu.roiv_apdu.invokeID.value;
      cSTA::CSTA::RORSapduSeq=CSTA::RORSapduSeq::New();
      with(cSTA::CSTA::RORSapduSeq)
        operation_value.value=211;
        anyDefBy=CSTA::GetAnyByInt(operation_value,2);
        with(anyDefBy)
          choiceId=CSTA::SystemStatusRes::noDataCid;
          noData =AsnNull::New();
    }
  }
  send_response=1;
elseif (operation_value.value==207) // SystemRegister
  // Received SystemRegister-Request--> Send SystemRegisterResult
  with (rose_res)
    choiceId=CSTA::ROSEapdus::rors_apduCid;
    rors_apdu=CSTA::RORSapdu::New();
    with (rors_apdu)
      invokeID.value=rose_apdu.roiv_apdu.invokeID.value;
      cSTA::CSTA::RORSapduSeq=CSTA::RORSapduSeq::New();
      with(cSTA::CSTA::RORSapduSeq)
        operation_value.value=207;
        //anyDefBy=CSTA::SystemRegisterResult::New();
        anyDefBy=CSTA::GetAnyByInt(operation_value,2);
        with (anyDefBy)
          sysStatRegisterID.octetLen=3;
          sysStatRegisterID.octs={ 1, 2, 3 };
    }
  send_response=1;
} // SystemRegister
if (send_response)
  b.InitInWriteMode();
```

```
rose_res.BEncPdu(b,bytesEncoded);
          b.PutByteRvs(bytesEncoded%256);
          b.PutByteRvs(bytesEncoded/256);
          hex=b.ToHex();
          sim.SendRequest(hex,3);
          os="";
          rose_res.Print(os);
          comwinFrame.ConsolePrint("\nSent:\n");
          comwinFrame.ConsolePrintStyle(os,cpsFixed);
    }
  return;
}
os="";
b.InstallDataFromHex(hex);
acse_apdu.Init();
ok=acse_apdu.BDecPdu(b,bytesDecoded,os);
if (ok)
  os << endl;
  acse_apdu.Print(os);
  comwinFrame.ConsolePrint("\nReceived:\n");
  comwinFrame.ConsolePrintStyle(os,cpsFixed);
  // Waiting for ACSE::AARQ
  // Send ACSE::AARE
  ACSE::ACSE_apdu resapdu;
  resapdu.choiceId=ACSE::ACSE_apdu::aareCid;
  resapdu.aare=ACSE::AARE_apdu::New();
  with (resapdu.aare)
  {
    application_context_name=acse_apdu.aarq.application_context_name;
    result.value=ACSE::Associate_result::accepted;
   result_source_diagnostic=ACSE::Associate_source_diagnostic::New();
    with (result_source_diagnostic)
      acse service user=ACSE::Associate source diagnosticInt::New();
      acse_service_user.value=ACSE::Associate_source_diagnosticInt::null1;
   user_information=ACSE::Association_information::New();
    with (user_information)
      with(list[0])
        direct_reference=AsnOid::New();
        direct_reference=acse_apdu.aarq.user_information.list[0].direct_reference;
        encoding=ACSE::EncodingCsta::New();
        encoding=acse_apdu.aarq.user_information.list[0].encoding;
    }
  b.InitInWriteMode();
```

Advanced topics

```
resapdu.BEncPdu(b,bytesEncoded);
 b.PutByteRvs(bytesEncoded%256);
 b.PutByteRvs(bytesEncoded/256);
 hex=b.ToHex();
  sim.SendRequest(hex,3);
 os="";
 resapdu.Print(os);
  comwinFrame.ConsolePrint("\nSent:\n");
  comwinFrame.ConsolePrintStyle(os,cpsFixed);
  // Send CSTA/ROSE::SystemStatus
  //
 rose_apdu.Init();
 with (rose_apdu)
    choiceId=CSTA::ROSEapdus::roiv_apduCid;
   roiv_apdu=CSTA::ROIVapdu::New();
    with (roiv_apdu)
      invokeID.value=0;
      operation_value.value=211;
      argument=CSTA::GetAnyByInt(operation_value,1);
      with(argument)
        systemStatus.value=CSTA::SystemStatus1::normal;
    }
 b.InitInWriteMode();
  rose_apdu.BEncPdu(b,bytesEncoded);
 b.PutByteRvs(bytesEncoded%256);
 b.PutByteRvs(bytesEncoded/256);
 hex=b.ToHex();
  sim.SendRequest(hex,3);
 os="";
 rose_apdu.Print(os);
  comwinFrame.ConsolePrint("\nSent:\n");
  comwinFrame.ConsolePrintStyle(os,cpsFixed);
  return;
}
```

}

This chapter describes the predefined CBL include files, the contained classes and their usage as well as the variables and functions of the interface to the CBL Interpreter itself.

# **Advanced topics**

- chapter 4.1, "Interface to the Interpreter"
- > chapter 4.2, "General functions"
- > chapter 4.3, "Interfaces to the HiPath 4000 Expert AccessFrame components"
- > chapter 4.4, "Designing forms"
- > chapter 4.5, "CBL National Language Support"

# 4.1 Interface to the Interpreter

This section describes some low level functions/variables of the CBL Interpreter.

# **Advanced topics**

- > chapter 4.1.1, "Command line parameters: Args"
- > chapter 4.1.2, "Interpreter functions"

# 4.1.1 Command line parameters: Args

Command line parameters can be accessed by a CBL program via the predefined array variable string [] Args. This global variable is generated as soon as the CBL program is started.

The last parameter of a command line call to the CBL Interpreter is the name of the desired CBL program.

```
cblrun.exe par1=value1 par2=value2 par3=value3 test.cbl cblrun.exe /par1 value1 /par2 value2 /par3 value3 test.cbl cblrun.exe -par1 value1 -par2 value2 -par3 value3 test.cbl
```

Then the Args array gets the following values:

Interface to the Interpreter

```
Args["par1"]="value1"
Args["par2"]="value2"
Args["par3"]="value3"
```

# 4.1.2 Interpreter functions

This sections lists all function that are implemented in the interpreter internally.



Functions starting with underscore \_ should only be called directly by the user if absolutely necessary. They are only intended for functions defined in system includes.

string TranslateIn(string)	Translates a string from external representation into application language by using the current text_table entries
string TranslateOut(string)	Translates a string from application language to external representation by using the current text_table entries
<pre>int TextHeight(string)</pre>	Calculates the height of a text in pixels. To be used for explicit calculation of a text field size on a form.
int TextWidth(string)	Calculates the width of a text in pixels. To be used for explicit calculation of a text field size on a form.
void Wait(int ms)	Suspends the current executed CBL program for ms milliseconds.
<pre>int ContainsStrIndex (void @array, string index)</pre>	Checks, if there is an array element array [index]. First Parameter array must be an string indexed array, otherwise a runtime error occurs. index is the string used to address the array element, if it exists.
int StartJavaServer (int port)	Starts the built-in Java Interface at the desired port.
void StopJavaServer()	Stops the built-in Java Interface
<pre>int GarbageCollec- tion()</pre>	Explicitly starts a garbage collection, i. e. memory not used anymore is released. The return value is the number of objects released. GarbageCollection() is also internally called by the interpreter itself. It is a good idea to call GarbageCollection() at times, when the user does not notice this, e. g. after showing a form (see Form::Show() in system include form.cbl) or after updating a form.

<pre>void ArrayRemoveAt( void @array, string index) void ArrayRemoveAt( void @array, int in- dex)</pre>	ArrayRemoveAt can be used to delete one specific element from an array identified by it's string index or sort order.
<pre>void ShowProgress(int _percent, string _comment)</pre>	A window showing progress is displayed. If _percent <0 or >100, the window is closed, otherwise _percent represents the position of the progress barcomment appears in the window's comment line.
<pre>void TracePrint(int _level, string _text)</pre>	Trace messages can be transferred to HiPath 4000 Expert Access's standard trace mechanism with TracePrint.
void Dispose(void @_obj)	An object can be explicitly and immediately released with Dispose. Afterwards, it can no longer be accessed as it was removed from the CBL Interpreter's symbol table. References to the server are immediately released, where applicable, in the case of OLE objects.
<pre>int _HttpDownloadFile (string _url, string _filename)</pre>	The function can be used to load a file via HTTP from the specified URL _url (http://) and save it under _filename.
<pre>int _WaitUntilReleaseWait (int @ _context, int _timeout) void _ReleaseWait (int _context, int _return)</pre>	_WaitUntilReleaseWait enables the CBL Interpreter to receive events that were produced by an OLE server for the time duration of _timeout milliseconds and process them with the relevant event handling routines. In the meantime, all other events (keyboard inputs, mouse actions) are processed as normal.  A value that can be used by _ReleaseWait is returned in _context so that the _WaitUntilReleaseWait function can be prematurely terminated.  The return value in the case of a timeout is 0, and in the case of premature termination via _ReleaseWait it is the transferred value of the _return argument.
<pre>int _Defined (void @_this, string _symbol)</pre>	_Defined can be used to check if a specific function named _symbol or a specific field is defined for an object.

Interface to the Interpreter

<pre>int _MemBlockGetPtr (_memblock @m);</pre>	The _MemBlock functions are needed for the implementation of memory blocks for the DLL interface.
<pre>void _MemBlockSetPtr (_memblock @m, int ptr)</pre>	see "Using the DLL interface" on page 60
<pre>void _MemBlockAlloc (_memblock @m, int si- ze)</pre>	
<pre>void _MemBlockFree (_memblock @m)</pre>	
<pre>int _MemBlockGetInt (_memblock @m, int offset, int size)</pre>	
<pre>void _MemBlockSetInt (_memblock @m, int offset, int size, int value)</pre>	
string _MemBlockGetString (_memblock @m, int offset, int size)	
<pre>void _MemBlockSetString (_memblock @m, int offset, int size, string s)</pre>	
<pre>int _MemBlockGetSize (_memblock @m)</pre>	
string _BeautifyXML(string s)	This function is used to "beautify" XML strings to enhance it's readabiltiy e.g. for printouts. Linefeeds and indents are inserted into the string. Its use is shown in section 3.3.6 on page 64.
_CorbaObjectBind	Not used at present.
_Delete	Delete a specific object.
_FormCheckComplete	Used by form.CheckComplete.
_FormCheckControl	Used by form.CheckControl
_FormClose	Used by form.Close.
_FormGet	Used by form.Get.

_FormShow	Used by form.Show
_FormStoreSizePos	Used by form.StoreSizePos
_FormResetModifiedCon trol	Used by form.ResetModifiedControl
_FormRetrieveSizePos	Used by form.RetrieveSizePos
_FormUpdate	Used by form.Update
_Import	This fuction implements the dynamical pendant for the import statement. (see "import_stmt" on page 18). It's usage is shown in section 3.3.5 on page 62.
void _Interrupt()	This function can set a "persistent" stop in CBL source code. If the CBL Interpreter is in "Debug" processing mode (to be set via the Option menu), then processing is interrupted afterInterrupt as if a stop were set there. If the CBL Interpreter is not in "Debug" mode, theInterrupt calls are simply ignored.
_OleCreateObject	Used by Variant.CreateObject
_OleFunction	Used by Variant.OleFunction
_OleProcedure	Used by Variant.OleProcedure
_OlePropertyGet	Used by Variant.OlePropertyGet
_OlePropertySet	Used by Variant.OlePropertySet
_RemoveLast	Removes last element of an array. Not yet used.
_RunModule	Includes a cbl module at runtime. Not yet used.
_SendMessage	Sends a message string via TCP to an IP/port. Not yet used.
_StartModal	Used by form.StartModal.

General functions

### 4.2 General functions

General functions can be included from the CBL include file sysfunc.cbl.

"General functions" covers functions for string handling, operating system interface, file handling, accessing the Windows registry database and some more.

# **Advanced topics**

>

```
chapter 4.2.1, "cbl_sysfunc_ (ole_class)"
chapter 4.2.2, "cbl_chain (ole_class)"
chapter 4.2.3, "cblFile (ole_class)"
chapter 4.2.4, "cblIniFile (ole_class)"
chapter 4.2.5, "cblZipFile (ole_class)"
chapter 4.2.6, "cbl_dialogs (ole_class)"
```

# 4.2.1 cbl\_sysfunc\_ (ole\_class)

chapter 4.2.7, "cblXmlFile (ole class)"

```
The OLE class "cblsys1.sysfunc" is implemented in the DLL cblsys1.dll.
```

```
ole_class cbl_sysfunc_ : "cblsys1.sysfunc"
 // string handling
 int strlen(string s) ⇒
 string substr(string s,int start, int end) ⇒
 int char(string s, int index) ⇒
 string trim(string s)⇒
 string ltrim(string s)⇒
 string rtrim(string s)⇒
 string stripquotes(string s)⇒
 int strfind(string s1, string pattern, int count=1)⇒
 int match_regex(string s, string regex, int index, string @match) ⇒
 string int2hex(int value,int digits) ⇒
 string [] string_lines(string _in) ⇒
 string toupper(string s)⇒
 string tolower(string s)⇒
 string [] sort_grid(string [] _in, int col)⇒
```

```
string format(string _in, string _sep, string _format) ⇒
// encryption / decryption
// operating system related functions/properties
string system(string cmd)⇒
int clock() ⇒
string currentDateTime ⇒
int ShellExecute(string operation, string file,
            void
     MessageBeep(int sound=-1)⇒
// procedures for AMO result handling
string [] prepare_regen_results(string _in)⇒
string [] param_ivals(string _in) ⇒
string [] parse_amo_result(string _in) ⇒
cblinterval [] param_intervals(string _in)⇒
//
// Registry access
//
int
     int
     RegistryReadInteger(string RootKey, string Key, string item,
     int Default=0) ⇒
void
     RegistryWriteString(string RootKey, string Key, string item,
     string value)⇒
void
     RegistryWriteInteger(string RootKey, string Key,
     string item, int value)⇒
string [] RegistryGetKeyNames(string RootKey, string Key )⇒
//
// Misc
//
string CreateTempDir() ⇒
string CreateTempFile(string dir) ⇒
void
     DeleteTempDir(string dir)⇒
int file_compare(string file1, string file2, int size=0) ⇒
ForceDirectories(string dir)⇒
string FindConnectProfile(string uw7ipaddr)
```

General functions

```
string FileDate(string file)

int SetFileDate(string file, string OsiDateTime)

cblUrl ParseUrl(string url)

}
```

Predefined object for this class:

```
cbl_sysfunc_ syslib
syn syn=syslib
```

# 4.2.1.1 String manipulation

# String length

```
int strlen(string s)
strlen() returns the number of characters of s.
```

# **Substring**

```
string substr(string s, int start, int len)
```

substr() returns a string which is a part of s. It begins at the position of start and has the length len. start is 0-based.

#### ASCII code of a character

```
int char(string s, int index)
```

char() returns the ASCII code of the character in the string s at the position index, which is 0-based.

# Removing blanks (spaces)

```
string trim(string s)
```

trim() returns the string s without any spaces and control characters.

# Removing blanks (spaces) from the left

```
string ltrim(string s)
```

ltrim() returns the string s where all spaces and control characters on the left have been removed.

### Removing blanks (spaces) from the right

```
string rtrim(string s)
```

rtrim() returns the string s where all spaces and control characters on the right have been removed..

# Fill a string from the left

```
string lfill(string s, int count, string fill)
```

lfill() returns a new string, where string fill has been inserted count times before string s.

# Strip quotes off a string

```
string stripquotes(string s)
```

stripquotes() returns string s, where in the first step trailing blanks and then one Double-Quote (") at the beginning and at the end of s has been removed, if there was one.

# Search a pattern in a string

```
int strfind(string s1, string pattern, int count=1)
```

strfind() returns an integer value of the position of the first or if specified the count-th occurrence of pattern in s1. -1 is returned, if pattern is not found.

# Turning decimal into hexadecimal

```
string int2hex(int value, int digits)
```

int2hex() transforms an integer to a hexadecimal. value is the integer number and digits is the length of the hexadecimal number the function should return. If digits is less than the positions needed, it will be ignored.

# Check string against a "regular expression"

```
int match_regex(string s, string regex, int index, string @match)
```

The character string s is checked against the regular expression regex. The regular expressions supported by the Unix command "egrep" are accepted as regex.

A regular expression is nothing else than a search pattern for finding matching patterns in an input string.

Overview of most common regular expressions:

- Searches the pattern at the beginning of a line.
  "^beginnt hier"
- \$ Searches the pattern at the end of a line. "endet hier\$"

General functions

```
Any number of the preceding character; in the example all " *schon"
            lines are searched that contain the word "schon" with any
            number of preceeding spaces:
            Exactly one character.
                                                                       ".och"
[]
            Excatly one of the enclosed characters.
                                                                       "[Dd]och"
            One of the characters matching a range.
                                                                       "[A-X]och"
[a-z]
            none of the enclosed characters
[^]
                                                                       "[^ln]och"
            Invalidates the special meaning of the succeeding charac- "x\$\>y"
\
            ters.
            Search pattern at the beginning of a word
\<
                                                                       "\<doch"
            Search pattern at the end of a word.
\>
                                                                       "ung\>"
            Remember enclosed patern; this can be accessed later
                                                                       "\(aff\)iq
 \(..\)
            using \1. Up to nine patterns can be stored in this way.
                                                                       \lenstark"
            m-timed occurance of character x.
x \setminus \{m \setminus \}
                                                                       "s\{3\}"
                                                                       "+\{5,8\}"
x \setminus \{m,n\} At least m-, at most n-timed occurance of character x
```

match\_regex supplies the number of hits as the return value

The contents of the index-ed hits are returned in match.

#### Example:

```
string s="is invisible and smells like hare";
string found;

int cnt=sys.match_regex(s,"and",1,found);
//-> cnt=1, found="and"

cnt=sys.match_regex(s,"s.",1,found);
//-> cnt=3, found="st"

cnt=sys.match_regex(s,"s.",2,found);
//-> cnt=3, found="si"

cnt=sys.match_regex(s,"rabbit",1,found);
//-> cnt=0, found=""
```

# Turning decimal into hexadecimal

```
string int2hex(int value, int digits)
```

int2hex() converts an integer to a hexadecimal number. Value is an integer. Digits indicates the length of the hexadecimal value to be returned by the function. If the value for digits is less than the number of required positions it is ignored.

# **Turning hexadecimal into decimal**

```
int hex2int(string value)
```

hex2int() turns the hexadecimal number of the string value into an integer, that the function will return.

# Split a string into lines

```
string [] string lines(string in)
```

string\_lines splits a string that contains linefeed characters ( $' \n'$ ) into separate lines and returns an array of these lines.

# Split a string into tokens

```
string [] string_token(string _in, string _sep)
```

string\_token returns an array of substrings of \_in which are separated by the separator
string\_sep. Example: string\_token("A.B.C",".") returns { "A", "B", "C" }.

# Convert string into all uppercase

```
string toupper(string s)
```

toupper converts all lowercase letters in string s to uppercase and returns the resulting string.

# Convert string into all lowercase

```
string tolower(string s)
```

tolower converts all uppercase letters in string s to lowercase and returns the resulting string.

### Replace a pattern within a string

```
string replace(string s, string old, string new)
```

replace replaces all occurrences of string old in string s with string the contents of string new.

### Sorting a separated string array by a certain column

```
string [] sort_grid(string [] _in, int col)
```

General functions

sort\_grid sorts a string array, whose entries are intended as the contents of a multi-column ctListbox control (see <a href="ctListbox">ctListbox</a> column defined by col. The first column has the index 0.

# Format a text string

```
string format(string _in, string _sep, string _format)
```

format can be used to format the contents of a string, e.g. for print-editing. The input string \_in is first split into one or more components, as defined by the separator \_sep, and then combined again, as defined by the format string \_format, before being output. The individual output fields in the formatted string are output as defined by %s and the corresponding format extensions. The format extensions correspond to the printf command in the C Reference.

# Examples:

# Simple encryption/decryption functions

```
string encrypt(string s, string p="")
string decrypt(string s, string p="")
```

encrypt returns string s in an encrypted version. It can be decrypted using decrypt. The encrypted string consists of printable characters. It's size is about twice as big as the decrypted string. Optionally you may pass a password p for the encryption. This is necessary for a successful decryption then.

These functions can be used to store/retrieve data which should not be stored in readable format (e. g. passwords).

# 4.2.1.2 Operating system oriented functions

#### **Execute command line commands**

```
string system(string cmd)
```

With this function it is possible to pass commands directly to the operating system. If the command does not succeed, the function will return the error message.

Example (starting the Netscape-Communicator in WindowsNT/Windows95):

#### **Execution time**

```
int clock()
```

The function <code>clock()</code> returns a time value in milliseconds (ms). The absolute value is meaningless for the caller. However, it is possible to measure the time between two occurrences. If the execution time is not available, or the value cannot be interpreted, the function will return -1.

### **Current date time**

```
string currentDateTime
```

The property currentDateTime returns the current date time in the CBL serialization format. This means that currentDateTime can be assigned to an object of type cblDateTime to be able to access year, month, day, hour, minute and sec

# Open file with the linked program

ShellExecute (see also Win32 API function "ShellExecute") can be used to open a file with the specially defined operation method. Optional callup parameters and a directory can also be specified.

### Examples:

```
sys.ShellExecute("open","textfile.txt"); // opens notepad
sys.ShellExecute("open","file.doc"); // opens Word
sys.ShellExecute("print","file.doc"); // prints via Word
```

# **Emit beep**

```
void MessageBeep(int sound=-1)
```

A beep or a system sound can be output with MessageBeep.

General functions

# 4.2.1.3 Public routines handling AMO-results

# Prepare regeneration results for further processing

```
string [] prepare_regen_results(string _in)
```

The prepare\_regen\_results() function creates a 0-based array of all the regen results. Every line is stored in a separate string. The string \_in is the reply, sent by HICOM, on a REGENERATE-command.

# Split linked values of a parameter of an AMO

```
string [] param_ivals(string _in)
```

The param\_ivals() function creates a 0-based array of the linked values of a parameter of an AMO. The list of the linked values separated with an ampersand (&) or dash (-) has to be the string \_in.

Example 1:

```
Array=param_ivals("1 & 5 & 6 & 13");
```

The result of this call would be:

```
Array: [0]:"1", [1]:"5", [2]:"6", [3]:"13"
```

# Example 2:

```
Array=param_ivals("1 && 5 & 13");
```

The result of this call would be:

```
Array: [0]:"1", [1]:"2", [2]:"3", [3]:"4", [4]:"5", [5]:"13"
```

This is especially useful for displaying all the values in a range in a combobox or listbox.

#### Example 3:

Variant 2 (values separated by dash) is especially useful for splitting LAGE parameters into its components:

```
param ivals("1-1-7-13");
```

The result of this call would be:

```
Array: [0]:"1", [1]:"1", [2]:"7", [3]:"13"
```

### Splitting a parameter into intervals

```
class cblinterval
{
   int lower;
   int upper;
}
```

```
interval [] param_intervals(string _in)
```

The param\_intervals() function splits a parameter list into intervals. Example:

```
sys.param_intervals("1 & 10 && 20 & 30");
```

#### The result is:

# Results of a HICOM command

```
string [] parse_amo_result(string _in)
```

The parse\_amo\_result() function creates a 0-based array of the results of any HICOM command. Every line in a separate string. The string \_in is the reply, sent by HICOM, on a HICOM command.

#### **Error numbers**

```
string [] parse_amo_errors(string _in)
```

The parse\_amo\_errors() function creates a 0-based array with the error numbers of the results of a HICOM command. All M-, S-, H- and F-messages are stored in the array. The string \_in is the reply, sent by HICOM, on a HICOM command.

### 4.2.1.4 Access to the Windows registry database

### Check for the existence of an registry key

```
int RegistryExistsKey(string RootKey, string Key)
```

RegistryExistsKey checks if the desired Key exists under the given RootKey. The Root-Key can take the values "HKEY\_LOCAL\_MACHINE", "HKEY\_CURRENT\_USER" etc. The function returns 1 if the key exists, else 0.

### Read a string value from the registry

```
string RegistryReadString(string RootKey, string Key, string item)
```

RegistryExistsString returns the desired string value of the desired item at the given Key and RootKey. The RootKey can take the values "HKEY\_LOCAL\_MACHINE", "HKEY\_CURRENT\_USER" etc. If the value could not be read the function returns "".

General functions

# Read an integer value from the registry

```
int RegistryReadInteger(string RootKey, string Key, string item,
    int Default=0)
```

This function is identical to RegistryReadString, except for the fact that an integer value is read in this case.

# Write a string to the registry

The function RegistryWriteString writes the string value value to the specified position in the registry, as defined by RootKey, Key and item. If no such entry exists, a new entry is created with the given value.

# Write an integer value to the registry

The function RegistryWriteInteger writes the integer value value to the specified position in the registry, as defined by RootKey, Key and item. If no such entry exists, a new entry is created with the given value.

# Get subkeys from the registry

```
string [] RegistryGetKeyNames(string RootKey, string Key )
```

RegistryGetKeyNames returns the names of all subkeys of the specified Key from the registry in the form of a string array.

### 4.2.1.5 Miscellaneous Functions

#### **Extract File Path**

```
string ExtractFilePath(string path)
```

ExtractFilePath extracts the file path of the given file path.

# **Create a temporary directory**

```
string CreateTempDir()
```

CreateTempDir creates a temporary directory. The path of the directory is returned. The directory is located beneath Window's temporary directory, usually C:/TEMP. The name of the temporary directory starts with "CBL".

# Create a temporary file

```
string CreateTempFile(string dir)
```

CreateTempFile creates a temporary file at the given directory dir. The file name starts with "CBL". The name of the file is returned.

# Delete a temporary directory

```
void DeleteTempDir(string dir)
```

DeleteTempDir tries to delete all files and subdirectories of directory dir. The value of dir must start with "CBL", this means it should have been created using CreateTempDir.

# Compare files

```
int file_compare(string file1, string file2, int size=0)
```

file\_compare compares the given files, opened in binary mode. If file1 could not be opened it returns -1; if file2 could not be opened it returns -2.

size defines the minimum number of bytes to be compared. If size equals 0 (default) the files are compared completely.

file\_compare returns 0 for equal, 1 for different files.

### **Find files**

```
string [] FindFile(string pattern)
```

FindFile returns all file names that match the specified pattern (which can be defined using the usual wildcards \* and ? allowed under Windows).

# **Create directory path**

```
void ForceDirectories(string dir)
```

ForceDirectories creates all directories from the specified path dir if the corresponding directories do not exist.

#### Read file date

```
string FileDate(string file)
```

FileDate returns the date of the specified file in OSI format, i.e.: yyyy-mm-dd hh:mm:ss.

General functions

### Set file date

```
int SetFileDate(string file, string OsiDateTime)
```

SetFileDate sets the date for the specified file to the date given in OsiDateTime, which is defined in OSI format (yyyy-mm-dd hh:mm:ss).

### Parse URL

```
cblUrl ParseUrl(string url)
```

ParseUrl parses (i.e. splits) the url that is passed to it as an argument into its respective components:

Туре	Field	Meaning
string	proto	Protocol (e.g. "http")
string	user	User name
string	pass	Password
string	host	Name or IP address of host
string	port	Port number
string	path	Path specification
string	filename	File name
string []	params	Array of parameters, indexed by parameter name

### Example:

```
cblUrl loc=ParseUrl(
"http://hpserv99.mch4.siemens.de:8080/ComWin/
download.html?par1=value1&par2=value2");
-->
loc.proto="http"
loc.user=""
loc.pass=""
loc.host="hpserv99.mch.pn.siemens.de"
loc.port="8080"
loc.path="/ComWin"
loc.filename="download.html"
loc.params["par1"]="value1"
loc.params["par2"]="value2"
```

# 4.2.2 cbl\_chain (ole\_class)

The OLE class "cblsys1.chain" is implemented in the DLL cblsys1.dll.

This class encapsulates functions for handling of concatenated AMO parameter values:

```
ole_class cbl_chain: "cblsys1.chain"
{
  void create(string s) 
  void remove_int_from_chain(int i) 
  void remove_chain_from_chain(string s)
  string chain_to_string()
}
```

Predefined object for this class:

none

# Creating a chain object from a chain string of ints

```
void create(string s)
```

The first step in working with chains of int values is converting this string into a chain object. This action converts the chain into a internal format.

# Example:

```
cbl_chain mychain;
mychain.create("1&&5&20&&40");
```

# Removing a single int value from a chain object

```
void remove int from chain(int i)
```

Removes an int value from the internal representation of the chain object. To see the resulting chain, you have to convert the chain object back into a string (see chain\_to\_string() below). Note that the actual parameter may be of type int or of type string due to CBL's type compatibility rules.

# Example:

```
mychain.void remove_int_from_chain(2);
mychain.void remove_int_from_chain("4");
```

# Removing a chain of int values from a chain object

```
void remove_chain_from_chain(string s)
```

General functions

Removes all values in int chain s from the internal representation of the chain object. To see the resulting chain, you have to convert the chain object back into a string (see chain\_to\_string() below).

# Example:

```
mychain.void remove_chain_from_chain("30&32&36&&38");
```

# Convert chain object into string

```
string chain to string()
```

Converts the internal representation of a chain object back into a string.

# Example:

```
string s;
s = mychain.chain to string();
```

After executing all commands in the examples above the result in s is:

"1&3&5&20&&29&31&33&&35&39&&40"

# 4.2.3 cblFile (ole\_class)

The OLE class "cblsys1.file" is implemented in the DLL cblsys1.dll.

The class encapsulates the access to text files on the hard disk/network etc.

```
ole_class cblFile : "cblsys1.file"
{
    string open(string name, string mode)
    string readln() 
    string read(int size=0) 
    int write(string txt) 
    void close() 
    int eof 
}
```

# Opening a file

```
string open(string name, string mode)
```

The function open() opens a file. Here, name is the name of the file and mode determines how the file will be opened. Legal mode values are:

```
"r" open a file for reading (this file must exist)
```

<sup>&</sup>quot;w" create a text file for writing (any already existing file with this name will be overwritten)

<sup>&</sup>quot;a" open a text file with mode append (new data will be appended to the end of the file).

If the function fails, an error message will be returned, otherwise an empty string will be returned.

# Example:

```
cblFile f;
f.open ("sysfunc.cbl", "r");
```

# Reading a string

```
string readln()
string read(int size=0)
```

The function readln() reads a line from a file opened in read mode by open(). The returned string are the data the function reads.

The function read reads a given number (size) of characters from the file. If size equals 0 (default) the file is read until the end of file is reached.

# Writing a string

```
int write(string txt)
```

The write() function write strings to a file that was previously opened (and created) for writing.

# Closing a file

```
void close()
```

The close() function closes a file that was opened by the open() function.

#### End of a file

```
int eof
```

If the end of a file is encountered the eof property returns true (1), otherwise it returns 0. Example:

```
cblFile f;
string line;
f.open("readme.txt","r");
line = f.readln();
while (!f.eof) {
   //handle line read:
   ...
   line = f.readln();
}
f.close();
```

General functions

The block after the *while\_stmt* is executed until the end of the file is reached.

# 4.2.4 cbllniFile (ole\_class)

The OLE class "cblsys1.cbllniFile" is implemented in the cblsys1.dll.

It encapsulates functions for convenient accessing .ini files as well as the Windows registry database.

```
const int ftIni=0;
const int ftRegIni=1;

ole_class cblIniFile : "cblsys1.cblIniFile"
{
    string Open(string name, int type)
    void Close()
    string ReadString(string _section, string _ident, string _default)
    int    ReadInteger(string _section, string _ident, int _default)
    void WriteString(string _section, string _ident, string _value)
    void WriteInteger(string _section, string _ident, int _value)
}
```

Open opens an ini file or a section in the registry below HKEY\_CURRENT\_USER depending on the value of type. If type==ftIni an ordinary file is opened, else the registry database. If the file is not yet existing it will be generated. If no path is qualified for the file it will be located in the Windows directory.

Close must be used to finish the ini file ore registry database.

ReadString/ReadInteger returns the value of \_ident from \_section or \_default if ident was not found.

WriteString/WriteInteger stores \_value to the idenifier \_ident in section \_section. If the section or identifier is not yet existing it will be generated.

# 4.2.5 cblZipFile (ole\_class)

The OLE class "cblsys1.cblZipFile" is implemented in the cblsys1.dll.

It encapsulates functions for working with zipped files.

open opens a zip file. It returns 1 if the zipfile could be opened, else it returns 0. close closes the zip file.

directory returns the files and paths that are contained within the zip file.

unzip unpacks the files matching the given pattern into the destination\_dir. If mode equals 1 a popup window shows the current unpacking progress.

# 4.2.6 cbl\_dialogs (ole\_class)

The OLE class "cblsys1.dialogs" is implemented in the cblsys1.dll.

It encapsulates functions for working with Windows' standard dialogs.

General functions

```
string Directory
string Filter

int MessageDialog(string message, int type, int buttons)
}
```

OpenDialog()/SaveDialog() opens a standard file open/save dialog. It returns 1 if the user pressed the OK button; otherwise, 0. The property Directory is used as starting directory for the dialog, the property FileName is the default value for the file name within the dialog. If OpenDialog/SaveDialog returns 1 the property FileName is set to the desired file name. It contains the absolute file path. Filter can be used to set the file filter for the dialogs. The format for Filter is shown in this example:

```
Filter="All files(*.*)|*.*||Text files (*.txt)|*.txt";
```

MessageDialog opens a standard message dialog. message contains the message to be displayed, type defines the type (and symbol) of the message dialog. The displayed but-tons are defined by a sum of the message button values. MessageDialog returns the button which has been pressed.

# Example:

# 4.2.7 cblXmlFile (ole\_class)

The OLE class "cblsys1.xmlfile" is implemented in the DLL cblsys1.dll.

This class implements a simple, non-validating XML parser.

```
class cblXmlRecord
{
  string    name;
  string [] params;

  cblXmlRecord [] items;
  string [] contents;
}

ole_class cblXmlFile : "cblsys1.xmlfile"
{
  string    header;
  cblXmlRecord body;
```

```
string open(string name)
int read()
void write()
void close()
}
```

An XML file can be opened with open.

The file is read in with read and the XML file header is saved in header. The recursive data structure body contains the complete contents of the XML file.

The current contents of body are written back to the XML file with write.

The XML file is closed with close.

A cblxmlRecord contains the name of the XML section, the value of the parameter defined in the current section in an appropriate string-indexed string array params, the subordinate XML sections items and all other text contents that are located between the XML sections above and below the subordinate XML sections.

Interfaces to the HiPath 4000 Expert AccessFrame components

# 4.3 Interfaces to the HiPath 4000 Expert AccessFrame components


The OLE classes described below are defined in the CBL include file comwin.cbl.

# **Advanced topics**

- chapter 4.3.1, "Comedit (ole\_class)"
- > chapter 4.3.2, "ComwinControl (ole\_class)"
- chapter 4.3.3, "(mode|=2: application handles wrong password, open returns immediately; mode|=4: deactivate autologon.)ComwinFrame (ole\_class)"
- > chapter 4.3.4, "ComwinCBL (ole\_class)"
- chapter 4.3.5, "ComWinFT (ole\_class)"
- chapter 4.3.6, "ComWinPPP (ole\_class)"
- > chapter 4.4, "Designing forms"
- chapter 4.3.8, "ComWinAccessSession (ole\_class)"
- chapter 4.3.9, "ComWinAccessFileman (ole\_class)"
- > chapter 4.3.10, "ComWinAccessDatabase (ole\_class)"
- chapter 4.3.11, "ComWinAccessQuery (ole class)"
- chapter 4.3.12, "ComWinFM (ole\_class)"

# 4.3.1 Comedit (ole\_class)

The OLE class "Comedit.MMLCommand" is implemented in the program HiPath 4000 Expert Access-MML Editor.



This class encapsulates the interface from a CBL program to HiPath 4000 Expert Access-MML\_Editor. It contains functions for handling of MML command strings and parsing of AMO output strings.

```
ole_class Comedit : "ComWin.MML_Command"
{
    string getParam(string param, int language=0) 
    int setParam(string param, string value, int language=0) 
    string getParamName(int index, int language=0)
```

```
string [] getParamNames()⇒
getParamProps(string param) ⇒
string getValueDesc(string param, int index, int language=0)⇒
string getParamValidation(string param, int language=0)⇒
     getParamIndex(string param) ⇒
string command ⇒
int
    Active ⇒
int
     ParamCount ⇒
string HicomVariant ⇒
int
     HicomLanguage ⇒
     ApplicationLanguage ⇒
int
string HicomCommand ⇒
string Noun 🗢
string Verb ⇒
string [] GetHicomVariants() ⇒
    KeywordOriented ⇒
string DestinationProcessor ⇒
     Error ⇒
int
string ErrorMsg ⇒
string ErrorParam ⇒
string ErrorParamIdx ⇒
string ErrorValue ⇒
int
    Check() ⇒
int
     CheckParam(string param) ⇒
int
     ExistsParam(string param) ⇒
     ShowParamDlg(string param) ⇒
int
string ShowCommandDlg(string command) \Rightarrow
void
     ShowCommand(int ConnectionId,
                String ConnectionName,
                String MMLCommand,
                String MMLVariant,
                      MMLLanguage,
                String ReplyObject,
                String ReplyMethod) ⇒
// AMO output mask parser interface
string AmoResult 🕏
int
     AmoResultPos ⇒
FindMask(string maskname) ⇒
string GetNextMask(string maskname) ⇒
     SkipLinesUntil(string pattern) ⇒
int
```

Interfaces to the HiPath 4000 Expert AccessFrame components

```
SkipLines(int cnt) ⇒
int
string FieldByIndex(int index) ⇒
string FieldName(int index) ⇒
int
      amoParseMaskRecord [] ParseAmoResult() ⇒
// Zusätzliche Funktionen
      ShowHelp(string url)
void
// File-oriented check function
      CheckFileUntilError (string inFile,
                         string outFile,
                         int StartPos,
                         int MaxLines,
                         int Action) ⇒
int
      ErrorLine
int
      FilePos
void CopyFrom(Comedit @src) ⇒
```

# Predefined object for this class

Comedit comedit:

# **Define the AMO command**

```
string command
```

The command property defines the AMO-command, which is necessary for the other functions of the class.

### Example:

```
Comedit comedit;
comedit.command = "EINR-SCSU:2100;";
tlnnu = comedit.getParam("TLNNU");
```

### Noun and verb of the current AMO command

```
string Noun
string Verb
```

The noun and verb of the current command can be read and set via the properties Noun and Verb.

# Initialize to work with a valid command

int Active

The Active property is set to 1 if command/HicomCommand contains a valid MML command. This does not imply that it is complete, but HiPath 4000 Expert Access-MML Editor has "something to work with".

The functions getParam, getParamDesc, getParamName, setParam, getValue, getValueDesc, Check, CheckParam, get ParamProps, getParamValidation, ExistsParam, ScanMask, FindMask, FieldByName etc. and the read accesses to the properties command, ParamCount, HicomCommand result in a runtime error if called when Active equals 0.

#### **Define the Hicom variant**

string HicomVariant

In the string HicomVariant the variant of the Hicom is defined.

#### Get a list of installed Hicom variants

```
string [] GetHicomVariants()
```

This function returns a list of Hicom variants as installed with HiPath 4000 Expert Access.

## **Hicom Language**

int HicomLanguage

The HicomLanguage specifies the current MML language of the PBX. 1 = german, 2 = english. Please refer to the description of HicomCommand for further details.

# **Application language**

```
int ApplicationLanguage
```

The ApplicationLanguage specifies the current MML language as used in the CBL application. It defines the language for parsing the MML commands as stored in command. 1 = german, 2 = english. Please refer to the description of HicomCommand for further details.

#### **Hicom command**

string HicomCommand

If HicomLanguage and ApplicationLanguage differ, the attribute HicomCommand can be used for an automated translation of the current MML command. If HicomCommand is assigned a MML command in HicomLanguage, it is automatically translated to ApplicationLanguage and stored into command (and vice versa). Please note that HicomCommand always uses HicomLanguage and command always uses ApplicationLanguage for MML parsing.

Interfaces to the HiPath 4000 Expert AccessFrame components

These attributes can be used to support Hicom language independent applications.

# Example:

# Define keyword or position oriented command output

```
int KeywordOriented
```

If KeywordOriented is set to 0 the MML command which is read from property command will be position oriented. If KeywordOriented is 1 it will be position oriented. If the value is 2, the command is kept as it was written.

# **Destination processor**

```
string DestinationProcessor
```

DestinationProcessor returns the name of the Hicom board where the AMO is designed to be executed. The value can be "SWU", "ADP", "VM", "TD" or "SS7". Please note that the destination processor can be defined at runtime, too.

# **Number of parameters**

```
int ParamCount
```

The ParamCount property returns the number of the defined parameters of the AMO-command. The AMO-command is defined in the property command, which is described above. ParamCount is a read-only property.

# Get the value of the parameter (by name)

```
string getParam(string param, int language=0)
```

The <code>getParam()</code> function returns the value of a parameter of an AMO. The string <code>param</code> is the name of the parameter. The AMO-command must be defined in the function <code>command</code>, which is described below. If the parameter does not exist <code>Error</code> is set to the appropriate error number.

If language equals 0 the value of the parameter is returned in the current ApplicationLanguage. If language equals MML\_german (1) or MML\_english (2) the value is translated to the desired language.

# Description of a parameter

```
string getParamDesc(string param, int language=0)
```

The getParamDesc() function returns a short help text of the parameter param.

If language equals 0 the description of the parameter is returned in the current ApplicationLanguage. If language equals MML\_german (1) or MML\_english (2) the description is translated to the desired language.

# Set the value of the parameter (by name)

```
int setParam(string param, string value, int language=0)
```

The setParam() function sets the value of a parameter of an AMO. The string param is the name of the parameter and value is the value of the parameter. The AMO-command must be defined in the function command, which is described below. If the functions fails (parameter not found in current parameter tree or MML syntax error) Error will be set to the appropriate error number. The result value is equal to Error (0 if ok). The function CheckParam is called internally.

If language equals 0 the value for the parameter is expected in the current Application—Language. If language equals MML\_german (1) or MML\_english (2) the value is expected in this language.

### Get an allowed value of a parameter

```
string getValue(string param, int index, int language=0)
```

The getValue() function returns an allowed value of the parameter param. The number of the values is index, which is 0-based. If there is no value with the number index the returned string is empty.

If language equals 0 the allowed value of the parameter is returned in the current ApplicationLanguage. If language equals MML\_german (1) or MML\_english (2) the allowed value is translated to the desired language.

### Description of an allowed value

```
string getValueDesc(string param, int index, int language=0)
```

The <code>getValueDesc()</code> function returns a short help text about an allowed value of the parameter <code>param</code>. The value is defined with the number <code>index</code>, which is 0-based.

Interfaces to the HiPath 4000 Expert AccessFrame components

If language equals 0 the value description of the parameter is returned in the current ApplicationLanguage. If language equals MML\_german (1) or MML\_english (2) the value description is translated to the desired language.

### Get the name of a parameter at a distinct position

```
string getParamName(int index)
```

This function retrieves the name of the parameter of the current command at position index, where index is 0-based.

# Get the index of a parameter by name

```
int getParamIndex(string name)
```

This function returns the index of parameter name within the current command. If the parameter is not found Error is set.

# Get the names of all parameters in the current command

```
string [] getParamNames()
```

This function retrieves the names of all parameters of the current command.

# **Get parameter properties**

```
int getParamProps(string param)
```

This function currently returns 0 for optional parameters 1 for required parameters (Bit0). The other bits of the return value are reserved for further use.

Get the value of the parameter (by index)

```
string getParamByIndex(int idx)
```

The getParam() function returns the value of a parameter of an AMO. The integer idx is the number of the parameter. The AMO-command must be defined in the function command, which is described above.

Set the value of the parameter (by index)

```
string setParamByIndex(int idx, string value)
```

The  $\mathtt{setParam}()$  function sets the value of a parameter of an AMO. The integer  $\mathtt{idx}$  is the number of the parameter and  $\mathtt{value}$  is the value of the parameter. The AMO-command must be defined in the function  $\mathtt{command}$ , which is described above. If the functions fails an error message will be returned.

Get the value of the parameter (by index)

```
string getParamByIndex(int idx)
```

The getParam() function returns the value of a parameter of an AMO. The integer idx is the number of the parameter. The AMO-command must be defined in the function command, which is described above.

Set the value of the parameter (by index)

```
string setParamByIndex(int idx, string value)
```

The setParam() function sets the value of a parameter of an AMO. The integer idx is the number of the parameter and value is the value of the parameter. The AMO-command must be defined in the function command, which is described above. If the functions fails an error message will be returned.

# Get complete validation of a parameter

```
string getParamValidation(string param, int language=0)
```

This function returns a string that can be passed to a object of class amoParam (defined in pdb.cbl). This object then contains all information about the Parameter (name, description, type, values, linkage). This object is designed to be used for the form control ctAmoParameter.

#### **Error** number

```
int Error
```

If the function Check() - which is described below - detects an error, the variable Error will be the error number.

Interfaces to the HiPath 4000 Expert AccessFrame components

(mode|=2: application handles wrong password, open returns immediately; mode|=4:

Error	Meaning
1	Reserved
2	Invalid character
3	End of input field
4	Start of input field
5	Input field full
6	Maximum number if individual values already marked
7	Too few individual values marked
8	Mandatory parameters need a value
9	Individual values may not contain blanks
10	Individual value contains odd number of quotation marks
11	First and last characters must be quotation marks
12	Individual value contains invalid length
13	Too few individual values
14	Too many individual values
15	Too many group parameters entered
16	Too few group parameters entered
17	Last parameter
18	First parameter
19	Invalid function key
20	Invalid individual value
21	Internal error
22	Output mask not found
23	Some values could not be assigned
24	Invalid value for branching parameters
25	Value too long
26	Too many parameter values
27	'Command' not set (verb/noun combination unknown)
28	No mask information in the PDB file
29	Output mask could not be analyzed
30	Input file could not be opened
31	Output file could not be opened

Error	Meaning
32	Invalid file position
33	Noun syntax incorrect
34	No MML command
35	PDB file not found
36	Verb not found in PDB file
37	Field not found in mask
38	End of AmoResult reached
40	Parameter not found
41	Index outside valid range
42	Parameter has no defined value list
43	Internal error during parameter check
44	Output mask not found
45	Hicom variant not found (check installation)
46	Syntactical error in GENDB format (faulty headers)
47	Value range links not permitted with 'And-And'
48	Command not terminated with semicolon
49	Link not permitted with 'And-And'
50	Parameter assigned several times
51	Combination of positions and keyword-oriented parameters not permitted
100	End of input file
500	Command buffer is empty
501	Command buffer emptied
502	Entry cannot be interpreted as MML command
503	An error occurred when sending back to HiPath 4000 Expert Access-Connect

deactivate autologon.)

With every call to a function or assignment to a property of the HiPath 4000 Expert Access-MML-Editor interface the properties <code>Error</code>, <code>ErrorParam</code>, <code>ErrorMsg</code> and <code>ErrorParamIdx</code> are set to the appropriate value.

# **Error message**

string ErrorMsg

Interfaces to the HiPath 4000 Expert AccessFrame components

If the check function - which is described below - detects an error, the error message is copied into the string ErrorMsg.

Possible error messages: see list above.

#### **Error location**

```
string ErrorParam
int ErrorParamIdx
string ErrorValue
```

The ErrorParam property holds the name of the parameter, which is causing an error, ErrorParamIdx it's position (as defined in the position oriented view). ErrorValue contains the value that caused the error, if available.

# Check all the parameters in current command

```
int Check()
```

The Check() function checks, if the value range, the syntax and declarations of all the parameters are correct. If an error is detected, the function returns the error number, otherwise it returns 0. The properties Error, ErrorParam and ErrorMsg are set to appropriate values.

# Check a distinct parameter

```
int CheckParam(string param)
```

The CheckParam() function checks, if the value range, the syntax and declarations of the parameter param are correct. If an error is detected, the function returns the error number, otherwise it returns 0. The Function also sets Error, ErrorMsg and ErrorParam to the accurate value.

### Check the existence of a parameter

```
int ExistsParam(string param)
```

This function returns 1 if the parameter param is defined in the current command, else it returns 0.

# Show dialog window for a validated parameter

```
int ShowParamDlg(string param)
```

The ShowParamDlg() function creates a dialog window with the parameter param. ComEdit's property command must have been set to an appropriate command beforehand. If you now make changes to the parameter the return value is 1 and the resulting command is returned in property command, otherwise the return value is 0 and property command remains unchanged.

### Show dialog window for a command

```
string ShowCommandDlg(string _command)
```

ShowCommandDlg opens a modal dialog window for the given parameter \_command. If the dialog window is closed with "Ok" ShowCommandDlg returns the user entered command and the property command is set. If the Dialog is closed with "Cancel" ShowCommandDlg returns \_command and the property command is unchanged.

### Transfer a command from another OLE server to HiPath 4000 Expert Access-MML-Editor

This method is designed for use by other OLE servers only, not for use within CBL applications!

ShowCommand passes the command MMLCommand to the current HiPath 4000 Expert Access-MML-Editor window. If there is no HiPath 4000 Expert Access-MML Editor window existing, a new one will be opened. The HiPath 4000 Expert Access-MML-Editor window will be brought to front. MMLVariant tells HiPath 4000 Expert Access-MML-Editor the Hicom variant, MML-Language (1=german, 2=english) the Hicom command language of the command to be displayed.

If ConnectionId is (used defined) non-negative and ConnectionName not empty a menu item "Send back to "plus ConnectionName will be available from the HiPath 4000 Expert Access-MML-Editor menu "Command". If this menu item (or Enter or F2 or Shift+F2) is executed HiPath 4000 Expert Access-MML-Editor will create a temporary OLE-connection to the OLE-object named ReplyObject (e.g. "ComWin.Control") and executes an OLE method named ReplyMethod (e.g. "SetCmd") passing ConnectionId as first, and the current MML command as second parameter. Then the OLE-connection will be released.

# Create a copy of a Comedit object

```
void CopyFrom(Comedit @src)
```

An exact copy of a Comedit object can be created via CopyFrom. All relevant information, such as HicomLanguage, ApplicationLanguage, command, HicomVariant, etc. is included by the source object src.

Interfaces to the HiPath 4000 Expert AccessFrame components

### Parsing AMO display masks

The following procedures/properties can be helpful for parsing AMO results that have been generated by the action ABFRAGEN/DISPLAY of an AMO. The usage of this functionality requires extensive knowledge of the internals of AMO programming and should hence be avoided if possible. **Try to use REGEN-results** instead!

First the "raw" AMO output is assigned to comedit. AmoResult.

Please note that comedit must know which AMO has sent the output. The following example shows how this can be achieved:

```
comedit.command="DISPLAY-DATE;";
comedit.AmoResult=comwin.Send(comedit.command);
```

Now an internal cursor needs to be positioned to the start position of an AMO output mask. This is done with SkipLinesUntil(string pattern):

```
comedit.SkipLinesUntil("+---");
```

Now the internal cursor points to the beginning of the line containing this pattern.

The position of the internal cursor can be read and set via AmoResultPos. The value always relates to the character position within the current AmoResult.

In the next step we can try to match the current output with an AMO output mask (as defined in the AMOs PD file) by calling <code>ScanMask(string maskname, int wrparaound=1, int skip=0)</code>. <code>ScanMask</code> returns the name of the output mask which could match the output or "" if there was no matching output mask found. The user can define a mask which should be used for the first try. If this mask did not match, <code>ScanMask</code> tries to match all output masks of the AMO. If the optional parameter <code>wrparaound</code> is set to <code>O</code>, <code>ScanMask</code> does not try all masks of the AMO, but only from the mask <code>maskname</code> to the end of the PD file. If <code>skip=1</code> was entered, <code>ScanMask</code> does not start at <code>maskname</code> but at the next

```
string mask=comedit.ScanMask("abfrdate");
```

The properties Error and ErrorMessage are set by ScanMask, SkipLinesUntil and FieldByName in case of an error.

If <code>comedit.ScanMask</code> returned a valid mask name, <code>FieldByName(string fieldname)</code> or <code>FieldByIndex(int index)</code> can be used to read the values of the variable fields in the current output mask. The int property <code>FieldCount</code> is set to the number of variable fields in the current output mask.

### Example:

```
string year=comedit.FieldByName("year");
string monat=comedit.FieldByName("month");
int fieldCnt=comedit.FieldCount;
```

The example trace.cbl gives another example where ScanMask is used to parse an AMO output. In this example it was necessary to use ScanMask because the values needed by the application were not available with REGEN commands.

Using the SkipLines(int cnt) function, a defined number (cnt) of lines can be skipped in the AmoResult.

Using the GetNextMask(string maskname) function, the name of the mask after the mask-name mask can be checked in the PD file.

As an alternative the function FindMask can be used to find a specific mask in AmoResult. FindMask tries to find the desired mask specified by the parameter maskname starting from the current position within AmoResult. All lines of AmoResult that do not match the desired mask are skipped. In case of an error (e.g. end of AMO result reached) the error variable Error is set and the error code will be returned. If mask is found the return value is 0. The current field values can be read by means of FieldByName.

## Example:

```
// Tell comedit to parse AMO BCSU
comedit.command="DISPLAY-BCSU:TAB,1,1;";
// Send the command to Hicom
string result=comwin.Send(comedit.HicomCommand);
// Give the result to Comedit
comedit.AmoResult=result;
// endless loop
for (;;)
  // search next occurrence of mask 'tabvar' in AmoResult
  int result=comedit.FindMask("tabvar");
  if (result==0) // if found
    // extract a field from the mask
    system.ConsolePrint("soll="+comedit.FieldByName("soll"));
  else
                 // some error occurred, e.g. end of amo result
    // leave the loop
   break;
}
```

Interfaces to the HiPath 4000 Expert AccessFrame components

The third alternative available is the function ParseAmoResult(). This function analyzes the complete current AmoResult and tries to cover as many AmoResult lines as possible with AMO masks. The result of analysis is returned as a return value in a suitable array.

As the algorithm is, understandably, not trivial and recursive, the AmoResult to be parsed should not be too large.

The elements of the result array are defined as follows:

```
class amoParseMaskRecord
{
  string maskname;
  string skipped;
  string [] fields;
}
```

The following example should clarify the function:

```
include "OpenConnDlg.cbl"
amoParseMaskRecord [] parseResult;
void PrintParseResult()
 int i;
 int f;
 comwinFrame.ConsolePrint("-----");
 for i=0 to parseResult.count-1 do
   with (parseResult[i])
     if (skipped!="")
     comwinFrame.ConsolePrintStyle("Skipped "+skipped,cpsWarning);
     if (maskname!="")
       comwinFrame.ConsolePrint("Found mask "+maskname);
       for f=0 to fields.count-1 do
         comwinFrame.ConsolePrint(" field "+fields[f].index
                          +" = '"+fields[f]+"'");
   }
 comwinFrame.ConsolePrint("-----");
```

```
void main()
{
    // tell comedit that we are using english AMOs within our Application comedit.ApplicationLanguage=MML_english;
    // tell comedit that we want to work with AMO VEGAS comedit.command="DISP-VEGAS;";
    // execute the AMO (HicomCommand returns the command
    // in the AMO language of the Hicom
    string result=comwin.Send(comedit.HicomCommand);
    // give comedit the AMO output comedit.AmoResult=result;

    parseResult=comedit.ParseAmoResult();

    PrintParseResult();

}
OpenConnDlg conn;
if (conn.show())
{
    main();
}
```

Interfaces to the HiPath 4000 Expert AccessFrame components

### **Additional functions**

The function **ShowHelp** causes a html file being displayed in the configured web browser (e.g. Netscape). The file name passed to ShowHelp is relative to the Service Handbook Base Url as defined for a specific Hicom Variant. This function can be used to display a specific file of the Service handbook (e.g. ad1sa.htm).

### File-related check function

The function CheckFileUntilError can be used to do a high performance check and transformation of MML batch files.

Parameter inFile specifies the name of the input file, parameter outFile specifies the name of the output file. It can be set to "" if the output of an check should not be stored.

StartPos defines the start position where CheckFileUntilError should start (absolute byte position from beginning of the file).

MaxLines specifies the maximum of number of lines to be processed until the function should end.

Action specifies how the input file should be processed. The value can be:

0 = quick-check; keep MML format.

1 = quick-check, transformation to position oriented MML format

2 = quick-check, transformation to keyword oriented MML format

8 = extensive check, keep MML format.

9 = extensive check, transformation to position oriented MML format

10 = extensive check, transformation to keyword oriented MML format

HicomLanguage and ApplicationLanguage must be set to the language of the MML batch file.

The following example shows how the function can be used to do syntax check of a MML batch file in steps of 1000 commands:

```
include "sysfunc.cbl"
include "comwin.cbl"
int result;
comedit.FilePos=0;
int lineno=0;
string line;
do
{
```

The property FilePos always points to the current read position within the input file.

The property ErrorLine points to the line number of the current processed command within the input file.


The property ErrorValue shows a parameter value which caused the error, if available.

The result value of CheckFileUntilError is the current Error number.

Interfaces to the HiPath 4000 Expert AccessFrame components

# 4.3.2 ComwinControl (ole\_class)

Interface to HiPath 4000 Expert Access - Connect.



```
ole_class ComwinControl: "ComWin.Control"
        Open (string host,
 int
              int mode=0,
              string FamosPassword="",
              int conn=0) ⇒
 string Logon(int deactAFR=0,
              int discVariant=0,
              string userid="",
              string password="",
              int OpenDirect ( ... )⇒
 int HTSOpen
              ( ... ) ⇒
 void Attach(string ConnId, int keepopen=0) ⇒
 void
        Show() ⇒
 void Hide() ⇒
 void BringToFront() ⇒
 int
       WindowState ⇒
 string [] Hosts() ⇒
 string [] Connections() ⇒
 string [] GetParameters(string host) ⇒
 string Logoff() ⇒
 string Send (string cmd) ⇒
 string SendEx(string cmd, int @retcode, string [] conditions,
              int count=1, int timeout=60000) ⇒
 string Break() ⇒
 string Print (string cmd)⇒
 string Message (string cmd) ⇒
 string Alert (string cmd) ⇒
 string NewLine () ⇒
 void Close () ⇒
 void CloseAll () ⇒
 int
       Status 🔿
                                               : "ConnStatus"
                                               : "ConnectionBusy"
 int
        _Busy ⇒
 string LastMessage ⇒
 int MacroRunning ⇒
```

```
Comedit mml

string HicomLanguage ⇒

string HicomVariant ⇒

string HostName ⇒

string HostDispName ⇒

string HostDesc ⇒

int OpenDialog(int mode=0) !!!

void StartBrowser(string url) !!!
```



Please note that the interface to CBL applications is slightly different to applications that connect immediate using the OLE interface. Please see module comwin.cbl to investigate the mapping between CBL- and OLE interface.

## Predefined object for this class

ComwinControl comwin;

## Open a connection to a host (via LAN connection directory)

```
int Open(string host, int mode=0, string FamosPassword="", int conn=0)
```

The Open function opens a connection to a host. The string host is the name of a connection profile defined in HiPath 4000 Expert Access-Connect.

The optional parameter mode can be used to determine the behavior on opening the connection:
description:
des

mode	Meaning
1	The connection window is hidden. It can be made visible via the HiPath 4000 Expert Access-Connect main window.
2	No password is requested.
4	The Autologon property from the connection profile, if present, is ignored.
8	No dialog windows are displayed on connection errors.
16	The connection to HiPath 4000 Expert Access-Connect is retained on releasing the OLE reference, i.e. the dialog window remains open.

immediately; mode = 4: deactivate autologon.)

The optional parameter FamosPassword is reserved for further use.

The connection type can be set via the optional parameter conn. If conn equals 0 the default connection as defined in the connection profile will be opened. If conn equals 1 or 2, a LAN connection or a serial connection will be opened.

Interfaces to the HiPath 4000 Expert AccessFrame components

(mode|=2: application handles wrong password, open returns immediately; mode|=4:

conn	Meaning
0	The connection type is set on the basis of the "Standard" connection in the definition of the connection profile.
1	Connection to FAMOS is set up via LAN/PPP.
2	Connection to RMX is set up via "serial".
8	Connection to Telnet interface.

deactivate autologon.)

If the functions fails it will return 0, otherwise 1.

## Open a connection to a host without entry in the connection directory

```
int OpenDirect (
                  int mode,
                  string HicomId,
                  string Name,
                  string Systemvariant,
                  int Language,
                  int Interface=0,
                  string Line="famos",
                  string Phonenumber="",
                  string Port="23",
                  string userid="",
                  string password="",
                  int AutoLogon=0,
                  string SrcName="FAMOS1",
                  string DstName="UFAMOS",
                  string PdbHost="",
                        ServerId=0,
                  string SessionToken="",
                  string TemplateProfile="")
```

Using OpenDirekt a connection can be opened without a connection profile having first been created in the connection directory. All connection-relevant data must be transferred as call arguments.

mode	See Open ⇒
HicomId	Random name for the connection
Name	Random name for the connection
Systemvariant	Hicom system variant (optional)
Language	Hicom AMO language (optional)

Interface	1	Connection via LAN	
	0x40	Connection to HiPath 4000 via LAN	
Line	famos	Connection to Famos	
	telnet	Connection to Telnet	
PhoneNumber	Phone n	umber or IP address, depending on the line type	
Port	102	For connections to Famos	
	23	For connections via Telnet	
UserId	User ID for registration		
Password	Password for registration		
AutoLogon	Perform automatic logon		
SrcName	TSAP-SRC for connections to FAMOS (see AMO CPTP)		
DstName	TSAP-D	TSAP-DST for connections to FAMOS (see AMO CPTP)	
PdbHost	Host address from which PDB files can be downloaded		
ServerId	ID of the ComWinAccessServer object in the case of connections to HiPath 4000 (interface=0x40)		
SessionToken	SessionToken for registration at HiPath 4000 (interface=0x40)		
TemplateProfile	Optional connection profile from the connection directory from which all non-specified arguments and other connection information should be transferred.		

# Open a connection to a host via a HTS 4.0/4.1, HTS 6 or HiPath Manager

int HTSOpen	(string	ServerAddress,
	string	ServerName,
	string	Region,
	string	DatabaseUser,
	string	DatabasePassword,
	string	Token,
	string	ServerPath,
	string	HicomId,
	string	Application,
	string	DSNHTSDB,
	string	DSNCorrDB,
	int	synchrone,
	string	ParameterString,
	string	HicomPassword,
	string	Version,

Interfaces to the HiPath 4000 Expert AccessFrame components

string SubDomain, string PdbHost)

Using this function an indirect connection can be set up to an application via a HTS server or HiPath Manager.

## Call parameter meaning:

ServerAddress	IP address of the HTS server/HiPath Manager			
ServerName	Name of the HTS server/HiPath Manager (for display only)			
Region	HTS server/HiPath Manager region			
DatabaseUser	User ID	for registration at database (HTS 4.0/4.1)		
DatabasePassword	Passwo	rd for registration at database (HTS 4.0/4.1)		
Token	For HTS	S 4.0/4.1: UDSC token, for HTS 6.0 SessionToken		
ServerPath	-			
HicomId		ID of Hicom to which the connection should be set up (database field chdmain.mnemonic)		
Application	-			
DSNHtsDb	Name of the ODBC DSN for the HTS DB (HTS 4.0/4.1)			
DSNCorrDb	Name of the ODBC DSN for the Corr DB (HTS 4.0/4.1)			
synchrone	If synchrone = 1, the function only returns after complete connection setup. Otherwise, connection setup is only started.			
ParameterString				
HicomPassword				
Version	V40	HTS 4.0		
	V41	HTS 4.1		
	V60	HTS 6.0/HiPath Manager		
SubDomain	-			
PdbHost	Address from which PDB files can be downloaded. The Server-Address can be entered here in the case of HTS 6.0/HiPath Manager.			

# "Attach" an application to an existing connection

void Attach(string ConnId, int keepopen=0)

Using this function a CBL application can be "attached" to an already open dialog connection and then send commands to this connection with Send.

A valid connection ID must be transferred as the ConnId. This is transferred as command line argument Args ["Id"] from a connection window by HiPath 4000 Expert Access-Connect when starting up a CBL application via "Start CBL" or via "CBL Bookmark" (see "Command line parameters: Args" on page 71).

Alternatively, the connection currently open can be checked via Connections() ⇒.

If keepopen!=0 is set, the connection remains open despite the fact that Close was called.

### Close the connection to a host

```
void Close()
```

The Close() function closes the current connection to a host.

### Close all connections

```
void CloseAll()
```

The CloseAll() function closes all the open connections.

### Status of the connection

int Status

int \_Busy

int MacroRunning

The Status property returns the current connection state.

Bit	connection type	description
Bit0 (LSB) (value 1)	LAN	partner exists
	Serial	COM port exists physically and is not locked by another application
Bit1 "opened" (value 2)	LAN	partner exists
	Serial	"there is something outside", probably a hicom (not sure)
Bit2 "connected" (value 4)	LAN	partner exists
	Serial	if there were digits stored in the connection profile, the modem has connected
Bit3 "logged on" (value 8)	LAN	logon successful
	Serial	

Interfaces to the HiPath 4000 Expert AccessFrame components

Bit	connection type	description
Bit4		the connection is not being used by another CBL application.
"free"		
(value 16)		

Please note that only bit 3 is unset if the connection state gets worse (e.g. due to a connection loss). Only Hangup or Logoff can be recognized by HiPath 4000 Expert Access-Connect.

The property \_Busy is 1 if the HiPath 4000 Expert Access-Connect is not yet ready to edit a new AMO command with Send, e.g. because a command entered by the user is still being edited.

The property MacroRunning is 1 if a macro is being executed on the current connection. Remark: A macro can also be started via comwin.Send("MACRO datei.cmd").

## Last error message in a connection

```
string LastMessage
```

If error messages were output during connection setup to the system, the last error message is saved in the property LastMessage.

# Log on to a host

The function Logon enables you to send the logon command to the host to which you are connected.

If the parameter deactAFR is non-zero, AMO AFR is regenerated, and the ACTIVATE command is stored. AFR is then deactivated.

If parameter discoverVariant is non-zero the Hicom-Variant and Hicom-Language is determined and stored into the property mml.HicomVariant and mml.HicomLanguage and into the properties HicomVariant and HicomLanguage.

if parameter userid (for "New password concept" since Hicom EV2.0 WP3) and password is passed to Logon, HiPath 4000 Expert Access-Connect uses these parameters for the logon instead of using the password/userid from the connection profile or prompting with a userid/password Dialog

If the functions fails an error message will be returned:

```
"!WR_PWD" = Wrong Hicom password,
```

### Log off from the host

```
string Logoff()
```

The Logoff () function enables you to logoff from the server, to which you are connected.

If AFR was deactivated in the corresponding Logon command the stored ACTIVATE-AFR commands will be sent in advance to the Logoff-sequence.

### Send a command to the host

```
string Send(string cmd)
```

The Send() function sends a command to the Hicom. The result of the Send function is the "piece of protocol" which is the result of the command execution until the host expects user input again (e.g. waiting for next command or prompting a parameter value).

## Send a command asynchronously to the host (without waiting for termination)

The SendEx() function sends a command to the Hicom.

The result of the Send function is the "piece of protocol"; this is the result of the command execution until the point at which count conditions from the conditions connection array are fulfilled or until the timeout (milliseconds) occurred.

The number is 0 at retcode in the event of the timeout, otherwise the number of applicable conditions is transferred.

The conditions are to be formulated as "regular expressions" (see Unix command egrep).

### Example:

<sup>&</sup>quot;! WR\_VAR" = Hicom release could not be retrieved or is not known to HiPath 4000 Expert Access-MML-Editor,

<sup>&</sup>quot;!NO\_HD" = Hicom hard disk is switched off and cannot be activated.

Interfaces to the HiPath 4000 Expert AccessFrame components

### Print a string in the protocol window

```
string Print(string cmd)
```

The Print() function prints the string cmd in the protocol window.

### Contents of the status line

```
string Message(string cmd)
```

The Message() function defines a text (cmd) for the status line of a window.

## New window for a message

```
string Alert(string cmd)
```

The Alert() function opens a message dialog with an (important) message which is defined in the string cmd.

### Append newline in protocol window

```
string NewLine()
```

With the NewLine() function a new-line is appended to the log file.

### Set interrupt signal to AMO/MMI

```
string Break()
```

Break sends an interrupt signal to Hicom to stop AMO execution or parameter prompting.

### Get Hicom variant / version of current connection

```
string HicomVariant string HicomLangauge
```

Using HicomVariant/HicomLanguage the HicomVariant and HicomLanguage can be retrieved for the current host. The properties are set if Logon was called with discoverVariant=1 (from an CBL application only). If the logon was done without discovering the Hicom version the value is taken from the last time it was set. The value is stored in the registry database at the hosts data. It is accessible via the connection profile directory of HiPath 4000 Expert Access-Connect too.

## Get host name and description of current connection

```
string HostName
string HostDesc
string HostDispName
```

HostName retrieves the host name of the current connection. HostDesc retrieves the description of the current connection, HostDispName retrieves the name of the connection as it appears in the title line (e.g. 8073@HTS1).

### Change dialog window display

```
void Show()
void Hide()
void BringToFront()
int WindowState
```

A hidden dialog window can be displayed with Show.

The current dialog window can be hidden with Hide.

The current window can be displayed on top with BringToFront. The Windows 2000 operating system does not support this function, however.

If WindowState is active, the current window is minimized, otherwise it is displayed as normal.

### Administer connections and connection data

```
string [] Hosts()
string [] Connections()
string [] GetParameters(string host)
```

The Hosts function provides a list of all connection profiles in the form

```
name Description name Description
```

The Connections function supplies a list of connections currently open in the form

Interfaces to the HiPath 4000 Expert AccessFrame components

```
name|connectionId|inUseFlag
name|connectionId|inUseFlag
```

Here, name is the connection name, connectionId is a value which can be used for the Attach function. The inUseFlag specifies whether an application is already connected to this connection.

Using the GetParameters function, specific information on the connection profile whose name is specified in host is read out. The result elements have the following meaning:

index	Meaning	
0	Famos password (new password concept since EV2.0)	
1	Reserved	
2	User ID (new password concept since EV2.0)	
3	Reserved	
4	Password (old password concept)	
5	Reserved	
6	Defined connections: sum of 1=LAN/FAMOS, 2=V.24 serial, 8=Telnet	
7	Default connection (1=LAN, 2=V24, 8=Telnet)	

# **4.3.3** (mode|=2: application handles wrong password, open returns immediately; mode|=4: deactivate autologon.)**ComwinFrame (ole\_class)**

Interface to HiPath 4000 Expert Access - Frame application.

HiPath 4000 Expert Access-Frame implements the architectural frame over HiPath 4000 Expert Access. It cares about the http server, the console window, management of execution of CBL applications by OLE requests and will be responsible for communication between CBL applications.



```
ole_class ComwinFrame : "ComWin.Frame"
{
    void ConsoleShow()
    void ConsoleResize(int top,int left, int width, int height)
    void ConsolePrint(string txt)
    void ConsolePrintStyle(string txt, int style)
    void ConsoleClear()
    void ConsoleHide()
    // mode=1 increment progress bar
    // mode=0 deactivate progress bar
    void ConsoleProgress(int mode)

    void StartApplication(string filename, string args)
    void ShowHelp(...) 
}
```



Please note that the interface to CBL applications is slightly different to applications that connect immediate using the OLE interface. Please see module comwin.cbl to investigate the mapping between CBL- and OLE interface.

# Predefined object for this class

```
ComwinFrame comwinFrame;

// constants for style of ConsolePrintStyle
const int cpsNormal =0; // Font Arial
const int cpsFixed =1; // Font Courier
```

Interfaces to the HiPath 4000 Expert AccessFrame components

```
const int cpsWarning=2; // Color blue
const int cpsError =4; // Color red
```

### Show a console window

```
void ConsoleShow()
```

ConsoleShow opens the Interpreters Console Window. Its Size, Position and contents can be controlled with the following functions:

# Set position and size of the console window

```
void ConsoleResize(int top,int left, int width, int height)
```

ConsoleResize sets the absolute position and size in pixels of the console window.

### Print a text to the console window

```
void ConsolePrint(string txt)
void ConsolePrintStyle(string txt, int style)
```

ConsolePrint/ConsolePrintStyle prints a text followed by a newline to the console window. If txt contains linefeeds the txt is split into multiple lines.

style defines font and color as shown in following example:

```
ConsolePrintStyle("This is \n an Error",cpsError);
ConsolePrintStyle("H01: MESSAGE FROM SWITCH",cpsFixed+cpsWarning);
```

### Clear the console window

```
void ConsoleClear()
```

### Hide the console window

```
void ConsoleHide()
```

### Show/hide a progress bar in the control window

```
void ConsoleProgress(int mode)
```

ConsoleProgress(1) shows a progress bar in the status line of the console window. Each call of this function shifts the progress bar some pixels.

ConsoleProgress(0) hides the progress bar.

### Start a CBL application

```
void StartApplication(string filename, string args)
```

This function causes a new instance of the CBL Interpreter to be executed. The filename of the CBL program is passed in parameter filename. Arguments can be passed with parameter args.

The format for args is "par1=val1 par2=val2 par3=val3". These values will be available stored into the Args array for the new CBL application (see "Command line parameters: Args" on page 71).

Since the new application is started in a separate process StartApplication returns immediately.

## Show help file

This function shows the help file.

Argument	Meaning
basedir	Base path for help files.
project	The .chm file (compiled HTML help project) or "", if .htm files are to be directly displayed.
file	The name of the HTML file included in the project or to be directly displayed.
topic	The name of an internal cross-reference destination within the HTML file ( <a name=""></a> ) or "", if the HTML file should be displayed from the start.
window	Optional; a type of window defined, where applicable, in the help project.

If Hypertext-Help-ActiveX is installed (under Win2000/XP) in the current environment, the hypertext help module is called with the following URL:

```
file:/<basedir>/<language>/<project>::<file>#<topic>
```

In addition, the window type defined in the help project (where applicable) is used for branching. <a href="classification-needed">clanguage</a> is the current language ID, see "CBL - National Language Support" on page 174.

Interfaces to the HiPath 4000 Expert AccessFrame components

If a project file is not specified or HyperHelp is not installed, then the following URL is transferred to the current HTML standard browser:

file:/<basedir>/<language>/<file>#<topic>

# 4.3.4 ComwinCBL (ole\_class)

Interface to HiPath 4000 Expert Access - CBL Interpreter



An architectural change caused all OLE requests from a CBL Interpreter to itself to be either implemented in Interpreter internal functions or be redirected to HiPath 4000 Expert Access-Frame. HiPath 4000 Expert Access-CBL is just listed here because the chosen implementation is backward-compatible. Consequently, you may find references to HiPath 4000 Expert Access-CBL in existing applications, but they are redirected to ComwinFrame (see CBL include file comwin.cbl).

All methods of the predefined object system are redirected to comwinFrame.

Interfaces to the HiPath 4000 Expert AccessFrame components

# 4.3.5 ComWinFT (ole\_class)

Interface to HiPath 4000 Expert Access - File Transfer.

Please make sure that you also reference the online help for specific details on the features and configuration of the HiPath 4000 Expert Access file transfer.

This object enables the exchange of files between the CBL application and Hicom or other servers using various protocols.



```
enum { FTProto_Local=0,
       FTProto RmxScsi=1,
       FTProto_FTP=3,
       FTProto_FJAM=4,
       FTProto HTS=5,
       FTProto_DispaList=6,
       FTProto_CORBA=10,
       FTProto_TFTP };
     { RmxFileType_ByteFile=0,
enum
        RmxFileType_Fix=1,
        RmxFileType_Var=2,
        RmxFileType_Dir=3,
        RmxFileType_ByteFileOMF=4 };
        FT Success=0,
enum {
        FT_UserInterrupt=1,
        FT Aborted=2,
        FT_LocalFile=3,
        FT_RemoteFile=4,
        FT_ConversionError=5,
        FT_WrongLogon=6,
        FT_TransmissionError=7,
        FT_NotConnected=8,
        FT Undefined=9,
        FT_NotSupported=10,
        FT_TransferAborted=11,
        FT_HtsError=12 };
class RmxFileInfo
{
        int FileSize;
```

```
int FileType;
       int RecordLength;
       string Access;
       string Date;
       string APS;
};
ole_class ComWinFT : "ComWin.FileTransfer"
 int SetProtocol(int Proto) ⇒
 string [] GetHosts() ⇒
 int Connect(string Host="", string user="", string pass="",
            string par1="", string par2="",
            string ftuser="", string ftpass="", int batch=0,
            string res1="", string res2="", string res3="",
            string res4="") ⇒
 int Disconnect() ⇒
 string [] GetDir (string Dir) ⇒
 int Get(string Local, string Remote,
         int ConvertSAM=0, int Batch=0, int maxlen=0) ⇒
 int Put(string Local, string Remote, ConvertSAM=0, int Batch=0) ⇒
 RmxFileInfo GetInfo(string Remote) ⇒
 int Delete (string Remote) ⇒
 int Rename (string oldname, string newname) ⇒
 int
        Connected ⇒
       Visible ⇒
 int
 int
       CloseAfterAutomation ⇒
        DialogMode ⇒
 string LocalFile ⇒
 string RemoteFile ⇒
        ShowBrowser() ⇒
 void
 int
        int
        FileSplit(string FileName) ⇒
}
```

# **Define transfer protocol**

```
int SetProtocol(int Proto)
```

SetProtocol is used to define the desired transfer protocol.

Interfaces to the HiPath 4000 Expert AccessFrame components

The following transfer protocols may be selected: FTProto\_RmxScsi, FTProto\_FTP, FTProto\_FJAM and FTProto\_DispaList. Note that the partners for the file transfer depend on which transfer protocol is used. For example, the protocol RmxScsi requires the PCHI tool to be installed and a SCSI cable to be connected, since the file transfer commands rmxcopy and rmxdir are combined here. The FTP protocol can be used to establish connections with standard FTP servers (e.g. Unix servers). The FJAM protocol can be used for LAN connections to the Hicom file transfer, which in turn requires the Hicom to be properly configured with the AMOs CPTP, FTCSM and FTRNS. The DispaList protocol can be used for all connections to Hicom systems (serial direct, modem and LAN), since the file transfer is implemented via the AMOs LIST and DISPA here.

### Get list of configured communication partners

```
string [] GetHosts()
```

GetHosts can be used to determine which communication partners are available for the currently set protocol. This is irrelevant for the FTP protocol; for FJAM and DispaList, the appropriate partners should be listed in the connection folder of HiPath 4000 Expert Access-Connect.

# Set up a connection

Connect sets up the initial connection to the communication partner. Depending on which protocol is set, appropriate arguments must be provided to establish the connection.

Host specifies the name of the respective partner.

The following overview shows the meaning of the parameters for the various protocols:

The return value indicates whether the connection was set up successfully. The return value for a successful setup is 0.

The following return values are defined:

Value	Meaning
1	Aborted by user
2	Operation aborted
3	Error on reading or creating local file
4	Error on reading or creating remote file
5	SAM - ASCII text conversion error
6	Invalid logon
7	Transmission error
8	Not connected
9	Undefined error
10	Operation not supported
11	Transmission interrupted
12	Error at HTS server

### Disconnect

```
int Disconnect()
```

Disconnect clears the current connection. The return values are the same as those indicated in the table above.

### **Get contents of remote directory**

```
string [] GetDir (string Dir)
```

Interfaces to the HiPath 4000 Expert AccessFrame components

The function GetDir returns the contents of the remote directory Dir.

### Retrieve a file

Get can be used to initiate the transfer of a remote file Remote to the local file Local from a remote system.

ConvertSAM specifies whether the remote file is an RMX-SAM file and is to be converted to an ASCII text file.

Batch! = 0 can be used to specify whether the transfer is to occur asynchronously (i.e. in the background) or whether the system should wait for the result of the transfer.

maxlen can be additionally used to define if the entire file (maxlen=0) is to be transferred or if only a maximum of maxlen characters should be received.

### Send a file

```
int Put(string Local, string Remote, ConvertSAM=0, int Batch=0)
```

Put can be used to transfer the local file Local to the remote file Remote on a remote host.

ConvertSAM specifies whether the remote file is an RMX-SAM file, i.e., whether the local AS-CII text file is to be converted during the file transfer to that format.

Batch! = 0 and be used to specify whether the transfer is to occur asynchronously (i.e. in the background) or whether the system should wait for the result of the transfer.

### Get file information

```
RmxFileInfo GetInfo(string Remote)
```

GetInfo returns information on the file Remote on the remote host, provided this function is supported by the selected transfer protocol.

The structure element FileSize contains the size of the file in bytes; FileType contains the type of file. A distinction is made between the following file types:

```
RmxFileType ByteFile=0 (binary file).
```

RmxFileType\_Fix=1 (SAM file with fixed record length),

RmxFileType Var=2 (SAM file with variable record length),

RmxFileType\_Dir=3 (directory),

RmxFileType\_ByteFileOMF=4 (binary file in OMF format).

RecordLengh contains the record length of SAM files with a fixed record length.

Access contains the access rights, depending on the transfer protocol and type of remote host.

Date contains the file date.

For binary files in OMF format, APS contains the designation of the APS with which the file was produced.

# Other attributes and functions

<pre>int Delete   (string Remote)</pre>	Deletes a file on the remote system.
<pre>int Rename (string oldname, string newname)</pre>	Renames a file on the remote system.
int Connected	Specifies whether or not a connection to the remote system exists.
int Visible	Visible can be used to determine or set if the application is to be visible or not.
int CloseAfterAutomation	CloseAfterAutomation defines whether or not the application is to be terminated after releasing the OLE reference. Default value is 1 (true).
int DialogMode	Can be set to 0 to prevent the dialog window from appearing in the event of a fault. Default value is 1 (true).
string LocalFile	Contains the local file name of the last file transfer.
string RemoteFile	Contains the file name on the remote system of the last file transfer.
void ShowBrowser()	Opens the "remote browser" for the remote system.
int FileSplit (string FileName)	A file on the local file system is split into 1MB blocks. The resulting files are named in the same way as the PCHI tool, i.e. <filena-me>.1.part, <filename>.2.part, etc.</filename></filena-me>
<pre>int FileUnsplit (string FileName)</pre>	A file that was split with FileSplit is merged back into a single file.

Interfaces to the HiPath 4000 Expert AccessFrame components

# 4.3.6 ComWinPPP (ole\_class)

This OLE class implements the OLE interface to the HiPath 4000 Expert Access-PPP-Manager. This OLE interface is primarily used by HiPath 4000 Expert Access-Connect to set up connections for which a PPP profile is entered in the LAN data. It can also be used directly by applications.

```
ole_class ComWinPPP : "ComWin.PPPMan"
 string Id
 int
       Visible
 string Profile
 string PhoneNumber
 string ServerIp
 string Device
 string Script
 string User
 string Password
 string Status
 int
       Connected
 string DeviceList
 int
       DestType
        RemoveProfile(string id, string profile="")
 int
 void InitProfile(int type)
 int
        CreateProfile(string srcid, string dstid, string
srcprofile="", string dstprofile="")
                     : "CreateProfile"
 int
        DialogMode
 int
        RasConnError
 int
        RasConnState
 string RasStatusString
```

string Id	Name of the HiPath 4000 Expert Access-Connect connection profile
int Visible	Specifies whether or not the PPP Manager is visible
string Profile	Name of the RAS profile for the current connection profile (the connection profile is prefixed by PPP_)
string PhoneNumber	Phone number of the RAS server

	· · · · · · · · · · · · · · · · · · ·
string ServerIp	IP address of the RAS server
string Device	Name of the modem to be used for setting up the connection
string Script	Path of the logon script assigned to the RAS profile
string User	CHAP name for RAS logon
string Password	CHAP secret for RAS logon
string Status	Specifies the current logon status
int Connected	Specifies whether or not a connection is set up to the RAS server. If Connected is set from 0 to 1, the connection setup attempt is started
int DestType	Specifies the type of the connection profile:  0 = connections to UW7 via V.24 for Hicom 300 <= EV3.1  1 = connections via WAML via ISDN  2 = connections to UW7 via V.24 for HiPath 4000 UV1.0 or later  3 = other connection type
int DialogMode	Specifies whether or not message dialogs are to be displayed in the event of faults. Default value 1.
int RasConnError	Error number of the last RAS connection error
int RasConnState	Number of the current RAS connection status
string RasStatusString	Textual value of the current RAS connection status

# 4.3.7 ComWinAccessServer (ole\_class)

The OLE class ComWinAccessServer implements the interface to the ComWinDbAccessClient.exe program. This program represents the interface to the server process ComWinAccess. This process runs in the Unix part of the HiPath 4000 ADP and under HiPath Manager and HTS V6.0. ComWinAccess server and client communicate via CORBA.

See also example "Database query via ComWinAccess" on page 142.

```
ole class ComWinAccessServer: "ComWinDbAccess.Server"
     string Open(string host, string port="7777")
     int
                    This function sets up a connection to the server process. An error
string Open
                    message is output in the event of a fault. The host parameter is then
(string host,
                    given the host name or the IP address of the server.
string
port="7777")
int
                    In the case of successful connection setup, Id contains a server ID
        Ιd
                    which is needed for the following objects of the types ComWinAc-
                    cessSession, ComWinAccessFileman, ComWinAccessDatabase
                    and ComWinAccessQuery.
```

# 4.3.8 ComWinAccessSession (ole\_class)

The OLE class ComWinAccessSession implements the interface to a session to a ComWinAccessServer, see "ComWinAccessServer (ole\_class)" on page 138.

This object administers all session-related data.

See also example "Database query via ComWinAccess" on page 142

int Id	The Id transferred here should be used for the objects ComWinAccess-Fileman, and ComWinAccessDatabase for their property Session to link these objects to this session.
int Server	After creating the object, the Id of a ComWinAccessServer object should be sent.
<pre>int Authentica- te(string Sessi- onToken)</pre>	The CBL applications uses this function for authentication at the Com-WinAccess server. A valid SessionToken or a string should be sent in the form " <user>/*::*/<password>", for example, "engr/*::*/xxx.xxx". If the SessionToken or the UserId password combination is invalid, then a logon dialog appears (unless DialogMode=0). The system returns 0 in the case of correct functionality, otherwise an error code.</password></user>
int GetFamosUser- Pass (string @ user, string @ pass)	In the case of successful registration, this function can be used to call up a valid Famos user ID and the associated Famos password for the current session.
string CreateSessi- onToken()	Additional SessionTokens can be generated with this function, as every SessionToken is invalid when used first.
string GetInfo(string item)	This function can be used to call up server- or session-related data from the server.  The following items are defined:  "user_supersess" = user name of the superordinate session  "user" = user name for session registration  "password" = password for session registration  "os_user" = user name on the operating system level  "featureList" = the user-assigned features  "HomeDir" = home directory of the user on the server  "ServerType" = server type ("RM" for RM, "UW" for UnixWare)  "ServerVersion" = internal server version
int Print- Log()	This function can be used to make entries in the SessionLog. At present, only 0 is implemented as $type$ . $p1$ should be the name of the PBX, with which the action is performed, $p2$ is a short message (30 characters), $p3$ is a "long" message (255 characters).

# 4.3.9 ComWinAccessFileman (ole\_class)

The OLE class ComWinAccessFileman implements the interface to the file system of the Com-WinAccess server, see "ComWinAccessServer (ole\_class)" on page 138.

Interfaces to the HiPath 4000 Expert AccessFrame components

This description is incomplete as it should only be used via HiPath 4000 Expert Access-File Transfer in FT\_CORBA mode, see "ComWinFT (ole\_class)" on page 130.

```
ole_class ComWinAccessFileman : "ComWinDbAccess.Fileman"
{
  int Server
  int Session
  int GetFile(string local, string remote)
}
```

int Server	The ID of a ComWinAccessServer object should be transferred here after object creation.
int Session	The ID of a ComWinAccessSession object should be transferred here after object creation.
<pre>int GetFile (string local, string remote)</pre>	Performs file transfer from the ComWinAccess server to the local file system. The return value corresponds to the HiPath 4000 Expert Access-File Transfer error code.

# 4.3.10 ComWinAccessDatabase (ole\_class)

The OLE class ComWinAccessDatabase implements the interface to a database on the Com-WinAccess server, see "ComWinAccessServer (ole\_class)" on page 138.

See also example "Database query via ComWinAccess" on page 142.

```
ole_class ComWinAccessDatabase : "ComWinDbAccess.Database"
{
  int Server
  int Session
  int Id
  int OpenDatabase(string dsn, string user, string pass)
  void CloseDatabase()
  string GetErrorMsg()
}
```

int Server	The Id of a ComWinAccessServer object should be transferred here after object creation.
int Session	The Id of a ComWinAccessSession object should be transferred here after object creation.
int Id	The Id read out here can be transferred in the Database property for one or more ComWinAccessQuery objects in order to link the SQL prompt with the database.

<pre>int OpenDatabase (string dsn,)</pre>	The database whose name is specified via dsn is opened with Open-Database.  The return value is 1 if the database could be opened, otherwise it is 0 or negative, if no valid session or no database processing authorization is available.
void CloseDatabase()	This closes the database.
string GetErrorMsg()	If an error occurs, an associated error message can be queried with this function.

# 4.3.11 ComWinAccessQuery (ole\_class)

The OLE class ComWinAccessQuery implements the interface to a database query on the ComWinAccess server.

```
see "ComWinAccessDatabase (ole_class)" on page 140
```

see "ComWinAccessServer (ole\_class)" on page 138


```
ole_class ComWinAccessQuery : "ComWinDbAccess.Query"
{
  int Server
  int Database
  string ExecSql(string sql)
  string SetParam(int param, int sqltype, string val)
  string GetFirst()
  string GetNext()
  string GetErrorMsg()
}
```

int Server	The ID of a ComWinAccessServer object should be transferred here after object creation.
int Database	The ID of a ComWinAccessDatabase object should be transferred here after object creation. The SQL statement is performed for the database opened there.
String ExecSql (string sql)	Using this, an SQL query or an SQL command can be sent to the currently connected database. Error messages or advisories are returned in the return value.
string SetParam (int param, int sqltype, string val)	Mit dieser Funktion können SQL-Parameter eingefügt werden, die im SQL-Statement noch mit ? vorbelegt waren.

Interfaces to the HiPath 4000 Expert AccessFrame components

string GetFirst()	This function supplies the first hit for an SQL query in CBL streaming format or a blank character string if the hit list is blank. See also the following example.
string GetNext()	This function supplies the next hit or a blank character string if there are no more hits.
string GetErrorMsg()	Supplies the last error message or advisory for the current SQL query.

# **Example: Database query via ComWinAccess**



```
ComWinAccessServer server;
ComWinAccessSession session;
ComWinAccessDatabase database;
ComWinAccessQuery
                     query;
server.Open("139.21.131.146");
session.Server=server.Id;
int authresult=session.Authenticate("dummy/*::*/x");
string usr=session.GetInfo("user");
string features=session.GetInfo("featureList");
database.Server=server.Id;
database.Session=session.Id;
int openresult=database.OpenDatabase("cdb", "u_dbuser", "as_unity");
string error;
error=database.GetErrorMsg();
query.Server=server.Id;
query.Database=database.Id;
```

Interfaces to the HiPath 4000 Expert AccessFrame components

# 4.3.12 ComWinFM (ole\_class)

The OLE class ComWinFM implements the OLE interface to the AfrSvr.exe program. This is an application which is capable of receiving Hicom/HiPath error messages sent from the PBX via LAN. The PBX should be configured accordingly. This is done via the AMOs CPTP, AFR, SI-GNL, and FBTID.

With the help of the ComWinFM class, a CBL application can be written and used to analyze and process error messages. An appropriate sample application can be found at the end of this section.

void Init()	This method should be called up after creating the object to initialize the object.
int Visible	Controls or specifies whether the application should run in the fore- ground (visible) or in the background.
void WaitForMes- sages(int sec)	This function is called up to enable the CBL Interpreter to receive events from an OLE server for a specific period of time (sec).  See <a href="mailto:int.waituntilReleaseWait">int.waituntilReleaseWait</a> (int @ context, int timeout)
OnDataAvailable	This is not a function, but rather an event handling routine which is called up when error messages are received.  To run a separate code for event handling, a separate class in which the OnDataAvailable function is declared must be derived from the ComWinFM basic class. See also the following example.

# **Example: Processing error messages further**

The following program receives Hicom error messages for a minute and outputs them via the HiPath 4000 Expert Access Frame console window.

```
class myFM extends ComWinFM
{
  void OnDataAvailable(string sender, string fbtid, string msg)
  {
    comwinFrame.ConsolePrint(msg);
}
```

Interfaces to the HiPath 4000 Expert AccessFrame components

```
}
myFM fm;
fm.Init();
fm.WaitForMessages(60);
```

# 4.4 Designing forms

Before you begin reading this section, please note that there is also a "GuiBuilder" tool supplied with HiPath 4000 Expert Access which - though still in a prototype or Beta version - can be used to graphically edit forms using Drag&Drop techniques. For more detailed information, please start the HiPath 4000 Expert Access-GuiBuilder and refer to the online help.

The include file **form.cbl** contains class definitions which are necessary for designing a GUI for a CBL application. Each cblForm object may act as a so called main form (representing the whole window) or as a embedded subform (representing e.g. a panel).

Each window consists of a main form which may contain several controls, a menu bar and a speed bar.

There are two groups of controls: Simple controls (label, edit, combo, memo, listbox, radiogroup, checkbox, button, bitmap) and compound controls (panel, pages, grid).

Compound controls are used to group subforms and to get a visual effect (e.g tab sheets). Of course, a subform cannot have a menu bar or speed bar of its own. These attributes are ignored for subforms.

To build a form, you create an object of class cblFormControl for each of your controls and an object of class cblForm for each of your main- and subforms. Then, you assign references to the contained controls objects to the controls[] attribute of the appropriate form object and you assign references to the contained subforms to the panels[] attribute of the appropriate compound control object.

It is highly recommended to assign these references at runtime by means of a init() method in your class and not through static initialization!

## **Advanced topics**

- chapter 4.4.1, "Form Layout"
- > chapter 4.4.2, "The form class cblForm"
- > chapter 4.4.3, "Form controls"
- > chapter 4.4.4, "Definition of menus"
- > chapter 4.4.5, "Form examples"
- > chapter 4.4.6, "Modal dialog example"

# 4.4.1 Form Layout

Currently there are two ways to define the layout of forms: Pixel based layout and cell layout. Here only cell layout is explained, as pixel based layout is considered obsolete.

In defining a layout, you have to specify size (height and width), position (top, left, col, row) and alignment of each control (including compound controls) and form.

You start with simple controls and group them into compound controls until you have defined the complete form.

#### 4.4.1.1 Size of Controls

For simple controls you usually don't specify a size. This causes the CBL-Interpreter to automatically compute the size needed. If you do specify size and/or position you have to specify it in pixels.

If you don't specify the size of a simple control, the CBL-Interpreter determines the size. For text strings (e.g. label captions) the font size, screen resolution and the actual text is considered automatically. This is especially handy, if you think about internationalization of your text strings! Additionally a standard function TextWidth(string in) is provided, which computes the length of its string parameter in pixels. Thus, you can use a call TextWidth("9999") to define the width of e.g. an edit field which is wide enough to contain four digits.

#### 4.4.1.2 Position of controls

Each (sub-)form consists of an invisible two-dimensional array of cells. Each contained control is placed into one of those invisible cells.

You simply specify the row and column of each contained control in the row and col attribute. Additionally you can specify either an pixel offset within the cell by using the top and left attribute or an alignment of the control within the cell.

The CBL-Interpreter then automatically determines the maximum width and height of all controls in a row resp. column and computes the necessary height and width of the rows and columns and thereby the size of the complete (sub-)form. The algorithm does not make a difference between visible and invisible controls. Thus, the layout does not change if you make controls visible or invisible at runtime. Another effect is, that you can use invisible controls to reserve space on your form and thereby better control the layout of the form.

# 4.4.1.3 Connecting controls with program variables

tbd.

object of class cblForm is usually a member of the corresponding data object;

## 4.4.2 The form class cblForm

```
class cblForm
 cblLayout
                  layout;
 string
                  caption;
 cblMenu
                  mainmenu;
 cblMenuItem
                  speedbar[];
 string
                  status;
 int
                  state;
                  @controls[];
 cblFormControl
 int
                  enabled=1;
 int
                  visible=1;
                  showModified=1;
 int
 int
                  isMainForm=0;
 string
                  icon;
                  helpContext=0;
 int
 int
                  @breakFlag;
 void
                  @onEnter;
 void
                  @onClose;
 void
                  @onHelp;
 void
                  Show()
 int
                  ShowModal()
 void
                  Update(int relayout=0)
 void
                  UpdateControl(cblFormControl @ctrl,
                                int recursive=0)
 int
                  CheckComplete()
 int
                  CheckControl(cblSyFormControl @ctrl)
 void
                  ResetModified()
 void
                  ResetModifiedControl(cblSyFormControl @ctrl)
 void
                  Get()
 void
                   GetControl(cblFormControl @ctrl,
                             int recursive=0)
 void
                  Close()
 void
                  FocusControl(cblFormControl @ctrl)
 void
                  SetStatus(string text)
 void
                  SetWindowState(int ws)
 void
                  StoreSizePos()
 void
                  RetrieveSizePos()
```

layout	defines position and size of the form.	
caption	defines the caption (title) of the form.	
mainmenu	assigns a menu to the form.	
speedbar	allows the definition of a row of speed-buttons (with bitmaps).	
controls	is the list of form controls as defined later.	
status	is the content of the status line of the form.	
state	is used for the form's state regarding to the CBL GUI Styleguide. It's values can be stQuery, stModify, stNew and stShow.	
isMainForm	if isMainForm equals 1 the caption of the form is shown in the task bar as application name.	
icon	icon points to an .ico file containing the icon for the CBL application.	
enabled	defines if the user can interact with a form. Default is true.	
visible	defines if the current form/panel is visible. Default value is true. This property is of interest if a form is used as tabsheet within a page control.	
showModified	defines if change bars are to be printed automatically. Default value is true.	
helpContext	The value of helpContext is passed to the onHelp handler function if F1 is pressed or "Help" is selected from the context sensitive menu.	
breakFlag	breakFlag can be used to assign an int variable to a form. This int variable is set to 1 as soon as the user presses the Ctrl+C key combination or executes a "Break" from the context-sensitive menu of the form. The CBL programmer is responsible for initializing and resetting the assigned variable.	
onEnter	is called as soon as form.Show() is called.	
onClose	The referred function is called if the user tries to close the form window by means of the window system menu or by clicking the title bar's close button. If the window should be closed the function Close() has to be called.  If onClose is not assigned the form will be closed automatically.	
onHelp	is a reference to a function which is called if the menu item "Help" is selected from the context sensitive menu (right mouse key) of the form or F1 is pressed. If onHelp refers to a function which accepts an integer value as first parameter the helpContext value of the currently active control is passed to this function.	

Designing forms

Show()	is used to display the form for the first time (or for redrawing if the layout has changed). The call will be like form1.Show(); To close the window later you have to call the Close() method. This is usually done in response to clicking an appropriate button on the form.		
ShowModal()	is used to display the form as a modal dialog. The dialog window is closed only when a button of the form is clicked, where all of the following conditions are met:		
	• button.style==0		
	• button.tag greater than 0		
	<ul> <li>if an onClick event handler is defined for the button and the event handler returns an int result, this result must not be equal 0</li> </ul>		
	ShowModal() returns the int result of the event handler, if it exists, otherwise it returns the tag value of the clicked button as result value. You never call the Close() method to close a modal dialog.		
Update (int relayout=0)	is used to show the values of the designated value variables to the corresponding form controls. It also updates/interprets the values of the options readonly, visible and enabled. If the optional parameter relayout is set to 1 the form is "relayouted" and repainted completely.		
UpdateControl (cblFormControl @ctrl, int recursive=0)	Same as Update, but updates only the one Control that is passed as argument ctrl. Example:  forml.UpdateControl(forml.controls["edit"]);  If parameter recursive is true and ctrl is a compound control, then the nested controls are updated, too.		
CheckComplete()	can be called to check if all form controls where the attribute required is true(1) got a value other than "". CheckComplete() does not check controls where the visible attribute is false. It returns 1 if the check was successful.  The attribute error is set to 1 for each required control with no value.		

CheckControl(cblsyFormCont-rol@ctrl)	checks the current value of the associated value variable against the validation specified by items. Only valid for controls of type ctAmo-Parameter.  The return value is:  0 = no error  1 = required parameter needs a value  2 = spaces are not allowed in individual values  3 = odd number of quotes  4 = quotation mark missing  5 = illegal individual value  6 = ranges may not be concatenated with &&  7 = too few individual values  8 = too many individual value  9 = illegal character in value
ResetModified()	resets the modified attribute of all controls contained in the form and all its subforms and internally stores the current value of each control as the new original value of the control. This original value is used to determine, when the modified attribute has to be set/reset by the CBL Interpreter.
ResetModified- Control(cblSy- FormControl @ctrl)	resets just the modified attribute of the control ctrl.
Get()	reads the values of <b>all</b> controls into the corresponding value variables. The values of all controls contained in a form are read, even if they are invisible, disabled or hidden by other controls, panels etc.
GetControl (cblFormControl @ctrl, int re- cursive=0)	Same as Get, but reads only the value of the one Control that is passed as argument ctrl. Example:  forml.GetControl(forml.controls["edit"]);  If parameter recursive is true and ctrl is a compound control, then the values of the nested controls are read, too.
Close()	is used to close the (nonmodal) window.
FocusControl (cblFormControl @ctrl)	can be used to give the focus to a specific form control. The control must be contained in the current form.
SetStatus (string text)	may be used to update the status field of a form immediately.

Designing forms

SetWindowState (int ws)	sets the display mode of the current form. ws accepts wsHide wsShow wsActivate (gives the current window the focus) wsMinimize wsMaximize	
StoreSizePos()	saves the current window position and size in the Windows registry (under HKEY_CURRENT_USER/Software/Siemens/ComWin 300/Layouts/ <name and="" application="" cbl="" of="" path="" the="">/<name (name)="" form="" of="" the="">/). This function should normally be called on closing the form. On calling the Show function, the CBL Interpreter first looks for a matching entry for the current window in the Windows registry and displays the window with the saved position and size if such an entry is found.</name></name>	
RetrieveSizePos ()	reads the window position and size that was saved with <code>StoreSiz-ePos</code> from the Windows registry and sets the position and size of the current window accordingly if a matching entry was found.	

## 4.4.3 Form controls

Class cblFormControl is the common class for all controls. The actual type of a control is determined by attribute type. Depending on the actual type of the control some of the attributes of the cblFormControl object may be ignored.

In this section only those attributes are explained, which are common to all types of controls.

```
class cblFormControl
  int
          type;
  int
          row;
  int
          col;
  int
          rowspan=1;
  int
          colspan=1;
  int
          left;
  int
          top;
  int
          width;
  int
          height;
  int
          align=alNone;
  string caption;
  string hint;
  int
          enabled=1;
```

```
int
        readonly=0;
        required=0;
int
int
        visible=1;
int
        outofdate=0;
        modified=0;
int
int
        error=0;
int
        default=0;
int
        translate=1;
int
        supportUndo=1;
        showModified=1;
int
string
        oldValue;
int
        align=alNone;
int
        style=0;
        taborder;
int
int
        taq;
int
        helpContext;
void
        @value;
void
        @items;
void
        &onEnter;
void
        &onExit;
void
        @onChange;
void
        @onClick;
void
        @onHelp;
cblForm @panels[];
CMenu
        popupMenu;
```

type defines the type of control (see next sections).

caption defines the caption of a control.

hint defines the quick-Help text associated with this control.

enabled (true=1, false=0) defines if this control can be used in the current context. De-

fault is true. enabled is available for all controls. Disabled controls are marked as usual under Windows (grayed). No user interaction is possible with disabled

controls.

}

readonly (true=1, false=0) defines, if the control's value can be changed at runtime by the

user. Default is false. Readonly edit fields get a gray background.

required (true=1, false=0) defines if the control has to be assigned some value. Use

cblForm's CheckComplete() to check the values of required parameters of a form. Default is false. Labels for required elements are shown in boldface.

Designing forms

(true=1, false=0) activates the automatic translation for the current control. Detranslate fault value is true (see "CBL - National Language Support" on page 174).

(true=1, false=0) defines, if the control is visible at runtime. Default is true. Avaivisible lable for all controls.

(true=1, false=0) is set immediately by the CBL system when the user modifies modified the value of a control. If the user changes the value of a control back to its original value, the modified attribute is reset immediately.

> The modified attribute is also reset by a call to the ResetModified() method of the form. Usually you call ResetModified() after a call to form. Get(), when you have verified that the value of each control is acceptable and processing of the data starts. The modified attribute must not be manipulated directly by the CBL application!

> The visual effect is, that a change bar appears to the left of the modified control. The color of the change bar is set in the options dialog of the CBL Interpreter and is yellow by default.

outofdate (true=1, false=0) defines, if the value of a control is not current. This attribute should be set by the CBL application, if you know that the value of a control is out of date, but you don't want to update it automatically, e.g. to avoid unnecessary data transfer to and from Hicom. Default is false.

> The visual effect is, that a change bar appears to the left of the outofdate control. The color of the change bar is set in the options dialog of the CBL Interpreter and is brown by default.

(true=1, false=0) defines, if the value of the control is erroneous. This attribute is set by the CheckComplete() method of a form, if a control which has the required attribute set, does not contain a value. The error attribute can also be set by the CBL-application. Default is false.

The visual effect is, that a red change bar appears to the left of the erroneous controls (only if change bars are activated).

Activates display of a change bar for this control. Default value is true. The showModichange bar is only activated if displaying change bars for the current form is acfied tivated.

(true=1, false=0) defines whether the context-sensitive menu (right mouse key) supfor this control should include the menu item "Undo". portUndo

This string is used to save the previous value (value) of a control element. ololdValue dValue can be set explicitly or via the functions ResetModified or ResetModifiedControl. In the case of the latter functions, oldValue is set to the current value. oldValue is also the value that is entered for the control on executing the Undo function. Furthermore, as soon as value and oldValue differ, i.e., modified is not equal to 0, the change bar is displayed.

column number which the control is assigned to. col

row number which the control is assigned to. row

error

# **CBL - Programmer's Reference**Designing forms

colspan and rowspan define the width and heights of the control in grid co-

rowspan lumns/rows. Default value is 1.

left offset of the left position relative to the layout cell; in pixels.

top offset of the top position, relative to the layout cell; in pixels.

width width of the control in pixels.

height height of the control in pixels.


Designing forms

align

This attribute is used to specify the alignment of a control (A) within the layout cell **or** (B) within the surrounding panel/form. Alignment with the surrounding panel/form (B) is used to define the layout of the control, when the window is resized by the user.

## (A) Alignment relative to the current layout cell:

All controls can be assigned to an "invisible" layout cell by setting the attributes col and row. The width of a column of this layout grid is defined by the widest control in this column, the height of a row of the layout grid is defined by the tallest control in this row.



For controls with a caption the width of the control can be computed automatically by the "layouter" (e.g. Label, Button, Checkbox, Radiogroup). The height of the control can be computed by the number of entries (e.g. Radiogoup). For controls that can contain other controls (e.g. panel) the size of this control is defined by the sum of the sizes of the contained controls.

The position of the control within a cell can be controlled by the value of the attribute align. In this case align can be a sum of values of alhLeft (adjust left, default), alhCenter (adjust horizontally centered), alhRight (adjust right), alvTop (adjust top, default), alvCenter (adjust vertically centered), alvBottom (adjust vertical bottom).

**Example**: align:alHCenter+alVBottom.

The size of a control within a cell can be defined by align too. To use the available horizontal space set align to allfill, to use the available vertical space set align to allfill.

Example: align: alVCenter+alHFill.

The size of a control and of the cell rows and columns is computed, when form. Show() is called and is not recomputed, when the window containing the controls is resized by the user!

# align (cont.)

# (B) Alignment within the surrounding panel:

align can take the values alNone, alTop, alBottom, alLeft, alRight and alClient. Default value is alNone.


With this means you can divide a (sub-)form either horizontally or vertically into up to three areas: top - client - bottom, left - client - right. You may only use a combination of either alTop, alBottom and alClient or alLeft, alRight and alClient.

On each (sub-)form no two controls must have the same value other than al-None in their align attribute.

Setting alignment to another value than alnone means that the size of this control is defined by the surrounding panel or form, e. g. like an editor area (=memo field) that resizes with the surrounding form.

If align is alTop or alBottom only the height attribute of the control is considered. top and left are ignored, width is taken form the surrounding panel.

alClient makes a control a client control: both position and size is defined by the available space.



Controls which can contain other controls are ctPanel, ctPages and ct-Grid.

see "Alignment to resizable panels" on page 171

Designing forms

taborder

defines the order in which the controls are selected if the user moves from control to control using the tab-key. taborder is optional and should start with 1. The default tab order is defined by the order in the controls[] array which differs if the controls array is integer or string indexed (alphabetically sorted by the indexes' values).

You may use the same value for taborder both for a control and its associated label. This is also useful to define a keyboard shortcut for a control: When the user enters the keyboard shortcut of the label, the associated controls gets the focus.

tag

can be used for general purposes by the user. It is only evaluated if a Button is clicked. Then the tag value is written into the value variable of the Button (if available). tag also defines the result value of the function ShowModal().

helpContext If F1 is pressed or the menu item "help" is selected from the context sensitive menu this value is passed to the onHelp-function of the form as argument.

value

is a reference to a variable holding the value for the current control. When the form's <code>Get()</code> method is called, the current values of all controls are copied from the form into the referenced variables. To avoid multiple write access to a variable, each variable must only be referenced in one value attribute within a form. Else the multiple write accesses to the variable would cause unpredictable results.

However, there is one exception to this rule: The value attribute of several buttons should reference the same variable! After clicking one of the buttons you can determine which one was pressed by checking which tag value is found in the variable referenced by the value attribute.

items

is a reference to a variable holding an array of items for the current control (e. q. items of a combo box).

onChange

is a reference to a function which is called if the value of the current control is changed.

onClick

is a reference to a function which is called if the current control is clicked.

onHelp

is a reference to a function which is called if the menu item "Help" is selected from the context sensitive menu (right mouse key) of a control.

onNaviga-

te

is a reference to a function which is called if the menu item "Go to object" is selected from the context sensitive menu of a control.

panels

is an array of subforms for compound controls (e. g. page control).

popupMenu allows to define a context sensitive menu for this specific control.

The onClick handlers of the menu items get the reference of the current control as first parameter. Example:

```
void abcClicked(CFormControl @control)
{
   comWinFrame.ConsolePrint("ABC clicked");
}
```

onEnter is a reference to a function which is called if the current control gets the focus.

onExit is a reference to a function which is called if the current control looses the focus.

Please note that the event handling routines cannot change the value of the current control.

#### 4.4.3.1 ctLabel

caption	string	label text
value <sup>*</sup>	string @	reference to a string variable containing the label text
onClick	function @	function which is to be called if label is clicked; a label where on Click is specified, is displayed with underlining like a HTML hyperlink.

<sup>\*</sup> Either value or caption should be set. If caption is set, the label will only be updated if the form is repainted using Show(). If the label's text is stored in a variable a reference to this variable must be assigned to label.value. Then the label's text is updated with every call of FormUpdate (better performance).

#### 4.4.3.2 ctEdit

value	string @	reference to a string variable containing the value of the edit field
onChange	function @	function which is called for every change in the edit field (each typed character!)
style	0	standard edit field
	1	edit field for password input (prompt character is *)

Designing forms

# 4.4.3.3 ctCombo

value	string @	reference to a string variable containing the value of the combo edit field
items	string [] @	reference to an array of strings to be displayed in the combo box
onChange	function @	reference to a function which is called for every change in the edit field (each typed character!) in the combo box.
onClick	function @	reference to a function which is called before the selection dialog is shown when the ""-button is clicked. This function can prepare the items array. Only available for style=1.
style	0	standard combo box (Windows style)
	1	Enhanced combo box, consists of edit field and ""-button to start a selection dialog. The selection dialog contains a string grid (do not confuse this with the ctGrid control!) which is filled with the items array. A ' '-characters in each item separates the columns in this string grid. If the 'Ok'-Button is pressed the value of the first column is displayed in the edit field after the selection dialog is closed.
	2	standard combo box (same as style=0) but without the possibility to edit a value. Only selection of predefined values is possible (drop down list).

# 4.4.3.4 ctMemo

items string [] reference to an array of strings to be displayed in the memo @

The memo control is readonly.

# 4.4.3.5 ctListbox

value	int @	reference to an int variable containing the index of the selected item (or -1 if none is selected)
items	string [] @	reference to array of strings to be displayed in the listbox
style	0	standard listbox (Windows style)
	1	Enhanced listbox. The array of items is displayed in as a table. ' '-characters in an item separate the columns in this table.

caption	string	used to define column headers for listbox of style 1; ignored for

listbox of style 0.

'|'-characters in caption are used to separate the column headers.

# 4.4.3.6 ctCheckListbox

value	int [] @	reference to an int array containing the values (states) of the CheckListbox entries. The size must be the equal to the numbers of items
items	string [] @	reference to array of strings to be displayed in the checklist box

# 4.4.3.7 ctRadiogroup

value	int @	reference to an int variable containing the index of the selected item (starting with 0)
items	string [] @	reference to array of captions of the radio buttons
caption	string	caption of the radio group (displayed in the radio group frame)

Designing forms

## 4.4.3.8 ctCheckbox

caption	string	caption of the checkbox
value	int 0 or 1 or 2	0 if the checkbox is not checked, 1 if checked, 2 if grayed.
style	0 1	Checkbox can have the states checked and not checked Checkbox can be grayed, too.

#### 4.4.3.9 ctButton

caption	string	caption of the button
onClick	function @	function to be called if button is pressed. If it returns an int result, the result is considered in deciding whether to close a modal dialog. The return value is only evaluated, if $tag!=0$ and $style==0$ .
tag	int	<pre>return value for ShowModal(), if onClick EventHand- ler does not return an int result. Also result value for value</pre>
value	int @	gets the value of ${\tt tag}$ if the button is pressed (before execution of ${\tt onClick})$
style	0	if tag>0 a modal dialog containing this button is closed.
	1	even if tag>0, a modal dialog will not be closed.
default	int	if default!=0 this button is the default button for the current form.

#### 4.4.3.10 ctAmoParameter

The AmoParameter control allows to define a HiPath 4000 Expert Access-MML-Editor styled control. All information about the AMO parameter is stored in the object that is passed to item. This object can be easily retrieved from HiPath 4000 Expert Access-MML-Editor using the method getParamValidation(string param).

## Example:

```
amoParam gerkon;
...
comedit.command="EINR-SCSU;";
gerkon=comedit.getParamValidation("GERKON");
```

_			•	
פבוו	SIM	ning	t∩r	mc
	ואַוכ	mig	101	1113

value	string @	gets the value of the parameter
item	amoParam	if ${\tt default!=0}$ this button is the default button for the current form.

# 4.4.3.11 ctBitmap

caption string path to the bitmap to be displayed

# 4.4.3.12 ctPanel

panels	cblForm[]	panels[0] contains the form which should be displayed within the panel.	
		The caption of the form defines the caption of the panel.	
		<ul> <li>If this caption is not empty, then style is ignored and a standard panel (Windows style) with a title in a frame is dis- played.</li> </ul>	
		<ul> <li>If this caption is empty the panel is just a rectangle with bevels defined in style.</li> </ul>	
style	0	the panel is a raised area (like a button)	
	1	the panel is plane	
	2	the panel is a lowered area	
	3	standard panel (Windows style)	
align		if align is alLeft, alRight, alTop, alBottom or alClient the attribute style is ignored. Instead the panel looks like style==1, if align is alLeft, alRight, alTop or alBot-	

# 4.4.3.13 ctPages

value	int @	current page index starting with 0
onChange	function @	function which is called when another page was selected by the user. This function should not take too much CPU time, because this function delays the switch to the next tab sheet.

tom and looks like style==2, if align is alClient.

Designing forms

panels cblForm[] array of forms which should be displayed in the different tab sheets. The caption of the tab sheet is the caption of the "subform".

#### 4.4.3.14 ctGrid

items is the reference to an array of an user defined grid class

which contains the actual values of the grid controls.

panels cblForm[] panels[0] contains the form which defines the controls to be

used within one line of the grid.

value int var index of the actual grid line. This value represents the line index

of the grid if an event handler has been called.

Grid controls are the most complex controls which can be defined on the GUI of CBL applications. The following example should show the usage of a grid control.

```
include "form.cbl"

class cblGridItem
{
   string caption;
   string value;
   string items[];
}

class gridItemCls
{
   cblGridItem A_edit1;
   cblGridItem B_combo1;
   cblGridItem C_button1;
}
```

```
gridItemCls gridItems[];
gridItems={ { A_edit1:{value:"edit1"},
              B_{combo1}: \{value: "combo", items: \{ "v1", "v2", "v3" \} \},
              C_button1:{caption:"b1"} },
             { A_edit1:{value:"12"},
              B_combo1:{value:"c2"},
              C_button1:{caption:"b2"} },
             { A_edit1:{value:"e3"},
              B_combo1:{value:"c3",items:{"a1","a2","a3"}},
              C_button1:{caption:"b3"} },
             { A_edit1:{value:"e4"},
              B_combo1:{value:"c4"},
              C_button1:{caption:"b4"} }
          };
class helloCls
  int gridLine;
  cblForm form1;
  int x;
  void get()
    form1.Get();
  void update()
```

Designing forms

```
{
    form1.Update();
  }
 void ButtonClicked()
    form1.Get();
   string line;
    line=gridLine;
   gridItems[gridLine].A_edit1.value="Line "+line;
   form1.Update();
  }
 void init()
  {
  form1 = { caption:"Grid Test Form",
            controls:
              { "grid1":
                 { type : ctGrid,
                   width :300, height:90,
                   items : gridItems,
                   value : gridLine,
                   panels: {{ controls:
                             { "A_edit1": { type: ctEdit,
caption:"feld1" },
                               "B_combo1": { type: ctCombo,
caption: "feld2" },
                               "C_button1":{ type: ctButton, value:x,
caption:"action", onClick:ButtonClicked }
```

```
}
}

}

put1": { type:ctButton, row:1, caption:"Get",
onClick:get },


"but2": { type:ctButton, row:1, left:150,
caption:"Update", onClick:update }

}

form1.Show();
}

helloCls hello;
hello.init();
```

The result window looks like this:



# 4.4.4 Definition of menus

```
is the text displayed as menu item and as hint for the speed but-
caption
               string
                             ton.
onClick
              function @ is the function to be called if the current menu item is clicked.
                             is the submenu of a menu item.
submenu
              cblMenu
                             defines if the current menu item can be selected or not. Default
               0=false,
enabled
                             is true.
               1=true
left
              int
                             defines the horizontal distance to the previous speedbutton in
                             pixel. Default is 0.
                             defines the file path to the bitmap which is to be used for dis-
bitmap
              string
                             playing the speedbutton.
```

```
class cblMenu
 cblMenuItem items[];
class cblMenuItem
 string
           caption;
 void
           @onClick;
  CMenu
           submenu;
                     // for menu only
  int
          enabled=1;
  int
          visible=1;
  int
          left;
                     // for speedbar only
          bitmap; // for speedbar only
  string
```

# 4.4.5 Form examples

## 4.4.5.1 Alignment to layout cells


This example shows a form using many features of the previous described form description method.

```
// FormExample
include "form.cbl"
class myWindow
  CForm form1;
  CForm subform1;
  CForm subform2;
  CForm subform3;
  string label1="Label 1";
 string val1="Value 1";
string val2="Val";
  string val3="Value 3";
  string val4="Choice 2";
  int
         val5=1;
  int
         val6;
         val7;
  int
         val8;
  int
  string[] choiceItems ={ "Choice 1", "Choice 2", "Choice 3" };
  string[] choiceItems2={ "Choice 1 | Description 1",
                            "Choice 2 Description 2"
                            "Choice 3 Description 3" };
  int pageIndex;
  void update()
                      form1.Update();
  void start()
                      form1.Get();
  void get()
                      form1.Get();
  void close()
                      form1.Close();
  void init()
    subform1={ caption: "Page 1",
               controls: { { type:ctLabel, col:0, row:0, caption:"label1", onClick:update },
                              type:ctLabel, col:0, row:1, caption:"label2"
                             { type:ctLabel, col:0, row:1, caption: label2 }, { type:ctLabel, col:0, row:3, caption: label3" } };
    subform2={ caption: "Page 2",
               controls: { { type:ctLabel, caption:"subform with
caption" } };
    subform3={ controls: { type:ctLabel, caption:"subform w/o
caption" } };
    form1={ caption: "Hello World",
        mainmenu: { items: { { caption: "&File",
                                 submenu: { items: {
                                                         caption: "&Open", onClick:start },
                                                          caption:"&Close", enabled:0 },
                                                          caption:"-" },
                                                          caption: "E&xit" }
                               { caption: "&Edit",
                                 submenu: { items: { { caption: "&Cut" },
                                                        caption: "&Paste" }
                                                    } } },
                                 caption: "&Help"
        controls: { "label1":{ type: ctLabel, col:0, row:0, caption : "Label"},
                     "label2":{ type: ctLabel, col:1, row:0, caption: "Label with onClick",
                                                onClick:close },
                     "lable3":{ type: ctLabel, col:0, row:1, caption: "Edit"},
                     "edit1" :{ type: ctEdit , col:1, row:1, value : val1, width:80,height:25},
"label4":{ type: ctLabel, col:0, row:2, caption : "Combo, default"},
                     "combo1":{ type: ctCombo, col:1, row:2, value : val2, items: choiceItems,
                                                 width:80,height:25 },
                     "label5":{ type: ctLabel, col:0, row:3, caption : "Combo, style=1"},
                     "combo2":{ type: ctCombo, col:1, row:3, value
                                                                        : val3, items:choiceItems2,
                                                 style:1, width:80, height:25 },
                     "radio1":{ type: ctRadiogroup, col:2, row:4, caption:"Radiogroup",
                                                 value:val5, items: choiceItems },
```

Designing forms

```
"label6":{ type: ctLabel, col:0, row:4, caption: "Listbox, default"},
                                                                   "listbox1":{ type: ctListbox, col:1, row:4, value:val7,
                                                                                                                                                       height:45, items: choiceItems },
                                                                   "label7":{ type: ctLabel, col:0, row:5, caption : "Listbox, style=1"},
                                                                   "listbox2":{ type: ctListbox, col:1, row:5, value:val8, items: choiceItems2,
                                                                                                                                                     height:70, style:1 },
                                                                   "check1":{ type: ctCheckbox, col:2, row:1,caption:"Checkbox1",value:val6 },
                                                                   "pages1":{ type: ctPages, col:0, row:6, value: pageIndex,
                                                                                                            panels : { subform1, subform2 },
                                                                                                                                                                                                                              width:150, height:100 },
                                                                   "panel1":{ type: ctPanel, col:1, row:6, style:0, panels: {
                                                                                                                                                                                                                                                                     subform1 }
                                                                   "panel3":{ type: ctPanel, col:0, row:7, style:1, panels: { subform3 }
"panel3":{ type: ctPanel, col:1, row:7, style:2, panels: { subform3 }
                                   "panels: { subform3 } , support the strain of the strain o
                                                                    "button1":{ type: ctButton, col:0, row:8, caption: "Ok",onClick: start,
                                                                                                                   enabled:1, tag:1 },
                                                                   "button2":{ type: ctButton, col:1, row:8, caption: "Get",onClick:get }, "button3":{ type: ctButton, col:2, row:8, caption: "Update",onClick:update}
                    form1.Show();
myWindow window;
window.init();
```

# This is the resulting form:






The "tagged" expression list has been used for initialization of the controls array of the form. If we do so, the controls array gets string indexed. Then we can access (and modify) each control element by it's name, e.g. for activation of a button:

form1.controls["button1"].enabled=1;

# 4.4.5.2 Alignment to resizable panels

```
// FormExample2
include "form.cbl"
class myWindow
  CForm form1;
  CForm header;
  CForm body;
  CForm footer;
  void init()
    header={ controls: { { type:ctLabel, caption: "header area" },
                         { type:ctEdit, col:1 } };
    body= { controls: { { type:ctLabel, caption:"body area" } };
    footer={ controls: { { type:ctLabel, caption:"footer" },
                         { type:ctButton, col:1, caption: "Button" } };
    form1= { caption: "Form-Example 2",
        controls: { "panel1":{ type: ctPanel, align:alTop,
                                                              panels: { header }
                    "panel2":{ type: ctPanel, align:alClient, panels: { body
                    "panel3":{ type: ctPanel, align:alBottom, panels: { footer }
          };
      form1.Show();
myWindow window;
window.init();
```

Designing forms



# 4.4.6 Modal dialog example

This example shows a form using many features of the previous described form description method.

```
class COpenConnection_Dialog
    cblForm form1;
    string host;
    int show(string title)
        CReply reply;
        int
               OK=1;
        int
               CANCEL=2;
        form1={ caption:title,
                controls: { { type: ctEdit,
                               caption: "IP address or\nlogical name :",
value:host,
                               layout:{left:30,top:10,width:100} },
                             { type: ctButton, caption: "OK", taq:OK,
                               layout:{left:70,top:60} },
                             { type: ctButton, caption: "Cancel", tag:CANCEL,
                               layout:{left:160,top:60} }
                layout: {left:250,top:200,width:290,height:150}
              };
        system.BringToFront();
        system.ConsoleClear();
        if (form1.ShowModal(this)==OK)
        {
            form1.Get();
            system.ConsolePrint("Initialisation of host "+host+" started.");
            reply=tools.open conn(host,comwin);
            system.ConsolePrint(reply.lines[0]);
        return(reply.status_ok);
    }
}
```

CBL - National Language Support

# 4.5 CBL - National Language Support

The goal of NLS (National Language Support) is to support writing language independent applications.

The CBL Interpreter supports two ways of defining national language depending texts. One Hi-Path 4000 Expert Access-own mechanism and one especially for HiPath 4000 Expert Access running in the H.O.T. (Hicom One Tool) environment.

## **Advanced topics**

- chapter 4.5.1, "CBL-intrinsic text tables"
- > chapter 4.5.2, "NLS texts from H.O.T."

## 4.5.1 CBL-intrinsic text tables

CBL allows the definition of text tables (see "text\_table\_stmt" on page 16).

This example shows the mechanism:

text_table {	{	"de"	,	"en"	,	"es"	}
"Bereit":	{	1111	,	"Ready"	,	"listo"	},
"Läuft":	{	1111	,	"Running"	,	"elaboración"	},
"Anzeigen":	{	1111	,	"Show"	,	"anuncio"	},
"Abfragen":	{	1111	,	"Query"	,	"buscar"	},
"Ändern":	{	1111	,	"Modify"	,	"modificar"	},
"Löschen":	{	1111	,	"Delete"	,	"borrar"	}
<b>}</b> ;							

Text tables can be used to define translations for language dependent strings. When the CBL program is read the global translation table is set up. Only the texts for *one* translation is actually stored by the interpreter even if there are more translations defined. The translation column is selected which corresponds to the value of a global variable named "Language". The initialization value is determined from the current user default language as stored in the Windows' registry database.

The tag (e.g. "Bereit":) is used within the application.

The translation table is used automatically for input and output texts of forms (e. g. label caption, combo box items etc.). The automatic translation can be switched off for each individual control by setting the attribute translate to 0 (=false).

If there is no value ("") defined as translation in the current language column, the tag value is used instead.

The translation table can be accessed by purpose using the interpreter defined functions "TranslateIn(string text)" and "TranslateOut(string text)".

Example: (Language=en)

TranslateOut("Anzeigen") returns "Show",

TranslateIn("Modify") returns "Ändern".

This list shows the abbreviations for the languages as supported in the current release of Hi-Path 4000 Expert Access:

german	de	english	en
spanish	es	dutch	nl
french	fr	finnish	fi
danish	da	portuguese	pt
korean	kr		

## 4.5.2 NLS texts from H.O.T.

NLS texts can be read at compile time from the HOT.NLS component.

Please see "syn\_stmt" on page 14 for details.

# 5 Introduction into CBL Programming

## **Advanced topics**

- > chapter 5.1, "Preface"
- > chapter 5.2, "Data types, variables and operators"
- chapter 5.3, "Statement and Expression"
- chapter 5.4, "Object and Class"
- chapter 5.5, "Programming with GUI-Builder"
- chapter 5.6, "HiPath 4000 Expert Access Interoperation"

## 5.1 Preface

CBL is a special language which has been created to provide more possibilities to automate the commands or create the application rather than using only the batch command line to control the Hicom switch.

This "Step-by-Step to CBL" will be the introduction to some basic ideas in CBL programming to get start to program CBL with the basic knowledge and to be able to understand the CBL programming reference later on for creating the sophisticated program on demands.


## **5.1.1** What is CBL?

CBL is the short form of Comtes Batch Language which was created to be the script language to communicate with all other components in the HiPath 4000 Expert Access platform. But it can also be considered as a general purpose programming language like C++, Basic or Java. CBL codes can be turned into the series of actions that do tasks or solve some problems which vary from the easy tasks (e.g. calculate some numbers) to the more specific and complicated applications that work between components (e.g. the program to show all the stations in Hicom switch).

CBL is relatively similar to Java or C++ in the way of syntax, object-oriented structure but even more simple to use. So it would be rather easy for the person who had already some experiences in programming and would not be too difficult for the beginner as well. In the programming structure aspect, CBL has the general style of primitive data types such as string, integer, array but can also define the complex data types by using classes. It can also be programmed in functions or methods which can be called later in the program. Besides the individual running program, it can be program to communicate with other HiPath 4000 Expert Access components such as HiPath 4000 Expert Access-MML-Editor or HiPath 4000 Expert Access-Frame by OLE-Automation.

## 5.1.2 What do we need to start?

Considering the type of CBL language, it is not a compiled language like C++ or Java which all the codes in the file will be read and compiled to generate the result by the compiler. On the other hand, CBL is an interpreted language like Basic or JavaScript which the code will be read and interpreted language expressions into actions statement by statement.



To start programming, we need to have an editor to write the code on. It works the same way as programmers who write Basic can use Visual Basic editor or Java use Jbuilder editor. Recently, CBL can be written on a very simple tool such as Notepad in Microsoft Windows operating system or any other kinds of editors. The CBL Interpreter and the HiPath 4000 Expert Access-GuiBuilder also has an built-in editor.


Currently ".cbl" files are associated with notepad by HiPath 4000 Expert Access installation.

# **Example:** Hello world

Start with the very famous simplest example, this example will give some ideas how the cbl program can be written, run and show the result under HiPath 4000 Expert Access environment. You can start now by following the steps as shown below.

- Open some Editor tool (e.g. Notepad: You can find it in the Start program->Accessories-> Notepad)
- 2. Then write the program to show the word "Hello world" by typing the code as followed.

  comwinFrame.ConsolePrint("Hello world!");
- 3. That's all the code you have. Next, save it by pick the name of your file as you like but do not forget to put the extension file as ".cbl"
- Now you have created the cbl file. To run it, first open the HiPath 4000 Expert Access CBL Interpreter. The interpreter "HiPath 4000 Expert Access - CBL Interpreter" looks like the picture below.




Load your cbl file into the interpreter by click Open icon (the first icon on the left) or select open in the menu File. Then you will have the file loaded. When the file is loaded the CBL syntax is checked.

**Remark:** The signature is automatically created after the file is loaded by the CBL interpreter. Currently it has no special function except it represents some internal checksum. In files you create you may remove the line but CBL interpreter will try to recreate it again. For the execution of the program it has no effect.

6. To run the program, press "Run" icon (the third button) in the menu bar. The code will be interpreted and the result will be generated. In this case, the word "Hello world!" will be shown in the HiPath 4000 Expert Access-Frame console window which will also be automatically popped up with the result inside.

# HiPath 4000 Expert Access-Frame

Console window is now used as the output console which contains the text result from the program in example 1.



7. In case you want to edit the source code, it can be done both by press the notepad icon on the menu bar while the code is loaded or open the code file in Notepad in the normal way. After the code is edited, it must be saved first. Then load it in the interpreter again or if it was saved in the same name, just reload it by pressing "Reset the program" (4th icon in the menu bar) and run it again by pressing "Run program" button.

After grabing the way to deal with the interpreter and the editor, we will go into more details in CBL language. Data types, program structure, and the more advance examples will be presented in the following chapters

## 5.2 Data types, variables and operators

Data types are considered as the first and the very essential step to master languages. Every language has data types as data abstractions or simply saying as a way to tell the compiler what kind of data using in the code in order to allocate the suitable memory, including the way to manipulate the data.

If you are familiar with the other programming languages, you might have known many data types already. Many languages may use different notions for the types but most of them have the same set of common basic data types eg. integer, string, float, boolean and etc. The same as CBL interpreter, it provides a set of predefined data types which composes of Integer, String and Array. It seems not so many data types predefined but it has been done on purpose. As from the objective of CBL which is mainly for switch controller, the data types offered as the primitive types would be enough to deal with this subject.

This chapter will present all primitive data types in CBL including the way to manipulate those data types with some examples and also about the variable.

## 5.2.1 Primitive data types

There are 3 data types which are included in CBL interpreter. In another word, it is called primitive data types or predefined types which the compiler provided with operators to maniputate. Integer, string and array are the 3 data types which have been mentioned. There are also another way to create complex data types by yourself which will be introduced later in the another chapter.

## 5.2.1.1 Integer type

Integer variables are stored as 32-bit numbers, which require 4 bytes of storage. Integers can be used to represent: the numbers in the designated range of -2147483648 to 2147483647. It can represent only the number without decimal or exponential multiplication. It can be used with 5, 96,324354, and so on within the range mentioned above but not 12.5, 0.214, 0.21x 10^3.

This numbers can be used in any other purposes in programming. For example it can be used to simulate boolean values which have two states: 1 for true and 0 for false or use as any identification numbers: the identification number of the stations.

Integer also has predefined operations which can be apply with this type of data, for example, interger number 3 and 5 had properties of integer so this number can be applied by the arithmatic operation like the basic operations such as plus(+), minus (-), multiply(x) and devide(/) and other operations as you can see in the CBL programmers guide/reference manual.

Data types, variables and operators

## **Example:** Simple calculation

This example is a simple calculation of mobile phone bill for a month. This calculation will just show the idea how to maniputate with integer data in CBL language although it wil not be the perfect calculation with 2 decimal digits like it is suposed to be in the real situation. In the integer system the value with be rounded(if it is not integer in result) before assigned to the integer type.

First, in this calculation, we have the monthly payment for the connection service, tax, call out cost for this month and we want to know the total cost alltogether. Then start with all four value in the declearation part. We can also initialize the value of monthly payment right there by put "=" follow by the amount. In this example, the monthly payment is around 13 Euro and tax is 16% so this program will use those numbers as the example. The name of the integer data type is "int".

```
int monthly = 13;
int callcost;
int tax;
int total;
```

This following line is just an output display for the title of the program.

```
comwinFrame.ConsolePrint("This is my mobile phone cost calculation.");
```

Start the calculation process, from assigning "callcost" for this month, assume that it is 50 Euro. Then total price needed to pay will be callcost + monthly. After that, calculate tax which is 16% and include tax in the total price.

```
callcost = 50;
total = callcost + monthly;
tax = total*16/100;
total = total + tax;
```

Display the result of the calculation by having the lines below. For the syntax, in case of text output, put the text in "...", and if it is a variable, put it without "...".

```
comwinFrame.ConsolePrint("I have to pay");
comwinFrame.ConsolePrint(total);
comwinFrame.ConsolePrint("Euro!! for my mobile!!");
```

Like in the last example, the result will be shown in HiPath 4000 Expert Access - Frame - Console. The calculation of this program will come out with 73 Euro with all the texts as shown below.

```
This is my mobile phone cost calculation.

I have to pay

73

Euro!! for my mobile!!
```

If you have some errors instead, check the spelling first. Then if you still cannot get it, may be you forgot the ";" at the end of the statements. Everybody will have simple errors at the beginning, so you donot have to worry about it. When you have more experience, errors will become less and you will enjoy programming.

## **5.2.1.2 String type**

The second primitive type provided by CBL interpreter is "string". It is used to represent the characters or text. String has also some operations to maniputate with data. Some of them are common with integer type but some are special operations for string which cannot be applied with integer. For example, "in" operation cannot be used by integer data type and some integer operations cannot be applied with string type, eg. Minus(-) operation.

The frequent use operations for string type are concatenation(+), "in" operation, assign operation(=).

## **Example:** String concatenation

In this example includes the string type assignment and concatenation. In the editor first we declear the veriable a, b and c to be string type by put the name of the variable followed by type. Then we will use a, b and c for some basic operations for string.

```
string a;
string b;
string c;
```

These two lines are for string assignment. We assign the text to the variable a and b.

```
a = "Hello world!!";
b = "Today is Friday, Yeah!";
```

For the variable c, we assign it's text to have text a, text b and more additional sentence. We can do it by using (+) operation which will concatenate the string in the variable a, b and the string c together. So the new text which will be assigned to c will be "Hello world!!" + " Today is Friday, Yeah!" + "Let's go out..."

```
c = a + b + "Let's go out...";
```

This comming last line in the program will print out the string in variable c.

Data types, variables and operators

```
comwinFrame.ConsolePrint(c);
```

The result will come out as followed.

```
Hello world!! Today is Friday, Yeah! Let's go out...
```

For other operations of string, e.g. "in" operation can be used to check whether the specific text is a part of another text or not. As stated in the sample code below.

```
string text1;
...
if ("no" in text1)
{subtask1}
...
```

From the program, if there is the text "no" occured inside the text in variable text1, subtask1 will be executed. Another usecase of "in" operation will be with String still have many other useful operations which can be found in the handbook for referencing.

## **5.2.1.3** Array type

Array is another useful primitive data type. Like in other languages, array used to represent the set of variables which have similar type. Thus, it has to be used with another data type, e.g. array of string or array of integer. For example, we have 10 stations which located in the different places and we would like to have variables of those ten with their location. We can use array of string because those ten station 's locations have the same data type which is string.



As from the diagram, the locations are store in the array of station which in this case "limited size array". There are two types of array, classified by the size. This first one is limited size array which programmer has to specify the size in the array declaration.

```
string day[7];
```

The variable "day" is a set of strings that contains only 7 of items as decleared. But in the case of unlimited size array, the array's items will not be limited. With this way studentname array can be added up unlimited as the example.

```
string studentname[];
```

The next important topic involved with array is indexing. As from the set structure of array, it has many items in the list. Thus, when the items need to be accessed, they need the indicators to identify themself which item are they. Each item in the list has its own identity idication which is an index. From the first example diagram, you can see the 10 stations which are having numbers from 0-9 in the bracket. Index numbers always start from 0, so 10 stations have index number 0-9. In the code, if you want to change the location of station 1 from Munich to Leipzig, Station 1 can be reached by mention Station[0].

```
station[0] = "Leipzig";
```

Type of the array just mentioned is *Integer indexed array* which is widely used in many languages.

In CBL, there is still one more type named *string indexed array.* This type, as the name, use string to be the index instead of integer which sometimes make more sense to do this way. For example, the case of employee's extension numbers, we can represent those data easily by using this way.

```
int[] x;
x["Erich"] = 52142;
x["Bernd"] = 56984;
x["Robert"] = 54632;
x["Emil"] = 58963;
```

So we can just use names as the indices to access each item in array. For instance, to display the telephone extension of Erich can be done directly by using indexed name and display the value.

```
comwinFrame.ConsolePrint(x["Erich"]);
```

The string indexed array has also the integer index set which mapped from the string indices, ordered alphanumerical. Thus, it can also be accessed like in the normal integer index array by mention the integer index. From in the telephone extension above, we can order the indexed name respectively as Bernd, Emil, Erich and Robert.

Data types, variables and operators

```
x[0] is mapped to x["Bernd"]x[1] is mapped to x["Emil"]x[2] is mapped to x["Erich"]x[3] is mapped to x["Robert"]
```

So these below statements mean the same thing.

```
comwinFrame.ConsolePrint(x["Erich"]);
comwinFrame.ConsolePrint(x[2]);
```

For initializing value in array, in the integer indexed type can be initialized as follow,

```
string setstring[] = {"Erich", "Robert", "Bernd"};
int setnumber[] = {1,2,3,4};
```

On the other hand, the string indexed type can be initialized this way.

```
int extensionset[] = {"Bernd":56984,"Erich":52142,"Emil":58963}
```

**Remark:** Only items that exist in the array can be accessed, otherwise the interpreter will give a warning message. For example, a couple lines of code below declear an array which has two items.

```
int item[];
item[0] = 32;
item[1] = 16;
comwinFrame.ConsolePrint(item[2]);
```

Although item[2] is not yet defined the above statement will work. If an array element of an integer indexed array is accessed that is not yet defined a new element with the default value (for integer this is 0) will be created automatically.

```
int[] x;
x["Erich"] = 52142;
x["Bernd"] = 56984;#
comwinFrame.ConsolePrint(x[2]);
comwinFrame.ConsolePrint(x["James"]);
```

The access with x[2] result in an error message because of range violation (only elements 0 til 1 defined) but with x["James"] interpreter will print the result of 0, represent the default value of item which is not exist (in case of item data type is string, it will show no character.)

#### 5.2.1.4 Variables

After data types, we have been using variables already in many examples. Now this will be explained more in details. Start from the answer of the question "What is a variable?" It is obvious that "variable" is not a new word. At least people knew it from Mathematics. Infact, concept of variable in both fields are basically comparable. In the definition, a variable is a symbol or a name that represent its data value. In programming, having variable is providing more flexibility to have dynamic changing of data. A variable provide another alternative by assigned the value in real time rather than using only fix value in the program.

The definition might look a bit complicated but a variable can be simply explained as the place used to store the value which can be changed over time. For example, a mobile phone has some memory to store the phone number. You can put your friend's name and telephone numbers and they will be stored in the memory. Over time, a friend "John" moves to another city, so you get his new number then you can replace the new number within the same name. The old number which is stored in "John" changed to a new one. This is happened with computer memory and variable which its value can be changed overtime. We can make use of the this feature. Without it computer programming will not be considered of a very useful innovation.

To use variables, we need to provide the name of the variable and also the data type of the variable. These two are called identifier and type identifier.

## 5.2.1.5 Identifier and type identifier

Identifier is not only used as the name of the variable but also for funtions and the other userdefined items which can be defined in condition with some rules. Identifier can be characters which can start with a letter or an underscore and the following characters must be either letters, digits, or underscores as the example shown below.

Correct identifier	Ind
employee	
_throw	
book_1	
salary12	

Incorrect identifier
test-2 : It has "-" .
abcd : It has "".
12ab : It begins with digits.
_test: It is reserved for CBL system

Identifiers are also case sensitive e.g. the variable named a and A are treated as the different variable.

### 5.2.1.6 Type identifier

Type identifier defines the data type of a variable and return value of the funtion. For variables they can be specified by the type integer, string and they can also be array of those two types as well.

Data types, variables and operators

- Integer uses "int" as the type indentifier.
- String uses "string" as the type indentifier.

Both of them have to be in the lower case letters and follow by the variable's name.

#### 5.2.1.7 Declaration

Declaration is one of programming statements. It is important to start using variables. Compiler / Interpreter will be informed about the variable from the declaration. It will allocate the memory space to the variables according to their data type.

A variable can be decleared in two ways. First, it can be decleared as the constant value. This case is useful when the program used many times a constant number. Thus, when you want to change this constant value, it is easier to change only one time the value of the variable instead of tracking all the codes to change line by line. Second, variable is decleared as a dynamic value variable which we have seen already.

The syntax of the first case of constant variable starts with keyword "const" then followed with the type identifier then the identifier and assigned value, e.g.

```
const int montly payment = 13;
```

Another case of normal variable, syntax would start with the type identifier then follows with the identifier.

### **Example:** Integer declaration

```
int variable1;
int set1;
```

## **Example:** String declaration

```
string booklist;
string text;
```

In case of array, the declaring variable's name has to be follow by brackets. As seen in the last topic of array, it has two different methods to difine which are limited size array (with the upper bound) and unlimited size array (without limited bound). It has two different types of access which are string indexed and integer indexed. Interpreter will allocation the memory space to array only when a new array element is accessed but not when it is defined. Therefore, accessing an element which is not yet created causes an empty element.

```
int book[];
int student[10];
string test[];
string text[3];
```

## Scope of variables:

The next question might be "where can I put the declaration statement?". Variables can be decleared in 4 different places which are :

- inside blocks (every sequence of statemens that are enclosed by curly braces { } , e. g. inside or outside of a function)
- in the definition of function parameters
- inside class, but outside of functions
- globally: outside of all classes and functions

Variables stated in the different places also have different functions which are local variables, formal parameters, member variables, and global variables respectively.


## **Example:** Variable's scope

Global variables and local variables have some differences. The global variable decleared outside the function and it can be accessed through out the entire program but the local one can just used only inside the local scope which it has been declared to used in. For example, gMax is a global variable and it can be used even inside the function add but the variable sum can be used only inside function block that it was decleared in.

In HiPath 4000 Expert Access - CBL - interpreter, there is a feature called data inspector which allowed you to trace the value of all variables including the scope information so that you can also see the global and local variable scope. To use data inspector, click an icon on the menu bar (the third one from the right). It will open the data inspector window(the window with the

Data types, variables and operators

title"Current symbols"). Like in the picture below, at the break point in function add, there are an amount of variables active at that moment. In the window, it shows values of interesting 4 variables which has underlined.



## 5.2.2 Operators

After got some ideas about the variables, then what can we do with them? To manipulate variables we need operators. In previous topics in this chapter, we have seen some operators for fulfilling explanation of data types, e.g. some arithematic operators: plus (+), minus(-) which are arithmetic operators or assignment operators but there are still more useful operators in CBL language. Operators can be classified into many types and have different functionalities. Here CBL operations will be explained according to type of the operations.

## 5.2.2.1 Boolean operators

Before getting into boolean operators, it's neccessary to know about boolean concept. Boolean value can be either true or false. It is always used in programming. Sometimes you want the program to do something if a specific *condition* you want is true, but do something else if it is false.

For example, if there is a person name "John" in the Hicom switch, read his extension number and output it on the screen. So if computer finds "John" in the switch the condition will become "true" and computer will proceed the task of reading and showing John's extension number. Otherwise, it will not do any task. That 's why boolean operators are very useful.

In CBL, there are two boolean operators given: logical and, logical or. Besides logical operators there are still be bitwise operators which are also using somehow the same logic to apply with operands. From now each operation will be explained one by one.

## Logical AND (&&)

This operator has two inputs and will give the result in one output. The following example will show some ideas of this operation.

## **Example:**

We have 3 expressions to consider.

- "John needs a mobile phone"
- 2. 2. "John has enough money"
- 3. 3. Will John buy a mobile phone?

So for the AND operation, if expression 1 and 2 is true that John needs a mobile phone and also has enough money, he will buy a mobile phone. Those sentenses can be represent using "&&" as a symbol for AND operation.

JohnWillBuy = (John has enough money)&&(John needs a mobile phone)

With AND, if any of the expression is false, it will result in false. So in these cases of :

- John has not enough money but he needs a mobile phone. He will not buy it.
- John has enough money but he does not need a mobile phone. He will not buy it.
- John has not enough money. He does not need a mobile phone. He will not buy it.

The only case that made John buy a mobile is both are true.

Thus, the logic of AND operation can be present as in table.

Operand1	Operand2	Result	
False	False	False	
False	True	False	
True	False	False	
True	True	True	

Data types, variables and operators

## Logical OR: (||)

OR operation use the operator symbol, | |. It works in the similar way like AND operator but the only different is the logic.

## **Example:**

The given 3 expressions are:

- 1. "The bin is full."
- 2. "Today is Saturday."
- 3. Jim will throw away garbages?

The expression will be

```
ThrowGarbages = (The bin is full) | (Today is Saturday)
```

From this expression, Jim will throw away garbages in condition if the bin is full or it is Saturday. For any of the true input expression will cause the true result. But the fault case will be only if both inputs are false. The bin is not full and today is not Saturday. So Jim will not throw away garbages.

You can also see from the logic table of OR

Operand1	Operand2	Result
False	False	False
False	True	True
True	False	True
True	True	True

### 5.2.2.2 Arithmetic operators

All arithmetic operators can be applied with integer except addition operation which will turn to be string concatenation if apply with string. The function of each operator are already known in mathematics.

Operator	Symbol	Example
addition/ string concatenation	+	int a = 7+2 strint text = "I know" + "CBL language"
subtraction	-	int b = 8 - 4;
multiplication	*	int c = 4*5;
division	1	int g = 10/5;
modulus	%	int r = 10%3;

## 5.2.2.3 Bitwise operators

Bitwise operators can be used to operate with integer variables in their binary data representation. There are a number of bitwise operators.

Operator	Symbol	Example
AND	&	Operand1 & Operand2
OR	I	Operand1   Operand2
XOR	۸	Operand1 ^ Operand2

You might still have a question of how is each operator work? Now each bitwise operator is going to be explained and also with some examples.

## Bitwise AND (&)

Every bitwise operators, including AND operator, will take the integer and change to binary number as digital bit representation. Then it will compare both operand bit by bit. The result will be according to AND logical as explained already in Boolean operation. Only 1,1 will make the result become 1, the rest will be 0.

```
int operand1 = 2;
int operand2 = 3
int result;

result = operant1&operand2;
comwinFrame.ConsolePrint(result);
```

The bit representation of the operand 1,2 will become like showing below and also the result.

Bitwise AND	Decimal value	Binary bit represented value
Operand1	2	0000010
Operand2	3	0000011
result	2	0000010

From the example, the last bit on the right of each operand will be compared and "AND" operation applied. So the result of 0,1 will be 0. The next bit of 1,1 will be 1. Then 00000010 is equal to 2 in decimal number.

## Bitwise OR (|)

The way of proceeding in this operation is the same as bitwise AND but just change the logic applied with two operands. In OR operation if any of the compared bits have 1 then the result will become 1, the only case that will cause 0 in result is when both compared bit are 0,0.

Data types, variables and operators

Bitwisw OR	Decimal value	Binary bit represented value
Operand1	2	0000010
Operand2	3	0000011
result	3	0000011

In the same codes as the last example with bitwise AND, the result will just change. As from the last bits 1,0 result in 1. So the result will become 00000011 which is 3 in decimal number.

## Bitwise XOR ( ^ )

The logic of XOR is not the same as AND, OR. It take two base two values to compare then if they are the same, the result will be 0 but if they are different, the result will be 1. All possibilities in XOR logic can be shown below.

Operand1	Operand2	Result	
0	0	0	
0	1	1	
1	0	1	
1	1	0	

Then using another sample codes for this operation. We have the codes like given:

```
int Operand1 = 90;
int Operand2 = 3;
int result;
result = Operand1^Operand2;
comwinFrame.ConsolePrint(result);
```

As always, the interpreter will interpret integer and take it as binary to do the operation which can be shown in the table below.

Bitwise XOR	Decimal value	Binary bit represented value
Operand1	90	01011010
Operand2	3	0000011
result	89	01011001

Then we will show the logic dertermination of this example bit by bit, starting from the first bit on the right to the left.

```
0 ^1 = 1

1 ^1 = 0

1 ^0 = 1

0 ^0 = 0
```

So the final result will be 01011001.

## 5.2.2.4 Equality operators

Equality operators can be very useful when you want to have the conditions like: less than, equal to, greater than. Then you code your conditions easily by using these operators.

For example, if you want to say "apply 16% tax just for the employees who has more than 3000 salary. But the rest who has below 3000 will have only 10% tax" It can be present by pseudocode(not the real code but more english related just to make it easy to understand) like this.

```
if (salary > 3000)then
  taxrate = 16%
otherwise
  taxrate = 10%
```

So it is obvious that without the equality operators, it will not be easy to express those expressions. Thus, CBL provide also equality operators which use also symbol to represent those meaning of "less then", "greater than" and so on. You can see all of them in the table below.

Operators	Symbol	Example	Result
equal	==	4==4	True
not equal	! =	5 != 6	True
greater than or equal	>=	5 >= 9	False
less than or equal	<=	6<=3	False
greater than	>	9>6	True
less than	<	7<3	False

### 5.2.2.5 Assignment operators

Before comming to this issue, you have been using already the assignment operators. The symbol of this operator is "=". In other examples, we have seen a lot of assignment process, such as:

```
int x;
int y;
string text;
x = 0;
```

Data types, variables and operators

```
y = 10;
text = "hello!";
comwinFrame.ConsolePrint(x);
```

You can see the assignment expressions in the example, e.g. the line of x = y = but what does it mean? The process of assigning is very simple as it takes value of the expression on the right-hand-side and assign it to be the value of the variable in the left-hand-side. So x = but will have 0 as its value, y = but will have 10, text will become "hello!".

Assigning integer value at the declaration statement, we can put "=" followed by integer number. With the string, we use the same "=" but follow with the string in double quotes sign, such as:

```
int a = 5;
string text = "Hello world";
```

There are also other operators in this assignment group which are very useful and make the command shorter. Assume that you want the codes below:

```
int x;
   int a;
   x = x+a;
```

You can write the code in another way around by using the operator += like this:

```
x +=a;
```

This line means the operator takes the value on the left-hand-side and add with the value on the right-hand-side then assign to the variable to the left-hand-side. In this case, the value of x will be taken and add by the value of a then assign it to the variable x;

There are some more operators with the arithematic operators mixed with the assignment operators and it works in the same way as +=. They are all including +=, -=, \*=, /=, %=. They will do the same method but change only the arithmetic operators.

## Assignment as the type conversion

Here comes another issue in assignment. Let's look at the expressions below.

```
int x = "Try";
string y = 1234;
```

Those expressions are correct or not? You might think, they are all wrong. Some will say they are all type mismatching. Although it is quite strange to have the string assign to the integer variable and also on the other way around with integer value assign to string variable but in

CBL, it is allowed to do so. But why and how? It is just an implicit way to convert the data to be in the type of the variable. Because of the data from Hicom switch (both numbers and text) normally comes in text form. So if you want to manipulate the data which is in text format e.g. you have "12345" and you want to do some arithmetic operations with it. You have to change it to interger somehow. Then it can be applied by the operators. And also on another way around to change the integer to string to send to Hicom switch.

## **Example:**

```
int aNum;
aNum = "254";
```

From the codes above, the string "254" is converted to be integer and then assigned to aNum.

```
string sTxt;
sTxt = 245;
```

As in the same way, the integer 245 will be converted into string "245"

But what will happen in these following cases.

```
int a = "test";
int b = "12 34";
int c = "58p";
```

In case the text assigned to an integer variable cannot be converted to number like the case variable a, it will just assign value 0 to a. But in case of b, the text has two groups of numbers seperated with the space. So this case it will take the first value of the text which is 12. For the c case, the string will be converted to 58 because it cut out the character "p" behind.

Thus, besides the normal way to use assignment operators, it can also be used for type conversion purpose. This machanism also works in another way not really at the declaration part, eq:

```
string y;
int x;
x = "123";
y = 123;
```

Those lines can result also in the same implicit type conversion.

Statement and Expression

## 5.2.2.6 Operation precedence

Interpreter takes the different piority of manipulating data due to the operation precedence. As you can see from the example:

```
x = -3

x == -3 \mid \mid x >= 0

x * -23 + 44 / 2

x = 5 / 2
```

x will be 2, because all numeric variables are integer (the remainder will be truncated)

```
x = 5 % 2
```

x will be 1, the remainder of the integer division. The semantics of modulo is the same as in C.

```
hello = Text
```

The precedence of all operators is:

```
Highest .

[
(
    * / % in
    + -
    < <= > >=
    == !=
    &
    ^
    |
    &&
```

The precedence might look difficult to remember but to learn it by heart is not the good way. There is also another way.

```
x = 3-5*2; // This might cause a wrong precedence determinationx x = (3-5)*2 // It is clear that "-" is the first then "*".
```

Thus, the easier way is using parenthesis to specify the order of operations yourself.

## 5.3 Statement and Expression

Last chapter we dealed with the primitive data types and how to use them and also looked at the way to use and declare the variables with types. The last thing we did is operators. This chapter will be involved with how we organize what we have in chapter 2 to code the whole program with conditions and direct how the program supposed to be executed.

Lowest

## 5.3.1 Expression

We have seen already many expressions in the last chapter. So what is exactly an expression? An expression is as simple as it contains one or more operations which represent by operators. The expression in the simplest way can be only the variable or number or string value such as:

```
MonthlyPayment
123
"Hello!"
```

It also can contain an operator, such as:

```
123 + 234
"Hello" + "world!"
9 & 5
```

Besides the expression with one operator, if it has more then one operator, it will be called *compound expression*. In order to deal with the execution of many operators, it has to determine the precedence of each operators it has, e.g:

```
3/5-2 6 / 3 | 5 + 2
```


The operators in the expression can be any of the operators mentioned in chaptor 2, e.g. arithmatic operators, boolean operators, bitwise operators and etc.

## 5.3.2 Statement flow control

The heart of programming is to execute commands automatically according to the purpose of the program. So the way to automate the commands without any help of human decision is to construct a flow control. A program can be broken up into parts which are control by a flow control.

### **Example:** Flow control

John will buy a mobile phone if he has enough money. So he has to check his bank account first, and if he has more than 500 Euro, he will buy a mobile but if not, he will start saving money everyday until he has enough money to buy. Then he will buy it. The following diagram will show the flow chart of a program how it is seperated in to stepsand the way to decide the branching decision point.



#### 5.3.2.1 Function - statement

In order to make the program easier and understandable, the whole complicated program need to be seperated into many small parts which are much easier to handle and to code. Functions are the key to do this job. Each function represent series of tasks in one name which can be used (call function). Then in your program you can write functions and control the flow easier by calling functions in the main program flow.

There are two types of functions; first, functions without any return value and second, functions with a return value. When a functions with a return value is called, it will proceed its task then return a value as a result. This retuen value can be in any of the valid data types in CBL language. Function has a quite simple syntax which starts with an identifier to specify the type of the return value (in case the function has no return value, "void" will be used there). Then the function's name will be put. Another thing next to the name will be a parenthesis which can contain parameters to use inside the function or can be just an empty one.

## **Example:** Function with a return value

```
int saveMoney(int amount)
{
   balance = balance + amount;
   return balance;
}
```

From John's example, saving money is a routine job which can be assigned as a function. This saveMoney function has an input parameter which is the amount of money to save. Then the saving amount will be added up with the old balance in the bank account then return the new balance as an integer value.

## **Example:** Funciton without a return value

```
int x;
void myFunction()
  int v;
  v = 30;
  x = v + v/2;
}
```

This example shows how to use the none-return function. This function will not return any value but only proceed the tasks in the function. So when the function myFunction is called the x equation will be calculated and the x value will be assigned.

### 5.3.2.2 If - statement

The "if - statement" is a conditional statement which allows you to write the condition and to control the program to execute some codes due to the conditions. So if the *if-expression* is considered to be true (can be anything except 0) then the corresponding code block will be executed. Otherwise the block of *else* will be executed.

## Example: If-else

```
x = 8;
if (x > 5)
{
    x = x * 10;
}
else
{
```

Statement and Expression

```
x = x * 20;
```

In this example, first, x is assigned to be 8. Then it is checked in the expression (x > 5) which become true. Thus, the block next to the expression  $(x = x^* 10)$  is executed. On the other hand, in case the value of x makes the expression become false(in case x<5), the block after *else*  $(x = x^* 20)$  will be executed.

If you want to make the conditions more complex, you can use the boolean operators, such as, and (&&), or (||), not (!) and if you have more than one condition you can use *else-if expression* which will be checked one after the other if the previous condition is false.

## Example: if - else if

```
int income;
int tax;
if (income < 500)
{
    tax = 0;
}
elseif ((income >= 500) && (income < 1000))
{
    tax = income * 10/100;
}
elseif ((income >= 1000) && (income < 2000))
{
    tax = income * 12/100;
}
else
{
    tax = income * 15/100;
}</pre>
```

This example shows the simple process of tax calculation which the tax will be calculated from the income level. The income will be checked whether which level it is in from the first *if-expression* and go to the next *elseif* (if the condition is false) until the program found the range that the income is in. Then it will calculate the tax with the percentage of that income level.

#### **5.3.2.3** for - statement

This statement used for repeating the execution the block of codes due to the conditions gave in *for-statement*. For the person who is familiar with pascal or C/C++ language already. CBL for-loop is really similar to them. The first style which is like C language will have a syntax com-

pose of 3 expression after "for" which will define the initial value of loop control variable, a relational expression that determines when the loop exists, and the condition that defines how the loop control variable changing in each round.

## **Example:** For-loop in C style

```
for (x = 0; x < 10; x++)
{
    saving = saving + 2;
    comwinFrame.ConsolePrint("Today my saving is =");
    comwinFrame.ConsolePrint(saving);
}</pre>
```

This for-loop will increase the value of saving variable in each time the loop is repeated. The loop start with a control variable x assigned to 0 then increasing by one as from the last expression in the parenthesis. It will be repeated until the value of x cannot meet the condition x<10 in the second expression.

The initialization part can be omitted if the initialization of the variable has been executed before the *for-statement*.

```
int x = 1;
for ( ;x<10;x++)
{
    comwinFrame.ConsolePrint(x);
}</pre>
```

But if all of the expressions in for-loop are empty, it means the loop will run forever. The code in the block will be executed again and again.

```
for ( ;; )
{
   comwinFrame.ConsolePrint("I'm running forever");
}
```

However, there is a break-statement which can terminate the loop from inside the block:

```
int x;
for (;;)
{
    x++;
    if (x>10)
```

Statement and Expression

```
break;
}
```

## **Example:** For-loop in Pascal style

```
for i = 1 to 100 do
{
    comwinFrame.ConsolePrint("I can count number :");
    comwinFrame.ConsolePrint(i);
}
```

The syntax in pascal style using "for... to" and it is ended with "do " and the code block in the bracket. In this example, the loop will be repeated 100 times and show the text as the codes in the bracket will be repeated.

#### 5.3.2.4 while - statement

Another posibility to use loops in your program is employing *while -statement*. There are two types of *while -statement* in CBL language. The *while* and *do while-statement* are slightly different in syntax and logic of the statement. While loop will be run only if the expression in condition is first proved to be true. On the other hand *do while-statement* will in anyway execute the code block first then check the condition in the while expression at the end of the code block. Thus it will be repeated until the expression is still ture. The different is *do while-statement* will execute the code block once anyway before check through the condition at the end but *while-statement* will check the condition first, so it will not execute the code block even once if the condition is not true at the beginning.

## **Example:** while loop

```
int x = 0;
while (x < 10)
{
    saving = saving +2;
    comwinFrame.ConsolePrint("Today my saving is");
    comwinFrame.ConsolePrint(saving);
    x++;
}</pre>
```

This example is using the first style of *while-statement*. The block code will be executed only if the condition x < 10 is true. Then the program will increase the value of saving variable and print out the result.

## Example: Do while - loop

```
int x = 0;
do
{
    saving = saving +2;
    comwinFrame.ConsolePrint("Today my saving is");
    comwinFrame.ConsolePrint(saving);
    x++;
} while (x < 10)</pre>
```

This program will first run through the code block after do and then check the while expression whether the condition is true or not. If the x < 10 is true, then the code block will be repeated otherwise the loop will be ended.


## 5.4 Object and Class

The new concept of Object-Oriented programming can be seen as an enhancement of the old style of procedural or structural programming. With the object oriented method, the program complixity will be reduced and will be more structured so that it made things easier for programmers. The advantages will be increasing the modularity, reusable features and more as you will see from the details later on.

# 5.4.1 What is an object?

To understand more about object-oriented programming, it is important to understand first the object concept. Object is everything around you or one can say anything in the universe, e.g. a car, a man and etc. With this concept, it is easier to model the complex things in real world to the abstract environment which can be used in programming. The key points of an object are its two types properties, data attribute and the function. Like the functions in the last chapters, an object can perform the tasks which are defined as its function. But unlike the a function, an object can do many predefined tasks and can also have its own data stored internally which is defined as its data attributes.


The example of the object can be an address book. The data attributes of this object can be the data field in the address books such as name, house number, street, city, zip code, telephone. For the actions, they can be all the actions that can apply with the address book: create, delete and edit a record. The object would look like this:



The figure above shows the adress book as an object with the data attributes which is called *Member data (Attribute in CBL)* and the functions that applied with this object, called *Member functions*. Member data can be compared with the normal variables which explained before but it is different from the normal variables in the way of accessibility. Member data cannot be accessed everywhere like the global variable but can only be accessed internally by the object. Member functions also work in the same way as member data. It can be called only by referencing to the object.

# 5.4.2 Object instantiation

After applied the object oriented concept and designed the objects, they can not be directly used. This designed object is used as a block or a template for creating the manipulatable object which will be called *instances* from now on. For example, the address book is a template and the intances of this template are the data records you put in the address book:



This record is an instance of the address book. Each instance has its own internal data stored and it's own accessible functions. Every instance has the same pattern. It contains the same data members and the same functions from the template object.

## 5.4.3 Class

A template or the block that used to create the instances is actually called a class in programming language. As mentioned from Data type chapter that besides the primitive data types, there is another kind of data types. It is called complex data type which can be created on demand by using class representation. For instance, the address book can be assigned as a complex data type. Thus, the address book type will contain data members, e.g. record number, name, address and etc which can be assigned with primitive types: record number can be integer; name, address, city can be string. Besides the attributes, the address book type will contain also the functions for manipulating instances. The functions; delete and edit; are also needed to be inside the class.

## Example: Address book class

```
class address_book
{ int recordno;
  string name;
  string address;
  string street;
  string city;
  string zipcode;
  string telephone;
  void displayPhone()
```

Object and Class

Like any other statements, class also has some syntax in CBL. The syntax looks not so new because it consists of known statements which can be either *funciton statements* or *declearation statements*. As in the example, the syntax of the class declaration start with the word class then the class name and the declaration of attributes and funciton members in the a curly bracket.

In order to use the class, you have to make the instance out of it then use the instance. The syntax of instantiation is as simple as declare a variable. On the other hand, you can take the class as a data type then assign it to a variable. For instance:

```
void main()
{
  address_book john;
  john.name = "John smith";
  john.telephone = "089-123456";
  .
  .
  .
  john.displayPhone();
}
```

This case the data members are initialized outside the class but it can be done also in the class so that the new instance will have the default value from right after it is created.

```
class point
{  int x = 0;
  int y = 0;
  int z = 0;
}
point p1;
comwinFrame.consoldPrint(p1.x);
comwinFrame.consoldPrint(p1.y);
comwinFrame.consoldPrint(p1.z);
```

In this class, the class represent point in 3 dimensional coordinate system which eash point in x,y,z axis has been initialized to 0. Thus, all points that are created from this class will have x,y,z value of 0 as the default value.

The member function of classes is like the normal function. It can be both with the input parameters or not. In the last example of address book, there are only functions without parameters. The syntax of member functions exactly the same as the normal function as the functions without parameters will start with *void* and the name of the function then function's statements inside curly bracket. Here is another example of

```
class person
{
   string name;
   int age;
   string sex;
   void incrementAge()
   { age++;
      comwinFrame.consolePrint("Now the age is");
      comwinFrame.consolePrint(age);
   }
}
```

If we create a person from this class, this person will have the function incrementAge which can be call without any parameters. Here is some codes of that show the way to call this function.

```
person john;
john.name = "John Smith";
john.age = 25;
john.incrementAge();
```

The same way as using the attributes of the instance, to call a function (also called method in this context)function, we need to mention the instance first. Thus, if we declared the instance name "john" as a person, the attributes and functions inside can be referred by using the instance name and a dot then follow with the specific attribute or function. Calling functions just have a bit different compared with the attributes that it needs to have the parenthesis after functions' name. If a the member function has parameters, it is called needed to have the name of parameters inside as shown in the function is followed by a parenthesis. example below.

If the member function has parameters, it is needed to have the parameters inside as shown in the example below.

```
class person
{
   string name;
   int age;
```

Object and Class

```
string sex;
int incrementAge(int y)
{ age = age + y;
   return age;
}
```

Now in this example, the incrementAge function has a parameter which is the amount of year to be incremented to the current age. The function 's type is not void but it is assigned to the type of return value which in this case "age" variable 's type. So when you call this function, it will automatically output the age variable after the process inside the function, for instance:


```
person john;
person jim;
int different;
john.age = 25;
jim.age = 20;
different = john.age-jim.age; // now the different will be 5.
john.age = jim.incrementAge(4);// But John& Jim is now 24.
```

The last expression assigns the return value of Jim's incremented age to John's age. So Jim's age will become 20+4 and then assigned to John's age.

## 5.5 Programming with GUI-Builder

Many programs have some interface to interact with the user. Thus, besides the program's machanism or the functions of the program, interface design and implimentation are also the important points that programmers need to know. The good Interfaces should be made to be easy to understand and to use so that in these days interfaces are generally designed in the graphical way with dialog boxes, buttons and input text boxes as we have seen in many programs in windows OS environment.

CBL language provide a so called "form library" that allowed you to use ready-made code to program your graphical interfaces easier but it is anyway not the best and comfortable way. Although interface coding with a support of library is possible, it is still be a hard work. HiPath 4000 Expert Access provide a tool which make the interface coding part easier. This nice tool called HiPath 4000 Expert Access CBL - GUI Builder which has quite similar features to C++ Builder interface or any other visual programming interface. It allowed you to create a form, buttons, edit boxes and etc. by using clickable menu bar.




GUI builder helps you to create your interface easily by providing menu bar to create forms, buttons, edit boxes. You can easily put the mouse curser on the icon to see each icon's description.

## **Example 5-2: Network broadcasting calculation**

This example is a small program doing the calcuation of network broadcasting address and subnet ID by using two inputs from the users which are IP address and the netmask. After having HiPath 4000 Expert Access - CBL- GUI Builder program on, you will see the program menu. Firstly, most often use buttons should be pressed on. They are the 3rd, 4th, 5th, 6th which will show the Object inspecter, source code editor, form editor and generate code..

Programming with GUI-Builder

The interface of Broadcast address calculation program look like the picture on the right with two sets of IP address and netmask for inputs and two sets of outputs in the grey boxes which are Broadcasting address and Subnet ID. The output will be calculated on everychage of the input fields.



- 1. The step of creating interface would rather be easy for this program.
  - Create new project by going to menu program File-> New. Then the new form, Source code editor and object inspector will be poped up.
  - You can see and config object properties in the object inspector. For instance, the empty form now named Window you can change at the caption to make it "Broadcast Address Calculator" also all other properties like can also be changed.
  - It needs 4 labels for IP, Netmask, Broadcast and Subnet ID. This can be done by click at the label icon then click at the form to put the label on the right position.
  - Each line need 4 edit boxes to put the 4 parts of IP address. It can be done in the same way as the label but select the icon edit instead.
  - To make it easier to follow and read the code, it is better to name the object in the same name as we do. So in the object inpector, some of the object name and value needed to be change
  - Form change the name from Window to Main, caption to Broadcast Address Calculator
  - Edit boxes named "editlp1" to 4 from left to right and Value is editlp1Value to 4 also


Name: editNetmask1 (to 4) Value: editNetmask1Value (to 4)
editBroadcast1 (to 4) editBroadcast1Value (to 4)
editSubnetId1 (to 4) editSubnetId1Value (to 4)

The two output lines which are Broadcast and Subnet ID should be set up to be readonly which can be done by checking Read-only checkbox in each box's property.

**Remark:** The status panel (which is showing "Ready." in the picture above) and the green and red(now grey) status lights are automatically done by the program. You do not have to create it yourself.



From the first step of layout the interface as the picture above, you can change the properties of the object including size of the edit boxes, title of the form and every captions to be your choices. Then it's ready to be programed.



- 2. Coming to the programming part, once again, the goal is to calculate the broadcasting address and the subnet ID in every change of each field in IP or Netmask. So we need all the input edit boxes has to provide some be put the code for each event handler for on the onChange event of the input fields.
  - If you select the first IP box, there will be the Events part on the bottom of object inspector. Double click in the onChange box, a function will be created. Then you have to put the code inside each function.
- 3. For the code, 8 funcitons are more or less using the same algorithm. The only minor points are changed. This part of the code will look like this.

Programming with GUI-Builder

```
}
// Function editIp2OnChange()
void editIp2OnChange()
 MainForm.Get();
  editBroadcast2Value=_string( _int(editIp2Value)
    (0xff ^ _int(editNetmask2Value)));
  editSubnetId2Value =_string( _int(editIp2Value) & _int(editNetmask2Value) );
  MainForm.Update();
// Function editIp3OnChange()
void editIp3OnChange()
 MainForm.Get();
  editBroadcast3Value=_string( _int(editIp3Value)
    (0xff ^ int(editNetmask3Value)));
  editSubnetId3Value =_string( _int(editIp3Value) & _int(editNetmask3Value) );
  MainForm.Update();
// Function editIp40nChange()
void editIp4OnChange()
  MainForm.Get();
  editBroadcast4Value= string( int(editIp4Value)
    (0xff ^ _int(editNetmask4Value)) );
  editSubnetId4Value =_string( _int(editIp4Value) & _int(editNetmask4Value) );
  MainForm.Update();
```

Similar to the changes of the IP address input fields the onChange event handlers for the netmask input fields needs to be provided:

```
// Function editNetmask2OnChange()
void editNetmask2OnChange()
  MainForm.Get();
  editBroadcast2Value=_string( _int(editIp2Value)
     (0xff ^ _int(editNetmask2Value)) );
  editSubnetId2Value =_string( _int(editIp2Value) & _int(editNetmask2Value) );
  MainForm.Update();
 }
// Function editNetmask3OnChange()
void editNetmask3OnChange()
  MainForm.Get();
  editBroadcast3Value=_string( _int(editIp3Value)
     (0xff ^ _int(editNetmask3Value)));
  editSubnetId3Value =_string( _int(editIp3Value) & _int(editNetmask3Value) );
  MainForm.Update();
// Function editNetmask4OnChange()
void editNetmask4OnChange()
  MainForm.Get();
  editBroadcast4Value=_string( _int(editIp4Value)
   (0xff ^ int(editNetmask4Value)));
  editSubnetId4Value =_string( _int(editIp4Value) & _int(editNetmask4Value) );
  MainForm.Update();
}
```

4. Then the program can be run by clicking the "Start CBL" button on the menu bar. It will ask you to save the project first then it will be run.

## 5.6 HiPath 4000 Expert Access Interoperation

HiPath 4000 Expert Access architecture composed of many components which are able to communicate to each other and make the complicated program easier by using many components.

For a detailed desciption of these components and their interfaces please see "Interfaces to the HiPath 4000 Expert AccessFrame components" on page 96

## **Example:** Display a list of station numbers

```
// Display all SCSU and SBCSU station numbers with PEN
// Some ComWin-CBL-Include files are automatically included (e.g.
// comwin.cbl) which contains the interface to ComWin-Connect and
// ComWin-Edit. sysfunc.cbl defines a lot
// of very useful function for processing of MML commands.
// OpenConnDlg defines an universal dialog for opening of Hicom
// connections which are stored in ComWin-Connects connection
// directory. If OpenConnDlkq is used in the demonstrated way
// a CBL application can be started from a open connection via context
// menu Macro-/CBL-Bookmarks as well without change.
include "OpenConnDlg.cbl"
// Following line creates an instance of the "univeral" dialog:
OpenConnDlg conn;
// No the function show() of this dialog is called.
// This causes the display of a connection directory or the
// automatically attaching to an already existing connection.
// Connection establishment, logon, retrieval of Hicom language and
// system variant are done automatically.
// If everything works well this function returns value 1 and "our"
// application can begin.
if (conn.show())
  // Now we can send the first command to Hicom.
  // Therefor the function Send of the predefined object named "comwin"
  // is called.
  // return value of this function is the complete AMO result of the
  // passed command.
  // Before we send the command we define a string variable named
```

```
// "result" that should take the AMO result. Values of of string
// variables can be unlimited in size (no limitation to
// 255 characters or similar restrictions)
string result;
// Now we let the Hicom execute "REGEN-SCSU;"
result=comwin.Send("REGEN-SCSU;");
// The result shall now be processed. In an array of strings each
// command of the regeneration result shall be stored.
// The array of strings named "cmds" is declared in this way:
string [] cmds;
// Using the functions sys.prepare regen results (from sysfunc.cbl)
// the AMO result gets parsed:
cmds=sys.prepare regen results(result);
// Now every command should be processed in a loop.
// Therefor we need a loop variable:
int i;
// With this loop construct we iterate over every command of the
// 'cmds' array
for i=0 to cmds.count-1 do
 // The job to parse the AMO command is passed to ComWin-Edit.
  // The predefined object comedit has already got the Hicom Variant
  // and Language by openConnDlg.
  // With this knowledge it is able to parse the AMO syntax.
 comedit.HicomCommand=cmds[i];
 // From comedit we can get every value of the different parameters.
 // And we can send this value e. g. into the ComWin-Connect
 // protocol window.
 comwin.Print(comedit.getParam("TLNNU")
               + " --> "
               + comedit.getParam("LAGE")
               + "\n" );
```

HiPath 4000 Expert Access Interoperation

Index	AND 189, 191 ApplicationLanguage (Comedit) 97 Args 71 Arithmetic operators 190
Symbole - 190 13 != 193 % 190 & 191 && 189 * 190	Array type 182 ArrayRemoveAt (interpreter functions) 73 arrays 51 ASN.1 67 assign statement 13 Assignment operators 193 Attach (ComWin-Connect) 114 Authenticate (ComWinAccessSession) 138
*= 13 + 190 ++ 13 += 13 / 190 /* 49 // 49 /= 13 -= 13 == 193 > 193	bitmap 163 Bitwise operators 191 Boolean operators 188 Break (ComWin-Connect) 114 break (keyword) 50 break statement 37 breakFlag 149 BringToFront (ComWin-Connect) 114 button 162
>= 193 ^ 191 _BeautifyXML 74 _Busy (ComWin-Connect) 114 _Defined (interpreter functions) 73 _HttpDownloadFile (interpreter functions) 73 _Import 62 _ReleaseWait (interpreter functions) 73 _WaitUntilReleaseWait (interpreter functions) 73   191    190	caption (cblForm) 149 caption (cblFormControl) 153 catch (keyword) 50 CBL 176 CBL Language 10 CBL Programmer's Reference 71 CBL Programming 176 cbl_chain 89 cbl_dialogs 93 cbl_sysfunc_ 76 cblFile 90
Active (Comedit) 97 AfrSvr.exe 144 Alert (ComWin-Connect) 114 align (cblFormControl) 156 AmoParameter control 162 AmoResult (Comedit) 97 AmoResultPos (Comedit) 97	cblForm 148 cblFormControl 152 cblIniFile 92 cblMenu 168 cblsys1.cblIniFile 92 cblsys1.cblZipFile 93 cblsys1.chain 89 cblsys1.dialogs 93 cblsys1.dll 76

cblsys1.file 90 ComWin.PPPMan 136 cblsys1.sysfunc 76 ComWin300 Architecture 7 cblsys1.xmlfile 94 ComWinAccessDatabase 140 cblXmlFile 94 ComWinAccessFileman 139 cblXmlRecord 94 ComWinAccessQuery 141 ComWinAccessServer 138 cblZipFile 93 chain to string (cbl chain) 89 ComWinAccessSession 138 char (sys) 76 ComwinControl 114 Check (Comedit) 97 ComWinDbAccess.Database 140 check listbox 161 ComWinDbAccess.Fileman 140 checkbox 162 ComWinDbAccess.Query 141 CheckComplete (cblForm) 150 ComWinDbAccess.Server 138 CheckControl (cblForm) 151 ComWinDbAccess.Session 138 CheckFileUntilError (Comedit) 98 ComWinFM 144 CheckParam (Comedit) 97 ComwinFrame 125 comwinFrame (predefined object) 125 class (keyword) 50 class hierarchy 27 ComWinFT 130 ComWinPPP 136 class statement 25 clock (sys) 77 Connect (ComWin-FT) 131 close (cblFile) 90 Connected (ComWin-FT) 131 Connected (ComWin-PPP) 136 Close (cblForm) 151 Connections (ComWin-Connect) 114 Close (cbllniFile) 92 ConsoleClear (ComWin-Frame) 125 close (cblXmlFile) 95 ConsoleHide (ComWin-Frame) 125 close (cblZipFile) 93 Close (ComWin-Connect) 114 ConsolePrint (ComWin-Frame) 125 CloseAfterAutomation (ComWin-FT) 131 ConsolePrintStyle (ComWin-Frame) 125 CloseAll (ComWin-Connect) 114 ConsoleProgress (ComWin-Frame) 125 ConsoleResize (ComWin-Frame) 125 CloseDatabase (ComWinAccessDatabase) 140 ConsoleShow (ComWin-Frame) 125 col (cblFormControl) 154 const (keyword) 50 colspan (cblFormControl) 155 ContainsStrIndex (interpreter functions) 72 combo edit field 160 controls 152 Comedit 96 controls (cblForm) 149 comedit (predefined object) 98 CopyFrom (Comedit) 98 Comedit.MMLCommand 96 count (keyword) 50 command (Comedit) 97 create (cbl\_chain) 89 Command line parameters 71 CreateSessionToken (ComWinAccessSessicomment (single line) 49 on) 138 comment (structured) 49 CreateTempDir (sys) 77 CreateTempFile (sys) 77 comwin (predefined object) 115 ComWin.Control 114 ctAmoParameter 162 ComWin.FileTransfer 131 ctBitmap 163 ComWin.FM 144 ctButton 162 ComWin.Frame 125 ctCheckbox 162

ctCheckListbox 161 ctCombo 160 ctEdit 159 ctLabel 159 ctListbox 160 ctMemo 160 ctPages 163 ctPanel 163 ctRadiogroup 161 currentDateTime (sys) 77	Error (Comedit) 97 ErrorLine (Comedit) 98 ErrorMsg (Comedit) 97 ErrorParam (Comedit) 97 ErrorParamIdx (Comedit) 97 ErrorValue (Comedit) 97 ExecSql (ComWinAccessQuery) 141 ExistsParam (Comedit) 97 Expression 197 expression 39 expression lists 44 extends (keyword) 50
data types 179 Database (ComWinAccessQuery) 141 declaration statement 22	ExtractFilePath (sys) 77  F
decrapt (sys) 77 Delete (ComWin-FT) 131 DeleteTempDir (sys) 77 DestinationProcessor (Comedit) 97 DestType (ComWin-PPP) 136 Device (ComWin-PPP) 136 DialogMode (ComWin-FT) 131 DialogMode (ComWin-PPP) 136 Directory (cbl_dialogs) 94 directory (cblZipFile) 93 Disconnect (ComWin-FT) 131 Dispose (interpreter functions) 73 DLL interface 60 dll_class (keyword) 50 do (keyword) 50 do_while statement 33	FieldByIndex (Comedit) 98 FieldByName (Comedit) 98 FieldCount (Comedit) 98 FieldName (Comedit) 98 file_compare (sys) 77 FileDate (sys) 78 FileName (cbl_dialogs) 93 FilePos (Comedit) 98 FileSplit (ComWin-FT) 131 FileUnsplit (ComWin-FT) 131 Filter (cbl_dialogs) 94 FindFile (sys) 77 FindMask (Comedit) 97 flow control 197 FocusControl (cblForm) 151 for - statement 200 for (keyword) 50
edit field 159 else (keyword) 50 elseif (keyword) 50 empty statement 17 enabled (cblForm) 149 enabled (cblFormControl) 153 encrypt (sys) 77 enum (keyword) 50 enum statement 15 eof (cblFile) 90 Equality operators 193 error (cblFormControl) 154	for statement 31 ForceDirectories (sys) 77 form.cbl 146 format (sys) 77 Function - statement 198 function call 14 function declaration 19 function parameters 20  G GarbageCollection (interpreter functions) 72 Get (cblForm) 151 Get (ComWin-FT) 131

P30357-B9800-B10-101 EN, 2002-10-29 ComWin 300 / CBL Programmer's Reference, Guide

GetControl (cblForm) 151 HostName (ComWin-Connect) 115 Hosts (ComWin-Connect) 114 GetDir (ComWin-FT) 131 HTSOpen (ComWin-Connect) 114 GetErrorMsg (ComWinAccessDatabase) 140 GetErrorMsg (ComWinAccessQuery) 141 icon (cblForm) 149 GetFamosUserPass (ComWinAccessSessi-Id (ComWinAccessDatabase) 140 on) 138 Id (ComWinAccessServer) 138 GetFile (ComWinAccessFileman) 140 Id (ComWinAccessSession) 138 GetFirst (ComWinAccessQuery) 141 Id (ComWin-PPP) 136 GetHicomVariants (Comedit) 97 Identifier 185 GetHosts (ComWin-FT) 131 identifier 46 GetInfo (ComWinAccessSession) 138 if - statement 199 GetInfo (ComWin-FT) 131 if (keyword) 50 GetNext (ComWinAccessQuery) 141 if statement 29 GetNextMask (Comedit) 97 import (keyword) 50 getParam (Comedit) 96 import statement 18 getParamDesc (Comedit) 97 in (keyword) 50 GetParameters (ComWin-Connect) 114 include (keyword) 50 getParamIndex (Comedit) 97 include statement 17 getParamName (Comedit) 96 getParamNames (Comedit) 97 index (keyword) 50 Init (ComWin-FM) 144 getParamProps (Comedit) 97 int (keyword) 50 getParamValidation 162 int2hex (sys) 76 getParamValidation (Comedit) 97 getValue (Comedit) 97 Integer type 179 isMainForm (cblForm) 149 getValueDesc (Comedit) 97 items (cblFormControl) 158 GUI-Builder 209 GuiBuilder 8 Н KeywordOriented (Comedit) 97 keywords 50 height (cblFormControl) 155 helpContext (cblForm) 149 helpContext (cblFormControl) 158 label text 159 hex2int (sys) 76

height (cblFormControl) 155
helpContext (cblForm) 149
helpContext (cblFormControl) 158
hex2int (sys) 76
Hicom/HiPath error messages 144
HicomCommand (Comedit) 97
HicomLanguage (Comedit) 97
HicomLanguage (ComWin-Connect) 115
HicomVariant (Comedit) 97
HicomVariant (Comedit) 97
HicomVariant (Comedit) 115
Hide (ComWin-Connect) 115
HostDesc (ComWin-Connect) 115
HostDispName (ComWin-Connect) 115

LastMessage (ComWin-Connect) 114
Layout 146
left (cblFormControl) 155
lfill (sys) 76
listbox 160
LocalFile (ComWin-FT) 131
Logoff (ComWin-Connect) 114
Logon (ComWin-Connect) 114
ltrim (sys) 76

#### M Operator + 41 operator ++ 13 MacroRunning (ComWin-Connect) 114 operator += 13 mainmenu (cblForm) 149 Operator = 43match\_regex (sys) 76 operator -= 13 memo control 160 Operator in 42 menu 168 Operators 188 Message (ComWin-Connect) 114 operators \*= 13 MessageBeep (sys) 77 OR 190, 191 MessageDialog (cbl\_dialogs) 94 outofdate (cblFormControl) 154 Modal dialog example 173 modified (cblFormControl) 154 P Ν panel 163 panels (cblFormControl) 158 namespace 19 param\_intervals (sys) 77 namespace (keyword) 50 param\_ivals (sys) 77 National Language Support 174 ParamCount (Comedit) 97 NewLine (ComWin-Connect) 114 parse\_amo\_errors (sys) 77 NLS 174 parse\_amo\_result (sys) 77 Noun (Comedit) 97 ParseAmoResult (Comedit) 98 null (keyword) 50 ParseUrl (sys) 78 0 Password (ComWin-PPP) 136 PhoneNumber (ComWin-PPP) 136 Object and Class 203 popupMenu (cblFormControl) 159 oldValue (cblFormControl) 154 PPP-Manager 136 ole\_class (keyword) 50 precedence 196 onChange (cblFormControl) 158 prepare\_regen\_results (sys) 77 onClick (cblFormControl) 158 Print (ComWin-Connect) 114 onClose (cblForm) 149 PrintLog (ComWinAccessSession) 138 OnDataAvailable (ComWin-FM) 144 Profile (ComWin-PPP) 136 onEnter (cblForm) 149 program 10 onHelp (cblForm) 149 onHelp (cblFormControl) 158 Put (ComWin-FT) 131 onNavigate (cblFormControl) 158 R open (cblFile) 90 radio buttons 161 Open (cbllniFile) 92 radio group 161 open (cblXmlFile) 95 RasConnError (ComWin-PPP) 136 open (cblZipFile) 93 RasConnState (ComWin-PPP) 136 Open (ComWinAccessServer) 138 RasStatusString (ComWin-PPP) 136 Open (ComWin-Connect) 114 read (cblFile) 90 OpenDatabase (ComWinAccessDatabase) read (cblXmlFile) 95 140 ReadInteger (cblIniFile) 92 OpenDialog (cbl\_dialogs) 93 readln (cblFile) 90 OpenDirect (ComWin-Connect) 114 readonly (cblFormControl) 153 Operator - 42 ReadString (cbllniFile) 92

reference variables 53	ShellExecute (sys) 77
RegistryExistsKey (sys) 77	Show (cblForm) 150
RegistryGetKeyNames (sys) 77	Show (ComWin-Connect) 114
RegistryReadInteger (sys) 77	ShowBrowser (ComWin-FT) 131
RegistryReadString (sys) 77	ShowCommand (Comedit) 97
RegistryWriteInteger (sys) 77	ShowCommandDlg (Comedit) 97
RegistryWriteString (sys) 77	ShowHelp (ComWin-Frame) 125
RemoteFile (ComWin-FT) 131	ShowModal (cblForm) 150
remove_chain_from_chain (cbl_chain) 89	showModified (cblForm) 149
remove_int_from_chain (cbl_chain) 89	showModified (cblFormControl) 154
Rename (ComWin-FT) 131	ShowParamDlg (Comedit) 97
replace (sys) 76	ShowProgress (interpreter functions) 73
required (cblFormControl) 153	signature statement 17
ResetModified (cblForm) 151	SkipLines (Comedit) 98
ResetModifiedControl (cblForm) 151	SkipLinesUntil (Comedit) 97
RetrieveSizePos (cblForm) 152	sort_grid (sys) 76
return (keyword) 50	speedbar (cblForm) 149
return statement 36	StartApplication (ComWin-Frame) 125
row (cblFormControl) 154	StartJavaServer (interpreter functions) 72
rowspan (cblFormControl) 155	state (cblForm) 149
rtrim (sys) 76	statement 11
	Statement flow control 197
S	status (cblForm) 149
SaveDialog (cbl_dialogs) 93	Status (ComWin-Connect) 114
ScanMask (Comedit) 97	Status (ComWin-PPP) 136
Scope of variables 187	StopJavaServer (interpreter functions) 72
Script (ComWin-PPP) 136	StoreSizePos (cblForm) 152
Send (ComWin-Connect) 114	strfind (sys) 76
SendEx (ComWin-Connect) 114	string (keyword) 51
Server (ComWinAccessDatabase) 140	String type 181
Server (ComWinAccessFileman) 140	string_lines (sys) 76
Server (ComWinAccessQuery) 141	string_token (sys) 76
Server (ComWinAccessSession) 138	stripquotes (sys) 76
ServerIp (ComWin-PPP) 136	strlen (sys) 76
Session (ComWinAccessDatabase) 140	substr (sys) 76
Session (ComWinAccessFileman) 140	super (keyword) 51
set (keyword) 50	supportUndo (cblFormControl) 154
set statement 16	syn (keyword) 51
SetFileDate (sys) 78	syn (predefined object) 78
setParam (Comedit) 96	syn statement 14
SetParam (ComWinAccessQuery) 141	Syntax description 10
SetProtocol (ComWin-FT) 131	syslib (predefined object) 78
SetStatus (cblForm) 151	system (sys) 77
SetWindowState (cblForm) 152	, (- <i>y</i> - )

#### Т

taborder (cblFormControl) 158 tag (cblFormControl) 158 text tables 174 text table (keyword) 51 text table statement 16 TextHeight (interpreter functions) 72 TextWidth (interpreter functions) 72 this (keyword) 51 throw (keyword) 51 throw statement 34 to (keyword) 51 tolower (sys) 76 top (cblFormControl) 155 toupper (sys) 76 TracePrint (interpreter functions) 73 translate (cblFormControl) 154 TranslateIn (interpreter functions) 72 TranslateOut (interpreter functions) 72 trim (sys) 76 try (keyword) 51 try catch statement 34 type (cblFormControl) 153 type identifier 185 type-identifier 45

## U

unzip (cblZipFile) 93 Update (cblForm) 150 UpdateControl (cblForm) 150 User (ComWin-PPP) 136

#### V

value (cblFormControl) 158
Variables 185
variant (keyword) 51
Verb (Comedit) 97
virtual (keyword) 51
visible (cblForm) 149
visible (cblFormControl) 154
Visible (ComWin-FM) 144
Visible (ComWin-FT) 131
Visible(ComWin-PPP) 136
void (keyword) 51

### W

Wait (interpreter functions) 72
WaitForMessages (ComWin-FM) 144
while - statement 202
while (keyword) 51
while statement 32
width (cblFormControl) 155
WindowState (ComWin-Connect) 114
with (keyword) 51
with statement 35
write (cblFile) 90
write (cblXmlFile) 95
WriteInteger (cblIniFile) 92
WriteString (cblIniFile) 92

### X

XOR 191 XSD 64