


## Plug 3.5mm audio jack all the way in on each split




## Set Master on Left Split

This is the default configuration when the drift keyboard is shipped. It means you connect the usb-c cable into the left halve. Wrongly setting or plugging may damage the keyboard, we are not responsible for such damages.







## Set Master on Right Split


You may set the right halve to be master by setting the switches as shown on the left.


Setting the switches wrongly as shown below will again, irreversibly damage the keyboard.

Both set to Master Both set to Slave









!!!Always unpower/unplug the usb-c before unplugging the 3.5mm audio jack or setting the master and slave switches. Failure to do so will damage the split keyboard and we will not be responsible for repairs.