ROCKCHIP I2C Developer Guide

ID: RK-KF-YF-27

Release Version: V2.0.0

Release Date: 2019-11

Security Level: Non-confidential

DISCLAIMER

THIS DOCUMENT IS PROVIDED "AS IS". FUZHOU ROCKCHIP ELECTRONICS CO., LTD. ("ROCKCHIP")DOES NOT PROVIDE ANY WARRANTY OF ANY KIND, EXPRESSED, IMPLIED OR OTHERWISE, WITH RESPECT TO THE ACCURACY, RELIABILITY,

COMPLETENESS,MERCHANTABILITY, FITNESS FOR ANY PARTICULAR PURPOSE OR NON-INFRINGEMENT OF ANY REPRESENTATION, INFORMATION AND CONTENT IN THIS DOCUMENT. THIS DOCUMENT IS FOR REFERENCE ONLY. THIS DOCUMENT MAY BE UPDATED OR CHANGED WITHOUT ANY NOTICE AT ANY TIME DUE TO THE UPGRADES OF THE PRODUCT OR ANY OTHER REASONS

Trademark Statement

"Rockchip", "瑞芯微", "瑞芯" shall be Rockchip's registered trademarks and owned by Rockchip. All the other trademarks or registered trademarks mentioned in this document shall be owned by their respective owners.

All rights reserved. ©2019. Fuzhou Rockchip Electronics Co., Ltd.

Beyond the scope of fair use, neither any entity nor individual shall extract, copy, or distribute this document in any form in whole or in part without the written approval of Rockchip.

Fuzhou Rockchip Electronics Co., Ltd.

No.18 Building, A District, No.89, software Boulevard Fuzhou, Fujian, PRC

Website: www.rock-chips.com

Customer service Tel: +86-4007-700-590

Customer service Fax: +86-591-83951833

Customer service e-Mail: fae@rock-chips.com

Preface


Overview

The Rockchip series of chips provides customers with a standard I2C bus that allows customers to control and access different external devices. The I2C bus controller transfers information between devices connected to the bus via serial data (SDA) lines and serial clock (SCL) lines. Each device has a unique address identification (whatever it is a microcontroller - MCU, LCD driver, memory or keyboard interface) and it can be used as a transmitter or receiver (depending on the implement of the device). The Rockchip I2C controller supports the following features:

• Compatible with I2C and SMBus

- Only supports master mode
- Software programmable clock frequency support up to 400kbps, some chips up to 1000kbps
- Supports 7-bit and 10-bit addressing modes
- Interrupt or poll up to 32 bytes of data transfer at a time

The following figure shows the hardware connection of the I2C bus. The pull-up resistors are required. Changing the pull-up resistor value can adjust the drive strength of the I2C bus.



Rockchip I2C has different driver on different chips and different kernel versions. The maximum frequency supported for different chips is also different.

Product Version

Chipset	Kernel Version	Driver	Max Frequency	
RK3066	3.x	i2c-rockchip.c	400K	
RK3066	4.4/4/19	i2c-rk3x.c	400K	
RK3188	3.x	i2c-rockehip.c	400K	
RK3188	4.4/4.19	i2c-rk3x.c	400K	
RK3288	3.10	i2c-rockchip.c	400K	
RK3288	4.4/4.19	i2c-rk3x.c	400K	
RK3036	3.10	i2c-rockchip.c	400K	
RK3036	4.4/4.19	i2c-rk3x.c	400K	
RK312x	3.10	i2c-rockchip.c	400K	
RK312x	4.4/4.19	i2c-rk3x.c	400K	
RK322x	3.10	i2c-rockchip.c	400K	
RK322x	4.4/4.19	i2c-rk3x.c	400K	

Chipset	Kernel Version	Driver	Max Frequency	
RK3368	3.10	i2c-rockchip.c	400K	
RK3368	4.4/4.19	i2c-rk3x.c	400K	
RK3366	4.4/4.19	i2c-rk3x.c	400K	
RK3399	4.4/4.19	i2c-rk3x.c	1000K	
RV1108	3.10	i2c-rk3x.c	1000K	
RV1108	4.4/4.19	i2c-rk3x.c	1000K	
RK3228H	3.10	i2c-rockchip.c	1000K	
RK3328	4.4/4.19	i2c-rk3x.c	1000K	
RK3326/PX30	4.4	i2c-rk3x.c	1000K	
RK3308	4.4/4.19	i2c-rk3x.c	1000K	
RK1808	4.4/4.19	i2c-rk3x.c	1000K	

Intended Audience

This document (this guide) is primarily intended for the following engineers: Field Application Engineer Software Engineer

Revision History

Version	Author	Date	Change Description		
V1.0.0	David Wu	2018-06-08	Initial version		
V2.0.0	David Wu	2019-11-14	support kernel-4.19		

Content

ROCKCHIP I2C Developer Guide

- 1 I2C flow
 - 1.1 Trasmint only mode(I2C_CON[1:0]=2'b00)
 - 1.2 Mix mode (I2C_CON[1:0]=2'b01 or I2C_CON[1:0]=2'b11)
 - 1.3 Receive only mode (I2C_CON[1:0]=2'b10)
- 2 I2C Driver Parameter Configuration
 - 2.1 Configuration for drive i2c-rk3x.c
 - 2.2 Configuration for driver i2c-rockchip.c
- 3 I2C usage
 - 3.1 Kernel space
 - 3.2 User space
- 3 I2C tools
- 4 GPIO simulation as I2C
- 4 I2C FAQ
 - 4.1 i2c-rk3x.c Driver
 - 4.1.1 NACK Error
 - 4.1.2 Timeout Error

4.1.2.1 Case 1

4.1.2.2 Case 2

4.1.2.3 Case 3

4.2 i2c-rockchip.c Driver

4.2.1 NACK Error

4.2.2 Timeout Error

4.2.2.1 Case 1

4.2.2.2 Case 2


4.2.2.3 Case 3

4.2 I2C waveform


1 I2C flow

The flow of I2C is roughly the same on both drivers about kernel 4.4 and kernel 3.10. The write is a simple TX mode (I2C_CON[1:0] = 2'b00), while the read generally uses the TRX mode (I2C_CON[1:0] = 2'b01). The following I2C controller operational flow diagram describes how the software configures and performs I2C tasks by this I2C controller register. The description consists 3 parts, transfer mode, mixed mode and receive mode.


1.1 Trasmint only mode(I2C_CON[1:0]=2'b00)



1.2 Mix mode (I2C_CON[1:0]=2'b01 or I2C_CON[1:0]=2'b11)



1.3 Receive only mode (I2C_CON[1:0]=2'b10)




The above is the main flow of I2C, and please refer to driver code to get the further implement.

2 I2C Driver Parameter Configuration

The mainly part of parameter configuration I2C is the configuration of I2C frequency. The I2C frequency can be matched not only related to the chip but also I2C SCL and SDA rise time, because the I2C standard protocol has requirements for rising and falling edge time, especially rising time. If the maximum value specified by the protocol is exceeded, the I2C communication may fail. The following is the maximum and minimum value specified in the protocol and figure shows the relationship between them:

Symbol	Parameter	Standard-mode		Fast-mode		Fast-mode Plus		unit
Symbol		Min	Max	Min	Max	Min	Max	unit
fSCL	SCL clock frequency		100		400		1000	KHZ
Tr	rise time of both SDA		1000	20	300		120	ns
	and SCL signals							
Tf	fall time of both SDA		300	20×	300	20×	300	ns
	and SCL signals			(VDD/5.5V		(VDD/5.5V		

The rising edge Tr and the falling edge Tf need to be measured with an oscilloscope, refer to the following diagram:



The I2C driver i2c-rk3x.c and i2c-rockchip.c are not the same. The differences are as follows:

2.1 Configuration for drive i2c-rk3x.c

The configuration of the i2c-rk3x.c driver is in DTS, reference file is

Documentation/devicetree/bindings/i2c/i2c-rk3x.txt. Here highlight the configuration items,
i2c-scl-rising-time-ns, i2c-scl-falling-time-ns:

- clock-frequency: The default frequency is 100k, the default frequency can be remained, the other I2C frequencies need to do configuration. The maximum configurable frequency is determined by i2c-scl-rising-time-ns. For example to configure 400k, set clock-frequency=<400000>; at dts.
- i2c-scl-rising-time-ns: The rise time of SCL is determined by hardware and changing the pull-up resistor can adjust the time. It needs to be measured by oscilloscope, refer to the above figure; for example, measure the rise edge of SCL is 265ns, set i2c-scl-rising-time-ns=<265>; at dts. (The default rising time can be remained, but the current rising edge time must be ensured that it is under the maximum rising edge time which defined by the I2C standard for the configured frequency).
- i2c-scl-falling-time-ns: The SCL fall edge time, which has no change generally, is equivalent to i2c-sda-falling-time-ns. (The default is also no need to configure).

```
1 &i2c1 {
2    status = "okay";
3    i2c-scl-rising-time-ns = <265>;
4    i2c-scl-falling-time-ns = <11>;
5    clock-frequency = <400000>;
6
7    es8316: es8316@10 {
```

```
#sound-dai-cells = <0>;
compatible = "everest,es8316";
reg = <0x10>;
clocks = <&cru SCLK_I2S_8CH_OUT>;
clock-names = "mclk";
spk-con-gpio = <&gpio0 11 GPIO_ACTIVE_HIGH>;
hp-det-gpio = <&gpio4 28 GPIO_ACTIVE_LOW>;
};
};
```

2.2 Configuration for driver i2c-rockchip.c

The i2c-rockchip.c driver still follows the constraint relationship between the I2C frequency and the rise edge of SCL. Whether the higher frequency can be used depends on i2c-scl-rising-time-ns; the I2C frequency is configured on the code scl_rate member at the i2c_msg structure directly. The default frequency is still 100k, such as the following 200K configuration:

```
struct i2c_msg xfer_msg;

xfer_msg[0].addr = client->addr;

xfer_msg[0].len = num;

xfer_msg[0].flags = client->flags;

xfer_msg[0].buf = buf;

xfer_msg[0].scl_rate = 200 * 1000; /* 200K i2c clock frequency */
```

3 I2C usage

The further instructions for using I2C are in <code>Documentation/i2c/*</code>. The following sections focus on the read and write sections:

3.1 Kernel space

Rockchip I2C sending and receiving communication uses the standard interface of Linux. Please refer to the Documentation/i2c/writing-clients under kernel for a description of the sending and receiving section.

3.2 User space

Typically, I2C devices are controlled by the kernel driver. However, all devices on the bus can also be accessed from the user mode through the <code>/dev/i2c-%d</code> interface. <code>Documentation/i2c/dev-interface</code> under the kernel has further descriptions and examples.

3 I2C tools

I2C tool is an open source tool, you can download it and cross-compile. The code download address is: https://www.kernel.org/pub/software/utils/i2c-tools/ OR <git clone git://git.kernel.org/pub/scm/utils/i2c-tools/i2c-tools.git>

After compiling, it will generate tools such as i2cdetect, i2cdump, i2cset, i2cget, i2cget, i2ctransfer, which can be used directly on the command line. The I2C tool are all open source. Please refer to the README and help instructions for compilation and using.

4 GPIO simulation as I2C

I2C is simulated with GPIO and the kernel has been implemented. Please refer to the documentation:

Documentation/devicetree/bindings/i2c/i2c-gpio.txt

The following is an example of using I2C nodes at dts.

```
1
            i2c@4 {
 2
                    compatible = "i2c-gpio";
 3
                    gpios = <&gpio5 9 GPIO_ACTIVE_HIGH>, /* sda */
                            <&gpio5 8 GPIO ACTIVE HIGH>; /* scl */
 4
 5
                     i2c-gpio, delay-us = <2>; /* ~100 kHz */
                     #address-cells = <1>;
 6
                     \#size-cells = <0>;
                    pinctrl-names = "default";
 8
                    pinctrl-0 = <&i2c4_gpio>;
 9
                    status = "okay";
11
                    gt9xx: gt9xx@14 {
13
                             compatible = "goodix,gt9xx";
                             reg = <0x14>;
14
15
                             touch-gpio = <&gpio5 11 IRQ_TYPE_LEVEL_LOW>;
16
                             reset-gpio = <&gpio5 10 GPIO_ACTIVE_HIGH>;
17
                             max-x = <1200>;
                             max-y = <1900>;
18
                             tp-size = <911>;
19
20
                             tp-supply = <&vcc_tp>;
                             status = "okay";
21
22
                     };
23
            };
```

GPIO method is generally not recommended due to low efficient.

Because we have two i2c drivers, so this chapter still have two parts:

4.1 i2c-rk3x.c Driver

4.1.1 NACK Error

If the return value of the I2C transport interface is [-6 (-ENXIO)], it is indicated as a NACK error, that is, the slave device does not respond, this problem usually is located at peripheral. The following are common cases:

- I2C address is incorrect;
- The I2C slave device is in an error working state, such as no power-on, incorrect power-on sequence, and device error.
- The I2C timing does not meet the requirements of the slave device, which also generates a NACK signal.
 For example, the slave device needs the stop signal while receives the repeat start signal, NACK signal will occur.
- The I2C bus bug caused by external signal can be seen when measured with an oscilloscope.

4.1.2 Timeout Error

4.1.2.1 Case 1

When I2C log is timeout, ipd: 0x00, state: 1 occurs, the I2C controller is working irregularly and it cannot generate an interrupt status, the start timing cannot be sent. There are several possibilities:

- I2C SCL or SDA Pin IO-MUX error;
- The pull-up voltage of I2C is incorrect, such as insufficient voltage or with no pull-up power supply;
- The I2C pin is held by the peripheral hardware and the voltage is incorrect;
- The I2C clock is not enabled, or the clock source is too small;
- I2C is configured with both the CON_START and CON_STOP bits.

4.1.2.2 Case 2

When the I2C log is timeout, ipd: 0x10, state: 1 occurs, the I2C controller is working properly, but the CPU cannot respond to the I2C interrupt. At this time, cpu0 may be blocked (generally the I2C interrupt is on cpu0, It can be viewed by command cat /proc/interrups), or the I2C interrupt source may be turned off make the irq can not trigger cpu to handle it.

4.1.2.3 Case 3

When the I2C log is timeout, ipd: 0x80, state: 1 occurs, the ipd is 0x80, which means that the current SCL is held by the slave, you need to find it was held by which slave for more slave case:

- The first method is exclusion, which is applicable to the case where there are not many peripherals, and the probability of recurrence is high;
- Second method, the hardware needs to be modified. The resistor is serially connected to the SCL bus. The voltage difference generated across the resistor is used to determine that the lower-side peripheral is the slave that is pulled low. The selection of the resistor can not affect the I2C transmission, which also should generate voltage difference. Generally, it can be 1/20 of the pull-up resistor or more. And the voltage difference can also be seen if the host pulled down the voltage. In addition, based on this, it is more intuitive to capture the waveform through the oscilloscope. Compare the low level voltage of different slaves and host, find the low level voltage which matches the value while problem occurring. The corresponding slave devices or host which equals the low level voltage value is the reason to pull down the voltage of the bus.

The common situation is that SDA is pulled down. To prove who is pulling down, also refer to the above method of "SCL is pulled down".

4.2 i2c-rockchip.c Driver

4.2.1 NACK Error

If the return value of the I2C transport interface is [-11 (-EAGAIN)], it is indicated as a NACK error, that is, the other device does not respond. This problem usually is located at slave devices. The following are common cases:

- I2C address is incorrect;
- The I2C slave device is in an error working state, such as no power-on, incorrect power-on sequence, and device error.
- The I2C timing does not meet the requirements of the slave device, which also generates a NACK signal. For example, the slave device needs the stop signal while receives the repeat start signal, NACK signal will occur
- The I2C bus bug caused by external signal can be seen when measured with an oscilloscope.

4.2.2 Timeout Error

4.2.2.1 Case 1

When I2C log is timeout, ipd: 0×00 , state: 1 occurs, the I2C controller is working irregularly and it cannot generate an interrupt status, the start timing cannot be sent. There are several possibilities:

- I2C SCL or SDA Pin IO-MUX error;
- The pull-up voltage of I2C is incorrect, such as insufficient voltage or with no pull-up power supply;
- The I2C pin is held by the peripheral hardware and the voltage is incorrect.
- The I2C clock is not enabled, or the clock source is too small;
- I2C is configured with both the CON START and CON STOP bits.

4.2.2.2 Case 2

When the I2C log is timeout, ipd: 0x10, state: 1 occurs, the I2C controller is working properly, but the CPU cannot respond to the I2C interrupt. At this time, cpu0 may be blocked (generally the I2C interrupt is on cpu0, It can be viewed by command cat /proc/interrups), or the I2C interrupt source may be turned off make the irq can not trigger cpu to handle it.

4.2.2.3 Case 3

When the I2C log timeout, ipd: 0x80, state: 1 occurs, here ipd is 0x80, or the printed scl was hold by slave, which means that the current SCL is held by the slave, you need to find it was held by which slave for more slave case:

- The first method is exclusion, which is applicable to the case where there are not many peripherals, and the probability of recurrence is high;
- Second method, the hardware needs to be modified. The resistor is serially connected to the SCL bus. The voltage difference generated across the resistor is used to determine that the lower-side peripheral is the slave that is pulled low. The selection of the resistor can not affect the I2C transmission, which also should generate voltage difference. Generally, it can be 1/20 of the pull-up resistor or more. And the voltage difference can also be seen if the host pulled down the voltage. In addition, based on this, it is more intuitive to capture the waveform through the oscilloscope. Compare the low level voltage of different slaves and host, find the low level voltage which matches the value while problem occurring. The corresponding slave devices or host which equals the low level voltage value is the reason to pull down the voltage of the bus.

The common situation is that SDA is pulled down. To prove who is pulling down, also refer to the above method of SCL is pulled down.

When the log is i2c is not in idle (state =x) occurs, it indicates that at least one I2C bus is low. For the solution, refer to the above:

- "state=1" means SDA is low;
- "state=2" means SCL is low;
- "state=3" means SCL and SDA are both low.

4.2 I2C waveform

If the I2C problem you meet is not mentioned here, the best way is to grab the waveform when the I2C error occurs and analyze the I2C problem through the waveform. The waveform of I2C is very useful, which can figure out most of the problems; You can operate to stuck the current i2c task(sch as while(1), etc.) while error occurring, the finally captured in oscilloscope is the waveform for the error. If you need to filter, you can also add the condition such as the device I2C address, etc.