

Document	Global Top Binary Sentence Function Specification				
Author	Hector Su	Date	2011.10.27	Ver.	1.3



Global Top Custom-made Function Specification

V 1.3

The document is the exclusive property of GlobalTop Tech Inc. and should not be distributed, reproduced, or any other format without prior permission of GlobalTop Tech Inc. 本資料為宇誠科技專有之財產,非經許可,不得複製或轉換成其他形式使用。
Specifications subject to change without prior notice. 規格如有變更不另行通知。



Document	Global Top Binary Sentence Function Specification				
Author	Hector Su	Date	2011.10.27	Ver.	1.3

Version History

	History				
Date	Rev.	Author	Description		
2010.05.26	1.0	Hector Su	1 ST Release		
2010.07.06	1.1	Hector Su	2 nd Release		
2010.12.01	1.2	Hector Su	3 rd Release		
2011.10.27	1.3	Hector Su	4 th Release		
			Name And		

The document is the exclusive property of GlobalTop Tech Inc. and should not be distributed, reproduced, or any other format without prior permission of GlobalTop Tech Inc. 本資料為宇誠科技專有之財產,非經許可,不得複製或轉換成其他形式使用。
Specifications subject to change without prior notice. 規格如有變更不另行通知。

GlobalTop Tech Inc.

No.16 Nan-ke 9th Rd., Science-based Ind. Park, Tainan 741-47, Taiwan R.O.C

Tel:+886-6-5051268 Fax:+886-6-5053381 http://www.gtop.info email: sales@gtop-tech.com

© Copyright 2011 GlobalTop Tech Inc.



Document	Global Top Binary Sentence Function Specification				
Author	Hector Su	Date	2011.10.27	Ver.	1.3

1. Provide Function

1.1

It supports to output custom-made sentence. It provides 3 modes:

- 1. Binary Sentence
- 2. Standard NMEA Sentence (default)

The format is shown in **Table 1**.

1.2

It supports custom-made command to switch mode between **Binary Sentence** and **Standard NMEA Sentence** mode, the format of command is shown in **Table 2**.

The document is the exclusive property of GlobalTop Tech Inc. and should not be distributed, reproduced, or any other format without prior permission of GlobalTop Tech Inc. 本資料為宇誠科技專有之財產,非經許可,不得複製或轉換成其他形式使用。
Specifications subject to change without prior notice. 規格如有變更不另行通知。



Document	Global Top Binary Sentence Function Specification				
Author	Hector Su	Date	2011.10.27	Ver.	1.3

Table 1 Custom-made Data Format

Name	Example	Units	Description
Preamble header	0x04 0x24	2 bytes	Preamble header
UTC Time	0x03	4 bytes	UTC Time(hhmmss.sss)
	0xDF	MSB to	064951.000*(10^3)=64951000 →
	0x12	LSB ^(Note 2.3)	0x03DF12D8
	0xD8		
Date	0x00	4 bytes	Date(ddmmyy)
	0x01	MSB to	20101008 →81010 →
	0x3C	LSB	0x00013C72
	0x72		
Latitude	0x01	4 bytes	Latitude (in decimal degrees)
	0x60	MSB to	23.098572*(10^6)=23098572 →
	0x74	LSB	0x016074CC
	0xCC		
N/S Indicator	0x01	1 byte	0x01→North or 0x02 →South
Longitude	0x07	4 bytes	Longitude (in decimal degrees)
	0x2B	MSB to	120.284383*(10^6)=120284383 →0x072B64DF
	0x64	LSB	
	0xDF		
E/W Indicator	0x01	1 byte	0x01→East or 0x02 →West
Fix Quality	0x03	1 byte	0x01 :GPS No Fix
			0x02 :2D GPS Fix
			0x03 :3D GPS Fix

The document is the exclusive property of GlobalTop Tech Inc. and should not be distributed, reproduced, or any other format without prior permission of GlobalTop Tech Inc. 本資料為宇誠科技專有之財產,非經許可,不得複製或轉換成其他形式使用。
Specifications subject to change without prior notice. 規格如有變更不另行通知。

GlobalTop Tech Inc.

No.16 Nan-ke 9th Rd., Science-based Ind. Park, Tainan 741-47, Taiwan R.O.C

Tel:+886-6-5051268 Fax:+886-6-5053381 http://www.gtop.info email: sales@gtop-tech.com

© Copyright 2011 GlobalTop Tech Inc.



Document	Global Top Binary Sentence Function Specification				
Author	Hector Su	Date	2011.10.27	Ver.	1.3

Fix Mode	0x01	1 byte	0x00 →GPS No Fix
			0x01 →GPS Fix without DGPS mode
			0x02 → GPS Fix with DGPS mode
Altitude	0x00	4 bytes	Altitude of current position (meter)
	0x00	MSB to	39.95 → 39.95*100=3995 → 0x00000F9B
	0x0F	LSB	
	0x9B		
Course over	0x00	4 bytes	Course over ground(in degree)
ground	0x00	MSB to	58.16 → 58.16*100=5816 → 0x000016B8
	0x16	LSB	
	0xB8		
Speed over	0x00	4 bytes	Ground Speed(km/hr)
ground	0x00	MSB to	0.62 → 0.62*100=62 → 0x0000003E
	0x00	LSB	
	0x3E		
Satellites in view	0x0A	1 byte	Number of satellite is in viewed
Satellites in used	0x09	1 byte	Number of satellite is in used
HDOP	0x00	2 bytes	Horizontal Dilution of Precision
	0x69	MSB to	1.05 → 1.05*100=105→0x0069
		LSB	
EPE	0x01	2 bytes	Estimated position error (meter)
	0x0D	MSB to	2.69 →2.69*100=269→0x010D
		LSB	
Asterisk	0x2A	1 byte	
Checksum	0x47	1 byte	(Note 2.2)
End Word	0x0D 0x0A	2 bytes	End of message termination (ASCII 13, ASCII 10)

The document is the exclusive property of GlobalTop Tech Inc. and should not be distributed, reproduced, or any other format without prior permission of GlobalTop Tech Inc. 本資料為宇誠科技專有之財產,非經許可,不得複製或轉換成其他形式使用。
Specifications subject to change without prior notice. 規格如有變更不另行通知。

GlobalTop Tech Inc.

No.16 Nan-ke 9th Rd., Science-based Ind. Park, Tainan 741-47, Taiwan R.O.C

Tel:+886-6-5051268 Fax:+886-6-5053381 http://www.gtop.info email: sales@gtop-tech.com

© Copyright 2011 GlobalTop Tech Inc.



Document	Global Top Binary Sentence Function Specification				
Author	Hector Su	Date	2011.10.27	Ver.	1.3

Table 2 Custom-made Command Format

Name	Example	Units	Description
Message ID	\$PGCMD		Custom-made header of command
Number of command	21		This number represents which command is used
Selection of mode	1		Selection of mode
			1→Binary Sentence mode
			3→Standard NMEA Sentence mode
Checksum	*6F		(Note 2.1)
<cr> <lf></lf></cr>			End of message termination (ASCII 13, ASCII 10)

Caution 1: When switch back to Standard NMEA mode, the period of sentence will be GGA(1), GSA(1), GSV(5), RMC(1), VTG(1), GLL(0), ZDA(0).

Caution 2: The command has the different parameter and acknowledge. The format of acknowledge is shown in Table 3.

Example:

- \$PGCMD,21,1*6F<CR><LF>
- \$PGCMD,21,3*6D<CR><LF>

The document is the exclusive property of GlobalTop Tech Inc. and should not be distributed, reproduced, or any other format without prior permission of GlobalTop Tech Inc. 本資料為宇誠科技專有之財產,非經許可,不得複製或轉換成其他形式使用。
Specifications subject to change without prior notice. 規格如有變更不另行通知。



Document	Global Top Binary Sentence Function Specification				
Author	Hector Su	Date	2011.10.27	Ver.	1.3

Table 3 Custom-made Acknowledge Format

Name	Example	Units	Description
Message ID	\$PGACK		Custom-made header of command
Number of command	21		This number represents which acknowledge is used
Status	1		It supports 4 status: 1→Binary Sentence mode be set 3→Standard NMEA Sentence mode be set -1→Mode switch fail
Checksum	*6C		(Note 2.1)
<cr> <lf></lf></cr>			End of message termination (ASCII 13, ASCII 10)

Example:

- ❖ \$PGACK,21,1*6C<CR><LF>
- \$PGACK,21,3*6E<CR><LF>
- ❖ \$PGACK,21,-1*41<CR><LF>

The document is the exclusive property of GlobalTop Tech Inc. and should not be distributed, reproduced, or any other format without prior permission of GlobalTop Tech Inc. 本資料為宇誠科技專有之財產,非經許可,不得複製或轉換成其他形式使用。
Specifications subject to change without prior notice. 規格如有變更不另行通知。



Document	Global Top Binary Sentence Function Specification				
Author	Hector Su	Date	2011.10.27	Ver.	1.3

2. Note

2.1

The checksum will be calculated by Xor all characters between \$ and *.

2.2

The checksum will be calculated by Xor all bytes between Preamble header and Asterisk.

2.3

It converts decimal value to hex value, and it provides example below:

♦ (79)₁₀₌(4F)₁₆

Decimal Hex Conversion Chart:

 $(120)_{10} = (78)_{16}$

http://www.binaryhexconverter.com/decimal-to-hex-converter

♦ (64951000)₁₀=(03DF12D8)₁₆

Decimal	Hexadecimal		
0	0		
1	1		
2	2		
3	3		
4	4		
5	5		
6	6		
7	7		
8	8		
9	9		
10	А		
11	В		
12	С		
13	D		
14	E		
15	F		

The document is the exclusive property of GlobalTop Tech Inc. and should not be distributed, reproduced, or any other format without prior permission of GlobalTop Tech Inc. 本資料為宇誠科技專有之財產,非經許可,不得複製或轉換成其他形式使用。
Specifications subject to change without prior notice. 規格如有變更不另行通知。