- Cubic Interpolation
  Free form curves using higher order equation
  APT- Automatic Programmed Tool
  CAD- Computer Aided Design
  CAM-Computer Aided Manufacturing
  CIM-Computer Integrated Manufacturing