SPACE SPACE ENCOUNTERS PARTS AND OPERATING MANUAL



MIDWAY MFG. CO.

10750 WEST GRAND AVENUE
FRANKLIN PARK, ILLINOIS 60131
U.S.A.

TABLE OF CONTENTS

	Page No.
GENERAL INSTRUCTIONS	1—2
SWITCH ADJUSTMENTS	3
NO. 645—SPACE ENCOUNTERS—PHOTOGRAPH	4-5
OPENED BACK VIEW PICTURE	6—7
CONTROL SHELF ASSEMBLY	8—10
EXPLOSION LIGHT ASSEMBLY	12—13
FRONT DOOR ASSEMBLY	14—15
TRANSFORMER BOARD ASSEMBLY	16—17
GAME LOGIC COMPONENT LAYOUT	18
GAME LOGIC R. R. C. LAYOUT	19
GAME LOGIC SCHEMATIC	21
MOTHER BOARD COMPONENT LAYOUT	23
MOTHER BOARD SCHEMATIC	24
POWER SUPPLY COMPONENT LAYOUT	25
POWER SUPPLY SCHEMATIC	26
SOUND GENERATOR SCHEMATIC	27
SOUND GENERATOR COMPONENT LAYOUT [FIRST 300 GAMES]	28
SOUND GENERATOR R.R.C. LAYOUT [FIRST 300 GAMES]	29
SOUND GENERATOR COMPONENT LAYOUT	30
STROBE & LIGHT P.C. COMPONENT LAYOUT	31
STROBE & LIGHT P.C. SCHEMATIC	33
WIRING SCHEMATIC	34
MONITOR SCHEMATIC [MOTOROLA]	35
MOTOROLA REPLACEMENT PARTS LIST	36—37
MONITOR SCHEMATIC [WELLS-GARDNER]	39
WELLS-GARDNER REPLACEMENT PARTS LIST	40—41
GAME LOGIC CHIP NUMBER & FUNCTION	42

WARNING

THIS GAME MUST BE GROUNDED. FAILURE TO DO SO MAY RESULT IN DESTRUCTION TO ELECTRONIC COMPONENTS.

COPYRIGHT 1980 @BY MIDWAY MFG. CO. ALL RIGHTS RESERVED.

NO PART OF THIS PUBLICATION MAY BE REPRODUCED BY ANY MECHANICAL, PHOTOGRAPHIC, OR ELECTRONIC PROCESS, OR IN THE FORM OF A PHONOGRAPHIC RECORDING, NOR MAY IT BE TRANSMITTED, OR OTHERWISE COPIED FOR PUBLIC OR PRIVATE USE, WITHOUT PERMISSION FROM THE PUBLISHER.

GENERAL INSTRUCTIONS FOR SPACE ENCOUNTERS

INSTALLATION

- 1. Remove shipping cleats located on bottom of cabinet.
- 2. Install four (4) provided leg levelers to bottom of cabinet and level cabinet.
- The power is controlled by a switch located on top of the cabinet. Plug into A.C. only, 115 volts, 60 cycles.

LINE VOLTAGE SAFETY SWITCH

A line voltage safety switch has been provided for your protection. It is located on the right rear side of the cabinet. When the door is removed, it opens the circuit to the line voltage. To restore power when servicing, pull switch fully out.

TO CENTER PICTURE

- 1. Place adjustment switch (5) "ON" and (6) "OFF". These switches are located on Game Logic (P.C. A084-90700-F645). Switch adjustment card is located in rear of cabinet area.
- 2. Adjust monitor so that cross-hatch is inside of viewing area.

TO SERVICE CONTROL PANEL

- 1. Open coin box door.
- 2. Release two (2) clamps, located on each side of cabinet.
- 3. Disconnect control cable jack if removing unit from cabinet.

TO ADJUST CONTROL PANEL VERTICAL AND HORIZONTAL ENCODERS

- 1. Place adjustment switch (5) "OFF" and (6) "ON".
- 2. Press trigger button, located on steering control to set encoder test mode.
- 3. Loosen set screws on vertical encoder gear (at rear of assembly).
- 4. Rotate encoder shaft until defense ship stops in lower part of the viewing area. NOTE: Steering control must be in it's furthest out position.
- 5. Tighten set screws.
- 6. Loosen set screws on horizontal encoder gear.
- 7. Hold hand grips in a horizontal position and rotate encoder shaft until defense ship is in center of screen.
- 8. Tighten set screws.




FIGURE I

During this test mode, you can play the game without the defense ship being hit to check:

- a. Coin switch
- b. Trigger switch
- c. Score and bonus
- d. All sounds (except defense ship hit)
- e. Defense ship travel
- f. Reset switches (5) and (6)

VOLTAGE CONTROL POTS

Located on Power Supply Board (P.C. A084-91324-F645) and are preset at the factory. These pots should not be tampered with unless the distributor service department is contacted.

VOLUME CONTROL

Located on sound board (P.C. A084-91324-0645) controls the volume of all sounds and may be varied as desired by rotating pot control.

STROBE LITE ASSEMBLY

Located on top shelf of game. Before servicing this unit, turn off game and wait three (3) minutes to avoid shock.

CLEANING OF PICTURE TUBE, GLASS & PLEXI

- 1. Remove control panel.
- 2. Remove screws at bottom of plastic viewing bezel. Remove bezel.
- 3. Remove two (2) brackets holding the clear front glass and lift out.
- 4. Remove two (2) brackets from bottom of interior shelf to lower screened plexi-glass for cleaning.

ELECTRICAL BULLETIN: FOR ALL APPARATUS COVERED BY THE CANADIAN STANDARDS ASSOCIATION (CSA) STANDARD C22.2 NO. 1, WHICH EMPLOYS A SUPPLY CORD TERMINATED WITH A POLARIZED 2-PRONG ATTACHMENT PLUG.

CAUTION:

TO PREVENT ELECTRIC SHOCK DO NOT USE THIS (POLARIZED) PLUG WITH AN EXTENSION CORD, RECEPTACLE OR OTHER OUTLET UNLESS THE BLADES CAN BE FULLY INSERTED TO PREVENT BLADE EXPOSURE.

ATTENTION:


POUR PREVENIR LES CHOCS ELECTRIQUES NE PAS UTILISER CETTE FICHE POLARISEE AVEC UN PROLONGATEUR. UNE PRISE DE COURANT OU UNE AUTRIE SORTIE DE COURANT, SAUF SI LES LAMES PEUVENT ETRE INSEREES A FOND SANS EN LAISSER AUCUNE PARTIE A DECOUVERT.

SWITCH ADJUSTMENTS

ſ	BONUS AT	
	SW. 1	SW. 2
2000, 4000, 8000 PTS.	ON	ON
3000, 6000, 12000 PTS.	OFF	ON
4000, 8000, 16000 PTS.	ON	OFF
5000, 10000, 20000 PTS.	OFF	OFF
MET	HOD OF PLAY	
	SW. 3	SW. 4
1 COIN - 1 PLAY	ON	ON
2 COINS — 1 PLAY	OFF	ON
1 COIN - 3 PLAYS	ON	OFF
2 COINS – 3 PLAYS	0FF	0FF
	SW. 5	SW. 6
BONUS	ON	ON
NO BONUS	OFF	OFF
CROSS HATCH	ON	OFF
RAM-ROM TEST	OFF	ON
ENCODER ALIGNMENT		
TIN	ME OF PLAY	
	SW. 7	SW. 8
45 SECONDS	ON	ON
60 SECONDS	OFF	ON
75 SECONDS	ON	OFF
90 SECONDS	OFF	OFF

M051-00645-A012


NO. 645 - SPACE ENCOUNTERS - PHOTOGRAPH



NO. 645 - SPACE ENCOUNTERS - PHOTOGRAPH ORDER BY PART NUMBER ONLY


	UNDEN	BI PART NUMBER ONLT	
ITEM	PART Nº	DESCRIPTION	
1 1	A645-00020-0000	PLASTIC BEZEL ASSY.	
2	0645-00919-0000	COLORED SCREEN OVERLAY	
3	0645-00910-0000	FRONT GLASS — 23-9/16" x 20" x 3/16"	
	0537-00903-0017	GLASS CHANNEL – 18-3/4" LG. (2 REQ'D.)	
1	0537-00903-0034	GLASS CHANNEL – 23" LG.	
	0629-00902-0700	GLASS LIFT CHANNEL 23-1/4" LG.	
	0645-00108-00XF	GLASS LOCK BRKT. (2 REQ'D.)	
4	0645-00916-0000	COCKPIT LIGHTS INSERT	
	0645-00506-0000	COCKPIT LIGHTS PANEL	
	0645-00111-0000	SUPPORT BRKT. (2 REQ'D.)	
	0017-00031-0030	WEDGE BASE LIGHT SOCKET (8 REQ'D.)	
	0017-00003-0182	7V., .43 AMP WEDGE LAMP (8 REQ'D.)	
	A645-00032-0000	COCKPIT LIGHTS CABLE ASSY.	
5	0645-00900-00XF	SCENERY CARD — BOTTOM	
	0645-00901-00XF	SCENERY CARD — RIGHT (NOT SEEN)	
	0645-00901-01XF	SCENERY CARD — LEFT (NOT SEEN)	
	0645-00902-00XF	SCENERY CARD — BACK (NOT SEEN)	
6	0645-00100-00XF	CONTROL SHELF PLATE	
7	0017-00102-0019	1/4-20 x 1-1/2 CARRIAGE BOLT (4 REQ'D.)	
	0017-00103-0018	1/4-20 HEX NUT (4 REQ'D')	
	0017-00104-0005	1/4 SPLIT LOCK WASHER (4 REQ'D.)	
8	0017-00101-0639	#8-32 x 1-1/4 CARRIAGE BOLT (4 REQ'D:)	
	0017-00103-0061	#8-32 HEX NUT (4 REQ'D.)	
	0017-00104-0022	#8 FLAT WASHER (4 REQ'D.)	
9	0017-00101-0062	#6 x 3/4 PHIL. PAN HD. SCREW (3 REQ'D')	
10	0017-00009-0393	SPEAKER GRILL & HARDWARE	
	0017-00003-0187	SPEAKER	
11	0017-00101-0642	#8-32 x 1-1/2 CARRIAGE BOLT (4 REQ'D.)	
12	A090-00020-2001	DOUBLE ENTRY COIN DOOR ASSY.	
42	A090-00057-0000	COIN METER ASSY. COIN DOOR FRAME	
13	0090-00002-02GR 0017-00101-0121	#6-32 x 5/16 PHIL. TRUS HD. M.S. (3 REQ'D.)	
	0017-00101-0121	(MOUNTS COIN DOOR TO FRAME)	
14	0645-00911-0000	ALUMINUM STEP	
15	0017-00102-0048	LEG LEVELERS (4 REQ'D.)	
'3	0017-00102-0048	LEG LEVELER NUTS (4 REQ'D.)	
	0017 00100-0020	NOT SHOWN LIST	
	0017-00009-0033	BASSICK CLAMP (2 REQ'D.)	
	0603-00131-0000	STRIKE (2 REQ'D.)	
	0645-00107-00XF	SPRING BRKT. (MOUNTS STEERING,	
	3010 00107 00/01	CONTROL SPRING TO CABINET SIDE).	

NO. 645 - SPACE ENCOUNTERS - BACK PICTURE



NO. 0645 - SPACE ENCOUNTERS - BACK PICTURE ORDER BY PART NUMBER ONLY

	UNDER	BI PART NUMBER ONLT
ITEM	PART Nº	DESCRIPTION
1	A082-90400-H000	POWER SUPPLY P.C.B. ASSY.
2	A082-90000-L645	MOTHER P.C.B. ASSY.
3	A084-90700-G645	GAME LOGIC P.C.B. ASSY.
4	A084-91324-F645	SOUND P.C.B. ASSY.
	0624-00902-0100	P.C. SUPPORT BRKT. 12" (5 REQ'D.)
	0624-00902-0300	P.C. SUPPORT BRKT. 2-1/2" (7 REQ'D.)
	0017-00101-0025	#8 x 1/2 HEX HD. WOOD SCREW (29 REQ'D.)
	0017-00104-0037	#8 FLAT WASHER (29 REQ'D.)
5	A905-00022-0000	TRANSFORMER BOARD ASSY.
6	0017-00003-0199	22" CATHODE RAY TUBE
7	0017-00003-0198	22" CHASSIS
	0017-00003-0322	22" C.R.T. YOKE
	A739-00010-0000	DAG SPRING ASSY.
	3000-17175-0000	GROUND STRAP
	0592-00104-0100	CHASSIS MTG. BRKT. R.H.
	0592-00104-0200	CHASSIS MTG. BRKT. L.H.
	0645-00502-0000	CHASSIS PANEL
8	0017-00101-0637	#8-32 x 1 CARRIAGE BOLT (4 TUBE, 4 CHASSIS)
	0017-00104-0022	#8 FLAT WASHER (4 TUBE, 4 CHASSIS)
	0017-00103-0061	#8-32 HEX NUT SEMS (4 TUBE, 4 CHASSIS)
9	0017-00032-0005	ON-OFF SWITCH
	0567-00106-0100	SWITCH MTG. PLATE
	0017-00101-0025	#8 x 1/2 SLOT HEX HD. WOOD SCREW (4 REQ'D.)
10	A645-00022-00XF	INTERLOCK SWITCH BRKT. ASSY.
	0017-00003-0225	INTERLOCK SWITCH
11	A622-00018-0000	COIN DOOR CABLE ASSY.
12	A645-00033-0000	CONTROL SHELF CABLE ASSY.
13	A645-00034-0000	MASTER CABLE ASSY.
		ADDITIONAL PARTS LIST
	A097-00001-0000	LOCK ASSY BACK DOOR (2 REQ'D.)
	0017-00009-0490	VENT SCREEN (4 REQ'D.)
	0017-00009-0477	MOLDED CASH BOX
	A623-00013-0000	COIN BOX COVER ASSY.
	A624-00001-0000	COIN BOX GUIDE BRKT. ASSY.
	0624-00101-0000	COIN BOX GUIDE BRKT.
[




NO. 645 - SPACE ENCOUNTERS - CONTROL SHELF ASSY.

ITEM	PART Nº	DESCRIPTION
1	A645-00006-00XF	BASE & BRACE ASSY.
2	0645-00106-00XF	STOP BRKT.
3	0017-00101-0652	#10-32 3/8 SLOT PAN HD. S.M.S. (9 REQ'D.)
4	A645-00011-0000	BASE - TUBE & HANDLE ASSY.
5	0017-00032-0004	SWITCH
6	0017-00033-0334	CABLE - 2 LEAD
7	M033-00100-0001	SHRINK TUBING (2 REQ'D.)
8	0010-00225-0200	CABLE GUARD
9	0017-00101-0307	#8-32 x 1/8 SETSCREW (2 REQ'D.)
10	0017-00009-0443	GRIP
11	0645-00917-0000	GRIP
12	0017-00021-0009	15/32-32 ROUND NUT
13	0645-00912-0000	CONTROL INSERT
14	0017-00101-0116	#10-32 \times 1/4 TAMPER PROOF SCREW (2 REQ'D.)
15	0017-00041-0617	RING - NEOPRENE (2 REQ'D.)
16	0645-00913-0000	WASHER - FRICTION (2 REQ'D.)
17	0645-00905-0000	SHROUD
18	A645-00012-0000	PEDESTAL ASSY.
19	0017-00102-0019	1/4-20 x 1-1/2 CARRIAGE BOLT (4 REQ'D.)
20	0017-00104-0005	1/4 SPLIT LOCK WASHER (4 REQ'D.)
21	0017-00103-0018	1/4-20 HEX NUT (4 REQ'D.)
22	A645-00008-00XF	STOP PLATE & HUB ASSY.
23	0017-00042-0016	SNAP BUSHING
24	A082-91101-B000	ENCODER (2 REQ'D.)
25	A645-00024-0000	GEAR & BUSHING ASSY.
26	0017-00101-0309	#8-32 x 1/4 SET SCREW (2 REQ'D.)
27	0017-00101-0658	#10-32 x 5/8 PHIL. PAN HD. SCREW (4 REQ'D.)
28	0017-00104-0032	FLAT WASHER (4 REQ'D.)
29	0645-00906-0000	BEARING (2 REQ'D.)
30	0645-00907-0000	RUBBER ROLLER (2 REQ'D.)
31	0017-00100-0031	E-RING (3 REQ'D.)
32	0017-00101-0652 0017-00033-0329	#10-32 x 3/8 SLOT. PAN HD. SCREW (2 REQ'D.) CABLE ASSY.
33	0645-00915-0000	INSULATOR STRIP
34 35	A645-00039-0000	CLAMP BRKT. & SPRING PLT. ASSY.
36	0017-00101-0598	#8-32 x 5/16 SLOT HEX HD. SCREW
37	0017-00101-0330	SPRING
38	0645-00117-00XF	"Z" - BRKT.
39	A645-00007-0000	GEAR & BUSHING ASSY.

NO. 645 - SPACE ENCOUNTERS - CONTROL SHELF ASSY.

ITEM	PART Nº	DESCRIPTION
40 41	0645-00702-00XF	ANTI-ROTATION ROD NYLON ROLLER
41	0645-00908-0000 0017-00100-0015	E-RING
43	0017-00100-0015	NYLINER 1-1/4
44	0645-00708-00XF	COLLAR
45	A645-00025-0000	PLUG & BEARING ASSY.
46	0645-00710-00XF	ANTI-TWIST SHAFT
47	0030-00125-0000	NYLON WASHER (4 REQ'D.)
48	0017-00100-0037	E-RING
49	A645-00010-0000	ARM & GEAR ASSY.
50	0645-00701-00XF	ROLLER
51	0645-00700-00XF	PIN
52	0017-00100-0018	E-RING (2 REQ'D.)
53	A645-00009-0000	BRKT. & PIN ASSY.
54	0583-00723-00B0	PINION - 16 TOOTH
55	0017-00101-0308	#8-32 x 3/16 SETSCREW (2 REQ'D.)
56	0010-00265-0000	SPRING
	0017-00009-0484	TAMPER PROOF ALLEN KEY (NOT SHOWN)
		THE FOLLOWING PARTS USED TO ATTACH ITEM 22 TO SHAFT
	0645-00712-00XF	PIN
	0017-00100-0037	E-RING (2 REQ'D.)
	0017-00102-0042	1/4-20 x 3/4 SOCKET HD. CAP SCREW
	:	




MIDWAY MFG. CO.

NO. 645 - SPACE ENCOUNTERS - EXPLOSION LIGHT ASSY.

ITEM	PART Nº	DESCRIPTION
Mail	FAKI NY	
1	0645-00115-0000	EXPLOSION LIGHT MTG. BRKT.
2	0017-00003-0135	LAMPSOCKET
3	0017-00101-0026	#8-32 x 5/8 SLOT HEX HD. SCREW (2 REQ'D.)
4	0017-00103-0061	#8-32 HEX NUT SEMS (2 REQ'D.)
5	0760-00945-00XF	LAMP GE 200 W RED
6	0017-00042-0231	STANDOFF 3/4 (4 REQ'D.)
7	A084-91359-B645	EXPLOSION P.C. BOARD
8	0017-00042-0232	STANDOFF 1-3/8 (4 REQ'D.)
9	0069-156XX-XXIX	FLASH TUBE - FT19-30K
10	0069-157XX-XXIX	REFLECTOR
11	0017-00042-0233	TENSION CLIP
12	0017-00101-0555	#6-32 x 5/16 SLOT HEX HD. SCREW
13	0017-00104-0019	#6 FLAT WASHER
14	0645-00116-0000	STROBE LIGHT HOUSING BRKT.
15	0645-00114-0000	STROBE LIGHT GUARD
16	0017-00101-0598	#8-32 x 5/16 SLOT HEX HD. SCREW (3 REQ'D.)
17	0645-00918-0000	GROMMET (2 REQ'D.)
	A645-00030-0000	STROBE LIGHT CABLE ASSY. (NOT SHOWN)
ļ		
1		
1		


NO. 645 - SPACE ENCOUNTERS - FRONT DOOR ASSY.



NO. 645 - SPACE ENCOUNTERS - FRONT DOOR ASSY.

	UNDEN	BI PARI NUMBER ONLI
ITEM	PART Nº	DESCRIPTION
1	0090-00902-0000	DRESS PLATE
•	0090-00902-0100	DRESS PLATE (W/O PRESS BUTTON TO
		START GAME)
2	0017-00101-0552	#6-32 x 1/4 CARRIAGE BOLT (2)
3	0090-00117-03XF	COIN ENTRY PLATE (25¢)
4	0090-00906-0000	PLASTIC START BUTTON
5	0010-00007-0000	COMPRESSION SPRING
6	0090-00013-0200	DOOR ASSY. DOUBLE ENTRY
7	0017-00005-0050	DOOR LOCK & KEY WITH SCREW & NUT
8	0090-00002-02BR	DOUBLE DOOR FRAME
9	0017-00005-0041	421 N.S. CAM
10	0090-00901-0000	DOOR SWITCH
11	0090-00126-01XF	SWITCH BACKUP PLATE
12	0017-00101-0528	#5-40 x 3/4" LNG. M.S.
13	0090-00903-0040	25¢ WINDOW
14	0090-00143-0000	COIN PLEX RETAINER
15	0017-00104-0002	SPLIT LOCK WASHER
16	0017-00007-0019	KEY HOOK
17	0017-00103-0005	#6-32 HEX NUT
18	0090-00010-0000	SW. PLATE & OILLITE ASSY.
19	0017-00100-0018	"E" RING
20	0090-00131-0000	SWITCH TOP & BTM. COIN CHUT W/BRKT. ASSY.
21	0090-00104-0000	#8-32 x 5/16 SCREW
22	0017-00101-0598 0010-00181-0100	SPRING
23 24	0090-00129-00XF	PIVOT POST
24 25	0010-00134-0000	SPRING
26 26	0090-00008-0000	ACCEPTOR FRAME ASSY.
27	0093-00155-00XF	REJECTOR LEVER
28	0017-00100-0012	"E" RING
29	0093-00151-00XF	COIN GUIDE MTG. BRACKET
30	0090-00005-0000	COIN GUIDE ASSY.
31	0017-00101-0555	#6-32 x 5/16 SCREW
32	0017-00005-0039	COIN SWITCH
33	0010-00557-2500	TRIP WIRE
34	0017-00007-0132	PUSH-ON RING (BIK)
35	0017-00101-0507	#4-36 x 3/4 SCREW
36	0090-00128-00XF	SWITCH BRKT DOOR TILT
	A090-00061-0000	ANTI-STRING DEVICE ASSY OPTIONAL
-		(REPLACES ITEM 30)
	A090-00064-0000	ANTI-PENNY DEVICE ASSY.

NO. 645 - SPACE ENCOUNTERS - TRANSFORMER BOARD ASSY.




MIDWAY MFG. CO.


NO. 645 - SPACE ENCOUNTERS - TRANSFORMER BOARD ASSY.

	UNDEN	BI PART NUMBER ONLT
ITEM	PART Nº	DESCRIPTION
1	MT00-00058-0000 MT00-00059-0000	TRANSFORMER — 60 CYCLE — DOMENTIC (OR) TRANSFORMER — 50 CYCLE — FOREIGN
2	0017-00101-0017	#6 x 1/2 SLT. HEX HD. WD. SCR. (2 REQ'D.)
3	0017-00101-0637	#8-32 x 1" CARRIAGE BOLT (2 REQ'D.) WITH
	0017-00103-0008	#8-32 HEX NUT (2 REQ'D.)
4	0720-00001-0200	2 POSITION FUSE BLOCK
	0017-00003-0103	FUSE 1.5 AMP
	0017-00003-0103	FUSE 4 AMP
5		
) ³	0017-00101-0018	#6 x 3/4 SLT. HEX HD. SCREW (5 REQ'D.)
	0017-00003-0064	16 FT. LINE CORD — NOT SHOWN
İ :	0017-00003-0114	NOISE FILTER - NOT SHOWN
		·
	•	
	,	

* INDICATES O.IMF. 50V. AXIAL LEAD CERAMIC CAP.

PAGE 18








"SPACE ENCOUNTERS" MIDWAY MFG. CO. 10750 W. GRAND AVE. FRANKLIN PARK, IL. 60131

CONNECTOR'A


GAME LOGIC SCHEMATIC P.C. A084-90700-G645 PART NO. MOSI-00645-A001










MOTHER BOARD SCHEMATIC A084-90000-L000













COMPONENT LAYOUT PART NO. MO51-00645-A005


RRC LAYOUT PART NO. MO51-00645-A006











REF. NO.	PART NUMBER	DESCRIPTION	REF. NO.	PART NUMBER	DESCRIPTION
ELECTRICAL PARTS			COILS &	CHOKES	
	1Y25017A01	MONITOR PANEL: complete;	L-1	24D68822A08	HORIZ SET
	1Y25017A02	KT364LM POWER, Audio Panel: complete:	L-2 L-3	24D68801A67 24D69163A18	COMPENSATING: 2000 uh HORIZ LINEARITY
	1 7 250 1 7 A 02	KT365LM	L-4	24V25000A74	HORIZ WIDTH: incls C42 & R68
CAPACIT	ORS		L-5	24D68523A15	DEFLECTION YOKE
C-1	23C65282A41	50 mf 50V Lytic	TRANSI		1 × VIDEO: 46U
C-2	23C65282A41	50 mf 50V Lytic	Q-1 Q-2	48S137171 48S137127	1st VIDEO: A6H 2nd VIDEO: P2S
C-3 C-4	21S180D10 23C65282A41	220 pf 20% 100V X5F (Use 21R132503) 50 mf 50V Lytic	Q-3 Q-4	48S134919 48S137317	VIDEO OUTPUT: A1M VIDEO DRIVER: A8H
C-5	21S180B98 23S10255A78	180 pf 10% 500V X5F 470 mf 16V Lytic	Q-5	48\$137115	SYNC SEPERATOR: A5U
C-6 C-7	21S180C01	680 pf 10% 500V X5F	Q-6 Q-7	48S137172 48S137127	HORIZ OSCILLATOR: A6J HORIZ PULSE SHAPER: P2S
C-8 C-10	21S180B85 8S10191B67	560 pf 10% 500V X5F :22 mf 10% 250V Polyester	Q-8	48\$137093	HORIZ DRIVER: ASF
C-11	8\$10191A54	.0068 mf 10% 160V Polyester	Q-9 Q-10	48S137203 48S137173	HORIZ OUTPUT: A6Z VERT OSCILLATOR (1): P2W
C-12 C-13	21S180D10 21S131625	220 pf 20% 100V X5F (Use 21R132503) 330 pf 10% X5F	Q-11 Q-12	48S137171 48S137115	VERT OSCILLATOR (2): A6H VERT DRIVER: A5U
C-15	21S180C41	.0027 mf 10% 500V Z5F (Use 21K 121699)	Q-13	48S134900	VERT OUTPUT: A1C
C-16	23S10229A07	1.0 mf +40-20% 15V Lytic	Q-14 Q-15	48S134952 48S137315	REGULATOR DRIVER; A2J REFERENCE AMP: A8G
C-17	8510191890	(Use 23C43280A17) .033 mf 10% 160V Polyester	Q-16	48\$137368	REGULATOR: ASW
C-18	8S10299A73	.01 mf 10% 100V Poly carb	Q-17 Q-18	48S137172 48S137168	AUDIO DRIVER: A6J AUDIO OUTPUT: P2V
C-19 C-20	8S10299A74 8S10191B98	.0082 mf 10% 160V Poly carb .01 mf 10% 250V Polyester	Q-19 Q-20	48S137169 48S137344	5V REGULATOR, Driver: A6G 5V REGULATOR: A8U
C-21	21S180B51	.001 mf 10% 500V X5F .01 mf 10% 160V Polyester	Q-21	48S137476	SPOT KILLER: B1E
C-22 C-23	8S10191B98 21S180C02	10 pf 10% N150	CONTRO	OLS	
C-24 C-25	23D65282A40 21S180B51	150 mf 10V Lytic .001 mf 10% 500V X5F	R-5	18D68222A34	CONTRAST: 250 Ohm
C-26	8\$10212853	.47 mf 10% 630V Mtlz Poly	R-10	18D66401A44	VIDEO BIAS: 4K
C-27 C-28	8S10212A11 8S10571A06	1.0 mf 10% 630V Mtlz Poly .01 mf 5% 1200V Poly Prop Foil	R-17 R-21	18D67858A12 18D68222A35	FOCUS: 2 meg BRIGHTNESS: 200K
C·29	8S10571A23	.56 mf 10% 250V Mtlz Prop Foil	R-34	18D68222A37	HORIZ HOLD: 25K
C-30 C-31	8S10191A32 21S180B87	.047 mf 10% 250V Polyester 220 pf 10% 500V X5F	R-59 R-65	18D66401A44 17D65820A38	VERT LINEARITY: 4K VERT SIZE: 15 Ohm
C32	21S180D34 8S10212A69	.005 mf 29% 1KV Z5F (Use 21S180D31) .47 mf 10% 100V Mtlz Poly	R-74 R-82	17D65820A37 18D68222A36	REGULATOR ADJUST: 2K VERT HOLD: 3K
C-33 C-34	8S10191A32	.047 10% 250V Polyester	R-85	18D68222A34	VOLUME: 250 Ohm
C-35 C-36	8S10191898 23S10255A69	.01 mf 10% 250V Polyester 4.7 mf 100V Lytic	RESIST	DRS	
C-37	8S10212A20	2.2 mf 10% 100V Mtzl Poly 2.2 mf 10% 100V Mtlz Poly	R-1	6S127633	470 10% 1/2W
C-38 C-39	8\$10212A20 8\$10191B67	.22 mf 10% 250V Polyester	R-2 R-3	6S125568 6S127541	22K 10% 1/2W 56K 10% 1/2W
C-40	8S10212A10	1.0 mf 10% 100V Mtiz Poly (Use 8S10191A46	R-4 R-6	6S127633	470 10% 1/2W 1500 10% 1W
C-41	8S10064A06	.01 mf 10% 600V Mylar	R-7	6S128955 6S121847	4700 10% 1/2W
C-42 C43	21S180A71 23C65807A47	470 pf 10% 500V X5F 400 mf/125V; 600 mf/50V;	R-8 R-9	6S122445 6S119926	1800 10% 1/2W 2700 10% 1/2W
•		20 mf/200V Lytic .01 mf +80-20% 50V Z5V	R-11	6\$128226	120 10% 1/2W
C-44 C-47	21S180E60 *23C65807A52	5000 mf 20V Lytic	R-12 R-13	6S127633 17S10731A02	470 10% 1/2W 7500 5% 5W WW
C-49 C-50	23S10255A31 23D65282A41	470 mf 40V Lytic 50 mf 50V Lytic	R-14 R-15	6S124797 6S127516	150 10% 1/2W 82 10% 1/2W
C-51	23510255843	40 mf 100V Lytic	R-18		Part of CRT socket assembly
DIODES &	RECTIFIERS		R-19 R-20		Part of CRT socket assembly Part of CRT socket assembly
D-1	48S134921 48S134978	DIODE, Silicon: D1D; Damper DIODE, Silicon: D1K; Pulse Limiter	R-22	6S129296	270K 10% 1/2W
D-2 D-3	48D67120A11	DIODE, Low Power	R-23 R-24	6S10053C67 6S127538	27K 5% 1/2W' 3.3 meg 10% 1/2W
D-4 D-5	48S137114 48S191A05	RECTIFIER, H. V.: Silicon; D2Y RECTIFIER, Silicon: 91A05 (Use	R-25 R-26	6S121300 6S127541	27K 10% 1/2W 56K 10% 1/2W
		48S191A07)	R-27	6S129875	2200 10% 1/2W
D-6 D-7	48S137469 48S134917	DIODE, Silicon: zener; D7G DIODE, Dual: D1C; Detector	R-28 R-29	6S125531 6S125531	180K 10% 1/2W 180K 10% 1/2W
D-8 D-9	48S67120A11 *48S191A10	DIODE, Low Power RECTIFIER, Silicon: 91A10	R-30	6\$125892	47K 10% 1/2W 100K 10% 1/2W
D-10	485191A10	RECTIFIER, Silicon: 91A10	R-31 R-32	6S125534 6S124506	3300 10% 1/2W
D-11 D-12	48S101A10 48S191A10	RECTIFIER, Silicon: 91A10 RECTIFIER, Silicon: 91A10	R-33 R-35	6S10053C53 6S127541	6800 5% 1/2W 56K 10% 1/2W
D-13	48D67120A11	DIODE, Low Power RECTIFIER, Silicon: 91A05	R-36	6S125545	390 10% 1/2W
D-14	48S191A05	(Use 48S191A07)	R-37 R-38	6S121301 6S10053C33	1000 10% 1/2W 1000 5% 1/2W
D-15	48S191A05	RECTIFIER, Silicon: 91A05 (Use 48S191A07)	R-39 R-40	6S127516 6S127547	82 10% 1/2W 1000 10% 1W
D-16	48S191A05	RECTIFIER, Silicon: 91A05	R-41	6S127099	220 10% 1/2W
D-17	48S191A05	(Use 48S191A07) RECTIFIER, Silicon: 91A05	R-42 R-43	6S127513 17S10130B07	1500 10% 1/2W 1500 10% 3W fxd mtl film
	48S191A05	(Use 48S191A07) RECTIFIER, Silicon: 91A05	R-44	17S744356	2.2 10% 2W WW
D-18		(Use 48S191A07)	R-45 R-46	6S120141 6S127634	150K 10% 1W 33K 10% 1W
D-19 D-20	48D67120A11 •48S10641D43	DIODE, Low Power DIODE, Silicon: D4.3	R-47 R-48	6S128229 6S10053D21	680K 1,0% 1/2W 4,7 meg 10% 1/2W
D-21	48D67120A11	DIODE, Low Power	R-49	6S124797	150 10% 1/2W
D-22	48S191A05	RECTIFIER, Silicon: 91A05 (Use 48S191A07)	R-50 R-52	6S10053C45 6S124506	3300 5% 1/2W 3300 10% 1/2W
D23	48S191A05	RECTIFIER Silicon: 91A05 (Use 48S191A07)	R-53	6 S129874	68 10% 1/2W
		100 101011	R-54 R-55	6S131972 6S10053C65	39 10% 1/2W 22K 5% 1/2W
FUSES F-1	65\$139424	FUSE: 1A-250V	R-56 R-57	6S125535 6S124506	39K 10% 1/2W 3300 10% 1/2W
F-1 F-2	65S139424 65S139424	FUSE: 1A-250V	R-58	6S129793	82K 5% 1/2W
	ATED CIRCUITS		R-60 R-61	6S129875 6S10053F29	2200 10% 1/2W 820 10% 1W
IC-1	*51S10732A01	INTEGRATED CIRCUIT: T3F	R-62	6S127515	3900 10% 1/2W
			<u> </u>		

REPLACEMENT PARTS LIST

REF. NO.	PART NUMBER	DESCRIPTION	REF. NO.		DESCRIPTION
		1000 1001 1/011	Ĭ	501/05000400	505 AKED: 4// 0M: '1- D00
R-63	6S121301	1000 10% 1/2W	E ⋅ 1	50V25008A22 65S139451	SPEAKER: 4" PM; incls D22 LAMP: No. 1436
R-64	17S10130C91	10 10% 1/2W (special)	E-1	055139451	LAMP: No. 1436
R-66	6S129064	4700 10% 1W			
R-67	65122848	18K 10% 1/2W	1		
R-68	6S124797	150 10% 1/2W 1200 10% 5W WW	IMECH	IANICAL PAR	RTS
R-69	17S647132	(Use 17S136197)	1	MICHE ! MI	
	60110036	2700 10% 1/2W			
R-71	6S119926	15K 10% 1/2W		9D66133A28	CAP, SS Rect (HV Transformer -
R-72	6\$124551	2200 10% 1/2W	1	0200.0020	PRI/SEC lead)
R-73	6S129875 6S121301	1000 10% 1/2W		42B25158A01	CLAMP, Metal: Defl Yoke Mtg
R-75	6S121301 6S124506	3300 10% 1/2W	1	31D70080B04	CONNECTOR, PC panel: 9 contact;
R-76		100 10% 1/2W	1	0.5,000000	on chassis
R-77	65129221	5600 10% 1/2W	S-2	15S10390A06	CONNECTOR, PC panel: 12 contact;
R-78	6S127005		~ ~	1001000000	less key and contacts (power-audio panel
R-79	175135589	150 10% 10W WW	P-1	*15S10183A69	CONNECTOR, Plug: 12 contact; less
R-81	6C66263A08	VARISTOR (Use 6S66263A16)	1, ,	1501010000	contacts (power)
R-86	6S127099	220 10% 1/2W	1		donitable (parter)
R-88	6S121301	1000 10% 1/2W	1	*39S10184A63	CONTACT, Plug: for power connector
R-89		Part of CRT Socket		33310104703	15S10183A69
R-90	6\$131412	56 10% 1/2W	1	39S10184A22	CONTACT: for S2 connector
R-91	6S10053C39	1800 5% 1/2W	1	15S10630A01	COVER, nylon: slide switch; SW1
R-92	6S10053C57	10K 5% 1/2W	ŀ	*7S10609A03	GROMMET, Plastic: PC panel mtg
R-95	6S125568	22K 10% 1/2W		26C66745A05	HEAT SINK: Q3
R-96	6S125568	22K 10% 1/2W		*26C25198A01	HEAT SINK: Q20
R-97	6S121847	4700 10% 1/2W		9C66238A02	HOLDER, Fuse: F1 & F2
R-98	6S127099	220 10% 1/2W	1	14A562353	INSULATOR, Mica: Transistor socket;
R-99	6S128226	120 10% 1/2W	1	14A562353	Q9, Q13, Q16 & Q20 (Use 14A543810)
			İ	28610722401	KEY, Plug: for S2 connector
SWITCHI	ES			28S10733A01 2S7051	NUT, hex: 3/8-32; control mtg
	10010001101	SWITCH, Slide: DPDT (115V-230V)		5S10281A03	RIVET, drive pin: nylon; HV transf mtg
SW-1	40S10624A01	SWITCH, Slide: DPDT (T15V=230V)		47C66082A03	ROD, Adjustment: width coil; L4
	ODMEDS				SCREW, tpg: 6-20 x 1/2 clu pan hd;
HANSE	ORMERS			3S136050	Q9, Q13, Q16 & Q20
T-1	25D67440A03	HORIZ DRIVER		0040442441	SOCKET, lamp: E1
T-2	24D69791A21	H. V. TRANSFORMER: complete		9\$10143A41	· · · · · · · · · · · · · · · · · ·
T-3	25D65840A22	VERT OUTPUT (Use 25D65840B23)	1	9D67555V27	SOCKET, CRT: incls leads & resistors
T-4	*25D68164A31	POWER	1	*9D25201A01	SOCKET, HV Rectifier (4): complete;
				0000005 + 04	incls 2nd anode lead & cup
MISCELL	ANEOUS ELECTE	RICAL PARTS	ł	9C63825A01	SOCKET, transistor: Q9, Q13, Q16
			I	9C63825A02	SOCKET, transistor: Q20
V-1	20WP4	CRT (XM501-10 19VP111)	I	41D65987A01	SPRING, special: CRT aquadag grnd
	23JEP4	CRT (XM701-10 23VP111)	•	66P65173A47	TOOL, contact removel (\$2 connector)


^{*} DENOTES NEW ITEM APPEARING ON ANY LIST FOR FIRST TIME.

MOTOROLA PARTS DEPT.

MOTOROLA INC.

1155 HARVESTER RD.

WEST CHICAGO, IL 60185
PHONE (312) 231-4400



NOTES:

- 1. VOLTAGE MAY VARY WITH CONTROL SETTING.
 2. LINE VOLTAGE MAINTAINED AT 120VAC, 5Q/60 Hz.
- 3 ALL D.C. VOLTAGES 2:10% MEASURED FROM POINT INDICATED TO CHASSIS USING HIGH IMPEDANCE METER WITH NO SIGNAL IMPUT. CONTRAST AND BRIGHTNESS CONTROLS AT MAXIMUM; ALL OTHER CONTROLS IN NORMAL OPERATING POSITION.

WELLS - GARDNER ELECTRONICS

2701 N. KILDARE AVE. • CHICAGO, ILL. 60639 • ALBANY 2-8220 TELEX 25-3286

NOTES:

INDICATES RESISTORS LOCATED IN PICTURE TUBE LEAD ASSEMBLY.

RESISTANCE VALUES IN OHMS, 1/2 WATT, 10% UNLESS OTHERWISE NOTED. K-1,000 M-1,000,000 CAPACITANCE VALUES OF 1 OR LESS ARE IN MICROFARADS. ABOVE 1 IN PICOFARADS UNLESS OTHERWISE MOTED.

MODEL NO. V1001-5734

REPLACEMENT PARTS LIST

CHASSIS PARTS

CAPACITORS

C101A,		800 μF/125V, 200 μF/100V
B, C, D	45X0558-001	200 μF/50V, 20 μF/200V
		Electrolytic
C102, 103		
104	80X0001-000	.001 μF, GMV Z5U Cer. Disc.
★ C105	342X5642-049	$.56 \mu$ F, 400V, 10% Polypropylene
★ C106	46X0536-001	.01 μ F, 1200V, 5% Polypropylene
C107	80X0099-006	470 pF, Z5F, 10%
C109	342X1044-040	0.1 μF, 400V, 20% Mylar
★ C110	46X0540-002	1.0 μF, 630V, 10% Polyester Film
C111	45X0515-032	33 μF, 150V, Electrolytic

CONTROLS

R108, 109	40X0585-091	25k Ohm, Horiz. & Vert. Hold
R116	40X0585-090	250 Ohm, Contrast
R121	40X0585-092	200k Ohm, Brightness

COILS & TRANSFORMERS

★ L101	9A2787-001	Coil, Width
★ T101	53X0475-001	Transformer, Power
★ T102	53X0474-001	Transformer, Flyback

RESISTORS

R101	340X3101-941	100 Ohm, 10%, 1/2W
R102, 115,		
120	340X3103-941	10k Ohm, 10%, 1/2W
★R103	340X0181-341	180 Ohm, 10%, 10W, WW
R104	340X3102-931	1k Ohm, 5%, 1/2W
★R105	340X6152-341	1.5k Ohm, 10%, 3W, WW
R106	340X3332-941	3.3k Ohm, 10%, 1/2W
R107	340X3563-941	56k Ohm, 10%, 1/2W
R110	340X3100-941	10 Ohm, 10%, 1/2W
R111	340X3151-941	150 Ohm, 10%, 1/2W
R119	340X3472-941	4.7k Ohm, 10%, 1/2W

SEMICONDUCTORS

D101, 102		
103, 104	66X0023-009	Rectifier, Silicon 500V 1N444B
★ D105	66X0067-001	Rectifier Varo H1802
★ D106	66X0068-001	Diode, Damper MR1-1600
D107	66X0053-001	Diode, 350V Amperex BA148
D108, 109	66X0046-001	Diode, Silicon FDH444
★ Q101	86X0117-001	Transistor (NPN) 2N5632 Regulator
Q102	86X0071-001	Transistor (NPN) Reg. Driver MPSA06
★ Q103	86X0118-001	Transistor (NPN) BU207 Hor. Output
Q104	86X0065-001	Transistor (NPN) D40N5 Spot Kill

MISCELLANEOUS

	16X0171-001	Fuse Holder
★ F101	16X0176-001	Fuse, 1.5 Amp. Slo-Blo 3AG
★ F102	16X0175-001	Fuse, 0.75 Amp, Slo-Blo 3AG
*	13X1201-001	HV Lead & Recept. Assy.
	28X0789-001	Spring, Dag, Grounding
*	9A2786-001	Deflection Yoke & Clamp
★ V101	19VARP4	CRT (19V1001)
or	or	
★ V101	22VATP4	CRT (22V1001)
	38A5473-000	2 PDT Small Relay (W/Wires)
	38A5474-000	6 PDT Large Relay (W/Wires)

[★] Product Safety Device

REPLACEMENT PARTS LIST P277 CIRCUIT BOARD ASSY.

CAPACITORS

RESISTORS (Cont'd.)

		Aditotio			•
C201, 202,			R220, 221	340X3184-944	180k Ohm, 10%, 1/2W
221	45X0524-027	47 μF, 50V, Electrolytic	R222	340X3473-944	47k Ohm, 10%, 1/2W
C203, 205,		-	R224	340X3104-944	100k Ohm, 10%, 1/2W
223, 225	80X0099-057	220 pF, 10%, Z5F, Cer. Disc.	R225	340X3682-944	6.8k Ohm, 10%, 1/2W
C204	45X0524-053	470 μF, 16V, Electrolytic	R226	340X3391-944	390 Ohm, 10%, 1/2W
C206	45X0524-051	100 μF, 50V, Electrolytic	R227	340X3102-944	1k Ohm, 10%, 1/2W
C207	80X0099-192	.005 μF, 20%, 1KV, Cer. Disc.	R228	340X3102-934	1k Ohm, 5%, 1/2W
C208	80X0099-036	10 pF, 10%, 500V, Cer. Disc.	R229	340X3820-944	82 Ohm, 10%, 1/2W
C209	80X0099-013	330 pF, 10%, 500V, Cer. Disc.	★R230	340X4102-843	1k Ohm, 10%, 1.0W
C210	349X4722-109	.0027 μF, 10%, Mylar	R232	340X3152-934	1.5k Ohm, 5%, 1/2W
C211	45X0524-023	1.0 µF, 15V, Electrolytic	★R233	340X6152-743	1.5k Ohm, 10%, 3.0W
C212	349X3332-109 46X0537-002	.033 μF, Mylar .01 μF, Poly	R234	340X5022-333	2.2 Ohm, 5%, 2.0W
C213 C214	46X0537-002 46X0537-003	.0082 μF, Poly	R235 R236	340X3151-944	150 Ohm, 10%, 1/2W 100 Ohm, 10%, 1/2W
C214 C215	349X1032-109	.01 μF, 10%, 100V Mylar	R238, 241	340X3101-944 340X3223-944	22k Ohm, 10%, 1/2W
C216, 218,	040X1002 100	.or p. , 10/6, 1001 myta.	R239	340X3182-944	1.8k Ohm, 10%, 1/2W
220, 238,			R243	340X3151-934	150 Ohm, 5%, 1/2W
239	80X0099-076	1000 pF, 10%, 500V, Cer. Disc.	R244	340X3680-934	68 Ohm, 5%, 1/2W
C217	349X1032-209	.01 μF, 10%, 200V, Mylar	R245, 266	340X3330-934	33 Ohm, 5%, 1/2W
C219	45X0524-052	150 μF, 10V, Electrolytic	R246	340X3273-944	27k Ohm, 10%, 1/2W
C222	80XQ099-137	680 pF, 10%, 500V, Cer. Disc.	R247, 248	340X3153-934	15k Ohm, 5%, 1/2W
C224	349X6822-109	.0068 μF, 10%, 100V, Mylar	R249, 275	340X3103-944	10k Ohm, 10%, 1/2W
C226, 227	80X0099-056	4700 μF, 10%, 500V, Cer. Disc.	R250	340X3822-944	8.2k Ohm, 10%, 1/2W
C228	349X4732-109	.047 μF, 10%, 100V, Mylar	R251	340X3684-944	680k Ohm, 10%, 1/2W
C229	349X1044-109	0.1 μF, 20%, 100V, Mylar	R252	340X 3 564-944	560k Ohm, 10%, 1/2W
C230	45X0515-014	1.0 μF, 50V, Electrolytic	R253, 276	340X3274-944	270k Ohm, 10%, 1/2W
C231	349X1042-109	0.1 μF, 10%, 100V, Mylar	R254	340X3562-944	5.6k Ohm, 10%, 1/2W
C232	45X0524-026	22 μF, 100V, Electrolytic	R258	340X3224-944	220k Ohm, 10%, 1/2W
C233	349X4742-109	.47 μF, 10%, 100V, Mylar 250 μF, 100V, Electrolytic	★R261	340X5150-843	15 Ohm, 10%, 2.0W
C234	45X0524-025 80X0099-006	470 pF, 10%, Z5F, Cer. Disc.	R262, 264	340X3824-934	820K Ohm, 5%, 1/2W
C235 C236	349X2242-109	.22 µF, 10%, 100V, Mylar	R265	340X3185-944	1.8M Ohm, 10%, 1/2W 1 Ohm, 5%, 1/2W
C237	46X0540-001	.47 μF, 10%, 630V, Polyester Film	R267, 268 R269	340X3010-934 340X4392-843	3.9K Ohm, 10%, 1/2W
0237	40/0040 001	.47 pt , 10/0, 0001, 1 01/00to. 1	R270	340X3471-934	470 Ohm, 5%, 1/2W
	CC	NTROLS	R272	340X3471-934 340X3475-944	4.7M Ohm, 10%, 1/2W
		MINOLS	R273	340X3155-944	1.5M Ohm, 10%, 1/2W
D000 050	40X0592-008	5k Ohm, Video Output, Size	★R274	340X4473-843	47k Ohm, 10%, 1.0W
R206, 256 R212					3.3 Ohm, 5%, 1/2W
M212			H2//	340X3033-934	3.3 Omin, 3/6, 1/244
P257 263	40X0585-093 40X0592-004	2.5k Ohm, Reg. Adj. 500k Ohm, Lin 1 & 2	R277	340X3033-934 SEMICONI	
R257, 263 R271	40X0592-004	500k Ohm, Lin 1 & 2 2M Ohm, Focus	H2//	SEMICONI	
R257, 263 R271		500k Ohm, Lin 1 & 2			
	40X0592-004 40X0585-094	500k Ohm, Lin 1 & 2 2M Ohm, Focus	D201, 202,		
	40X0592-004 40X0585-094	500k Ohm, Lin 1 & 2	D201, 202, 203, 204,	SEMICONI	DUCTORS
R271	40X0592-004 40X0585-094	500k Ohm, Lin 1 & 2 2M Ohm, Focus	D201, 202, 203, 204, 207, 208	SEMICONE 66X0046-001	DUCTORS Diode, Silicon FDH444
R271 ★L201	40X0592-004 40X0585-094 COILS &	500k Ohm, Lin 1 & 2 2M Ohm, Focus TRANSFORMERS	D201, 202, 203, 204, 207, 208 D205A, 205B	SEMICONE 66X0046-001 66X0066-001	Diode, Silicon FDH444 Diode, Dual, MSD6102
R271	40X0592-004 40X0585-094 COILS & 9A2788-001	500k Ohm, Lin 1 & 2 2M Ohm, Focus TRANSFORMERS Horiz. Osc.	D201, 202, 203, 204, 207, 208 D205A, 205B D206	SEMICONE 66X0046-001	DUCTORS Diode, Silicon FDH444
R271 ★L201 ★L202	40X0592-004 40X0585-094 COILS & 9A2788-001 9A2789-001 52X0126-001	500k Ohm, Lin 1 & 2 2M Ohm, Focus TRANSFORMERS Horiz. Osc Horiz. Lin Horiz. Driver	D201, 202, 203, 204, 207, 208 D205A, 205B D206 Q201, 205,	66X0046-001 66X0066-001 66X0054-002	Diode, Silicon FDH444 Diode, Dual, MSD6102 Diode, RCA D2102SF
R271 ★L201 ★L202	40X0592-004 40X0585-094 COILS & 9A2788-001 9A2789-001 52X0126-001	500k Ohm, Lin 1 & 2 2M Ohm, Focus TRANSFORMERS Horiz. Osc. Horiz. Lin.	D201, 202, 203, 204, 207, 208 D205A, 205B D206 Q201, 205, 206	66X0046-001 66X0066-001 66X0054-002 86X0113-001	Diode, Silicon FDH444 Diode, Dual, MSD6102 Diode, RCA D2102SF Transistor (NPN) 2N3904
★L201 ★L202 ★T201	40X0592-004 40X0585-094 COILS & 9A2788-001 9A2789-001 52X0126-001	500k Ohm, Lin 1 & 2 2M Ohm, Focus TRANSFORMERS Horiz. Osc. Horiz. Lin. Horiz. Driver ESISTORS	D201, 202, 203, 204, 207, 208 D205A, 205B D206 Q201, 205,	66X0046-001 66X0066-001 66X0054-002	Diode, Silicon FDH444 Diode, Dual, MSD6102 Diode, RCA D2102SF
★L201 ★L202 ★T201	40X0592-004 40X0585-094 COILS & 9A2788-001 9A2789-001 52X0126-001 R 340X3102-954	500k Ohm, Lin 1 & 2 2M Ohm, Focus TRANSFORMERS Horiz. Osc. Horiz. Lin. Horiz. Driver ESISTORS 1k Ohm, 20%, 1/2W	D201, 202, 203, 204, 207, 208 D205A, 205B D206 Q201, 205, 206 Q202, 208	66X0046-001 66X0066-001 66X0054-002 86X0113-001 86X0114-001	Diode, Silicon FDH444 Diode, Dual, MSD6102 Diode, RCA D2102SF Transistor (NPN) 2N3904 Transistor (PNP) 2N3906
*L201 *L202 *T201 R201 R201 R202	40X0592-004 40X0585-094 COILS & 9A2788-001 9A2789-001 52X0126-001	500k Ohm, Lin 1 & 2 2M Ohm, Focus TRANSFORMERS Horiz. Osc. Horiz. Lin. Horiz. Driver ESISTORS 1k Ohm, 20%, 1/2W	D201, 202, 203, 204, 207, 208 D205A, 205B D206 Q201, 205, 206 Q202, 208 Q203	66X0046-001 66X0066-001 66X0054-002 86X0113-001 86X0114-001 86X0071-001	Diode, Silicon FDH444 Diode, Dual, MSD6102 Diode, RCA D2102SF Transistor (NPN) 2N3904 Transistor (PNP) 2N3906 Transistor (NPN)
R271 ★L201 ★L202 ★T201 R201 R202 R203, 237,	40X0592-004 40X0585-094 COILS & 9A2788-001 9A2789-001 52X0126-001 R 340X3102-954 340X3563-944	500k Ohm, Lin 1 & 2 2M Ohm, Focus TRANSFORMERS Horiz. Osc. Horiz. Lin. Horiz. Driver ESISTORS 1k Ohm, 20%, 1/2W 56k Ohm, 10%, 1/2W	D201, 202, 203, 204, 207, 208 D205A, 205B D206 Q201, 205, 206 Q202, 208 Q203 Q204, 212	66X0046-001 66X0066-001 66X0054-002 86X0113-001 86X0114-001 86X0071-001	Diode, Silicon FDH444 Diode, Dual, MSD6102 Diode, RCA D2102SF Transistor (NPN) 2N3904 Transistor (PNP) 2N3906 Transistor (NPN) Transistor (NPN) MPSA06 Transistor (NPN) MPSA20 Transistor Horiz, Driver (NPN)
R271 ★L201 ★L202 ★T201 R201 R202 R203, 237, 240	40X0592-004 40X0585-094 COILS & 9A2788-001 9A2789-001 52X0126-001 R 340X3102-954 340X3563-944	500k Ohm, Lin 1 & 2 2M Ohm, Focus TRANSFORMERS Horiz. Osc. Horiz. Lin. Horiz. Driver ESISTORS 1k Ohm, 20%, 1/2W 56k Ohm, 10%, 1/2W 470 Ohm, 10%, 1/2W	D201, 202, 203, 204, 207, 208 D205A, 205B D206 Q201, 205, 206 Q202, 208 Q203 Q204, 212 Q207, 211 Q209	66X0046-001 66X0066-001 66X0054-002 86X0113-001 86X0071-001 86X0071-001 86X0058-002 86X0116-001	Diode, Silicon FDH444 Diode, Dual, MSD6102 Diode, RCA D2102SF Transistor (NPN) 2N3904 Transistor (PNP) 2N3906 Transistor (NPN) Transistor (NPN) MPSA06 Transistor (NPN) MPSA20 Transistor (NPN) MPSA20 Transistor Horiz, Driver (NPN) 2N6557
R271 ★L201 ★L202 ★T201 R201 R202 R203, 237, 240 ★R204	40X0592-004 40X0585-094 COILS & 9A2788-001 9A2789-001 52X0126-001 R 340X3102-954 340X3563-944	500k Ohm, Lin 1 & 2 2M Ohm, Focus TRANSFORMERS Horiz. Osc. Horiz. Lin. Horiz. Driver ESISTORS 1k Ohm, 20%, 1/2W 56k Ohm, 10%, 1/2W 470 Ohm, 10%, 1/2W	D201, 202, 203, 204, 207, 208 D205A, 205B D206 Q201, 205, 206 Q202, 208 Q203 Q204, 212 Q207, 211 Q209	66X0046-001 66X0066-001 66X0054-002 86X0113-001 86X0114-001 86X0071-001 86X0071-001 86X0058-002 86X0116-001	Diode, Silicon FDH444 Diode, Dual, MSD6102 Diode, RCA D2102SF Transistor (NPN) 2N3904 Transistor (PNP) 2N3906 Transistor (NPN) Transistor (NPN) MPSA06 Transistor (NPN) MPSA20 Transistor (NPN) MPSA20 Transistor Horiz, Driver (NPN) 2N6557 Transistor (PNP) MPSA70
R271 ★L201 ★L202 ★T201 R201 R202 R203, 237, 240 ★R204 R205, 223,	40X0592-004 40X0585-094 COILS & 9A2788-001 9A2789-001 52X0126-001 R 340X3102-954 340X3563-944 340X3471-944 340X4152-843	500k Ohm, Lin 1 & 2 2M Ohm, Focus TRANSFORMERS Horiz. Osc. Horiz. Lin. Horiz. Driver ESISTORS 1k Ohm, 20%, 1/2W 56k Ohm, 10%, 1/2W 470 Ohm, 10%, 1/2W 1.5k Ohm, 10%, 1.0W	D201, 202, 203, 204, 207, 208 D205A, 205B D206 Q201, 205, 206 Q202, 208 Q203 Q204, 212 Q207, 211 Q209 Q210 Q210 Q213	66X0046-001 66X0066-001 66X0054-002 86X0113-001 86X0071-001 86X0071-001 86X0058-002 86X0116-001 86X0066-001 86X0072-001	Diode, Silicon FDH444 Diode, Dual, MSD6102 Diode, RCA D2102SF Transistor (NPN) 2N3904 Transistor (PNP) 2N3906 Transistor (NPN) Transistor (NPN) MPSA06 Transistor (NPN) MPSA20 Transistor (NPN) MPSA20 Transistor Horiz, Driver (NPN) 2N6557 Transistor (PNP) MPSA70 Transistor (PNP) MPSA56
R271 ★L201 ★L202 ★T201 R201 R202 R203, 237, 240 ★R204 R205, 223, 260	40X0592-004 40X0585-094 COILS & 9A2788-001 9A2789-001 52X0126-001 R 340X3102-954 340X3563-944 340X3471-944 340X4152-843 340X3332-944	500k Ohm, Lin 1 & 2 2M Ohm, Focus TRANSFORMERS Horiz. Osc. Horiz. Lin. Horiz. Driver ESISTORS 1k Ohm, 20%, 1/2W 56k Ohm, 10%, 1/2W 470 Ohm, 10%, 1/2W 1.5k Ohm, 10%, 1.0W 3.3k Ohm, 10%, 1/2W	D201, 202, 203, 204, 207, 208 D205A, 205B D206 Q201, 205, 206 Q202, 208 Q203 Q204, 212 Q207, 211 Q209 Q210 Q213 Q214	66X0046-001 66X0066-001 66X0054-002 86X0113-001 86X0071-001 86X0071-001 86X0071-001 86X0058-002 86X0116-001 86X0066-001 86X0072-001 86X0073-001	Diode, Silicon FDH444 Diode, Dual, MSD6102 Diode, RCA D2102SF Transistor (NPN) 2N3904 Transistor (PNP) 2N3906 Transistor (NPN) Transistor (NPN) MPSA06 Transistor (NPN) MPSA20 Transistor Horiz, Driver (NPN) 2N6557 Transistor (PNP) MPSA70 Transistor (PNP) MPSA56 Transistor (NPN) MPSA56 Transistor (NPN) MPSA07
R271 ★L201 ★L202 ★T201 R201 R202 R203, 237, 240 ★R204 R205, 223, 260 R207	40X0592-004 40X0585-094 COILS & 9A2788-001 9A2789-001 52X0126-001 R 340X3102-954 340X3563-944 340X3471-944 340X4152-843 340X3332-944 340X3372-944	500k Ohm, Lin 1 & 2 2M Ohm, Focus TRANSFORMERS Horiz. Osc. Horiz. Lin. Horiz. Driver ESISTORS 1k Ohm, 20%, 1/2W 56k Ohm, 10%, 1/2W 470 Ohm, 10%, 1/2W 1.5k Ohm, 10%, 1/2W 3.3k Ohm, 10%, 1/2W 4.7k Ohm, 10%, 1/2W 4.7k Ohm, 10%, 1/2W	D201, 202, 203, 204, 207, 208 D205A, 205B D206 Q201, 205, 206 Q202, 208 Q203 Q204, 212 Q207, 211 Q209 Q210 Q213 Q214 Q215	66X0046-001 66X0066-001 66X0054-002 86X0113-001 86X0071-001 86X0071-001 86X0071-001 86X0058-002 86X0116-001 86X0072-001 86X0073-001 86X0074-001	Diode, Silicon FDH444 Diode, Dual, MSD6102 Diode, RCA D2102SF Transistor (NPN) 2N3904 Transistor (PNP) 2N3906 Transistor (NPN) Transistor (NPN) MPSA06 Transistor (NPN) MPSA20 Transistor Horiz, Driver (NPN) 2N6557 Transistor (PNP) MPSA70 Transistor (PNP) MPSA56 Transistor (PNP) MPSA56 Transistor (NPN) MPSU07 Transistor (NPN) MPSU07 Transistor (NPN) 2N5192
R271 ★L201 ★L202 ★T201 R201 R202 R203, 237, 240 ★R204 R205, 223, 260 R207 ★R208	40X0592-004 40X0585-094 COILS & 9A2788-001 9A2789-001 52X0126-001 R 340X3102-954 340X3563-944 340X3471-944 340X4152-843 340X3332-944	500k Ohm, Lin 1 & 2 2M Ohm, Focus TRANSFORMERS Horiz. Osc. Horiz. Lin. Horiz. Driver ESISTORS 1k Ohm, 20%, 1/2W 56k Ohm, 10%, 1/2W 470 Ohm, 10%, 1/2W 1.5k Ohm, 10%, 1.0W 3.3k Ohm, 10%, 1/2W 4.7k Ohm, 10%, 1/2W 7.5k Ohm, 5%, 4.0W	D201, 202, 203, 204, 207, 208 D205A, 205B D206 Q201, 205, 206 Q202, 208 Q203 Q204, 212 Q207, 211 Q209 Q210 Q213 Q214 Q215 Q216	66X0046-001 66X0066-001 66X0054-002 86X0113-001 86X0114-001 86X0071-001 86X0071-001 86X0058-002 86X0116-001 86X0072-001 86X0073-001 86X0074-001 86X0075-001	Diode, Silicon FDH444 Diode, Dual, MSD6102 Diode, RCA D2102SF Transistor (NPN) 2N3904 Transistor (PNP) 2N3906 Transistor (NPN) Transistor (NPN) MPSA06 Transistor (NPN) MPSA20 Transistor Horiz, Driver (NPN) 2N6557 Transistor (PNP) MPSA70 Transistor (PNP) MPSA56 Transistor (PNP) MPSA56 Transistor (NPN) MPSU07 Transistor (NPN) MPSU07 Transistor (NPN) 2N5192 Transistor (PNP) 2N5195
R271 ★L201 ★L202 ★T201 R201 R202 R203, 237, 240 ★R204 R205, 223, 260 R207 ★R208 R209	40X0592-004 40X0585-094 COILS & 9A2788-001 9A2789-001 52X0126-001 R 340X3102-954 340X3563-944 340X3471-944 340X4152-843 340X332-944 340X3472-944 340X7752-733	500k Ohm, Lin 1 & 2 2M Ohm, Focus TRANSFORMERS Horiz. Osc. Horiz. Lin. Horiz. Driver ESISTORS 1k Ohm, 20%, 1/2W 56k Ohm, 10%, 1/2W 470 Ohm, 10%, 1/2W 1.5k Ohm, 10%, 1.0W 3.3k Ohm, 10%, 1/2W 4.7k Ohm, 10%, 1/2W 4.7k Ohm, 10%, 1/2W 7.5k Ohm, 5%, 4.0W 120 Ohm, 10%, 1/2W	D201, 202, 203, 204, 207, 208 D205A, 205B D206 Q201, 205, 206 Q202, 208 Q203 Q204, 212 Q207, 211 Q209 Q210 Q213 Q214 Q215 Q216 Q216 Q217	66X0046-001 66X0066-001 66X0054-002 86X0113-001 86X0071-001 86X0071-001 86X0058-002 86X0116-001 86X0066-001 86X0072-001 86X0073-001 86X0075-001 86X0075-001	Diode, Silicon FDH444 Diode, Dual, MSD6102 Diode, RCA D2102SF Transistor (NPN) 2N3904 Transistor (NPN) 2N3906 Transistor (NPN) MPSA06 Transistor (NPN) MPSA20 Transistor (NPN) MPSA20 Transistor Horiz, Driver (NPN) 2N6557 Transistor (PNP) MPSA70 Transistor (PNP) MPSA56 Transistor (PNP) MPSA56 Transistor (NPN) MPSU07 Transistor (NPN) 2N5192 Transistor (PNP) 2N5195 Transistor (PNP) 2N5195 Transistor (PNP) 2N5195
#L201 ★L202 ★T201 #R202 #R203, 237, 240 ★R204 #R205, 223, 260 #R207 ★R208 #R208 #R209 #R210	40X0592-004 40X0585-094 COILS & 9A2788-001 9A2789-001 52X0126-001 R 340X3102-954 340X3563-944 340X3471-944 340X4152-843 340X332-944 340X3472-944 340X7752-733 340X3121-944	500k Ohm, Lin 1 & 2 2M Ohm, Focus TRANSFORMERS Horiz. Osc. Horiz. Lin. Horiz. Driver ESISTORS 1k Ohm, 20%, 1/2W 56k Ohm, 10%, 1/2W 470 Ohm, 10%, 1/2W 1.5k Ohm, 10%, 1.0W 3.3k Ohm, 10%, 1/2W 4.7k Ohm, 10%, 1/2W 4.7k Ohm, 10%, 1/2W 7.5k Ohm, 5%, 4.0W 120 Ohm, 10%, 1/2W	D201, 202, 203, 204, 207, 208 D205A, 205B D206 Q201, 205, 206 Q202, 208 Q203 Q204, 212 Q207, 211 Q209 Q210 Q213 Q214 Q215 Q216	66X0046-001 66X0066-001 66X0054-002 86X0113-001 86X0114-001 86X0071-001 86X0071-001 86X0058-002 86X0116-001 86X0072-001 86X0073-001 86X0074-001 86X0075-001	Diode, Silicon FDH444 Diode, Dual, MSD6102 Diode, RCA D2102SF Transistor (NPN) 2N3904 Transistor (PNP) 2N3906 Transistor (NPN) Transistor (NPN) MPSA06 Transistor (NPN) MPSA20 Transistor Horiz, Driver (NPN) 2N6557 Transistor (PNP) MPSA70 Transistor (PNP) MPSA56 Transistor (PNP) MPSA56 Transistor (NPN) MPSU07 Transistor (NPN) MPSU07 Transistor (NPN) 2N5192 Transistor (PNP) 2N5195
R271 ★L201 ★L202 ★T201 R201 R202 R203, 237, 240 ★R204 R205, 223, 260 R207 ★R208 R209	40X0592-004 40X0585-094 COILS & 9A2788-001 9A2789-001 52X0126-001 R 340X3102-954 340X3563-944 340X3471-944 340X4152-843 340X332-944 340X3472-944 340X7752-733 340X3121-944	500k Ohm, Lin 1 & 2 2M Ohm, Focus TRANSFORMERS Horiz. Osc. Horiz. Lin. Horiz. Driver ESISTORS 1k Ohm, 20%, 1/2W 56k Ohm, 10%, 1/2W 470 Ohm, 10%, 1/2W 470 Ohm, 10%, 1/2W 3.3k Ohm, 10%, 1/2W 4.7k Ohm, 10%, 1/2W 4.7k Ohm, 10%, 1/2W 4.7sk Ohm, 10%, 1/2W 4.7sk Ohm, 10%, 1/2W 4.7sk Ohm, 5%, 4.0W 4.20 Ohm, 10%, 1/2W 4.300 Ohm, 5%, 1/2W 4.300 Ohm, 5%, 1/2W	D201, 202, 203, 204, 207, 208 D205A, 205B D206 Q201, 205, 206 Q202, 208 Q203 Q204, 212 Q207, 211 Q209 Q210 Q213 Q214 Q215 Q216 Q216 Q217	66X0046-001 66X0066-001 66X0054-002 86X0113-001 86X0071-001 86X0071-001 86X0058-002 86X0116-001 86X0066-001 86X0072-001 86X0073-001 86X0075-001 86X0075-001	Diode, Silicon FDH444 Diode, Dual, MSD6102 Diode, RCA D2102SF Transistor (NPN) 2N3904 Transistor (NPN) 2N3906 Transistor (NPN) MPSA06 Transistor (NPN) MPSA20 Transistor (NPN) MPSA20 Transistor Horiz, Driver (NPN) 2N6557 Transistor (PNP) MPSA70 Transistor (PNP) MPSA56 Transistor (PNP) MPSA56 Transistor (NPN) MPSU07 Transistor (NPN) 2N5192 Transistor (PNP) 2N5195 Transistor (PNP) 2N5195 Transistor (PNP) 2N5195
R271 ★L201 ★L202 ★T201 R201 R201 R202 R203, 237, 240 ★R204 R205, 223, 260 R207 ★R208 R209 R210 R211, 242,	40X0592-004 40X0585-094 COILS & 9A2788-001 9A2789-001 52X0126-001 R 340X3102-954 340X3563-944 340X3471-944 340X4152-843 340X3472-944 340X37752-733 340X3121-944 340X3560-944	500k Ohm, Lin 1 & 2 2M Ohm, Focus TRANSFORMERS Horiz. Osc. Horiz. Lin. Horiz. Driver ESISTORS 1k Ohm, 20%, 1/2W 56k Ohm, 10%, 1/2W 470 Ohm, 10%, 1/2W 470 Ohm, 10%, 1/2W 47k Ohm, 10%, 1/2W 47k Ohm, 10%, 1/2W 47k Ohm, 10%, 1/2W 47k Ohm, 5%, 4.0W 120 Ohm, 5%, 4.0W 120 Ohm, 10%, 1/2W 56 Ohm, 10%, 1/2W 4300 Ohm, 5%, 1/2W Thermistor	D201, 202, 203, 204, 207, 208 D205A, 205B D206 Q201, 205, 206 Q202, 208 Q203 Q204, 212 Q207, 211 Q209 Q210 Q213 Q214 Q215 Q216 Q216 Q217	66X0046-001 66X0066-001 66X0054-002 86X0113-001 86X0071-001 86X0071-001 86X0058-002 86X0116-001 86X0066-001 86X0072-001 86X0073-001 86X0075-001 86X0075-001	Diode, Silicon FDH444 Diode, Dual, MSD6102 Diode, RCA D2102SF Transistor (NPN) 2N3904 Transistor (NPN) 2N3906 Transistor (NPN) MPSA06 Transistor (NPN) MPSA20 Transistor (NPN) MPSA20 Transistor Horiz, Driver (NPN) 2N6557 Transistor (PNP) MPSA70 Transistor (PNP) MPSA56 Transistor (PNP) MPSA56 Transistor (NPN) MPSU07 Transistor (NPN) 2N5192 Transistor (PNP) 2N5195 Transistor (PNP) 2N5195 Transistor (PNP) 2N5195
R271 ★L201 ★L202 ★T201 R201 R202 R203, 237, 240 ★R204 R205, 223, 260 R207 ★R208 R209 R209 R210 R211, 242, 259	40X0592-004 40X0585-094 COILS & 9A2788-001 9A2789-001 52X0126-001 R 340X3102-954 340X3563-944 340X3471-944 340X4152-843 340X3472-944 340X7752-733 340X3121-944 340X3560-944 340X3432-934	500k Ohm, Lin 1 & 2 2M Ohm, Focus TRANSFORMERS Horiz. Osc. Horiz. Lin. Horiz. Driver ESISTORS 1k Ohm, 20%, 1/2W 56k Ohm, 10%, 1/2W 470 Ohm, 10%, 1/2W 470 Ohm, 10%, 1/2W 476 Ohm, 10%, 1/2W 47k Ohm, 10%, 1/2W 47k Ohm, 10%, 1/2W 47k Ohm, 5%, 4.0W 120 Ohm, 5%, 4.0W 120 Ohm, 10%, 1/2W 4300 Ohm, 5%, 1/2W Thermistor 5.1k Ohm, 5%, 1/2W	D201, 202, 203, 204, 207, 208 D205A, 205B D206 Q201, 205, 206 Q202, 208 Q203 Q204, 212 Q207, 211 Q209 Q210 Q213 Q214 Q215 Q216 Q216 Q217	66X0046-001 66X0066-001 66X0054-002 86X0113-001 86X0071-001 86X0071-001 86X0058-002 86X0116-001 86X0066-001 86X0072-001 86X0073-001 86X0074-001 86X0075-001 86X0070-001 66X0040-004	Diode, Silicon FDH444 Diode, Dual, MSD6102 Diode, RCA D2102SF Transistor (NPN) 2N3904 Transistor (NPN) 2N3906 Transistor (NPN) MPSA06 Transistor (NPN) MPSA20 Transistor (NPN) MPSA20 Transistor Horiz, Driver (NPN) 2N6557 Transistor (PNP) MPSA70 Transistor (PNP) MPSA56 Transistor (PNP) MPSA56 Transistor (NPN) MPSU07 Transistor (NPN) 2N5192 Transistor (PNP) 2N5195 Transistor (PNP) 2N5195 Transistor (P.U.T.) MPU131 Diode, Zener 31V
#L201 ★L202 ★L202 ★T201 R201 R202 R203, 237, 240 ★R204 R205, 223, 260 R207 ★R208 R209 R210 R211, 242, 259 R213 R214, 255 R215	40X0592-004 40X0585-094 COILS & 9A2788-001 9A2789-001 52X0126-001 R 340X3102-954 340X3563-944 340X3471-944 340X3472-944 340X3472-944 340X37752-733 340X3121-944 340X3560-944 340X3432-934 43X0467-001 340X3512-934 340X3153-944	500k Ohm, Lin 1 & 2 2M Ohm, Focus TRANSFORMERS Horiz. Osc. Horiz. Lin. Horiz. Driver ESISTORS 1k Ohm, 20%, 1/2W 56k Ohm, 10%, 1/2W 470 Ohm, 10%, 1/2W 470 Ohm, 10%, 1/2W 47k Ohm, 10%, 1/2W 47k Ohm, 10%, 1/2W 47k Ohm, 10%, 1/2W 47k Ohm, 5%, 4.0W 120 Ohm, 10%, 1/2W 56 Ohm, 10%, 1/2W 4300 Ohm, 5%, 1/2W Thermistor 5.1k Ohm, 5%, 1/2W 15k Ohm, 5%, 1/2W 15k Ohm, 10%, 1/2W	D201, 202, 203, 204, 207, 208 D205A, 205B D206 Q201, 205, 206 Q202, 208 Q203 Q204, 212 Q207, 211 Q209 Q210 Q213 Q214 Q215 Q216 Q216 Q217	66X0046-001 66X0066-001 66X0054-002 86X0113-001 86X0071-001 86X0071-001 86X0058-002 86X0116-001 86X0066-001 86X0072-001 86X0073-001 86X0074-001 86X0075-001 86X0075-001	Diode, Silicon FDH444 Diode, Dual, MSD6102 Diode, RCA D2102SF Transistor (NPN) 2N3904 Transistor (NPN) 2N3906 Transistor (NPN) MPSA06 Transistor (NPN) MPSA20 Transistor (NPN) MPSA20 Transistor Horiz, Driver (NPN) 2N6557 Transistor (PNP) MPSA70 Transistor (PNP) MPSA56 Transistor (PNP) MPSA56 Transistor (NPN) MPSU07 Transistor (NPN) 2N5192 Transistor (PNP) 2N5195 Transistor (PNP) 2N5195 Transistor (P.U.T.) MPU131 Diode, Zener 31V
#L201 ★L202 ★L202 ★T201 #R202 R203, 237, 240 ★R204 R205, 223, 260 R207 ★R208 R209 R210 R211, 242, 259 R213 R214, 255 R215 ★R216	40X0592-004 40X0585-094 COILS & 9A2788-001 9A2789-001 52X0126-001 R 340X3102-954 340X3563-944 340X3471-944 340X3472-944 340X3472-944 340X37752-733 340X3121-944 340X3560-944 340X3432-934 43X0467-001 340X3512-934 340X3153-944 340X4154-843	500k Ohm, Lin 1 & 2 2M Ohm, Focus TRANSFORMERS Horiz. Osc. Horiz. Lin. Horiz. Driver ESISTORS 1k Ohm, 20%, 1/2W 56k Ohm, 10%, 1/2W 470 Ohm, 10%, 1/2W 470 Ohm, 10%, 1/2W 476 Ohm, 10%, 1/2W 47k Ohm, 10%, 1/2W 47k Ohm, 10%, 1/2W 47k Ohm, 10%, 1/2W 56 Ohm, 10%, 1/2W 4300 Ohm, 5%, 4.0W Thermistor 5.1k Ohm, 5%, 1/2W Thermistor 5.1k Ohm, 5%, 1/2W 15k Ohm, 10%, 1/2W 15k Ohm, 10%, 1/2W	D201, 202, 203, 204, 207, 208 D205A, 205B D206 Q201, 205, 206 Q202, 208 Q203 Q204, 212 Q207, 211 Q209 Q210 Q213 Q214 Q215 Q216 Q216 Q217	66X0046-001 66X0066-001 66X0054-002 86X0113-001 86X0071-001 86X0071-001 86X0058-002 86X0116-001 86X0066-001 86X0072-001 86X0073-001 86X0074-001 86X0075-001 86X0070-001 66X0040-004	Diode, Silicon FDH444 Diode, Dual, MSD6102 Diode, RCA D2102SF Transistor (NPN) 2N3904 Transistor (NPN) 2N3906 Transistor (NPN) MPSA06 Transistor (NPN) MPSA20 Transistor (NPN) MPSA20 Transistor Horiz, Driver (NPN) 2N6557 Transistor (PNP) MPSA70 Transistor (PNP) MPSA56 Transistor (PNP) MPSA56 Transistor (NPN) MPSU07 Transistor (NPN) 2N5192 Transistor (PNP) 2N5195 Transistor (PNP) 2N5195 Transistor (P.U.T.) MPU131 Diode, Zener 31V
#L201 ★L201 ★L202 ★T201 R201 R202 R203, 237, 240 ★R204 R205, 223, 260 R207 ★R208 R209 R210 R211, 242, 259 R213 R214, 255 R215 ★R216 R217	40X0592-004 40X0585-094 COILS & 9A2788-001 9A2789-001 52X0126-001 R 340X3102-954 340X3563-944 340X3471-944 340X3472-944 340X3472-944 340X37752-733 340X3121-944 340X3560-944 340X3432-934 340X3560-944 340X35312-934 340X3153-944 340X335-944	500k Ohm, Lin 1 & 2 2M Ohm, Focus TRANSFORMERS Horiz. Osc. Horiz. Lin. Horiz. Driver ESISTORS 1k Ohm, 20%, 1/2W 56k Ohm, 10%, 1/2W 470 Ohm, 10%, 1/2W 470 Ohm, 10%, 1/2W 470 Ohm, 10%, 1/2W 47k Ohm, 10%, 1/2W 4.7k Ohm, 10%, 1/2W 4.7k Ohm, 10%, 1/2W 56 Ohm, 10%, 1/2W 4.7k Ohm, 5%, 4.0W 4.7k Ohm, 5%, 4.0W 4.7k Ohm, 5%, 4.0W 4.7k Ohm, 5%, 1/2W 5.5k Ohm, 5%, 1/2W 5.5k Ohm, 10%, 1/2W 4.5k Ohm, 10%, 1/2W	D201, 202, 203, 204, 207, 208 D205A, 205B D206 Q201, 205, 206 Q202, 208 Q203 Q204, 212 Q207, 211 Q209 Q210 Q213 Q214 Q215 Q216 Q216 Q217	66X0046-001 66X0066-001 66X0054-002 86X0113-001 86X0071-001 86X0071-001 86X0058-002 86X0116-001 86X0066-001 86X0072-001 86X0073-001 86X0074-001 86X0075-001 86X0070-001 66X0040-004	Diode, Silicon FDH444 Diode, Dual, MSD6102 Diode, RCA D2102SF Transistor (NPN) 2N3904 Transistor (NPN) 2N3906 Transistor (NPN) MPSA06 Transistor (NPN) MPSA20 Transistor (NPN) MPSA20 Transistor Horiz, Driver (NPN) 2N6557 Transistor (PNP) MPSA70 Transistor (PNP) MPSA56 Transistor (PNP) MPSA56 Transistor (NPN) MPSU07 Transistor (NPN) 2N5192 Transistor (PNP) 2N5195 Transistor (PNP) 2N5195 Transistor (P.U.T.) MPU131 Diode, Zener 31V
#L201 ★L201 ★L202 ★T201 R201 R202 R203, 237, 240 ★R204 R205, 223, 260 R207 ★R208 R209 R210 R211, 242, 259 R213 R214, 255 R215 ★R216 R217 R218, 231	40X0592-004 40X0585-094 COILS & 9A2788-001 9A2789-001 52X0126-001 R 340X3102-954 340X3563-944 340X3471-944 340X3472-944 340X37752-733 340X3121-944 340X3560-944 340X3432-934 43X0467-001 340X3153-944 340X3153-944 340X3355-944 340X3355-944	500k Ohm, Lin 1 & 2 2M Ohm, Focus TRANSFORMERS Horiz. Osc. Horiz. Lin. Horiz. Driver ESISTORS 1k Ohm, 20%, 1/2W 56k Ohm, 10%, 1/2W 470 Ohm, 10%, 1/2W 470 Ohm, 10%, 1/2W 470 Ohm, 10%, 1/2W 470 Ohm, 10%, 1/2W 470 Ohm, 10%, 1/2W 470 Ohm, 10%, 1/2W 470 Ohm, 10%, 1/2W 470 Ohm, 10%, 1/2W 470 Ohm, 10%, 1/2W 470 Ohm, 10%, 1/2W 470 Ohm, 10%, 1/2W 470 Ohm, 10%, 1/2W 470 Ohm, 10%, 1/2W 470 Ohm, 10%, 1/2W 480 Ohm, 5%, 1/2W 4800 Ohm, 10%, 1/2W	D201, 202, 203, 204, 207, 208 D205A, 205B D206 Q201, 205, 206 Q202, 208 Q203 Q204, 212 Q207, 211 Q209 Q210 Q213 Q214 Q215 Q216 Q216 Q217	66X0046-001 66X0066-001 66X0054-002 86X0113-001 86X0071-001 86X0071-001 86X0058-002 86X0116-001 86X0072-001 86X0073-001 86X0074-001 86X0075-001 86X0070-001 66X0040-004	Diode, Silicon FDH444 Diode, Dual, MSD6102 Diode, RCA D2102SF Transistor (NPN) 2N3904 Transistor (NPN) 2N3906 Transistor (NPN) Transistor (NPN) MPSA06 Transistor (NPN) MPSA20 Transistor (NPN) MPSA20 Transistor (NPN) MPSA70 Transistor (PNP) MPSA70 Transistor (PNP) MPSA56 Transistor (NPN) MPSU07 Transistor (NPN) MPSU07 Transistor (NPN) 2N5192 Transistor (PNP) 2N5195 Transistor (P.U.T.) MPU131 Diode, Zener 31V
#L201 ★L201 ★L202 ★T201 R201 R202 R203, 237, 240 ★R204 R205, 223, 260 R207 ★R208 R209 R210 R211, 242, 259 R213 R214, 255 R215 ★R216 R217	40X0592-004 40X0585-094 COILS & 9A2788-001 9A2789-001 52X0126-001 R 340X3102-954 340X3563-944 340X3471-944 340X3472-944 340X3472-944 340X37752-733 340X3121-944 340X3560-944 340X3432-934 340X3560-944 340X35312-934 340X3153-944 340X335-944	500k Ohm, Lin 1 & 2 2M Ohm, Focus TRANSFORMERS Horiz. Osc. Horiz. Lin. Horiz. Driver ESISTORS 1k Ohm, 20%, 1/2W 56k Ohm, 10%, 1/2W 470 Ohm, 10%, 1/2W 470 Ohm, 10%, 1/2W 470 Ohm, 10%, 1/2W 470 Ohm, 10%, 1/2W 470 Ohm, 10%, 1/2W 470 Ohm, 10%, 1/2W 470 Ohm, 10%, 1/2W 470 Ohm, 10%, 1/2W 470 Ohm, 10%, 1/2W 470 Ohm, 10%, 1/2W 470 Ohm, 10%, 1/2W 470 Ohm, 10%, 1/2W 470 Ohm, 10%, 1/2W 470 Ohm, 10%, 1/2W 480 Ohm, 5%, 1/2W 4800 Ohm, 10%, 1/2W	D201, 202, 203, 204, 207, 208 D205A, 205B D206 Q201, 205, 206 Q202, 208 Q203 Q204, 212 Q207, 211 Q209 Q210 Q213 Q214 Q215 Q216 Q216 Q217	66X0046-001 66X0066-001 66X0054-002 86X0113-001 86X0071-001 86X0071-001 86X0058-002 86X0116-001 86X0066-001 86X0072-001 86X0073-001 86X0074-001 86X0075-001 86X0070-001 66X0040-004	Diode, Silicon FDH444 Diode, Dual, MSD6102 Diode, RCA D2102SF Transistor (NPN) 2N3904 Transistor (NPN) 2N3906 Transistor (NPN) MPSA06 Transistor (NPN) MPSA20 Transistor (NPN) MPSA20 Transistor Horiz, Driver (NPN) 2N6557 Transistor (PNP) MPSA70 Transistor (PNP) MPSA56 Transistor (PNP) MPSA56 Transistor (NPN) MPSU07 Transistor (NPN) 2N5192 Transistor (PNP) 2N5195 Transistor (PNP) 2N5195 Transistor (P.U.T.) MPU131 Diode, Zener 31V

[★] Product Safety Device

SPACE ENCOUNTERS

GAME LOGIC BOARD [PC - A084 - 90700 - A905]		STROBE AND LIGHT UNIT [PC A084 - 91359]		
CHIP NUMBER	FUNCTION	DEVICES	FUNCTION	
7400	Quad two input Nand	MDC3011	Opto - Isolator	
7402	Quad two input Nor	SC141D	Triac	
7404	Hex inverter	7414	Hex Schmitt Trigger	
74LS08	Quad two input And	555	Timer	
7417	Hex Buffer	FT19 - 30K	Strobe Light Assembly	
7438	Quad two input Nand Buffer	C108C1	SCR	
7442	BCD-Decimal Decoder	1N4004	Diode	
7474	Dual ''D'' Type Flip - Flop			
7483	4 Bit Binary Adder			
74\$89	64 Bit Ram	SOUN	O GENERATOR	
74109	Dual ''JK'' Flip Flop	[PC A084	1 - 91324 - F - 645]	
74LS138	3 to 8 line Decoder Multiplexer	CHIP NUMBER	FUNCTION	
74LS153	Dual 4 to 1 line Multiplexer	4006	18 Bit Shift Register	
74157	Quad 2 to 1 line Multiplexer	4016	Quad Electronic Switch	
74161	4 Bit Binary Counter	4030	Quad Exclusive OR	
74174	Hex ''D'' Type Flip Flop	LM324	Quad OP. Amp.	
74175	Quad "D" Type Flip Flop	LM339	Quad Voltage Comparator	
74191	Binary up - down Counter	LM377	Dual Audio Amp.	
74S201	256 Bit Ram	556	Dual Timer	
27LS00	256 Bit Ram	76477	Sound Generator	
74LS298	Quad 2 input Multiplexer	7411	3 Input And	
ADDITIONAL		2N4871	Unijunction Transistor	
DEVICES	FUNCTION	ADDITIONAL		
2N4401	Transistor	DEVICES	FUNCTION	
TIP-110	Transistor	C108B1	SCR	
1N4004	Diode	MPSA20	Transistor	
1N4148	Diode	TIP-32	Transistor	