OPERATOR'S MANUAL



快打獅子皇帝

SS711105)

▼ 取扱説明書 ▶

POWER SUPPLY	DC+5V DC+12V				
MONITOR	VERTICAL SCREEN				
GAME STYLE	2-PLAYER SIMULTANEOUS				



CONNECTOR DIAGRAM

SOLDER SIDE	NO.	NO.	PARTS SIDE
GND	A	1	GND
GND	В	2	GND
+5 V	С	3	+5V
+5V	D	4	+5V
−5V	E	5	-5V
+12V	F	6	+12V
	Н	7	
COIN COUNTER 2	J	8	COIN COUNTER 1
	K	9	9
SPEAKER(-)	L	10	SPEAKER(+)
	M	11	0 8
VIDEO GREEN	N	12	VIDEO RED
VIDEO SYNC	P	13	VIDEO BLUE
SERVICE SW	R	14	VIDEO GND
TEST SW	S	15	
COIN SW 2	Т	16	COIN SW 1
2-P START	U	17	1-P START
2-P UP	V	18	1-P UP
2-P DOWN	w	19	1-P DOWN
2-P LEFT	X	20	1-P LEFT
2-P RIGHT	Y	21	1-P RIGHT
2-P SW 1 BUTTON	z	22	1-P SW 1 BUTTON
2-P SW 2 BUTTON	а	23	1-P SW 2 BUTTON
	b	24	
	C	25	
	d	26	13
GND	e	27	GND
GND	f	28	GND

HOW TO PLAY

- ■ショットとミサイル・ボムを使い、敵を倒します。
- **■**6つのステージをクリアするとエンディングです。
- Attack the enemy mith the shot and missile bomb.
- ■Game is over when you clear six stages.

CONTROL PANEL

Controls your Figter.



Shot Sub Weapon





Button-A

Button-B

Special

DIP-SWITCH 1

	4	[1]	[2]	[3]	[4]	[5]	[6]	[7]	[8]
Fighters	•3	* OFF	* OFF						
	•1	ON	OFF						
	•2	OFF	ON						
	●5	ON	ON						
Bomb	•3			* OFF	* OFF				
	• 1	15		ON	OFF				
	•2			OFF	ON				
	●5			ON	ON				
Difficulty	• Easy					OFF	OFF		
	Normal					* ON	* OFF		
	Hard		1			OFF	ON		
	Super Hard					ON	ON		
Extend	● 200,000 and 500,000							* OFF	* OFF
Player	● 100,000 and 300,000							ON	OFF
	• 500,000 and 1,000,000							OFF	ON
	●1,000,000 and 3,000,000			122				ON	ON

DIP-SWITCH 2

	[1]	[2]	[3]	[4]	[5]	[6]	[7]	[8]
Coin 1 ●1 COIN = 1 CREDIT	* OFF	* OFF	* OFF	* OFF				
• 2 COINS = 1 CREDIT	ON	OFF	OFF	OFF		-6	×	
•3 COINS = 1 CREDIT	OFF	ON	OFF	OFF				
4 COINS = 1 CREDIT	ON	ON	OFF	OFF				
•5 COINS = 1 CREDIT	OFF	OFF	ON	OFF		12		
● 6 COINS = 1 CREDIT	ON	OFF	ON	OFF				
● 1 COIN = 2 CREDITS	OFF	ON	ON	OFF	- 7			
• 1 COIN = 3 CREDITS	ON	ON	ON	OFF	P 5			
● 1 COIN = 4 CREDITS	OFF	OFF	OFF	ON	0,-			
• 1 COIN = 5 CREDITS	ON	OFF	OFF	ON				
● 1 COIN = 6 CREDITS	OFF	ON	OFF	ON		1.5		
● 2 COINS = 3 CREDITS	ON	ON	OFF	ON				
•3 COINS = 2 CREDITS	OFF	OFF	ON	ON				
•5 COINS = 3 CREDITS	ON	OFF	ON	ON				
●8 COINS = 3 CREDITS	OFF	ON	ON	ON				
● FREE PLAY	ON	ON	ON	ON				
Screen Revers • Normal • Invert			s.' .		* OFF ON	200		
Continue ON					0.0	* OFF		
• OFF						ON		
Demo Sound ● ON							* OFF	
● OFF							ON	
Test Mode ● OFF								* OFF
● ON								ON

[■]Demo SoundがOFFの時は、コイン待ちデモの時に音が鳴らないようになります。 ■When DEMO-SOUND is "OFF", there will be no sound during demonstration mode.

⁻* 出荷時の設定

^{*} INDICATES FACTORY SETTING.

