■PULSTAR SOFT DIP■

INITIAL SETTING SCREEN

	P	U	L	S	T	A	R	
FIGHTERS								3
CONTINUE								HTIW
DEMO SOUND								WITH
HOW TO PLAY								WITH
DIFFICULTY								LEVEL 4
CREDIT								WITH
LEVEL								WITH
1UP SCORE								300k/200k

[HOW TO PLAY]

- ① Use the Joystick to move cursor to items you want to change.
- ② Press A Button to proceed to new settings and set selections. Press B Button to return to previous settings.

41
[PLAYER STOCK] Set numbers of fighters.
NORMAL SETTING $3 \sim 6$
[CONTINUE] Set "CONTINUE" option.
NORMAL SETTING With → Without
[DEMO SOUND] Set sound during demonstration screens.
NORMAL SETTING With → Without
[HOW TO PLAY] Set the "How to Play" instructions at the
beginning of the game.
NORMAL SETTING With → Without
[DIFFICULTY] Select 1 of 8 difficulty settings.
Level 1 \rightarrow Level 2 \rightarrow Level 3 \rightarrow Level 4 \rightarrow Level 5 \rightarrow
Level 6 \rightarrow Level 7 \rightarrow Level 8 $\%$ 1/Easiest 8/Most difficui
[CREDIT] Set credit displays.
NORMAL SETTING With → Without WITH
[LEVEL] WITH OR WITHOUT DIFFICULTY DISPLAY
NORMAL SETTING With -> Without
[1UP SCORE] Select score for extra fighter.
$\frac{10}{10}$ 10k=10,000 points.
$200k/200k \rightarrow 300k/200k \rightarrow 300k/300k \rightarrow 400k/300k$
NODMAT CEMMING 3001/2001

NORMAL SETTING 300k/200k

SETTING UP THE SOFT DIP ON THE MULTI VIDEO SYSTEM

- 1. TURN POWER ON.
- 2. PUSH THE TEST BUTTON INSIDE THE CABINET.
- THE FOLLOWING SCREEN WILL APPEAR.

MOVE LEFT JOYSTICK UP/DOWN TO MOVE THE POINTER TO "SETTING UP THE SOFT DIP". PRESS "A" BUTTON TO SET.

HARDWARE TEST
SETTING UP THE HARD DIP
SETTING UP THE SOFT DIP
BOOKKEEPING
SETTING UP THE CODE NUMBER
SETTING UP THE CALENDAR
EXIT

THE FOLLOWING SCREEN WILL BE DISPLAYED:

SLOT 1 (GAME TITLE)
SLOT 2 (GAME TITLE)
SLOT 3 (GAME TITLE)
SLOT 4 (GAME TITLE)
SLOT 5 (GAME TITLE)
SLOT 6 (GAME TITLE)

CABINET SET UP

4. SELECT THE GAME TITLE YOU WANT AND PRESS "A" BUTTON TO VIEW THE SOFT DIP SETTING OF EACH INDIVIDUAL GAME.