









APPENDIX C

ARCADE MAIN HARNESS DEFINITIONS

FROM	PIN	T9	PIN	SIGNAL
LF SW SW LF LF	HOT N/OPEN N/OPEN NEUTRAL NEUTRAL	SW PS1 VDP PS1 VDP	COMMON 3 HOT 2 NEUTRAL	AC LINE HOT AC LINE HOT AC LINE HOT AC LINE NEUTRAL AC LINE NEUTRAL
PS2 PS2 PS2 PS2 PS2 PS2	1 3 3 2 4 4	ISO LAMP FAN ISO LAMP FAN	PRI HOT HOT PRI NEUTRAL NEUTRAL	115V AC #1 HOT 115V AC #2 HOT 115V AC #2 HOT 115V AC #1 NEUTRAL 115V AC #2 NEUTRAL 115V AC #2 NEUTRAL
MON PS1 LF LF CPU COIN OCP	FRAME 1 FRAME FRAME FRAME 3 9	LAMP MON PS1 CPU COIN OCP CP	FRAME FRAME 1 FRAME 3 9 7	FRAME GROUND
PS1 PS1 PS1 PS1 PS1	9 10 11 7 12	CEU CEU CEU CEU	3 4· 7 30 8	+5V +5V +5V RETURN +25V +25V RETURN
PSI PSI COIN COIN COIN	5 4 1 2 7	COIN COIN CPU CPU CPU	8 9 10 14 11	6.3V AC LAMPS 6.3V AC LAMPS RETURN COIN SLOT 0 COIN SLOT 1 COIN RETURN
មិដូដូដូដូដូដូ	2 3 4 5 6 8 9	CPU CPU CPU CPU CPU CPU CPU	6 2 1 29 5 9 13 12	AUX GROUND AUX +5V NOT USED NOT USED HEADPHONE (LEFT) NOT USED NOT USED HEADPHONE RETURN (LEFT)
0CP 0CP 0CP 0CP 0CP 0CP	4 8 3 1 5 7	CPU CPU CPU CPU CPU	33 32 J8CENTER J8SHIFLD J7CENTER J7SHIFLD	COIN COUNTER COIN COUNTER RETURN L VOLUME OUT L VOLUME OUT RETURN R VOLUME OUT R VOLUME OUT

FROM	PIN	TO	PIN	SIGNAL
0CP 0CP 0CP 0CP	2 1 6 7	CPU CPU CPU CPU	24 23 16 15	L VOLUME IN L VOLUME IN RETURN R VOLUME IN R VOLUME IN RETURN
CPU CPU	28 27	SPKR SPKR	[.+ [SPEAKER (LEFT) SPEAKER RETURN (LEFT)
CPU CPU	20 19	SPKR SPKR	R+ R-	SPEAKER (RIGHT) SPEAKER RETURN (RIGHT)

PS1 = POWER SUPPLY 12 PIN CONNECTOR PS2 = POWER SUPPLY 4 PIN CONNECTOR

FAN = COOLING FAN SW = POWER SWITCH

CPU = CIRCUIT BOARD MODULE

LAMP = FLUORESCENT LAMP (MARQUEE)

CP = CONTROL PANEL

SPKR = SPEAKERS COIN = COIN DOOR MON = MONITOR

VDP = VIDEODISC PLAYER LF = AC LINE FILTER

LF = AC LINE FILTER

OCP = OPERATOR CONVENIENCE PANEL

ISO = MONITOR ISOLATION TRANSFORMER

NOTE: GAMES EQUIPPED WITH PR7820 DISC PLAYERS HAVE DISC PLAYER FRAME GROUND TIED TO LINE FILTER FRAME GROUND.