



# SCPH-30000 R series

## SERVICE MANUAL

4th Edition

for GH015(12/22) MOUNT ( F-type model )

SCPH-30001 R  
SCPH-30002 R  
SCPH-30003 R  
SCPH-30004 R  
SCPH-30005 R  
SCPH-30006 R  
SCPH-30007 R

PlayStation®2

Sony Computer Entertainment Inc.  
Quality Assurance Department  
Published in Japan ©12.2001. 9-927-093-51



**NOTICE**

Copyright by Sony Computer Entertainment Inc. All rights reserved. No reproduced and transferred required except permission by Sony Computer Entertainment Inc. No commercial use and rental required.

**REVISIONS.**

This manual compiled by second edition of SCPH-30000 R series D type and F type models design data. Design and Specification will be subject to changed without notice. The latest versions of service manual, Technical memo, Technical information should be used together.

**SAFETY-RELATED COMPONENT WARNING !!**

COMPONENTS IDENTIFIED BY MARK ▲ OR DOTTED LINE WITH MARK ▲ ON THE SCHEMATIC DIAGRAMS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY.

**ATTENTION AU COMPOSANT AYANT RAPPORT À LA SÉCURITÉ !**

LES COMPOSANTS IDENTIFIÉS PAR UNE MARQUE ▲ SUR LES DIAGRAMMES SCHÉMATIQUES ET LA LISTE DES PIÈCES SONT CRITIQUES POUR LA SÉCURITÉ DE FONCTIONNEMENT. NE REMPLACER CES COMPOSANTS QUE PAR DES PIÈCES SONY DONT LES NUMÉROS SONT DONNÉS DANS CE MANUEL OU DANS LES SUPPLÉMENTSUBLIÉS PAR SONY.

**CAUTION**

Replace the battery with a Sony CR2032 battery. Use of any other type of battery may present the risk of fire or explosion. The battery may explode if mistreated. Do not recharge, disassemble, or dispose of in fire.

**CAUTION**

The use of optical instruments with this product will increase eye Hazard. As the laser beam used in this CD/DVD player is harmful To eyes, do not attempt to disassemble the cabinet. Refer servicing to qualified personnel only.

**WARNING !!**

WHEN SERVICING, DO NOT APPROACH THE LASER EXIT WITH THE EYE TOO CLOSELY. IN CASE IT IS NECESSARY TO CONFIRM LASER BEAM EMISSION, BE SURE TO OBSERVE FROM A DISTANCE OF MORE THAN 25cm FROM THE SURFACE OF THE OBJECTIVE LENS ON THE OPTICAL PICK-UP BLOCK.

**CAUTION**

Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

**CAUTION for electric shock**

When power is ON, Don't touch to Power supply block, AC-inlet, Power switch and so on, not to get an electric shock at repair.

**CAUTION for burning**

When current is supplied, Some of part surface temperature like EE, GS, Regulator-IC, power supply, Optical device and so on. These part surface is become high temperature condition. When it repair, Don't touch them at a time during it surface is high temperature condition to take prevent against burning. Do repair after it is cooled down enough.

**CAUTION**

Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Discard used batteries according to the manufacturer's instructions.

**ADVARSEL!**

Lithiumbatteri - Eksplorationsfare ved fejlagtig håndtering. Udskiftning må kun ske med batteri af samme fabrikat og type. Lever det brugte batteri til leverandøren.

**ADVARSEL**

Eksplorationsfare ved feilaktig skifte av batteri. Benytt samme batteritype eller en tilsvarende type anbefalt av apparatfabrikanten. Brukte batterier kasseres i henhold til fabrikantens instruksjoner.

**VARNING**

Explosionsfara vid felaktigt batteribyte. Använd samma batterityp eller en ekvivalent typ som rekommenderas av apparattillverkaren. Kassera använd batteri enligt fabrikantens instruktion.

**VAROITUS**

Paristo voi räjähtää, jos se on virheellisesti asennettu. Vaihda paristo ainoastaan valmistajan suosittelemaan tyypin. Hävitä käytetty paristo valmistajan ohjeiden mukaisesti.

**SAFETY CHECK-OUT**

After correcting the original service problem, perform the following safety checks before releasing the set to the customer:

1. Check the area of your repair for unsoldered or cold-soldered connections. Check the entire board surface for solder splashes and bridges.
2. Check the inter board wiring to ensure that no wires are "pinched" or contact high-wattage resistors.
3. Look for unauthorized replacement parts, particularly transistors, that were installed during a previous repair. Point them out to the customer and recommend their replacement.
4. Look for parts which, though functioning, show obvious signs of deterioration. Point them out to the customer and recommend their replacement.
5. Check the line cord for cracks and abrasion. Recommend the replacement of any such line cord to the customer.
6. Check the b+ voltage to see it is at the values specified.
7. Check the antenna terminals, metal trim, "metalized" knobs, screws, and all other exposed metal parts for ac leakage. Check leakage as described below.

**LEAKAGE**

The AC leakage from any exposed metal part to earth ground and from all exposed metal parts to any exposed metal part having a Return to chassis, must not exceed 0.5 mA (500 micro-amperes). Leakage current can be measured by any one of three methods.

1. A commercial leakage tester, such as the SIMPSON 229 or RCA WT-540A. Follow the manufacturers' instructions to use these instruments.
2. A battery-operated AC milli-ammeter. The Data Precision 245 digital multi-meter is suitable for this job.
3. Measuring the voltage drop across a resistor by means of a VOM or battery-operated ac voltmeter. The "limit" indication is 0.75V, so analog meters must have an accurate low-voltage scale. The SIMPSON 250 and SANWA SH-63TRD are examples of a passive VOM that is suitable. Nearly all battery operated digital multi-meters that have a 2V AC range are suitable.




Fig A. Using AC voltmeter to check AC leakage

**NOTIFICATION for environmental assessment**

This model is CR2032 lithium battery onboard inside on the GB MOUNT or GH MOUNT as Timer backup power. CR2032 life may be about 5 to 8 years, so you have very few need for changing to new one. But if you have necessary to replaced to new one or disassemble for scrapping, you have to keep your country law, regulation, standard, etc. of environmental assessment and safety.

# TABLE OF CONTENTS

## SCPH-30000 R series F-type model with GH015(12/22) MOUNT

<b>1. SPECIFICATIONS</b>	.....	GH015(12/22)- 4
<b>2. SUPPLIED ACCESSORIES AND PACKING BLOCK</b>	.....	GH015(12/22)- 5
<b>3. INSTRUCTION MANUAL BLOCK</b>	.....	GH015(12/22)- 7
<b>4. EXPLODED VIEWS</b>		
Overall and Main Block	.....	GH015(12/22)- 8
MD Block	.....	GH015(12/22)-11
GH Mount Block and Shield (A) Assy Block	.....	GH015(12/22)-12
Switch Assy Block	.....	GH015(12/22)-13
Power Switch, Fan and Rear Panel Assy Block	.....	GH015(12/22)-14
<b>5. Block Diagram</b>	.....	GH015(12/22)-15
<b>6. Printed Wiring Boards and Schematic Diagrams</b>		
Note for Printed Wiring Boards and Schematic Diagrams	.....	GH015(12/22)-16
GH015(12/22) Mount	.....	GH015(12/22)-17
Electrical Parts List for GH015(12/22) Mount	.....	GH015(12/22)-28
Switch Mount	.....	GH015(12/22)-37

## 1. SPECIFICATIONS

### General

#### Power requirements

120 V AC, 60 Hz	for SCPH-30001 R
220 -240 V AC, 50/60 Hz	for SCPH-30002 R/-30003 R/-30004 R
220 V AC, 50/60 Hz	for SCPH-30005 R
220 -240 V AC, 50/60 Hz	for SCPH-30006 R
110 V AC, 50/60 Hz	for SCPH-30007 R

#### Power consumption

79 W	for SCPH-30001 R
50 W	for SCPH-30002 R/-30003 R/-30004 R
	SCPH-30005 R/-30006 R
47W	for SCPH-30007 R

#### Dimensions

301 x 78 x 182 mm (w/h/d)

#### Mass

2.4 kg

### Inputs/Outputs on the front

Controller ports (2)  
Memory card slots (2)  
USB ports (2)  
S400 (i-Link) port (1)

### Inputs/Outputs on the rear

HDD bay slot (1)

### Outputs on the rear

AV Multi out port (1)  
RGB, Ycbcr, Y/C, Composite-video,  
Audio-L/R, XGA  
Digital out port (1)  
Optical audio

### Supplied accessories

AC power cord (1)  
A/V connecting cable (1)  
Dualshock2 Analog controller (1)  
Euro-AV Connector (1)  
for SCPH-30003 R/-30004 R

## 2. SUPPLIED ACCESSORIES AND PACKING BLOCK

## NOTE :

- Due to standardization, replacements in the parts list may be different from the parts specified in the diagrams or the components used on the set.
- -XX and -X mean standardized parts, so they may have some difference from the original one.
- RESISTORS  
METAL : Metal-film resistor.  
F : nonflammable  
Unit is  $\Omega$ .

- SEMICONDUCTORS  
In each case, u :  $\mu$ , for example :  
uA ... :  $\mu$ A ... uPA ... :  $\mu$ PA ...  
uPB ... :  $\mu$ PB ... uPC ... :  $\mu$ PC ... uPD ... :  $\mu$ PD ...
- CAPACITORS  
uF :  $\mu$ F
- COILS  
uH :  $\mu$ H

The components identified by mark  $\triangle$  or dotted line with mark  $\triangle$  are critical for safety.  
Replace only with part number specified.

## SUPPLIED ACCESSORIES and PACKING GROUP

PLACE CODE #23

## \*\*\*\*\* SCPH-30001 R F-type model ACCESSORIES &amp; PACKING GROUP \*\*\*\*\*

Ref.	Part No.	Description
$\triangle$ AC	1-790-108-21	CORD, POWER
AV	1-792-028-11	AV CABLE (Integrated audio/video)
AV	1-792-028-21	AV CABLE (Integrated audio/video)
AV	1-792-028-31	AV CABLE (Integrated audio/video)
AV	1-792-028-41	AV CABLE (Integrated audio/video)
AV	1-792-028-51	AV CABLE (Integrated audio/video)
AV	1-792-028-61	AV CABLE (Integrated audio/video)
CONT	1-792-238-72	ANALOG CONTROLLER (DUALSHOCK 2)
CONT	1-823-069-11	ANALOG CONTROLLER (DUALSHOCK 2)
CONT	1-823-091-11	ANALOG CONTROLLER (DUALSHOCK 2)
CONT	1-823-552-11	ANALOG CONTROLLER (DUALSHOCK 2)
CU	3-064-714-01	CUSHION
CU2	3-064-713-01	CUSHION 2
SH	3-065-170-01	SHEET, PROTECTION
CA	3-071-632-11	INDIVIDUAL CARTON
MC	3-071-633-01	MASTER CARTON, 3 SETS
TA	3-987-483-11	TAPE, BERODDED PREVENTION
IMB	A-6785-354-A	MANUAL BLOCK ASSY, INSTRUCTION

## \*\*\*\*\* SCPH-30002 R F-type model ACCESSORIES &amp; PACKING GROUP \*\*\*\*\*

Ref.	Part No.	Description
$\triangle$ AC	1-555-074-51	CORD, POWER
AV	1-792-028-11	AV CABLE (Integrated audio/video)
AV	1-792-028-21	AV CABLE (Integrated audio/video)
AV	1-792-028-31	AV CABLE (Integrated audio/video)
AV	1-792-028-41	AV CABLE (Integrated audio/video)
AV	1-792-028-51	AV CABLE (Integrated audio/video)
AV	1-792-028-61	AV CABLE (Integrated audio/video)
CONT	1-792-238-72	ANALOG CONTROLLER (DUALSHOCK 2)
CONT	1-823-069-11	ANALOG CONTROLLER (DUALSHOCK 2)
CONT	1-823-091-11	ANALOG CONTROLLER (DUALSHOCK 2)
CONT	1-823-552-11	ANALOG CONTROLLER (DUALSHOCK 2)
CU	3-064-714-01	CUSHION
SH	3-060-494-01	SHEET, PROTECTION
CA	3-071-639-01	INDIVIDUAL CARTON
PAD	3-065-172-01	PAD, TOGETHER PACKING
MC	3-071-635-52	MASTER CARTON, 3 SETS
TA	3-987-483-11	TAPE, BERODDED PREVENTION
IMB	A-6785-379-A	MANUAL BLOCK ASSY, INSTRUCTION

## \*\*\*\*\* SCPH-30003 R F-type model ACCESSORIES &amp; PACKING GROUP \*\*\*\*\*

Ref.	Part No.	Description
CONV	1-785-004-12	CONNECTOR, CONVERSION
CONV	1-573-291-12	CONNECTOR, CONVERSION
$\triangle$ AC	1-751-115-21	CORD, POWER
$\triangle$ AC	1-751-115-31	CORD, POWER
$\triangle$ AC	1-790-023-21	CODE, POWER
AV	1-792-028-11	AV CABLE (Integrated audio/video)
AV	1-792-028-21	AV CABLE (Integrated audio/video)
AV	1-792-028-31	AV CABLE (Integrated audio/video)
AV	1-792-028-41	AV CABLE (Integrated audio/video)
AV	1-792-028-51	AV CABLE (Integrated audio/video)
AV	1-792-028-61	AV CABLE (Integrated audio/video)
CONT	1-792-238-72	ANALOG CONTROLLER (DUALSHOCK 2)
CONT	1-823-069-11	ANALOG CONTROLLER (DUALSHOCK 2)
CONT	1-823-091-11	ANALOG CONTROLLER (DUALSHOCK 2)
CONT	1-823-552-11	ANALOG CONTROLLER (DUALSHOCK 2)
CU	3-064-714-01	CUSHION
SH	3-060-494-01	SHEET, PROTECTION
CA	3-071-634-11	INDIVIDUAL CARTON
PAD	3-065-172-01	PAD, TOGETHER PACKING
MC	3-071-635-42	MASTER CARTON, 3 SETS
TA	3-987-483-11	TAPE, BERODDED PREVENTION
IMB	A-6785-377-A	MANUAL BLOCK ASSY, INSTRUCTION

## \*\*\*\*\* SCPH-30004 R F-type model ACCESSORIES &amp; PACKING GROUP \*\*\*\*\*

Ref.	Part No.	Description
CONV	1-785-004-12	CONNECTOR, CONVERSION
CONV	1-573-291-12	CONNECTOR, CONVERSION
$\triangle$ AC	1-575-131-82	CORD, POWER
$\triangle$ AC	1-823-152-11	CORD, POWER
AV	1-792-028-11	AV CABLE (Integrated audio/video)
AV	1-792-028-21	AV CABLE (Integrated audio/video)
AV	1-792-028-31	AV CABLE (Integrated audio/video)
AV	1-792-028-41	AV CABLE (Integrated audio/video)
AV	1-792-028-51	AV CABLE (Integrated audio/video)
AV	1-792-028-61	AV CABLE (Integrated audio/video)
CONT	1-792-238-72	ANALOG CONTROLLER (DUALSHOCK 2)
CONT	1-823-069-11	ANALOG CONTROLLER (DUALSHOCK 2)
CONT	1-823-091-11	ANALOG CONTROLLER (DUALSHOCK 2)
CONT	1-823-552-11	ANALOG CONTROLLER (DUALSHOCK 2)
CU	3-064-714-01	CUSHION
SH	3-060-494-01	SHEET, PROTECTION
CA	3-071-634-02	INDIVIDUAL CARTON
PAD	3-065-172-01	PAD, TOGETHER PACKING
MC	3-071-635-32	MASTER CARTON, 3 SETS
TA	3-987-483-11	TAPE, BERODDED PREVENTION
IMB	A-6785-382-A	MANUAL BLOCK ASSY, INSTRUCTION

**NOTE :**

- Due to standardization, replacements in the parts list may be different from the parts specified in the diagrams or the components used on the set.
- -XX and -X mean standardized parts, so they may have some difference from the original one.
- **RESISTORS**  
METAL : Metal-film resistor.  
F : nonflammable  
Unit is  $\Omega$ .

- **SEMICONDUCTORS**  
In each case, u :  $\mu$ , for example :  
uA ... :  $\mu$ A ... uPA ... :  $\mu$ PA ...  
uPB... :  $\mu$ PB... uPC... :  $\mu$ PC... uPD... :  $\mu$ PD...
- **CAPACITORS**  
uF :  $\mu$ F
- **COILS**  
uH :  $\mu$ H

The components identified by mark  $\triangle$  or dotted line with mark  $\triangle$  are critical for safety.  
Replace only with part number specified.

**SUPPLIED ACCESSORIES and PACKING GROUP**

PLACE CODE #23

**SCPH-30005 R F ACCESSORIES & PACKING GROUP**

Ref. Part No. Description

$\triangle$ AC	1-823-638-11	CORD, POWER
AV	1-792-028-11	AV CABLE (Integrated audio/video)
AV	1-792-028-21	AV CABLE (Integrated audio/video)
AV	1-792-028-31	AV CABLE (Integrated audio/video)
AV	1-792-028-41	AV CABLE (Integrated audio/video)
AV	1-792-028-51	AV CABLE (Integrated audio/video)
AV	1-792-028-61	AV CABLE (Integrated audio/video)
CONT	1-792-238-72	ANALOG CONTROLLER (DUALSHOCK 2)
CONT	1-823-069-11	ANALOG CONTROLLER (DUALSHOCK 2)
CONT	1-823-091-11	ANALOG CONTROLLER (DUALSHOCK 2)
CONT	1-823-552-11	ANALOG CONTROLLER (DUALSHOCK 2)
CU	3-064-714-01	CUSHION
SH	3-060-494-01	SHEET, PROTECTION
CA	3-072-722-01	INDIVIDUAL CARTON
MC	3-072-723-01	MASTER CARTON, 3 SETS
IMB	A-6705-464-A	MANUAL BLOCK ASSY, INSTRUCTION

**SCPH-30006 R F ACCESSORIES & PACKING GROUP**

\*\*\*\*\*

Ref. Part No. Description

$\triangle$ AC	1-823-738-11	CORD, POWER
AV	1-792-028-11	AV CABLE (Integrated audio/video)
AV	1-792-028-21	AV CABLE (Integrated audio/video)
AV	1-792-028-31	AV CABLE (Integrated audio/video)
AV	1-792-028-41	AV CABLE (Integrated audio/video)
AV	1-792-028-51	AV CABLE (Integrated audio/video)
AV	1-792-028-61	AV CABLE (Integrated audio/video)
CONT	1-792-238-72	ANALOG CONTROLLER (DUALSHOCK 2)
CONT	1-823-069-11	ANALOG CONTROLLER (DUALSHOCK 2)
CONT	1-823-091-11	ANALOG CONTROLLER (DUALSHOCK 2)
CONT	1-823-552-11	ANALOG CONTROLLER (DUALSHOCK 2)
CU	3-064-714-01	CUSHION
SH	3-060-494-01	SHEET, PROTECTION
CA	3-072-727-01	INDIVIDUAL CARTON
MC	3-072-728-01	MASTER CARTON, 3 SETS
IMB	A-6705-462-A	MANUAL BLOCK ASSY, INSTRUCTION

**SCPH-30007 R F ACCESSORIES & PACKING GROUP**

\*\*\*\*\*

Ref. Part No. Description

$\triangle$ AC	1-757-562-61	CORD, POWER
AV	1-792-028-11	AV CABLE (Integrated audio/video)
AV	1-792-028-21	AV CABLE (Integrated audio/video)
AV	1-792-028-31	AV CABLE (Integrated audio/video)
AV	1-792-028-41	AV CABLE (Integrated audio/video)
AV	1-792-028-51	AV CABLE (Integrated audio/video)
AV	1-792-028-61	AV CABLE (Integrated audio/video)
CONT	1-792-238-72	ANALOG CONTROLLER (DUALSHOCK 2)
CONT	1-823-069-11	ANALOG CONTROLLER (DUALSHOCK 2)
CONT	1-823-091-11	ANALOG CONTROLLER (DUALSHOCK 2)
CONT	1-823-552-11	ANALOG CONTROLLER (DUALSHOCK 2)
CU	3-064-714-01	CUSHION
SH	3-060-494-01	SHEET, PROTECTION
CA	3-074-221-01	INDIVIDUAL CARTON
MC	3-074-220-01	MASTER CARTON, 3 SETS
IMB	A-6705-476-A	MANUAL BLOCK ASSY, INSTRUCTION

### 3. INSTRUCTION MANUAL BLOCK

## NOTE :

- SEMICONDUCTORS  
In each case, u :  $\mu$ , for example :  
uA ... :  $\mu$ A ... uPA ... :  $\mu$ PA ...  
uPB... :  $\mu$ PB... uPC... :  $\mu$ PC... uPD... :  $\mu$ PD...
  - CAPACITORS  
 $\mu$ F :  $\mu$ F
  - COILS  
 $\mu$ H :  $\mu$ H
  - RESISTORS
- METAL : Metal-film resistor.  
F : nonflammable  
Unit is  $\Omega$ .

The components identified by mark  $\triangle$  or dotted line with mark  $\triangle$  are critical for safety.  
Replace only with part number specified.

## INSTRUCTION MANUAL BLOCK ASSY

PLACE CODE #23

A-6785-354-A INSTRUCTION MANUAL BLOCK ASSY  
for SCPH-3001 R (F-type)

<u>Ref.</u>	<u>Part No.</u>	<u>Description</u>
CI	3-072-824-01	CARD, CUSTOMER INQUIRY
CS	3-066-966-01	CARD, SERVICE NUMBER
ES	3-060-161-02	SHEET, ESRB
IM	3-071-581-13	MANUAL, INSTRUCTION

A-6785-377-A INSTRUCTION MANUAL BLOCK ASSY  
for SCPH-3003 R (F-type)

<u>Ref.</u>	<u>Part No.</u>	<u>Description</u>
BOR	3-066-159-02	CARD (B), OWNER REGISTRATION
DISK	3-073-543-01	DISK, DEMONSTRATION
IM	3-071-581-33	MANUAL, INSTRUCTION
SE	3-987-375-02	SEAL, SEAL

A-6705-464-A INSTRUCTION MANUAL BLOCK ASSY  
for SCPH-3005 R (F type)

<u>Ref.</u>	<u>Part No.</u>	<u>Description</u>
IM	3-071-581-61	MANUAL, INSTRUCTION

A-6705-476-A INSTRUCTION MANUAL BLOCK ASSY  
for SCPH-3007 R (F-type)

<u>Ref.</u>	<u>Part No.</u>	<u>Description</u>
IM	3-071-581-	MANUAL, INSTRUCTION

A-6785-379-A INSTRUCTION MANUAL BLOCK ASSY  
for SCPH-3002 R (F-type)

<u>Ref.</u>	<u>Part No.</u>	<u>Description</u>
AOR	3-066-158-02	CARD (A), OWNER REGISTRATION
DISK	3-073-543-01	DISK, DEMONSTRATION
IM	3-071-581-22	MANUAL, INSTRUCTION
SE	3-987-375-02	SEAL, SEAL

A-6785-382-A INSTRUCTION MANUAL BLOCK ASSY  
for SCPH-3004 R (F-type)

<u>Ref.</u>	<u>Part No.</u>	<u>Description</u>
COR	3-066-160-03	CARD (C), OWNER REGISTRATION
DISK	3-073-543-01	DISK, DEMONSTRATION
IM	3-071-581-43	MANUAL, INSTRUCTION
IM	3-071-581-53	MANUAL, INSTRUCTION
SE	3-987-375-02	SEAL, SEAL


A-6705-462-A INSTRUCTION MANUAL BLOCK ASSY  
for SCPH-3006 R (F-type)

<u>Ref.</u>	<u>Part No.</u>	<u>Description</u>
IM	3-071-581-71	MANUAL, INSTRUCTION

## 4. EXPLODED VIEWS

## Overall and Main Block

for SCPH-30001 R(UC2)



## CAUTION


The components identified by mark  $\triangle$  or dotted line with mark  $\triangle$  are critical for safety.  
Replace only with part number specified.

**CAUTION :**  
Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

## OVERALL AND MAIN BLOCK

Ref-No.	Part No.	Description	Remark	Place code
$\triangle$	60	POWER BLOCK	for 120V AC	#00
$\triangle$	60	POWER BLOCK	for 120V AC	#00
61	1-528-174-41	BATTERY, LITHIUM (CR2032 TYPE)		#25GH
62	1-694-873-11	TERMINAL BOARD (FRONT)		#17
62	1-694-874-11	TERMINAL BOARD (FRONT)		#17
$\triangle$	62	TERMINAL BOARD (FRONT)		#17
$\triangle$	71	LABEL, MODEL NUMBER (UC2)		#87
75	3-059-626-03	COVER, SCREW		#22
76	3-059-627-01	CAP		#22
84	3-067-170-01	TAPE (20X20), HARNESS STOPPER		#87
91	A-6705-440-A	MD BLOCK ASSY		#10
92	A-6705-439-A	SWITCH BLOCK ASSY		#87
93	X-3951-706-2	COVER ASSY, LOWER		#87
94	X-3951-705-2	COVER ASSY, UPPER		#87
95	X-3951-099-1	PLATE ASSY, ORNAMENTAL		#87
$\triangle$	103	LABEL, CAUTION		#87
106	3-070-847-01	LID		#87
112	3-066-253-01	TAPE, VOID		#87
151	1-757-934-11	CABLE, FLEXIBLE FLAT (FFC-011)		#12
151	1-757-934-21	CABLE, FLEXIBLE FLAT (FFC-011)		#12
151	1-757-934-31	CABLE, FLEXIBLE FLAT (FFC-011)		#12
152	1-823-341-11	CABLE, FLEXIBLE FLAT (FFC-015)		#12
152	1-823-341-21	CABLE, FLEXIBLE FLAT (FFC-015)		#12
156	3-071-970-02	SHIELD B (F)		#16
$\triangle$	157	3-071-971-01	SHEET, INSULATING	#16
$\triangle$	158	SHIELD HDD (F)		#87
160	3-703-692-01	LABEL, CAUTION, BARRIER		#16
162	3-069-212-01	TAPE, HARNESS STOPPER		#87
B265	3-069-170-01	TAPPING (B2X6.5)		#87
BV312	3-325-679-21	SCREW, TAPPING +BV 3X12		#87
BV316	3-070-296-01	TAPPING +BV 3X16		#87
BV316	3-325-679-91	SCREW (2 LOCK), +BV TAPPING		#87
M354	3-059-622-02	SCREW (M3X54), HEAD TAPPING		#87
M360	3-069-168-01	TITE (CZN), M3X6 +BV S		#87
T250	3-071-976-01	TAPPING (2X5)		#87

## Overall and Main Block for SCPH-30002 R(AU3) /-30003 R(CEK) /-30004 R(CEL)



## CAUTION


The components identified by mark  $\triangle$  or dotted line with mark  $\triangle$  are critical for safety.  
Replace only with part number specified.

**CAUTION :**  
Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

## OVERALL AND MAIN BLOCK

Ref-No.	Part No.	Description	Remark	Place code
$\triangle$ 60	1-468-605-11	POWER BLOCK	for 220-240V AC	#00
$\triangle$ 60	1-468-605-21	POWER BLOCK	for 220-240V AC	#00
$\triangle$ 61	1-528-174-41	BATTERY, LITHIUM (CR2032 TYPE)		#25GH
62	1-694-873-11	TERMINAL BOARD (FRONT)		#17
62	1-694-874-11	TERMINAL BOARD (FRONT)		#17
62	1-694-875-11	TERMINAL BOARD (FRONT)		#17
$\triangle$ 71	3-072-419-01	LABEL, MODEL NUMBER (AU3)	for SCPH-30002 R F	#87
$\triangle$ 71	3-072-418-01	LABEL, MODEL NUMBER (CEK)	for SCPH-30003 R F	#87
$\triangle$ 71	3-072-417-01	LABEL, MODEL NUMBER (CEL)	for SCPH-30004 R F	#87
75	3-059-626-03	COVER, SCREW		#22
76	3-059-627-01	CAP		#22
84	3-067-170-01	TAPE (20X20), HARNESS STOPPER		#87
91	A-6705-440-A	MD BLOCK ASSY		#10
92	A-6705-439-A	SWITCH BLOCK ASSY		#87
93	X-3951-722-2	COVER ASSY, LOWER		#87
94	X-3951-721-2	COVER ASSY, UPPER		#87
95	X-3951-099-1	PLATE ASSY, ORNAMENTAL		#87
106	3-070-847-11	LID		#87
112	3-066-498-01	TAPE, VOID		#87
$\triangle$ 135	3-988-711-02	LABEL, LASER CAUTION		#87
151	1-757-934-11	CABLE, FLEXIBLE FLAT (FFC-011)		#12
151	1-757-934-21	CABLE, FLEXIBLE FLAT (FFC-011)		#12
151	1-757-934-31	CABLE, FLEXIBLE FLAT (FFC-011)		#12
152	1-823-341-11	CABLE, FLEXIBLE FLAT (FFC-015)		#12
152	1-823-341-21	CABLE, FLEXIBLE FLAT (FFC-015)		#12
$\triangle$ 156	3-071-970-02	SHIELD B (F)		#16
157	3-071-971-01	SHEET, INSULATING		#16
158	3-071-973-01	SHIELD HDD (F)		#87
162	3-069-212-01	TAPE, HARNESS STOPPER		#87
B265	3-069-170-01	TAPPING (B2X6.5)		#87
BV312	3-325-679-21	SCREW, TAPPING +BV 3X12		#87
BV316	3-070-296-01	TAPPING +BV 3X16		#87
BV316	3-325-679-91	SCREW (2 LOCK), +BV TAPPING		#87
M354	3-059-622-02	SCREW (M3X54), HEAD TAPPING		#87
M360	3-069-168-01	TITE (CZN), M3X6 +BV S		#87
T250	3-071-976-01	TAPPING (2X5)		#87

# Overall and Main Block for SCPH-30005 R(KR2) /-30006 R(E12) /-30007 R(TW1)




## CAUTION

The components identified by mark  $\triangle$  or dotted line with mark  $\triangle$  are critical for safety.  
Replace only with part number specified.

**CAUTION :**  
Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

## OVERALL AND MAIN BLOCK

Ref-No.	Part No.	Description	Remark	Place code
$\triangle$ 60	1-468-605-11	POWER BLOCK	for SCPH-30005 R /-30006 R	#00
$\triangle$ 60	1-468-605-21	POWER BLOCK	for SCPH-30005 R /-30006 R	#00
$\triangle$ 60	1-468-670-11	POWER BLOCK	for SCPH-30007 R	#00
61	1-528-174-41	BATTERY, LITHIUM (CR2032 TYPE)		#25GH
62	1-694-873-11	TERMINAL BOARD (FRONT)		#17
62	1-694-874-11	TERMINAL BOARD (FRONT)		#17
62	1-694-875-11	TERMINAL BOARD (FRONT)		#17
$\triangle$ 71	3-072-581-01	LABEL, MODEL NUMBER (KR2)	for SCPH-30005 R	#87
$\triangle$ 71	3-072-582-01	LABEL, MODEL NUMBER (E12)	for SCPH-30006 R	#87
$\triangle$ 71	3-073-958-01	LABEL, MODEL NUMBER (TW1)	for SCPH-30007 R	#87
75	3-059-626-03	COVER, SCREW		#22
76	3-059-627-01	CAP		#22
84	3-067-170-01	TAPE (20X20), HARNESS STOPPER		#87
91	A-6705-440-A	MD BLOCK ASSY		#10
92	A-6705-439-A	SWITCH BLOCK ASSY		#87
93	X-3951-706-2	COVER ASSY, LOWER	for SCPH-30005 R	#87
93	X-3951-722-2	COVER ASSY, LOWER	for SCPH-30006 R /-30007 R	#87
94	X-3951-705-2	COVER ASSY, UPPER	for SCPH-30005 R	#87
94	X-3951-721-2	COVER ASSY, UPPER	for SCPH-30006 R /-30007 R	#87
95	X-3951-099-1	PLATE ASSY, ORNAMENTAL		#87
106	3-070-847-11	LID		#87
112	3-073-722-01	VOID TAPE (E12)	for SCPH-30006 R /-30007 R	#87
112	3-073-723-01	VOID TAPE (KR2)	for SCPH-30005 R	#87
151	1-757-934-11	CABLE, FLEXIBLE FLAT (FFC-011)		#12
151	1-757-934-21	CABLE, FLEXIBLE FLAT (FFC-011)		#12
151	1-757-934-31	CABLE, FLEXIBLE FLAT (FFC-011)		#12
152	1-823-341-11	CABLE, FLEXIBLE FLAT (FFC-015)		#12
152	1-823-341-21	CABLE, FLEXIBLE FLAT (FFC-015)		#12
156	3-071-970-02	SHIELD B (F)		#16
$\triangle$ 157	3-071-971-01	SHEET, INSULATING		#16
158	3-071-973-01	SHIELD HDD (F)		#87
162	3-069-212-01	TAPE, HARNESS STOPPER		#87
B265	3-069-170-01	TAPPING (B2X6.5)		#87
BV312	3-325-679-21	SCREW, TAPPING +BV 3X12		#87
BV316	3-059-622-02	SCREW (2 LOCK), +BV TAPPING		#87
M354	3-325-679-91	SCREW (M3X54), HEAD TAPPING		#87
M360	3-069-168-01	TITE (CZN), M3X6 +BV S		#87
T250	3-071-976-01	TAPPING (2X5)		#87

**MD Block****CAUTION**



The components identified by mark  $\triangle$  or dotted line with mark  $\triangle$  are critical for safety.  
Replace only with part number specified.

**CAUTION :**  
Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

**MD BLOCK**

Ref-No.	Part No.	Description	Remark	Place code
2	1-763-700-21	MOTOR, DC (SPINDLE)		#10SP
2	8-835-733-03	MOTOR, DC SSC28C/C-NP		#10SP
3	1-763-639-21	MOTOR, DC(SLED)		#10
5	3-059-845-01	SCREW (B2X6.5), SHAFT RETAINER		#10
7	X-3951-637-1	FRAME ASSY, SUB		#10
8	3-065-277-01	INSULATOR		#10
9	3-065-276-01	SCREW, STEP		#10
10	3-071-957-01	CHASSIS, MAIN		#10
13	3-059-854-02	SHAFT, MAIN		#10
14	3-059-855-02	RACK		#10
16	3-060-399-01	SCREW, SKEW		#10
17	3-060-400-01	TAPPING (B2X6.5)		#10
22	3-062-728-01	O PLATE 3 MAIN M2X3.2		#10
$\triangle$ 23	1-758-717-11	DEVICE, OPTICAL SF-HD7	Made by Sanyo (Not supply)	#100P
$\triangle$ 23	8-820-151-01	DEVICE, OPTICAL KHS-400C	Made by Sony	#100P
26	X-3952-057-1	CHASSIS ASSY, SUB		#10
27	X-3952-059-1	BRACKET ASSY, PULLEY		#10
28	X-3952-060-1	TRAY ASSY		#10TR
30	X-3952-058-1	FRAME ASSY, MAIN		#10
31	1-680-370-21	PWB, FLEXIBLE		#10
32	3-068-075-02	SCREW (SUB), STEP		#10
33	3-071-965-01	CAM, TILT		#10
34	3-071-966-01	SPRING (TILT), LEAF		#10
35	3-065-282-01	GUIDE (L)		#10
36	3-065-283-01	GUIDE (R)		#10
37	3-065-557-01	SCREW (M2X6.0)		#10


CAUTION : EEPROM DATA is different between optical device made by Sony and made by Sanyo.  
EEPROM DATA have to rewrite BASED ON replacing OPTICAL DEVICE.

**GH Mount Block****Shield (A) Assy Block****GH MOUNT BLOCK**

<u>Ref-No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Remark</u>	<u>Place code</u>
87	3-068-806-02	SHEET (DRIVER), ELECTRIC HEAT		#87
GH015	A-6714-501-A	GH-015 MOUNT	for SCPH-30001 R	#25GH
GH015	A-6714-504-A	GH-015 MOUNT	for SCPH-30002 R	#25GH
GH015	A-6714-505-A	GH-015 MOUNT	for SCPH-30003 R /-30004 R	#25GH
GH015	A-6714-514-A	GH-015 MOUNT	for SCPH-30005 R	#25GH
GH015	A-6714-513-A	GH-015 MOUNT	for SCPH-30006 R	#25GH
GH015	A-6714-520-A	GH-015 MOUNT	for SCPH-30007 R	#25GH

**SHIELD (A) ASSY BLOCK**

<u>Ref-No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Remark</u>	<u>Place code</u>
97	X-3952-061-1	SHIELD A (F) ASSY		#87
120	3-059-652-01	SHEET (A), ELECTRIC HEAT		#87

**Switch Assy Block****SWITCH ASSY BLOCK****A-6705-439-A SW-367 SWITCH ASSY BLOCK for GH015 MOUNT**


<u>Ref-No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Remark</u>	<u>Place code</u>
50	3-059-665-03	BUTTON, SWITCH		#25SW
51	3-059-666-05	BRACKET, SWITCH		#25SW
51	3-066-494-01	BRACKET, SWITCH		#25SW
52	7-685-105-11	TPG +P 2X8, TYPE 2, NON-SLIT		#25SW
53	A-6714-500-A	SW-367 MOUNT		#25SW

**Power Switch, Fan and Rear Panel Assy Block****CAUTION**


The components identified by mark  $\triangle$  or dotted line with mark.  $\triangle$  are critical for safety. Replace only with part number specified.

**CAUTION :**  
Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

<u>Ref-No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Remark</u>	<u>Place code</u>
63	1-763-480-31	DC. FAN		#74
63	1-763-554-31	FAN, DC		#74
63	1-763-756-21	FAN, D.C.		#74
$\triangle$ 64	1-771-994-31	SWITCH, POWER (WITH AC INLET)	for SCPH-30001 R / -30005 R	#00
$\triangle$ 64	1-786-209-21	SWITCH, POWER (WITH AC INLET)	for SCPH-30002 R / -30003 R / -30004 R SCPH-30006 R / -30007 R	#00
159	3-071-901-01	PANEL, REAR	for SCPH-30001 R / -30005 R	#87
159	3-071-901-11	PANEL, REAR	for SCPH-30002 R / -30003 R / -30004 R SCPH-30006 R / -30007 R	#87
BV312	3-325-679-21	SCREW, TAPPING +BV 3X12		#87



## 5. BLOCK DIAGRAM



## 6. PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS for GH015(12/22) MOUNT

### THIS NOTE IS COMMON FOR PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS.

#### Note on Printed Wiring Boards :

- Through hole is omitted.
-  : Pattern on the side which is seen.


#### Note on Schematic Diagram :


- Use caution when replacing chip parts.  
New parts must be attached after removal of chip.  
Be careful not to heat the minus side of tantalum capacitor,  
because it is damaged by the heat.
- All capacitors are in  $\text{F}$  unless otherwise noted.  $\text{pF}$  :  $\text{F}$  50  $\text{WV}$  or less are not indicated except for electrolytics and tantalums.
- All resistors are in  $\Omega$  and 1/4  $\text{W}$  (Chip resistors : 1/10 $\text{W}$ ) unless otherwise specified.
- Chip resistors are 1/8  $\text{W}$  or 1/10  $\text{W}$  unless otherwise noted.  
 $\text{k}\Omega$  : 1000 $\Omega$ ,  $\text{M}\Omega$  : 1000 k $\Omega$ .


<b>Note :</b> The components identified by mark $\triangle$ or dotted line with mark $\triangle$ are critical for safety. Replace only with part number specified.	<b>Note :</b> Les composants identifiés par une marque $\triangle$ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.
--	--


#### Note on DC Power line :

Unit of voltage is V (volt)


- |   |  |
|---|--|
| • +12V :   | • +3.3V :             |
| • +8.0V :  | • +2.5V :             |
| • +5.0V :  | • +1.8V :             |
| • +3.5V :  | • VC :                |
| • +1.7V :  | • +1.5V :             |
| • IN :     | • Main Signal Line :  |
| • OUT :    |  |







— GH015(12/22)-19 —

**note1**

R409 & R414 : 0 ohm  
When C243 is mounted : 33K ohm 0.5%  
When C243 is not mounted : 30K ohm 0.5%


**F type model****GH-015(12/22)-1 (4/8)****Reproduction Prohibited**

## IC607 type used for this circuit.

CXP103049-102GG-TL for SCPH-30001 R

CXP103049-302GG-TL for SCPH-30002 R

CXP103049-202GG-TL for SCPH-30003 R/-30004 R




F type model


note1


R409 & R414 : 0 ohm  
When C243 is mounted : 33K ohm 0.5%  
When C243 is not mounted : 2.2K ohm 30K ohm 0.5%


GH-015(12/22)-2 (4/8)

Reproduction Prohibited











F type model

GH-015(12/22) (8/8)

Reproduction Prohibited





GH-015(12/22)  
B side

## ELECTRICAL PARTS LIST for GH015(12/22) MOUNT

## NOTE :

- Due to standardization, replacements in the parts list may be different from the parts specified in the diagrams or the components used on the set.
- -XX and -X mean standardized parts, so they may have some difference from the original one.
- RESISTORS
  - METAL : Metal-film resistor
  - F : nonflammable
  - Unit is Ω.
- SEMICONDUCTORS
  - In each case, u : μ, for example :
  - uA... : μA...
  - uPA... : μPA...
  - uPB... : μPB...
  - uPC... : μPC...
  - uPD... : μPD...
- CAPACITORS
  - uF : μF
- COILS
  - uH : μH

The components identified by mark  $\triangle$  or dotted line with mark K  $\triangle$  are critical for safety. Replace only with part number specified.

## CAUTION.

TIMER and EEPROM circuit are difference among the MECACON(IC607) VERSION.

## Dissimilarity Parts List for GH015(12/22) MOUNT on SCPH-30000 R series F-type model

## A-6714-501-A GH015(12/22) MOUNT on SCPH-30001 R(UC2) F-type model

Ref.	Part No.	Description	Remarks	Ref.	Part No.	Description	Remarks	Ref.	Part No.	Description	Remarks
IC607	8-752-928-26	IC CXP103049-102GG-TL	MECHACON	C231	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	(1608)	R413	1-218-883-91	RES, CHIP 33K	(1608)
IC505	6-801-172-01	IC MR27V4812F-012TMZ	BOOT+DVD-ROM	C232	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	(1608)	R414	1-216-864-91	CONDUCTOR, CHIP	(1608)
IC505	6-801-195-01	IC K3NSV104SB-TC1AT00	BOOT+DVD-ROM	C233	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	(1608)	C212	1-125-837-91	CAP, CHIP CERAMIC 1MF B	(1608)
IC416	6-701-551-01	IC BU9861FV-WE2	TIMER+EEPROM	C234	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	(1608)	C213	1-125-837-91	CAP, CHIP CERAMIC 1MF B	(1608)
C445	1-117-720-91	CAP, CERAMIC 4.7MF F (2012)		C235	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	(1608)	C214	1-125-837-91	CAP, CHIP CERAMIC 1MF B	(1608)
C449	1-162-964-91	CAP, CHIP CERAMIC 100PF B (1608)		C236	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	(1608)	C215	1-125-837-91	CAP, CHIP CERAMIC 1MF B	(1608)
C452	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)		C237	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	(1608)	C216	1-125-837-91	CAP, CHIP CERAMIC 1MF B	(1608)
C453	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)		C238	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	(1608)	C217	1-125-837-91	CAP, CHIP CERAMIC 1MF B	(1608)
R429	1-216-833-91	RES, CHIP 10K (1608)		C239	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	(1608)	C218	1-125-837-91	CAP, CHIP CERAMIC 1MF B	(1608)
R603	1-216-833-91	RES, CHIP 10K (1608)		C240	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	(1608)	C219	1-125-837-91	CAP, CHIP CERAMIC 1MF B	(1608)
X403	1-760-928-41	VIBRATOR, CRYSTAL		C241	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	(1608)	C220	1-125-837-91	CAP, CHIP CERAMIC 1MF B	(1608)
X403	1-767-300-21	VIBRATOR, CRYSTAL		C990	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	(1608)	C221	1-125-837-91	CAP, CHIP CERAMIC 1MF B	(1608)
X403	1-781-266-41	VIBRATOR, CRYSTAL						C222	1-125-837-91	CAP, CHIP CERAMIC 1MF B	(1608)
X403	1-782-266-61	VIBRATOR, CRYSTAL						C223	1-125-837-91	CAP, CHIP CERAMIC 1MF B	(1608)
								C224	1-125-837-91	CAP, CHIP CERAMIC 1MF B	(1608)
R478	1-216-833-91	RES, CHIP 10K (1608)	Mark for US model					C225	1-125-837-91	CAP, CHIP CERAMIC 1MF B	(1608)
C291	1-162-921-91	CAP, CERAMIC 33pF CH (1608)		Ref.	Part No.	Description	Remarks	C226	1-125-837-91	CAP, CHIP CERAMIC 1MF B	(1608)
L206	1-412-960-21	INDUCTOR, SMALL TYPE 56UH (2518)		IC607	8-752-928-45	IC CXP103049-101GG-TL	MECHACON	C231	1-125-837-91	CAP, CHIP CERAMIC 1MF B	(1608)
C246	1-135-609-91	CAP, CHIP TANTALUM ELECT 220MF		IC505	6-801-195-01	IC MR27V4812F-012TMZ	BOOT+DVD-ROM	C232	1-125-837-91	CAP, CHIP CERAMIC 1MF B	(1608)
R409	1-218-855-91	RES, CHIP 2.2K (1608)		IC505	6-801-172-01	IC K3NSV104SB-TC1AT00	BOOT+DVD-ROM	C233	1-125-837-91	CAP, CHIP CERAMIC 1MF B	(1608)
R410	1-218-882-91	RES, CHIP 30K (1608)		IC405	8-759-560-17	IC RS5C348A-E2	TIMER	C234	1-125-837-91	CAP, CHIP CERAMIC 1MF B	(1608)
R413	1-218-882-91	RES, CHIP 30K (1608)		IC406	8-759-698-67	IC BR2880F-E2	EEPROM	C235	1-125-837-91	CAP, CHIP CERAMIC 1MF B	(1608)
R414	1-218-855-91	RES, CHIP 2.2K (1608)		C411	1-117-720-91	CAP, CERAMIC 4.7MF F (2012)		C236	1-125-837-91	CAP, CHIP CERAMIC 1MF B	(1608)
C212	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	(1608)	C406	1-162-964-91	CAP, CHIP CERAMIC 100PF B	(1608)	C237	1-125-837-91	CAP, CHIP CERAMIC 1MF B	(1608)
C213	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	(1608)	C405	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)		C238	1-125-837-91	CAP, CHIP CERAMIC 1MF B	(1608)
C214	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	(1608)	C454	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)		C239	1-125-837-91	CAP, CHIP CERAMIC 1MF B	(1608)
C215	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	(1608)	R602	1-216-833-91	RES, CHIP 10K (1608)		C240	1-125-837-91	CAP, CHIP CERAMIC 1MF B	(1608)
C216	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	(1608)	X402	1-760-928-41	VIBRATOR, CRYSTAL		C241	1-125-837-91	CAP, CHIP CERAMIC 1MF B	(1608)
C217	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	(1608)	X402	1-767-300-21	VIBRATOR, CRYSTAL		C242	1-125-837-91	CAP, CHIP CERAMIC 1MF B	(1608)
C218	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	(1608)	X402	1-781-266-41	VIBRATOR, CRYSTAL		C243	1-135-609-91	CAP, CHIP TANTALUM ELECT 220MF	
C219	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	(1608)	X402	1-782-266-61	VIBRATOR, CRYSTAL		R409	1-216-864-91	CONDUCTOR, CHIP (1608)	
C220	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	(1608)	R478	1-216-833-91	RES, CHIP 10K (1608)	Mark for US model	R410	1-218-883-91	RES, CHIP 33K (1608)	
C221	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	(1608)	C291	1-162-921-91	CAP, CERAMIC 33pF CH (1608)		L206	1-412-960-21	INDUCTOR, SMALL TYPE 56UH (2518)	
C222	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	(1608)	C243	1-135-609-91	CAP, CHIP TANTALUM ELECT 220MF					
C223	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	(1608)	R409	1-216-864-91	CONDUCTOR, CHIP (1608)					
C224	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	(1608)	R410	1-218-883-91	RES, CHIP 33K (1608)					
C225	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	(1608)								
C226	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	(1608)								

## Dissimilarity Parts List for GH015(12/22) MOUNT on SCPH-30000 R series F-type model

A-6714-504-AGH015(12/22) MOUNT on SCPH-30002 R(AU3) F-type model

<u>Ref.</u>	<u>Part No.</u>	<u>Description</u>	<u>Remarks</u>	<u>Ref.</u>	<u>Part No.</u>	<u>Description</u>	<u>Remarks</u>
IC607	8-752-930-05	IC CXP103049-302GG-TL	MECHAON	IC607	8-752-929-46	IC CXP103049-301GG-TL	MECHAON
IC505	6-801-243-01	IC MR27V4812F-014TMZ	BOOT+DVD-ROM	IC505	6-801-243-01	IC MR27V4812F-014TMZ	BOOT+DVD-ROM
IC416	6-701-551-01	IC BU9861FV-WE2	TIMER+EEPROM	IC405	8-759-560-17	IC RS5C348A-E2	TIMER
C445	1-117-720-91	CAP, CERAMIC 4.7MF F (2012)		IC406	8-759-698-67	IC BR2880F-E2	EEPROM
C449	1-162-964-91	CAP, CHIP CERAMIC 100PF B (1608)		C411	1-117-720-91	CAP, CERAMIC 4.7MF F (2012)	
C452	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)		C405	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)	
C453	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)		C406	1-162-964-91	CAP, CHIP CERAMIC 100PF B (1608)	
R429	1-216-833-91	RES, CHIP 10K (1608)		C454	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)	
R603	1-216-833-91	RES, CHIP 10K (1608)		R602	1-216-833-91	RES, CHIP 10K (1608)	
X403	1-760-928-41	VIBRATOR, CRYSTAL		X402	1-760-928-41	VIBRATOR, CRYSTAL	
X403	1-767-300-21	VIBRATOR, CRYSTAL		X402	1-767-300-21	VIBRATOR, CRYSTAL	
X403	1-781-266-41	VIBRATOR, CRYSTAL		X402	1-781-266-41	VIBRATOR, CRYSTAL	
X403	1-782-266-61	VIBRATOR, CRYSTAL		X402	1-782-266-61	VIBRATOR, CRYSTAL	
R480	1-216-841-91	RES, CHIP 47K (1608)	Mark for AU3 model	R480	1-216-841-91	RES, CHIP 47K (1608)	Mark for AU3 model
C291	1-162-923-91	CAP, CERAMIC 47pF CH (1608)		C291	1-162-923-91	CAP, CERAMIC 47pF CH (1608)	
L206	1-412-956-21	INDUCTOR, SMALL TYPE 27uH (2518)		L206	1-412-956-21	INDUCTOR, SMALL TYPE 27uH (2518)	
C246	1-135-609-91	CAP, CHIP TANTALUM ELECT 220MF		C243	1-135-609-91	CAP, CHIP TANTALUM ELECT 220MF	
R409	1-218-855-91	RES, CHIP 2.2K (1608)		R409	1-216-864-91	CONDUCTOR, CHIP (1608)	
R410	1-218-882-91	RES, CHIP 30K (1608)		R410	1-218-883-91	RES, CHIP 33K (1608)	
R413	1-218-882-91	RES, CHIP 30K (1608)		R413	1-218-883-91	RES, CHIP 33K (1608)	
R414	1-218-855-91	RES, CHIP 2.2K (1608)		R414	1-216-864-91	CONDUCTOR, CHIP (1608)	
C212	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)		C212	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)	
C213	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)		C213	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)	
C214	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)		C214	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)	
C215	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)		C215	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)	
C216	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)		C216	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)	
C217	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)		C217	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)	
C218	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)		C218	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)	
C219	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)		C219	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)	
C220	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)		C220	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)	
C221	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)		C221	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)	
C222	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)		C222	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)	
C223	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)		C223	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)	
C224	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)		C224	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)	
C225	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)		C225	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)	
C226	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)		C226	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)	
C231	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)		C231	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)	
C232	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)		C232	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)	
C233	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)		C233	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)	
C234	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)		C234	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)	
C235	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)		C235	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)	
C236	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)		C236	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)	
C237	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)		C237	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)	
C238	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)		C238	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)	
C239	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)		C239	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)	
C240	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)		C240	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)	
C241	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)		C241	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)	
C990	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)		C990	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)	

\*\*\*\*\*

\*\*\*\*\*

## Dissimilarity List for GH015(12/22)MOUNT on SCPH-30000 R series F-type model

A-6714-505-A

GH015(12/22) MOUNT on SCPH-30003 R(CEL)/-30004 R(CEK) F-type model

<u>Ref.</u>	<u>Part No.</u>	<u>Description</u>	<u>Remarks</u>	<u>Ref.</u>	<u>Part No.</u>	<u>Description</u>	<u>Remarks</u>
IC607	8-752-928-27	IC CXP103049-202GG-TL	MECHAON	IC607	8-752-929-37	IC CXP103049-201GG-TL	MECHAON
IC505	6-801-242-01	IC MR27V4812F-013TMZ	BOOT+DVD-ROM	IC505	6-801-242-01	IC MR27V4812F-013TMZ	BOOT+DVD-ROM
IC416	6-701-551-01	IC BU9861FV-WE2	TIMER+EEPROM	IC405	8-759-560-17	IC RS5C348A-E2	TIMER
C445	1-117-720-91	CAP, CERAMIC 4.7MF F (2012)		C406	8-759-698-67	IC BR2880F-E2	EEPROM
C449	1-162-964-91	CAP, CHIP CERAMIC 100PF B (1608)		C411	1-117-720-91	CAP, CERAMIC 4.7MF F (2012)	
C452	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)		C406	1-162-964-91	CAP, CHIP CERAMIC 100PF B (1608)	
C453	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)		C405	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)	
R429	1-216-833-91	RES, CHIP 10K (1608)		C454	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)	
R603	1-216-833-91	RES, CHIP 10K (1608)		R602	1-216-833-91	RES, CHIP 10K (1608)	
X403	1-760-928-41	VIBRATOR, CRYSTAL		X402	1-760-928-41	VIBRATOR, CRYSTAL	
X403	1-767-300-21	VIBRATOR, CRYSTAL		X402	1-767-300-21	VIBRATOR, CRYSTAL	
X403	1-781-266-41	VIBRATOR, CRYSTAL		X402	1-781-266-41	VIBRATOR, CRYSTAL	
X403	1-782-266-61	VIBRATOR, CRYSTAL		X402	1-782-266-61	VIBRATOR, CRYSTAL	
R479	1-216-837-91	RES,CHIP 22K (1608)	Mark for CEK model	R479	1-216-837-91	RES,CHIP 22K (1608)	Mark for CEK model
C291	1-162-923-91	CAP, CERAMIC 47pF CH (1608)		C291	1-162-923-91	CAP, CERAMIC 47pF CH (1608)	
L206	1-412-956-21	INDUCTOR, SMALL TYPE 27uH (2518)		L206	1-412-956-21	INDUCTOR, SMALL TYPE 27uH (2518)	
C246	1-135-609-91	CAP, CHIP TANTALUM ELECT 220MF		C243	1-135-609-91	CAP, CHIP TANTALUM ELECT 220MF	
R409	1-218-855-91	RES, CHIP 2.2K (1608)		R409	1-216-864-91	CONDUCTOR, CHIP (1608)	
R410	1-218-882-91	RES, CHIP 30K (1608)		R410	1-218-883-91	RES, CHIP 33K (1608)	
R413	1-218-882-91	RES, CHIP 30K (1608)		R413	1-218-883-91	RES, CHIP 33K (1608)	
R414	1-218-855-91	RES, CHIP 2.2K (1608)		R414	1-216-864-91	CONDUCTOR, CHIP (1608)	
C212	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)		C212	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)	
C213	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)		C213	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)	
C214	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)		C214	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)	
C215	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)		C215	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)	
C216	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)		C216	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)	
C217	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)		C217	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)	
C218	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)		C218	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)	
C219	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)		C219	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)	
C220	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)		C220	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)	
C221	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)		C221	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)	
C222	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)		C222	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)	
C223	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)		C223	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)	
C224	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)		C224	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)	
C225	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)		C225	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)	
C226	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)		C226	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)	
C231	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)		C231	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)	
C232	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)		C232	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)	
C233	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)		C233	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)	
C234	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)		C234	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)	
C235	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)		C235	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)	
C236	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)		C236	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)	
C237	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)		C237	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)	
C238	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)		C238	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)	
C239	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)		C239	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)	
C240	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)		C240	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)	
C241	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)		C241	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)	
C990	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)		C990	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)	

\*\*\*\*\*

\*\*\*\*\*

## Dissimilarity List for GH015(12/22)MOUNT on SCPH-30000 R series F-type model

A-6714-514-A GH015(12/22)MOUNT on SCPH-30005 R(KR2) F-type model

Ref.	Part No.	Description	Remarks
IC607	8-752-929-57	IC CXP103049-401GG-TL	MECHAON
IC505	6-801-493-01	IC MR27V4812F-016TMZ	BOOT+DVD-ROM
IC416	6-701-551-01	IC BU9861FV-WE2	TIMER+EEPROM
C445	1-117-720-91	CAP, CERAMIC 4.7MF F (2012)	
C449	1-162-964-91	CAP, CHIP CERAMIC 100PF B (1608)	
C452	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)	
C453	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)	
R429	1-216-833-91	RES, CHIP 10K (1608)	
R603	1-216-833-91	RES, CHIP 10K (1608)	
X403	1-767-300-21	VIBRATOR, CRYSTAL	
X403	1-760-928-41	VIBRATOR, CRYSTAL	
X403	1-767-300-21	VIBRATOR, CRYSTAL	
X403	1-781-266-41	VIBRATOR, CRYSTAL	
X403	1-782-266-61	VIBRATOR, CRYSTAL	
R477	1-216-833-91	RES, CHIP 10K (1608)	Mark for KR2 model
C291	1-162-921-91	CAP, CERAMIC 33PF CH (1608)	
L206	1-412-960-21	INDUCTOR, SMALL TYPE 56UH (2518)	
C246	1-135-609-91	CAP, CHIP TANTALUM ELECT 220MF	
R409	1-218-855-91	RES, CHIP 2.2K (1608)	
R410	1-218-882-91	RES, CHIP 30K (1608)	
R413	1-218-882-91	RES, CHIP 30K (1608)	
R414	1-218-855-91	RES, CHIP 2.2K (1608)	
C212	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)	
C213	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)	
C214	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)	
C215	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)	
C216	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)	
C217	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)	
C218	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)	
C219	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)	
C220	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)	
C221	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)	
C222	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)	
C223	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)	
C224	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)	
C225	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)	
C226	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)	
C231	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)	
C232	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)	
C233	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)	
C234	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)	
C235	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)	
C236	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)	
C237	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)	
C238	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)	
C239	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)	
C240	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)	
C241	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)	
C990	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)	

A-6714-513-A GH015(12/22)MOUNT on SCPH-30006 R(E12) F-type model

Ref.	Part No.	Description	Remarks
IC607	8-752-929-57	IC CXP103049-401GG-TL	MECHAON
IC505	6-801-492-01	IC MR27V4812F-015TMZ	BOOT+DVD-ROM
IC416	6-701-551-01	IC BU9861FV-WE2	TIMER+EEPROM
C445	1-117-720-91	CAP, CERAMIC 4.7MF F (2012)	
C449	1-162-964-91	CAP, CHIP CERAMIC 100PF B (1608)	
C452	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)	
C453	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)	
R429	1-216-833-91	RES, CHIP 10K (1608)	
R603	1-216-833-91	RES, CHIP 10K (1608)	
X403	1-760-928-41	VIBRATOR, CRYSTAL	
X403	1-767-300-21	VIBRATOR, CRYSTAL	
X403	1-781-266-41	VIBRATOR, CRYSTAL	
X403	1-782-266-61	VIBRATOR, CRYSTAL	
R478	1-216-837-91	RES, CHIP 22K (1608)	Mark for E12 model
R479	1-216-853-91	RES, CHIP 470K (1608)	Mark for E12 model
C291	1-162-921-91	CAP, CERAMIC 33PF CH (1608)	
L206	1-412-960-21	INDUCTOR, SMALL TYPE 56UH (2518)	
C246	1-135-609-91	CAP, CHIP TANTALUM ELECT 220MF	
R409	1-218-855-91	RES, CHIP 2.2K (1608)	
R410	1-218-882-91	RES, CHIP 30K (1608)	
R413	1-218-882-91	RES, CHIP 30K (1608)	
R414	1-218-855-91	RES, CHIP 2.2K (1608)	
C212	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)	
C213	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)	
C214	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)	
C215	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)	
C216	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)	
C217	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)	
C218	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)	
C219	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)	
C220	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)	
C221	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)	
C222	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)	
C223	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)	
C224	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)	
C225	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)	
C226	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)	
C231	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)	
C232	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)	
C233	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)	
C234	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)	
C235	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)	
C236	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)	
C237	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)	
C238	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)	
C239	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)	
C240	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)	
C241	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)	
C990	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)	

A-6714-520-A GH015(12/22)MOUNT on SCPH-30007 R(TW1) F-type model

Ref.	Part No.	Description	Remarks
IC607	8-752-929-57	IC CXP103049-401GG-TL	Mechacom
IC505	6-801-492-01	IC MR27V4812F-015TMZ	BOOT+DVD-ROM
IC416	6-701-551-01	IC BU9861FV-WE2	TIMER+EEPROM
C445	1-117-720-91	CAP, CERAMIC 4.7MF F (2012)	
C449	1-162-964-91	CAP, CHIP CERAMIC 100PF B (1608)	
C452	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)	
C453	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)	
R429	1-216-833-91	RES, CHIP 10K (1608)	
R603	1-216-833-91	RES, CHIP 10K (1608)	
X403	1-760-928-41	VIBRATOR, CRYSTAL	
X403	1-767-300-21	VIBRATOR, CRYSTAL	
X403	1-781-266-41	VIBRATOR, CRYSTAL	
X403	1-782-266-61	VIBRATOR, CRYSTAL	
R477	1-216-833-91	RES, CHIP 470K (1608)	Mark for TW1 model
R479	1-216-853-91	RES, CHIP 470K (1608)	Mark for TW1 model
C291	1-162-921-91	CAP, CERAMIC 33PF CH (1608)	
L206	1-412-960-21	INDUCTOR, SMALL TYPE 56UH (2518)	
C246	1-135-609-91	CAP, CHIP TANTALUM ELECT 220MF	
R409	1-218-855-91	RES, CHIP 2.2K (1608)	
R410	1-218-882-91	RES, CHIP 30K (1608)	
R413	1-218-882-91	RES, CHIP 30K (1608)	
R414			

## Common Parts List for GH015(12/22) MOUNT on SCPH-30000 R series

Ref.	Part No.	Description	Ref.	Part No.	Description	Ref.	Part No.	Description	Ref.	Part No.	Description			
PWB	1-683-434-12	PWB, GH-015	C164	1-128-964-91	CAP, CHIP TANTALUM ELECT 100MF	C269	1-164-160-91	CAP, CERAMIC 20PF CH	(1608)	C364	1-107-826-91	CAP, CHIP CERAMIC 100000PF B		
PWB	1-683-434-22	PWB, GH-015	C168	1-162-964-91	CAP, CHIP CERAMIC 1000PF B	(1608)	C270	1-107-826-91	CAP, CHIP CERAMIC 100000PF B		C365	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	
BT101	1-756-076-21	HOLDER, LITHIUM BATTERY	C170	1-125-837-91	CAP, CHIP CERAMIC 1MF B	(1608)	C271	1-125-837-91	CAP, CHIP CERAMIC 1MF B	(1608)	C366	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	
		<CAPACITOR>	C175	1-125-777-81	CAP, CHIP CERAMIC 0.1MF B	(1005)	C272	1-125-837-91	CAP, CHIP CERAMIC 1MF B	(1608)	C367	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	
C101	1-128-964-91	CAP, CHIP TANTALUM ELECT 100MF	C176	1-125-777-81	CAP, CHIP CERAMIC 0.1MF B	(1005)	C275	1-107-826-91	CAP, CHIP CERAMIC 100000PF B		C368	1-125-777-81	CAP, CHIP CERAMIC 0.1MF B	(1005)
C102	1-128-964-91	CAP, CHIP TANTALUM ELECT 100MF	C177	1-216-861-91	RES, CHIP 2.2M	(1608)	C276	1-162-965-91	CAP, CERAMIC 1500PF B	(1608)	C369	1-125-777-81	CAP, CHIP CERAMIC 0.1MF B	(1005)
C103	1-128-964-91	CAP, CHIP TANTALUM ELECT 100MF	C179	1-107-826-91	CAP, CHIP CERAMIC 100000PF B		C277	1-162-965-91	CAP, CERAMIC 1500PF B	(1608)	C370	1-162-964-91	CAP, CHIP CERAMIC 1000PF B	(1608)
C104	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C180	1-162-964-91	CAP, CHIP CERAMIC 1000PF B	(1608)	C278	1-113-619-91	CAP, CERAMIC 470000PF F	(1608)	C371	1-162-964-91	CAP, CHIP CERAMIC 1000PF B	(1608)
C105	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C181	1-107-826-91	CAP, CHIP CERAMIC 100000PF B		C279	1-113-619-91	CAP, CERAMIC 470000PF F	(1608)	C372	1-165-492-21	CAP, ELECT 100MF	
C106	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C182	1-162-964-91	CAP, CHIP CERAMIC 1000PF B	(1608)	C282	1-113-619-91	CAP, CERAMIC 470000PF F	(1608)	C373	1-165-492-21	CAP, ELECT 100MF	
C107	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C183	1-107-826-91	CAP, CHIP CERAMIC 100000PF B		C285	1-113-619-91	CAP, CERAMIC 470000PF F	(1608)	C392	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	
C108	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C184	1-162-964-91	CAP, CHIP CERAMIC 1000PF B	(1608)	C286	1-113-619-91	CAP, CERAMIC 470000PF F	(1608)	C401	1-125-777-81	CAP, CHIP CERAMIC 0.1MF B	(1005)
C109	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C185	1-125-837-91	CAP, CHIP CERAMIC 1MF B	(1608)	C287	1-107-826-91	CAP, CHIP CERAMIC 100000PF B		C402	1-164-505-91	CAP, CHIP CERAMIC 2.2MF F	(2012)
C110	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C186	1-107-826-91	CAP, CHIP CERAMIC 100000PF B		C288	1-125-837-91	CAP, CHIP CERAMIC 1MF B	(1608)	C403	1-164-937-81	CAP, CHIP CERAMIC 1000PF B	(1005)
C111	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C187	1-162-970-91	CAP, CERAMIC 10000PF B	(1608)	C289	1-162-964-91	CAP, CHIP CERAMIC 1000PF B	(1608)	C404	1-125-837-91	CAP, CHIP CERAMIC 1MF B	(1608)
C112	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C188	1-162-964-91	CAP, CHIP CERAMIC 1000PF B	(1608)	C290	1-113-619-91	CAP, CERAMIC 470000PF F	(1608)				
C113	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C189	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	(1608)	C292	1-107-826-91	CAP, CHIP CERAMIC 100000PF B					
C114	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C293	1-137-765-21	CAP, ELECT 47MF		C296	1-126-210-21	CAP, ELECT 220MF		C407	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	
C115	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C297	1-126-210-21	CAP, ELECT 220MF		C298	1-126-210-21	CAP, ELECT 220MF		C408	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	
C116	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C301	1-107-826-91	CAP, CHIP CERAMIC 100000PF B		C305	1-107-826-91	CAP, CHIP CERAMIC 100000PF B		C409	1-162-969-91	CAP, CERAMIC 6800PF B	(1608)
C117	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C306	1-164-387-91	CAP, CERAMIC 240PF CH	(1608)	C307	1-107-826-91	CAP, CHIP CERAMIC 100000PF B		C410	1-162-969-91	CAP, CERAMIC 6800PF B	(1608)
C118	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C308	1-165-112-91	CAP, CERAMIC 330000PF F	(1608)	C309	1-162-970-91	CAP, CERAMIC 10000PF B	(1608)	C414	1-162-965-91	CAP, CERAMIC 1500PF B	(1608)
C119	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C310	1-162-970-91	CAP, CERAMIC 10000PF B	(1608)	C311	1-162-916-91	CAP, CERAMIC 12PF CH	(1608)	C415	1-162-965-91	CAP, CERAMIC 1500PF B	(1608)
C120	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C312	1-162-917-91	CAP, CERAMIC 15PF CH	(1608)	C313	1-162-919-91	CAP, CERAMIC 22PF CH	(1608)	C416	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	
C121	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C314	1-162-919-91	CAP, CERAMIC 22PF CH	(1608)	C315	1-107-826-91	CAP, CHIP CERAMIC 100000PF B		C417	1-164-379-91	CAP, CERAMIC 43PF CH	(1608)
C122	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C316	1-165-112-91	CAP, CERAMIC 330000PF F	(1608)	C317	1-162-970-91	CAP, CERAMIC 10000PF B	(1608)	C418	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	
C123	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C318	1-162-970-91	CAP, CERAMIC 10000PF B	(1608)	C319	1-162-970-91	CAP, CERAMIC 10000PF B	(1608)	C419	1-162-970-91	CAP, CERAMIC 10000PF B	(1608)
C124	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C320	1-162-970-91	CAP, CERAMIC 10000PF B	(1608)	C321	1-162-970-91	CAP, CERAMIC 10000PF B	(1608)	C420	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	
C125	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C322	1-162-970-91	CAP, CERAMIC 10000PF B	(1608)	C322	1-162-970-91	CAP, CERAMIC 10000PF B	(1608)	C421	1-127-820-91	CAP, SQUARE TYPE CHIP 4.7MF	
C126	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C323	1-162-970-91	CAP, CERAMIC 10000PF B	(1608)	C323	1-162-970-91	CAP, CERAMIC 10000PF B	(1608)	C422	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	
C127	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C324	1-107-826-91	CAP, CHIP CERAMIC 100000PF B		C324	1-162-970-91	CAP, CERAMIC 10000PF B	(1608)	C423	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	
C128	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C325	1-162-970-91	CAP, CERAMIC 10000PF B	(1608)	C325	1-162-970-91	CAP, CERAMIC 10000PF B	(1608)	C424	1-127-820-91	CAP, SQUARE TYPE CHIP 4.7MF	
C129	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C326	1-162-970-91	CAP, CERAMIC 10000PF B	(1608)	C326	1-124-779-21	CAP, ELECT 10MF		C425	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	
C131	1-162-970-91	CAP, CERAMIC 10000PF B	C327	1-162-970-91	CAP, CERAMIC 10000PF B	(1608)	C327	1-107-826-91	CAP, CHIP CERAMIC 100000PF B		C426	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	
C132	1-125-777-81	CAP, CHIP CERAMIC 0.1MF B	C328	1-162-970-91	CAP, CERAMIC 10000PF B	(1608)	C328	1-117-681-21	CAP, ELECT 100MF		C427	1-117-681-21	CAP, ELECT 100MF	
C134	1-125-777-81	CAP, CHIP CERAMIC 0.1MF B	C329	1-162-970-91	CAP, CERAMIC 10000PF B	(1608)	C329	1-107-826-91	CAP, CHIP CERAMIC 100000PF B		C430	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	
C135	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C330	1-162-970-91	CAP, CERAMIC 10000PF B	(1608)	C330	1-107-826-91	CAP, CHIP CERAMIC 100000PF B		C431	1-107-826-91	CAP, CHIP CER	


Ref.	Part No.	Description	Ref.	Part No.	Description	Ref.	Part No.	Description	Ref.	Part No.	Description
C477	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C634	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)	C797	1-162-927-91	CAP, CERAMIC 100PF CH (1608)	C898	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)
C478	1-126-209-21	CAP, ELECT 100MF	C635	1-162-968-91	CAP, CHIP CERAMIC 4700PF B (1608)	C798	1-162-927-91	CAP, CERAMIC 100PF CH (1608)	C899	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)
C480	1-107-725-91	CAP, CERAMIC 100000PF B (2012)	C636	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C801	1-115-467-91	CAP, CHIP CERAMIC 0.22MF B (1608)	C901	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C482	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C637	1-162-964-91	CAP, CHIP CERAMIC 1000PF B (1608)	C802	1-115-467-91	CAP, CHIP CERAMIC 0.22MF B (1608)	C902	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C483	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C638	1-162-970-91	CAP, CERAMIC 10000PF B (1608)	C803	1-162-927-91	CAP, CERAMIC 100PF CH (1608)	C903	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C485	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C639	1-164-217-91	CAP, CERAMIC 150PF CH (1608)	C804	1-162-927-91	CAP, CERAMIC 100PF CH (1608)	C904	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C486	1-137-765-21	CAP, ELECT 47MF	C640	1-135-259-91	CAP, CHIP TANTALUM ELECT 10MF	C805	1-162-927-91	CAP, CERAMIC 100PF CH (1608)	C905	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C487	1-165-874-21	CAP, ELECT 120MF	C642	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)	C806	1-162-927-91	CAP, CERAMIC 100PF CH (1608)	C906	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C488	1-115-566-91	CAP, CERAMIC 4.7MF B	C643	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C807	1-162-927-91	CAP, CERAMIC 100PF CH (1608)	C907	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C489	1-165-874-21	CAP, ELECT 120MF	C644	1-164-230-91	CAP, CERAMIC 220PF CH (1608)	C808	1-162-927-91	CAP, CERAMIC 100PF CH (1608)	C908	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C490	1-126-209-21	CAP, ELECT 100MF	C645	1-165-176-91	CAP, CERAMIC 47000PF B (1608)	C809	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C909	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C491	1-126-209-21	CAP, ELECT 100MF	C646	1-162-964-91	CAP, CHIP CERAMIC 1000PF B (1608)	C810	1-104-851-91	CAP, CHIP TANTALUM ELECT 10MF	C910	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C494	1-107-725-91	CAP, CERAMIC 100000PF B (2012)	C647	1-117-863-91	CAP, CHIP CERAMIC 0.47MF B (1608)	C811	1-135-900-21	CAP, TANTALUM ELECT 22MF	C911	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C495	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)	C648	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)	C812	1-164-730-91	CAP, CERAMIC 1200PF B (1608)	C912	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C496	1-107-682-91	CAP, CERAMIC 100000PF B (3216)	C649	1-162-970-91	CAP, CERAMIC 10000PF B (1608)	C819	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C913	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C497	1-162-964-91	CAP, CHIP CERAMIC 1000PF B (1608)	C650	1-164-230-91	CAP, CERAMIC 220PF CH (1608)	C821	1-104-851-91	CAP, CHIP TANTALUM ELECT 10MF	C914	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C498	1-127-760-91	CAP, CERAMIC 4.7MF (2012)	C651	1-162-966-91	CAP, CERAMIC 2200PF B (1608)	C824	1-135-900-21	CAP, TANTALUM ELECT 22MF	C915	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C499	1-164-505-91	CAP, CHIP CERAMIC 2.2MF F (2012)	C652	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C825	1-164-730-91	CAP, CERAMIC 1200PF B (1608)	C916	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C501	1-164-346-91	CAP, CHIP CERAMIC 1MF F (2012)	C654	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)	C827	1-162-966-91	CAP, CERAMIC 2200PF B (1608)	C917	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C502	1-113-619-91	CAP, CERAMIC 470000PF F (1608)	C655	1-135-259-91	CAP, CHIP TANTALUM ELECT 10MF	C828	1-162-966-91	CAP, CERAMIC 2200PF B (1608)	C918	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C503	1-163-009-91	CAP, CHIP CERAMIC 1000PF B (2012)	C656	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)	C829	1-162-966-91	CAP, CERAMIC 2200PF B (1608)	C919	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C504	1-164-346-91	CAP, CHIP CERAMIC 1MF F (2012)	C657	1-164-230-91	CAP, CERAMIC 220PF CH (1608)	C830	1-162-966-91	CAP, CERAMIC 2200PF B (1608)	C920	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C507	1-163-009-91	CAP, CHIP CERAMIC 1000PF B (2012)	C658	1-164-230-91	CAP, CERAMIC 220PF CH (1608)	C831	1-162-975-91	CAP, CERAMIC 24PF CH (1608)	C921	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C508	1-113-619-91	CAP, CERAMIC 470000PF F (1608)	C660	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C832	1-115-467-91	CAP, CHIP CERAMIC 0.22MF B (1608)	C922	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C509	1-113-619-91	CAP, CERAMIC 470000PF F (1608)	C661	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)	C834	1-163-038-91	CAP, CERAMIC 100000PF F (2012)	C923	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C510	1-113-619-91	CAP, CERAMIC 470000PF F (1608)	C662	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)	C835	1-127-692-91	CAP, CHIP CERAMIC 10MF B (3225)	C924	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C513	1-113-619-91	CAP, CERAMIC 470000PF F (1608)	C664	1-135-259-91	CAP, CHIP TANTALUM ELECT 10MF	C836	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C925	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C514	1-113-619-91	CAP, CERAMIC 470000PF F (1608)	C665	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)	C837	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C926	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C516	1-113-619-91	CAP, CERAMIC 470000PF F (1608)	C666	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)	C839	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)	C927	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C517	1-113-619-91	CAP, CERAMIC 470000PF F (1608)	C667	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)	C840	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)	C928	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C518	1-113-619-91	CAP, CERAMIC 470000PF F (1608)	C668	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C843	1-162-970-91	CAP, CERAMIC 10000PF B (1608)	C929	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C521	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)	C671	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)	C844	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)	C930	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C522	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)	C672	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)	C845	1-162-970-91	CAP, CERAMIC 10000PF B (1608)	C931	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C523	1-162-970-91	CAP, CERAMIC 10000PF B (1608)	C673	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)	C848	1-107-823-91	CAP, CERAMIC 470000PF B (2012)	C932	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C524	1-113-619-91	CAP, CERAMIC 470000PF F (1608)	C674	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)	C850	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C933	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C525	1-113-619-91	CAP, CERAMIC 470000PF F (1608)	C675	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)	C851	1-162-970-91	CAP, CERAMIC 10000PF B (1608)	C934	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C527	1-162-964-91	CAP, CHIP CERAMIC 1000PF B (1608)	C676	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)	C853	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C935	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C528	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)	C684	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)	C854	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C936	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C529	1-128-008-21	CAP, ELECT (CHIP) 3.3MF	C685	1-117-863-91	CAP, CHIP CERAMIC 0.4						

Ref.	Part No.	Description	Ref.	Part No.	Description	Ref.	Part No.	Description	Ref.	Part No.	Description	
C966	1-107-826-91	CAP, CHIP CERAMIC 10000PF B	D403	8-719-074-34	DIODE RB495D-T146	IC106	6-700-967-01	IC CY24141ZC-3T	L408	1-419-902-21	COIL, CHOKE (SMD) 5.6UH	
C967	1-125-837-91	CAP, CHIP CERAMIC 1MF B	(1608)	D403	8-719-081-84	DIODE HRW0202BTL	IC202	6-701-570-01	IC CXD2949GB-T7	L410	1-411-197-21	COIL, DD CONVERTER
C968	1-125-837-91	CAP, CHIP CERAMIC 1MF B	(1608)	D404	8-719-033-15	DIODE HN2D02FU-TE85R	IC205	6-701-557-01	IC SC44728CPBEB	L410	1-424-788-21	COIL, CHOKE (SMD) 10UH
C980	1-107-826-91	CAP, CHIP CERAMIC 10000PF B	D405	8-719-066-98	DIODE RB051L-40TE25	IC206	8-752-093-56	IC CXA3525R-T4	L410	1-424-922-21	COIL, CHOKE (SMD) 10UH	
C981	1-107-826-91	CAP, CHIP CERAMIC 10000PF B	D405	8-719-078-04	DIODE EC31QS03L-TE12L	IC206	8-752-099-53	IC CXA3525BR-T4	L411	1-424-789-41	COIL, CHOKE (SMD) 10UH	
C982	1-107-826-91	CAP, CHIP CERAMIC 10000PF B	D405	8-719-085-58	DIODE EC30HA03L-TE12L	IC207	8-759-691-00	IC JCP78M05CDTRK	L411	1-424-916-21	COIL, CHOKE (SMD) 10UH	
C983	1-107-826-91	CAP, CHIP CERAMIC 10000PF B	D407	8-719-074-34	DIODE RB495D-T146	IC207	8-759-697-61	IC L78M05CDT-TR (P)	L411	1-424-918-21	COIL, CHOKE (SMD) 10UH	
C984	1-107-826-91	CAP, CHIP CERAMIC 10000PF B	D407	8-719-081-84	DIODE HRW0202BTL	IC209	6-701-174-01	IC MM1573DNLE	L412	1-424-788-21	COIL, CHOKE (SMD) 10UH	
C985	1-107-826-91	CAP, CHIP CERAMIC 10000PF B	D408	8-719-074-34	DIODE RB495D-T146	IC209	6-701-602-01	IC LP2985IMX-3.3P	L412	1-424-922-21	COIL, CHOKE (SMD) 10UH	
C986	1-107-826-91	CAP, CHIP CERAMIC 10000PF B	D408	8-719-081-84	DIODE HRW0202BTL	IC210	6-701-556-01	IC SC44750PBEB	L413	1-424-789-41	COIL, CHOKE (SMD) 10UH	
C987	1-107-826-91	CAP, CHIP CERAMIC 10000PF B	D500	8-719-024-81	DIODE 1SS300-TE85L	IC303	6-701-662-01	IC CXD9660GB	L413	1-424-916-21	COIL, CHOKE (SMD) 10UH	
C988	1-107-826-91	CAP, CHIP CERAMIC 10000PF B	D500	8-719-941-21	DIODE DAP202UT106	IC305	6-700-119-01	IC T5NB8(YEL)	L413	1-424-918-21	COIL, CHOKE (SMD) 10UH	
C989	1-107-826-91	CAP, CHIP CERAMIC 10000PF B	D501	8-719-082-76	DIODE CL-201TLY-C-TU	IC305	6-700-549-01	IC K4Q153212MJC60T	L414	1-424-789-41	COIL, CHOKE (SMD) 10UH	
C991	1-113-619-91	CAP, CERAMIC 470000PF F	D801	8-719-065-68	DIODE MAZF04700LS0	IC402	6-800-967-01	IC TMP87C807U-2C64	L414	1-424-916-21	COIL, CHOKE (SMD) 10UH	
C992	1-113-619-91	CAP, CERAMIC 470000PF F	D801	8-719-082-00	DIODE MM3Z4V7T1	IC403	6-700-665-01	IC MM1550AFBE	L414	1-424-918-21	COIL, CHOKE (SMD) 10UH	
C993	1-128-004-21	CAP, ELECT (CHIP) 10MF	D802	8-719-065-68	DIODE MAZF04700LS0	IC404	6-700-664-01	IC SN105216DBTR	L801	1-400-073-21	INDUCTOR, CHIP 4.7UH	
C993	1-128-004-21	CAP, ELECT (CHIP) 10MF	D802	8-719-082-00	DIODE MM3Z4V7T1				L801	1-469-524-91	INDUCTOR 4.7UH (NLVF25)	
C994	1-125-777-81	CAP, CHIP CERAMIC 0.1MF B	<CONNECTOR>	<CONNECTOR>					L802	1-400-073-21	INDUCTOR, CHIP 4.7UH (NLVF25)	
C995	1-125-777-81	CAP, CHIP CERAMIC 0.1MF B	(1005)	<CONNECTOR>					L802	1-469-524-91	INDUCTOR 4.7UH (NLVF25)	
C996	1-125-777-81	CAP, CHIP CERAMIC 0.1MF B	(1005)	<CONNECTOR>					L803	1-414-394-41	INDUCTOR (SMD) 2.2UH	
C997	1-125-777-81	CAP, CHIP CERAMIC 0.1MF B	(1005)	<CONNECTOR>								
C998	1-125-777-81	CAP, CHIP CERAMIC 0.1MF B	(1005)	<CONNECTOR>								
CN201	1-815-631-11	CONNECTOR, SQUARE TYPE 12P	FB102	1-469-667-21	FERRITE, EMI (SMD)	IC413	6-700-968-01	IC MM1573FNLE	LF352	1-428-877-21	COIL, COMMOM MODE CHOKE	
CN302	1-794-206-21	CONNECTOR, FFC/FPC (ZIF) 36P	FB103	1-469-667-21	FERRITE, EMI (SMD)	IC413	8-759-598-12	IC LP2985IMX-3.5				
CN303	1-694-822-11	TERMINAL BOARD (ILINK/USB)	FB104	1-469-667-21	FERRITE, EMI (SMD)	IC414	6-701-175-01	IC MC7808CDTT5	<LINK>			
CN401	1-815-630-11	PIN, CONNECTOR 4P	FB105	1-469-667-21	FERRITE, EMI (SMD)	IC414	8-759-069-41	IC TA7808F(TE16L)				
CN401	1-816-242-11	PIN, CONNECTOR 4P	FB201	1-414-813-21	FERRITE, EMI (SMD)	IC414	8-759-473-16	IC BA17808FP-E2				
CN403	1-784-650-21	CONNECTOR 2P	FB202	1-500-113-22	BEAD, FERRITE (CHIP)	IC414	8-759-697-62	IC NJM7808DL1A(TE1)				
CN406	1-779-345-11	CONNECTOR, FFC/FPC 7P	FB203	1-500-113-22	BEAD, FERRITE (CHIP)	IC415	8-759-581-11	IC NJM2125F(TE2)				
CN501	1-476-736-11	TRANSMITTER UNIT, LIGHT	FB204	1-500-113-22	BEAD, FERRITE (CHIP)	IC501	6-701-214-01	IC CXD9611BR				
CN504	1-815-632-11	CONNECTOR BOARD TO BOARD 110P	FB205	1-500-113-22	BEAD, FERRITE (CHIP)	IC502	6-701-050-01	IC MSM10V976F-50TKR1				
CN801	1-794-237-21	CONNECTOR, FFC/FPC 30P	FB206	1-500-113-22	BEAD, FERRITE (CHIP)	IC502	8-759-712-79	IC K4E151612D-TL50T00				
CN802	1-816-184-21	CONNECTOR, FFC/FPC 5P	FB303	1-400-154-21	FERRITE, EMI	IC502	8-759-712-80	IC MT4LC1M16E5TG-5TR				
CN803	1-770-687-11	CONNECTOR, FFC/FPC 4P	FB305	1-414-555-21	FERRITE, EMI (SMD)	IC502	8-759-712-81	IC GM71V18163CT-5T				
CN803	1-779-206-21	CONNECTOR, FFC(LIF(NON-ZIF)) 4P	FB308	1-400-154-21	FERRITE, EMI	IC502	8-759-712-82	IC SDMV18165CTM6S				
CN804	1-794-194-21	CONNECTOR, FFC/FPC 13P	FB310	1-414-555-21	FERRITE, EMI (SMD)	IC504	8-752-416-23	IC CXD2950R-TL				
CN804	1-816-226-21	CONNECTOR, FFC/FPC 13P	FB313	1-469-324-21	FERRITE, EMI (SMD)	IC517	8-759-667-10	IC CS4335-KS				
CN804	1-816-226-21	CONNECTOR, FFC/FPC 13P	FB314	1-469-324-21	FERRITE, EMI (SMD)	IC603	8-759-370-11	IC NJM2100V-TE2				
CN804	1-816-226-21	CONNECTOR, FFC/FPC 13P	FB315	1-469-324-21	FERRITE, EMI (SMD)	IC605	8-752-416-13	IC CXD1886Q				
CP201	1-234-724-21	NETWORK, RC	FB316	1-469-324-21	FERRITE, EMI (SMD)	IC801	6-700-585-01	IC SP3727AFA0PMR				
CP201	1-234-724-21	NETWORK, RC	FB317	1-469-110-21	FERRITE, EMI (SMD)	IC802	8-759-697-65	IC BA5815FM-E2				
CP201	1-234-724-21	NETWORK, RC	FB318	1-469-110-21	FERRITE, EMI (SMD)	IC803	8-759-588-60	IC BA6664FM-E2				
D201	8-719-065-78	DIODE MAZF12000LS0	FB319	1-469-110-21	FERRITE, EMI (SMD)	IC805	8-759-712-38	IC HD74HC1G66CME				
D201	8-719-082-01	DIODE MM3Z12VT1	FB320	1-469-110-21	FERRITE, EMI (SMD)	IC805	8-759-712-63	IC MC74VHC1G66DFT1				
D202	6-500-009-01	DIODE RSE6.8XN-TR	FB321	1-469-110-21	FERRITE, EMI (SMD)	IC806	8-759-693-13	IC NJM12904V(TE2)				
D202	6-500-044-01	DIODE DF6A6.8FU(TE85R)	FB322	1-469-110-21	FERRITE, EMI (SMD)	IC807	8-759-691-00	IC JCP78M05CDTRK				
D202	6-500-045-01	DIODE MAZB068H0LS0	FB323	1-469-110-21	FERRITE, EMI (SMD)	IC807	8-759-697-61	IC L78M05CDT-TR (P)				
D202	6-500-053-01	DIODE DF6A6.8FUT1	FB324	1-469-110-21	FERRITE, EMI (SMD)							
D203	6-500-009-01	DIODE RSE6.8XN-TR	FB408	1-469-667-21	FERRITE, EMI (SMD)							
D203	6-500-044-01	DIODE DF6A6.8FU(TE85R)	FB801	1-469-562-21	FERRITE, EMI (SMD)							
D203	6-500-045-01	DIODE MAZB068H0LS0	FB802	1-469-562-21	FERRITE, EMI (SMD)							
D203	6-500-053-01	DIODE DF6A6.8FUT1										
D208	6-500-009-01	DIODE RSE6.8XN-TR										
D208	6-500-044-01	DIODE DF6A6.8FU(TE85R)										
D208	6-500-045-01	DIODE MAZB068H0LS0										
D208	6-500-053-01	DIODE DF6A6.8FUT1										
D301	8-719-027-76	DIODE 1SS357-TPH3										
D301	8-719-058-24	DIODE RB501V-40TE-17										
D301	8-719-071-87	DIODE MA785-(TX),SO										
D302	8-719-027-76	DIODE 1SS357-TPH3										
D302	8-719-058-24	DIODE RB501V-40TE-17										
D302	8-719-071-87	DIODE MA785-(TX),SO										
D402	8-719-074-34	DIODE RB495										


Ref.	Part No.	Description	Ref.	Part No.	Description	Ref.	Part No.	Description	Ref.	Part No.	Description		
Q405	8-729-052-36	TRANSISTOR UMH2NTN	R133	1-216-833-91	RES, CHIP 10K	(1608)	R352	1-216-797-91	RES, CHIP 10	(1608)	R491	1-216-864-91	CONDUCTOR, CHIP
Q405	8-729-427-47	TRANSISTOR XP4213-TXE	R134	1-218-965-81	RES, CHIP 10K	(1608)	R365	1-216-805-91	RES, CHIP 47	(1608)	R492	1-216-864-91	CONDUCTOR, CHIP
Q406	8-729-053-79	TRANSISTOR IRF7901D1-TR	R139	1-216-801-91	RES, CHIP 22	(1608)	R366	1-218-937-81	RES, CHIP 47		R493	1-216-864-91	CONDUCTOR, CHIP
Q406	8-729-053-80	TRANSISTOR SI4830DY-T1	R145	1-218-953-81	RES, CHIP 1.0K		R367	1-216-805-91	RES, CHIP 47	(1608)	R494	1-216-864-91	CONDUCTOR, CHIP
Q406	8-729-054-68	TRANSISTOR FDS6986S	R146	1-216-821-91	RES, CHIP 1.0K	(1608)	R368	1-216-805-91	RES, CHIP 47	(1608)	R495	1-216-864-91	CONDUCTOR, CHIP
Q407	8-729-046-04	TRANSISTOR FDS6690A	R147	1-216-821-91	RES, CHIP 1.0K	(1608)	R390	1-216-857-91	RES, CHIP 1.0M	(1608)	R503	1-216-803-91	RES, CHIP 33
Q407	8-729-054-66	TRANSISTOR HAT2071R-EL	R158	1-216-803-91	RES, CHIP 33	(1608)	R391	1-216-833-91	RES, CHIP 10K	(1608)	R504	1-216-803-91	RES, CHIP 33
Q408	8-729-051-61	TRANSISTOR IRF7807D1-TR	R159	1-216-803-91	RES, CHIP 33	(1608)	R392	1-216-801-91	RES, CHIP 22	(1608)	R505	1-216-803-91	RES, CHIP 33
Q408	8-729-054-67	TRANSISTOR FDS6690S	R164	1-216-864-91	CONDUCTOR, CHIP	(1608)	R393	1-216-801-91	RES, CHIP 22	(1608)	R506	1-216-809-91	RES, CHIP 100
Q409	6-550-076-01	TRANSISTOR MUN5213T1	R185	1-216-829-91	RES, CHIP 4.7K	(1608)	R394	1-216-801-91	RES, CHIP 22	(1608)	R509	1-216-821-91	RES, CHIP 1.0K
Q409	8-729-013-97	TRANSISTOR RN1304-TE85L	R188	1-216-829-91	RES, CHIP 4.7K	(1608)	R395	1-218-957-81	RES, CHIP 2.2K		R513	1-216-805-91	RES, CHIP 47
Q410	6-550-076-01	TRANSISTOR MUN5213T1	R196	1-218-933-81	RES, CHIP 22		R396	1-216-801-91	RES, CHIP 22	(1608)	R516	1-216-809-91	RES, CHIP 100
Q410	8-729-013-97	TRANSISTOR RN1304-TE85L	R201	1-216-829-91	RES, CHIP 4.7K	(1608)	R397	1-216-801-91	RES, CHIP 22	(1608)	R517	1-216-809-91	RES, CHIP 100
Q410	8-729-029-14	TRANSISTOR DTC144EUA-T106	R202	1-216-833-91	RES, CHIP 10K	(1608)	R399	1-216-801-91	RES, CHIP 22	(1608)	R522	1-218-965-81	RES, CHIP 10K
Q411	6-550-027-01	TRANSISTOR FDS6375	R203	1-218-851-91	RES, CHIP 1.5K	(1608)	R403	1-216-833-91	RES, CHIP 10K	(1608)	R531	1-216-809-91	RES, CHIP 100
Q411	6-550-028-01	TRANSISTOR IRF7233-TR	R212	1-218-961-81	RES, CHIP 4.7K		R404	1-216-845-91	RES, CHIP 100K	(1608)	R574	1-216-812-91	RES, CHIP 180
Q412	6-550-026-01	TRANSISTOR IRF7328-TR	R213	1-218-961-81	RES, CHIP 4.7K		R405	1-216-845-91	RES, CHIP 100K	(1608)	R575	1-216-850-91	RES, CHIP 270K
Q412	6-550-036-01	TRANSISTOR FDS4935	R214	1-216-864-91	CONDUCTOR, CHIP	(1608)	R406	1-216-811-91	RES, CHIP 150	(1608)	R576	1-216-833-91	RES, CHIP 10K
Q412	6-550-068-01	TRANSISTOR SI4943DY-T1	R217	1-216-864-91	CONDUCTOR, CHIP	(1608)	R407	1-216-811-91	RES, CHIP 150	(1608)	R577	1-216-818-91	RES, CHIP 560
Q415	8-729-052-41	TRANSISTOR 2SC4541 (2TL SONY1)	R220	1-218-933-81	RES, CHIP 22		R408	1-216-839-91	RES, CHIP 33K	(1608)	R578	1-216-818-91	RES, CHIP 560
Q415	8-729-209-77	TRANSISTOR 2SC2873Y-TE12L	R225	1-216-833-91	RES, CHIP 10K	(1608)	R411	1-218-883-91	RES, CHIP 33K	(1608)	R579	1-216-833-91	RES, CHIP 10K
Q505	8-729-021-09	TRANSISTOR RN4904(TE85R)	R226	1-216-833-91	RES, CHIP 10K	(1608)	R412	1-218-883-91	RES, CHIP 33K	(1608)	R580	1-216-850-91	RES, CHIP 270K
Q506	8-729-056-15	TRANSISTOR IMH20T108	R227	1-216-864-91	CONDUCTOR, CHIP	(1608)	R415	1-216-839-91	RES, CHIP 33K	(1608)	R604	1-216-845-91	RES, CHIP 100K
Q600	8-729-016-26	TRANSISTOR 2SK1958-T1	R236	1-216-809-91	RES, CHIP 100	(1608)	R416	1-216-839-91	RES, CHIP 33K	(1608)	R606	1-218-965-81	RES, CHIP 10K
Q600	8-729-048-50	TRANSISTOR 2SK3018-T106	R244	1-218-825-91	RES, CHIP 120	(1608)	R417	1-216-813-91	RES, CHIP 220	(1608)	R607	1-216-833-91	RES, CHIP 10K
Q603	8-729-017-33	TRANSISTOR RN1706-TE85R	R245	1-218-825-91	RES, CHIP 120	(1608)	R418	1-216-817-91	RES, CHIP 470	(1608)	R613	1-216-833-91	RES, CHIP 10K
Q801	6-550-008-01	TRANSISTOR UM6K1N-TN	R246	1-218-825-91	RES, CHIP 120	(1608)	R419	1-216-833-91	RES, CHIP 10K	(1608)	R614	1-216-833-91	RES, CHIP 10K
Q801	6-550-014-01	TRANSISTOR SSM6N15FU(TE85R)	R251	1-216-837-91	RES, CHIP 22K	(1608)	R421	1-216-790-91	RES, CHIP 2.7	(1608)	R619	1-216-833-91	RES, CHIP 10K
Q801	6-550-017-01	TRANSISTOR XP0487800LS0	R252	1-216-839-91	RES, CHIP 33K	(1608)	R422	1-216-797-91	RES, CHIP 10	(1608)	R620	1-218-965-81	RES, CHIP 10K
Q802	8-729-014-02	TRANSISTOR RN1306-TE85L	R253	1-216-833-91	RES, CHIP 10K	(1608)	R423	1-216-790-91	RES, CHIP 2.7	(1608)	R623	1-216-837-91	RES, CHIP 22K
Q802	8-729-029-13	TRANSISTOR DTC143ZUA-T106	R257	1-216-824-91	RES, CHIP 1.8K	(1608)	R424	1-216-797-91	RES, CHIP 10	(1608)	R624	1-216-850-91	RES, CHIP 270K
Q804	8-729-055-22	TRANSISTOR 2SA1734(TE12L)	R258	1-208-923-81	RES, CHIP 33K	(1005)	R426	1-216-879-91	RES, CHIP 22K	(1608)	R625	1-216-864-91	CONDUCTOR, CHIP
Q805	8-729-055-22	TRANSISTOR 2SA1734(TE12L)	R259	1-216-824-91	RES, CHIP 1.8K	(1608)	R427	1-218-871-91	RES, CHIP 10K	(1608)	R626	1-216-833-91	RES, CHIP 10K
Q805	8-729-103-96	TRANSISTOR 2SB798-T1DL	R261	1-216-829-91	RES, CHIP 4.7K	(1608)	R428	1-216-309-91	RES, CHIP 5.6	(2012)	R627	1-216-837-91	RES, CHIP 22K
Q806	8-729-016-26	TRANSISTOR 2SK1958-T1	R263	1-216-825-91	RES, CHIP 2.2K	(1608)	R433	1-216-821-91	RES, CHIP 1.0K	(1608)	R630	1-216-837-91	RES, CHIP 22K
Q806	8-729-048-50	TRANSISTOR 2SK3018-T106	R264	1-216-821-91	RES, CHIP 1.0K	(1608)	R440	1-218-831-91	RES, CHIP 220	(1608)	R636	1-216-864-91	CONDUCTOR, CHIP
Q808	6-550-008-01	TRANSISTOR UM6K1N-TN	R265	1-216-821-91	RES, CHIP 1.0K	(1608)	R441	1-218-871-91	RES, CHIP 10K	(1608)	R640	1-216-864-91	CONDUCTOR, CHIP
Q808	6-550-014-01	TRANSISTOR SSM6N15FU(TE85R)	R270	1-218-853-91	RES, CHIP 1.8K	(1608)	R442	1-218-865-91	RES, CHIP 5.6K	(1608)	R642	1-216-833-91	RES, CHIP 10K
Q808	6-550-017-01	TRANSISTOR XP0487800LS0	R272	1-218-859-91	RES, CHIP 3.3K	(1608)	R443	1-218-858-91	RES, CHIP 3.0K	(1608)	R644	1-216-837-91	RES, CHIP 22K
Q814	8-729-014-02	TRANSISTOR RN1306-TE85L	R273	1-218-851-91	RES, CHIP 1.5K	(1608)	R444	1-218-867-91	RES, CHIP 6.8K	(1608)	R649	1-216-833-91	RES, CHIP 10K
Q814	8-729-029-13	TRANSISTOR DTC143ZUA-T106	R277	1-218-853-91	RES, CHIP 1.8K	(1608)	R445	1-218-857-91	RES, CHIP 2.7K	(1608)	R650	1-218-965-81	RES, CHIP 10K
R101	1-211-983-91	RES, CHIP 39	R292	1-216-833-91	RES, CHIP 10K	(1608)	R446	1-218-874-91	RES, CHIP 13K	(1608)	R651	1-216-835-91	

Ref.	Part No.	Description		Ref.	Part No.	Description		Ref.	Part No.	Description		Ref.	Part No.	Description
R805	1-216-809-91	RES, CHIP 100	(1608)	RB113	1-234-710-21	RES, CHIP NETWORK 47X8	(3816)	RB604	1-233-415-21	RES, CHIP NETWORK 10K	(3216)			
R806	1-216-833-91	RES, CHIP 10K	(1608)	RB114	1-234-710-21	RES, CHIP NETWORK 47X8	(3816)	RB605	1-233-415-21	RES, CHIP NETWORK 10K	(3216)			
R807	1-216-809-91	RES, CHIP 100	(1608)	RB117	1-234-710-21	RES, CHIP NETWORK 47X8	(3816)	RB606	1-233-412-21	RES, CHIP NETWORK 1.0K	(3216)			
R808	1-216-833-91	RES, CHIP 10K	(1608)	RB118	1-234-710-21	RES, CHIP NETWORK 47X8	(3816)	RB609	1-233-423-21	RES, CHIP NETWORK 47	(3216)			
R813	1-216-158-91	RES, CHIP 22	(3216)	RB121	1-233-423-21	RES, CHIP NETWORK 47	(3216)	RB803	1-233-415-21	RES, CHIP NETWORK 10K	(3216)			
R814	1-216-158-91	RES, CHIP 22	(3216)	RB122	1-233-423-21	RES, CHIP NETWORK 47	(3216)							
R815	1-216-797-91	RES, CHIP 10	(1608)	RB123	1-234-710-21	RES, CHIP NETWORK 47X8	(3816)							
R816	1-216-158-91	RES, CHIP 22	(3216)	RB124	1-234-710-21	RES, CHIP NETWORK 47X8	(3816)	△ TH001	1-533-817-21	THERMISTOR				
R817	1-216-158-91	RES, CHIP 22	(3216)	RB139	1-233-414-21	RES, CHIP NETWORK 4.7K	(3216)	△ TH001	1-804-384-21	THERMISTOR, POSITIVE				
R818	1-216-797-91	RES, CHIP 10	(1608)	RB147	1-234-710-21	RES, CHIP NETWORK 47X8	(3816)	△ TH002	1-533-817-21	THERMISTOR				
R819	1-218-889-91	RES, CHIP 56K	(1608)	RB148	1-234-710-21	RES, CHIP NETWORK 47X8	(3816)	△ TH002	1-804-384-21	THERMISTOR, POSITIVE				
R820	1-218-881-91	RES, CHIP 27K	(1608)	RB149	1-234-710-21	RES, CHIP NETWORK 47X8	(3816)	△ TH002	1-804-384-31	THERMISTOR, POSITIVE				
R821	1-218-881-91	RES, CHIP 27K	(1608)	RB242	1-234-710-21	RES, CHIP NETWORK 47X8	(3816)	△ TH003	1-533-817-21	THERMISTOR				
R822	1-218-881-91	RES, CHIP 27K	(1608)	RB244	1-234-710-21	RES, CHIP NETWORK 47X8	(3816)	△ TH003	1-804-384-21	THERMISTOR, POSITIVE				
R823	1-218-890-91	RES, CHIP 62K	(1608)	RB246	1-234-710-21	RES, CHIP NETWORK 47X8	(3816)	△ TH003	1-804-384-31	THERMISTOR, POSITIVE				
R826	1-218-871-91	RES, CHIP 10K	(1608)	RB295	1-233-412-21	RES, CHIP NETWORK 1.0K	(3216)							
R827	1-218-871-91	RES, CHIP 10K	(1608)	RB296	1-234-598-21	RES, CHIP NETWORK 75X4	(3216)							
R828	1-218-881-91	RES, CHIP 27K	(1608)	RB297	1-234-599-21	RES, CHIP NETWORK 180X4	(3216)	X102	1-781-640-21	VIBRATOR, CRYSTAL				
R830	1-216-815-91	RES, CHIP 330	(1608)	RB298	1-234-598-21	RES, CHIP NETWORK 75X4	(3216)	X102	1-781-640-41	VIBRATOR, CRYSTAL				
R831	1-216-810-91	RES, CHIP 120	(1608)	RB303	1-233-412-21	RES, CHIP NETWORK 1.0K	(3216)	X301	1-781-856-21	VIBRATOR, CRYSTAL				
R834	1-208-911-81	RES, CHIP 10K	(1005)	RB310	1-233-414-21	RES, CHIP NETWORK 4.7K	(3216)	X301	1-781-856-41	VIBRATOR, CRYSTAL				
R837	1-208-922-81	RES, CHIP 30K	(1005)	RB311	1-233-679-91	RES, NETWORK (1608) 470	(3216)	X302	1-781-768-21	VIBRATOR, CRYSTAL				
R838	1-208-922-81	RES, CHIP 30K	(1005)	RB312	1-233-786-91	RES, NETWORK 220	(1608)	X401	1-760-496-22	VIBRATOR, LITHIUM NIOBATE				
R840	1-208-916-81	RES, CHIP 16K	(1005)	RB314	1-233-681-91	RES, NETWORK (1608) 4.7K								
R843	1-208-922-81	RES, CHIP 30K	(1005)	RB317	1-233-423-21	RES, CHIP NETWORK 47	(3216)							
R846	1-208-922-81	RES, CHIP 30K	(1005)	RB318	1-233-423-21	RES, CHIP NETWORK 47	(3216)							
R847	1-218-977-81	RES, CHIP 100K		RB319	1-233-423-21	RES, CHIP NETWORK 47	(3216)							
R850	1-208-911-81	RES, CHIP 10K	(1005)	RB320	1-233-423-21	RES, CHIP NETWORK 47	(3216)							
R851	1-208-916-81	RES, CHIP 16K	(1005)	RB321	1-233-423-21	RES, CHIP NETWORK 47	(3216)							
R852	1-218-873-91	RES, CHIP 12K	(1608)	RB322	1-233-412-21	RES, CHIP NETWORK 1.0K	(3216)							
R853	1-216-298-91	RES, CHIP 2.2	(2012)	RB323	1-233-412-21	RES, CHIP NETWORK 1.0K	(3216)							
R854	1-216-298-91	RES, CHIP 2.2	(2012)	RB324	1-233-412-21	RES, CHIP NETWORK 1.0K	(3216)							
R855	1-216-298-91	RES, CHIP 2.2	(2012)	RB325	1-233-412-21	RES, CHIP NETWORK 1.0K	(3216)							
R856	1-216-298-91	RES, CHIP 2.2	(2012)	RB326	1-233-412-21	RES, CHIP NETWORK 1.0K	(3216)							
R866	1-216-845-91	RES, CHIP 100K	(1608)	RB327	1-233-415-21	RES, CHIP NETWORK 10K	(3216)							
R868	1-216-849-91	RES, CHIP 220K	(1608)	RB328	1-233-414-21	RES, CHIP NETWORK 4.7K	(3216)							
R870	1-216-849-91	RES, CHIP 220K	(1608)	RB332	1-233-575-21	RES, CHIP NETWORK 22								
R871	1-218-896-91	RES, CHIP 110K	(1608)	RB401	1-233-415-21	RES, CHIP NETWORK 10K	(3216)							
R872	1-216-844-91	RES, CHIP 82K	(1608)	RB402	1-233-803-91	RES, NETWORK 1.5K	(1608)							
R873	1-216-839-91	RES, CHIP 33K	(1608)	RB403	1-233-415-21	RES, CHIP NETWORK 10K	(3216)							
R874	1-216-828-91	RES, CHIP 3.9K	(1608)	RB405	1-233-803-91	RES, NETWORK 1.5K	(1608)							
R875	1-216-023-91	RES, CHIP 82	(2012)	RB406	1-233-792-91	RES, NETWORK 100K	(1608)							
R876	1-216-023-91	RES, CHIP 82	(2012)	RB408	1-233-415-21	RES, CHIP NETWORK 10K	(3216)							
R877	1-216-023-91	RES, CHIP 82	(2012)	RB409	1-233-415-21	RES, CHIP NETWORK 10K	(3216)							
R878	1-216-023-91	RES, CHIP 82	(2012)	RB410	1-233-415-21	RES, CHIP NETWORK 10K	(3216)							
R879	1-216-023-91	RES, CHIP 82	(2012)	RB411	1-233-412-21	RES, CHIP NETWORK 1.0K	(3216)							
R880	1-216-023-91	RES, CHIP 82	(2012)	RB511	1-233-423-21	RES, CHIP NETWORK 47	(3216)							
R881	1-216-023-91	RES, CHIP 82	(2012)	RB517	1-233-575-21	RES, CHIP NETWORK 22								
R882	1-216-023-91	RES, CHIP 82	(2012)	RB518	1-233-575-21	RES, CHIP NETWORK 22								
R901	1-218-937-81	RES, CHIP 47		RB519	1-233-575-21	RES, CHIP NETWORK 22								
R902	1-218-937-81	RES, CHIP 47		RB520	1-233-575-21	RES, CHIP NETWORK 22								
R974	1-216-801-91	RES, CHIP 22	(1608)	RB521	1-233-575-21	RES, CHIP NETWORK 22								
R975	1-216-801-91	RES, CHIP 22	(1608)	RB522	1-233-575-21	RES, CHIP NETWORK 22								
		<RESISTOR BLOCK>		RB523	1-233-575-21	RES, CHIP NETWORK 22								
RB101	1-234-496-21	ARRAY, RESISTOR 39		RB524	1-233-575-21	RES, CHIP NETWORK 22								
RB102	1-234-496-21	ARRAY, RESISTOR 39		RB525	1-233-575-21	RES, CHIP NETWORK 22</td								


## SWITCH MOUNT



**SW-367**  
A side



**SW-367**  
B side



**SW-367**

### SWITCH MOUNTED CIRCUIT BOARD

Ref-No.	Part No.	Description	Remark	Place code
PWB	1-683-435-11	PWB, SW-367		
PWB	1-683-435-21	PWB, SW-367		
CN751	1-785-470-21	CONNECTOR, FPC(LIF(NON-ZIF) 7P		
D751	8-719-078-90	DIODE CL-165HR/G1-D-T		
D752	6-500-240-01	DIODE CL-190UB2-X-T		
Q751	8-729-013-97	TRANSISTOR RN1304-TE85L		
Q751	8-729-029-14	TRANSISTOR DTC144EUA-T106		
Q751	8-729-402-44	TRANSISTOR UN5213-TX		
R751	1-216-833-91	RES, CHIP 10K (1608)		
R752	1-216-835-91	RES, CHIP 15K (1608)		
R753	1-216-993-91	RES, CHIP 2.4K (1608)		
S751	1-771-917-21	SWITCH, TACTILE		
S752	1-771-917-21	SWITCH, TACTILE		