

## Allied's

## TENNIS TOURNEY

PARTS CATALOG




ALLIED LEISURE INDUSTRIES INC. 245 WEST 74TH PLACE HIALEAH, FLORIDA 33010




## TENNIS TOURNEY - 4 PLAYER


ITEM	PART NO.	DESCRIPTION
1 2 3 4 5 6 7 8 9 10	249-1-1 249-9-1 249-3-6 249-3-7 249-1-3 249-1-19 249-3-4 249-6-2 249-6-1 249-1-10 249-1-11	Tennis Tourney Cabinet Ass'y 22" Table T.V. Sylvania T.V. Rear Supp. Bracket T.V. Front Bottom Bracket Supp. T.V. Base Support Ass'y Front Top Panel Ass'y Light Panel Brk't Top Screen Glass Smoked Glass Lock Stop Bracket L.H. Ass'y Lock Stop Bracket R.H. Ass'y
12	249-1-12	Coin Chute & Bracket Ass'y
13	<b>249-1-9</b> See Page #4	Deck Control Ass'y
14		
15	249-3-2	Front Bracket Cover
16	249-3-3	Bracket Cover Rear Support
17	249-1-6	Cash Door Ass'y
18	249-3-17	Coin Chute Tube
19	240-1-507	Cash Box Weldment
20	249-1-8	Chassis Ass'y
21	249-9-2	P.C.B. 040 Video Control
22	<b>249-1-1</b> 5 See Page #5	24V Power Supply Ass'y 4-Players
23	249-1-14	Cabinet Base Ass'y
24	240-3-46	Leg Leveler Tap Plate
25	240-8-9	Leg Leveler
26 27	<b>240-1-35</b> 249-1-20 SEE PAGE #5	On-Off Switch Ass'y Counter Ass'y




SIDE VIEW - CABINET

(1) 1 249-3-24 Loc (5) 1 240-9-23 D15 (6) 1 240-9-24 LA1 (7) 1 240-71-1 Sw1 (7) 1 240-71-1 Sw1 (7) 1 240-71-1 Sw1 (8) 1 249-6-3 Pus (9) 1 249-6-3 Instant (1) 249-6-3 FRO (2) 4 249-2-1 KNU (3) 4 249-3-1 FRO (4) 249-3-1 FOORT	COUNTER ASSY
1 240-9-23 1 240-9-24 1 240-7/-/ 1 240-7/-/ 1 249-6-3 1 249-6-3 1 249-6-3 4 249-2-1 4 249-3-13 1 249-3-13 1 249-3-13	OCK PLATE
1 240-9-24 1 73-58 1 240-7/-/ 1 240-2-35 1 249-6-3 1 249-6-3 4 249-2-1 4 249-3-13 1 249-3-13 1 249-3-1	DISPLAY LAMP WH 44
1 73.58 1 240-7/-/ 1 240-2-35 1 249-6-3 1 249-3-13 4 249-2-1 4 249-3-1 1 249-3-1	LAMP SOCKET
1 240-7/-/ 1 240-2-35 1 249-6-3 1 249-6-3 4 249-2-1 4 249-3-1 1 249-8-44	SWITCH COVER PLATE
1 240-2-35 1 5-7 1 249-6-3 1 249-3-13 4 249-2-1 4 249-3-13 1 249-3-1	SWITCH-CREDIT BUTTON
5-7   1 249-6-3   1 249-3-13   4 249-2-1   4 249-3-5   1 249-3-1	PUSH BUTTON JACKET
1 249-6-3 1 249-3-13 4 249-2-1 4 249-3-5 4 249-13 1 249-3-1	PUSH BUTTON
1 249-3-13 4 249-2-1 4 249-3-5 4 249-13 1 249-3-1	INSTRUCTION PANEL
4 249-2-1 4 249-3-5 4 249-1-13 1 240-8-44 1 249-3-1	FRONT PANEL INST. COVER
4 249-3-5 4 249-1-13 1 240-8-44 1 249-3-1	KNOB
4 249-1-13 1 240-8-44 1 249-3-1	KNOB PLATE
1 240-8-44	Pot AssY
1 249-3-1	KEY LOCK
	CONTROL TABLE-ALUM, TRIM
3   1 249-4.7 CONT	CONTROL TABLE BOTTOM BRD.
2) 4 235-8-211 INSU	INSULATOR WASHER
0       243-1-5 CON	CONTROL TABLE ASSY
97Y PER ASSY DWG.NO. DB	DESCRIPTION







ITEM		QTY.	ON PART NO.	DESCRIPTION
(0)		_	249-8-5	REED P.C.B.
G			2-6-642	MBGNETIC REED SM
<b>a</b>		4		*4-40 KEPS NUT
<b>0</b>		7	249-3-3A	BRACKET
(2)		4		#4-40x1/4
$\Theta$		1	235-9-32	235-9-32 COUNTER 24V 50/60HZ

