
Exit, quit, or Ctrl+C
Exit, quit, or Ctrl+C
s0 — LED
OFF
OFF
s1 — LED
ON
ON
OFF
ON