

HANDS ON STEP BY STEP

Platform site
wellnova.ai

Consult site
doc.wellnova.ai

Follow the steps and complete the tasks.

01

Log in with the credentials sent to your email.

02

Click on "New Well."

Upload the file
Logging_Data_9OGX44HP.DLIS

03

Check the upload status.

Click on the clock icon in the top-right corner of the screen.



04

Click on the card of the uploaded well and add the Completion data.

Upload the PDF named
Completion_9OGX44HP.pdf

05

Click on the "+" button in the document section to upload a file.

Upload the file **CBL_USIT_Logs.pdf**

06

Access the Data Visualization module.



Select the **9-OGX-44HP**.

07

Add a comment to a track by clicking the comment balloon icon in the right-hand side menu.

08

Click on "Quality Control" to verify the log quality.

09

Enable the Advanced Options menu and check the Well Sketch.

Select the "Show as a track" option

10

Use Combine Channels to merge two channels into a new track:

- CBL (0 to 50 mV)
- AIAV (0 to 10 MRayl)

11

Click on 'New Track' to display any other channel available in the uploaded file.

12

Access the Interpretation module from the left side menu.



Select the well **9-OGX-44HP**.

Click "Continue" to view the results.

13

Click on the Features button and enable the "Track Line" option.

A support line will appear on the screen.

14

Modify the interpretation type in Interpretation Settings.

Click on "Bond Quality" and change the classification from 6 classes to 3 classes (Free Pipe, Poor Bond, and Good Bond).

15

Add a new interpretation track based only on CBL + VDL.

Select "Add New".

Then select "2 Interpretations" in the Quantity field and choose "CBL/VDL" in the Interpretation 02 field.

16

Add a comment to any Bond Quality track.

17

Click on "Results Comparison" to generate a Comparison Matrix.

Upload the file
2nd_Opinion_9OGX44HP.csv and process it to display the Comparison Matrix.

18

Click on Generate Report to view the final Bond Quality Report.