

HANDS ON STEP BY STEP

Follow the steps and complete the tasks.

Platform site
wellnova.ai

Consult site
doc.wellnova.ai

01

Log in with the credentials sent to your email.

02

Add "New well".

Upload the file
Logging_Data_159F11B.DLIS

03

Check the upload status.

On the clock in the top right of the screen. 

04

Click on the card of the uploaded well and add the Completion data.

Upload the PDF named
Completion_159F11B.pdf

05

Click on the "+" button in the document area to upload a document.

Upload the file **CBL_USIT_Logs.pdf**

06

Access the Data Visualization module. 

Select the **15-9-F11-B**.

07

Click on "Quality Control" to check the quality of the logs.

08

Enable the Advanced Options menu and toggle the "Track line" option.

A support line will appear on screen.

09

Combine Channels to merge two channels into a new track.

CBL (0 to 50 mV).

AIAV (0 to 10 MRayl).

10

Click on New Track to display any other channel available in the uploaded file.

11

Access the Interpretation module. 

Select the **15-9-F11-B** well.

12

Modify the interpretation type in "Interpretation settings".

Change from 6 classes to 3 classes (Free Pipe, Poor Bond, and Good Bond).

13

Add a new interpretation track based on only CBL+VDL or only Impedance data.

14

Access the Interpretation module through the left side menu. 

Select the **15-9-F11-B** well;

In the left side select "Disagree" and modify an interval of your choice.;

Click "Run" to view the results;

15

Add a comment to the Bond Quality Track.

16

Click on "Results Comparison" to generate a Comparison Matrix.

Upload the .csv file named **2nd_Opinion_159F11B.csv** and process it to view the Comparison Matrix.

17

Click to Generate Report.

To visualize the final Bond Quality Report.