TAPE READ/WRITE

```
0090
       E2
             SEX
                   2
                         : X = 2
  91
       96
             GHI
                   R6
       73
86
  92
             STXD
                         :Push R6.1
  93
94
                   R6
             GLO
       73
F8
             STXD
                         ; Push R6.0 (Save old R6)
  95
96
             LDI
       05
  97
98
       BA
             PHI
                   RA
       В6
             PHI
                   R6
  99
       F8
             LDI
                         ;Set R6 = 0500, beginning data area
  9A
       00
                         Also setting RA for later display
  9B
       AA
             PLO
                   RA
  90
       A6
             PLO
                   R6
                         :And disassemble
  9D
       F8
             LDI
       03
  9E
  9F
       AE
             PLO
                   RE
                         :Set RE.0 = Number pages fixed at 3
00A0
       22
             DEC
                   R2
                         ;R2 - 1 to compensate for next unwanted inc.
       61
  A1
             INP
                         ; Turn off video (R(x)+1)
       83
  A2
             GLO
                   R3
       A4
  A3
             PLO
                   R4
  A4
       24
             DEC
                   R4
                         ;Swap program counters - (R4=PC) R4 must
  A5
A6
       93
B4
             GHI
                   R3
                             later be set = 0313 for sub routine calls
                   R4
             PHI
  A7
       D4
             SEP
                   R4
  A8
       F8
             LDI
       80
  A9
  AA
       B3
             PHI
                         :R3.1 = Read/Write page location in ROM
                   R3
       8Ē
  AB
             GLO
                   RF
  AC
       FB
             XRI
                         :Test RF.O if Write selected
  AD
       OF
  AE
       3A
             BNZ
                         :If not, branch to test for Read
  AF
       B6
       F8
                         :Begin call to Tape Write
00B0
             LDI
       91
  B1
       Â3
  B2
             PLO
                         ;Set R3 = Write sub in ROM @ 8091
                   R3
  B3
       D3
             SEP
                   R3
                         ;Do sub - Write 3 pages to tape
  B4
       30
             BN
                         Branch to exit
  B5
       C1
  Вб
       8F
             GLO
                   RF
  B7
       FB
             XRI
                         Test if Tape Read selected (RF.0 = OB)
  B8
       0B
        3A
  B9
             BNZ
                         If not, branch to exit, turning video
       CO
  BA
                         :Back on
  BB
       F8
             LDI
                         ; Begin call to Tape Read
       C2
  BC
  BD
       A3
             PLO
                         :R3= OBC2 - Read routine in ROM
                   R3
                         :Do sub - Read 3 pages
  BE
       D3
             SEP
                   R3
        38
             SKP
  BF
                         :Always skip
```