- 5. Enter three digits of the last address. (See step 1.)
  Remember not to include the leading zero.
- 6. Enter three digits of the new start address. (See Step 2.) Again, exclude the leading zero.
- 7. Press Key 0 again.
- 8. Adjust target addresses within the shifted block for all GOTO or GOSUB (branch) instructions.

To escape from Relocate Mode prior to step 7, press Key F repeatedly. To escape at step 7, press any key except Key 0.

Zeros will be entered automatically into the vacated addresses.

9. After the data has been relocated, use Key E to enter the forgotten instructions.