keyboard under the control of Modification #2 is nearly identical to the operation under Modification #1. (If you have not read that section, please do before continuing.) To select One Key Functions, hold down the CONTROL key, then press the desired key as explained before.

To select the bank of Escape Functions, first press the ESCAPE key. A tone will be heard indicating, again, that the next key pressed will select an Escape Function. Using the same list of numbers that were originally intended for the hexpad, press the key on your keyboard that corresponds to the number or letter of the function you want. You do not have to hold down the CONTROL key to select an Escape Function after pressing the ESCAPE key. Just press the right key and the function will be performed. Return to normal typing mode is automatic just as it is for Modification #1.

If after pressing the ESCAPE key you change your mind and do not wish to select any function, pressing the ESCAPE key a second time will return control to normal operation. So will pressing the number 0 just as it did on the hexpad under Modification #1. Be careful to press number 0 and not letter 0 to return to normal typing mode, though. (Realizing the possible