you have a "pause" control, set the tape machine to record, but do not start the tape just yet. (If you do not have a "pause" control, you will have to start recording in whatever way is normal for you.) Make a note of the location number from your tape counter.

Taping is in two parts as mentioned previously.

Once taping has begun, DO NOT STOP THE TAPE RECORDER

UNTIL AFTER PART 2 HAS BEEN COMPLETED. Between parts,
the display will return and you must resist the urge to
turn off the recorder in between parts.

Following is the tape output format:

- 1) Symbol and Link Tables 6 pages display off
- 2) Four-second pause (approximate) display on
- 3) Object program 3 pages display off

Taping begins as soon as you press Key F for the second time. (You do not have to specify addresses or the number of pages -- all is automatically controlled by Chip-8 Assembler-3.)

First start the tape with your machine in the record mode. Next press Key F.. The familiar high-pitched tone of recording will be heard as the output is sent to tape. Sit back in your chair, and when the display returns, sit on your hands! DO NOT STOP THE TAPE