system following a tape operation. This means you should never have to reset the run switch after the initial power up as the first page of text will automatically be displayed, ready for your commands, following either taping operation.

Backing up to the first level functions again, please note that moving the cursor right past a line end causes an auto carriage return, so typing does not need to be interrupted. Moving left will cause the cursor to eventually stop at the far left. Going up or down too far causes an automatic home and tone warning. Scrolling up does not affect the <u>display</u> cursor position to allow typing new lines on the bottom of pages as old lines are scrolled up automatically out out the way. Scrolling back homes the cursor. (Presumably you are scrolling back to get to a new top line)

In addition to the program itself, you need to enter your character set in the two pages just below the four used for display refresh. This character set conforms to the format of my program "A CHARACTER DESIGNER for the VIP" so it will not be discussed here. (see program description for further details, however.) This also applies to DISASSEMBLER-7.

Systems with only 3K of memory can use TEXT EDITOR-21