通信系Add-Onボード(9pin)のピンアサイン

			GNSS	iS110B t	ypeA	iS110B typeB		iS110B typeC		WISUN	422/485		CAN	AN				ELTRES Zeta		W5500-Ether		BLE1507			MM-S50MV(ToF)		eMMC Add-on		USB Host	
				default		default		default			JP1/2 em		emmc	12S					eMMC		no reset	eMMC	12S	SPI	UART	I2S	UART		1	
スタッカブル			0	1					0		0					0					0		0			0				
pin情号	D00	UART2_RX		0	Δ	0	Δ	0	Δ	0	0	0	0					0	0			0	0	0		0			0	
	D01	UART2_TX		0	Δ	0	Δ	0	Δ	0	0	0	0					0	0			0	0	0		0			0	
	D27	UART2_CTS		0	0	×	0	×	0	-	0		-					0	-			0	0	0		0		0	-	
	D28	UART2_RTS		0	0	×				-	0							0				0	0	0		0				
	D25	2S0_LRCK												0			0	0			0									
	D26	2S0_BCK																0			0						0			
	D18	I2SO_DATA_OUT		0									0					0												
	D19	I2SO_DATA_IN											0	0		0		0						0						
	D16	SPI5_MOSI	EMMC_DATA0	0	0	Δ	0	Δ	0	Δ	0									0	0				0		0	0		0
	D17	SPI5_MISO	EMMC_DATA1	0	0	Δ	0	Δ	0	Δ	0									0	0				0		0	0		0
	D23	SPI5_SCK	EMMC_CLK		0	Δ	0	Δ	0	Δ										0	0				0		0	0		0
	D24	SPI5_CS_X	EMMC_CMD		0	Δ	0	Δ	0	Δ					0				0	0	0				0		0	0		0
	D20		EMMC_DATA2				0	0	0	0	0	0			0	0	0		0	0			0				0	0	0	0
	D21		EMMC_DATA3						0	0	0	0								0							0	0	0	0
	D14	12C0_SDA		Δ																										
	D15	12C0_SDL		Δ																										
	D22	SEN_IRQ_IN		0																										

色ごとにピングループになっている。

○ 本来の目的で接続△ 接続されているが別で使用可能× 本来の目的で使用不可能