



43243242 — TRËTTER — 10

Page 1 / 3 — Confidential

[object Promise]



Nov 23, 2025 00:43

TRËTTER

Style / Article: 43243242 | Version: 10 | Season: SS25

BRAND

Fashion Forward

CATEGORY

Polo Shirts

DESIGNER

Ava Nguyen

SUPPLIER

Vietnam Textile Manufacturing Co., Ltd.

GENDER

Men

COLLECTION

Spring Essentials 2025



Page 1 / 3 — Confidential



FABRIC & NOTES

Fabric: 100% Premium Cotton, 180 GSM, Single Jersey Knit, Pre-shrunk, Soft Touch Finish

Description: Production ready. All materials approved. Target delivery: Q2 2025. Minimum order quantity: 500 units per colorway.

Notes: Production ready. All materials approved. Target delivery: Q2 2025. Minimum order quantity: 500 units per colorway.

BILL OF MATERIALS

Total Items: **8**

Suppliers: **5**

Approved: **0**

MEASUREMENTS

Total POM: **8**

Critical Points: **0**

Size Range: **S – XXL**

HOW TO MEASURE

Steps: **5**

Diagrams: **1**

Tips: **16**

NOTES & CARE

Notes: **2**

Care Symbols: **0**

Last Export: —



43243242 — TRÈTTER — 10

Page 3 / 3 — Confidential

ADDITIONAL INFO

Colorways: 3

Page 3 / 3 — Confidential



43243242 — TRËTTER — 10

Page 1 / 4 — Confidential

[object Promise]

Page 1 / 4 — Confidential



BILL OF MATERIALS

#	ITEM	PART	PLACE MENT	QT Y	UO M	SUPPLIER	NOTES
1	Premium Cotton Single Jersey	Main Fabric Size: All Sizes	Front Body, Back Body, Sleeves	1.2	m	Vietnam Textile Manufacturing Co., Ltd. Code: VTM-COT-180-SJ	Pre-approved fabric. Color matching required for each colorway.
2	Cotton Rib Knit	Ribbed Collar Size: All Sizes	Collar	0.15	m	Vietnam Textile Manufacturing Co., Ltd. Code: VTM-COT-RIB-200	Must match main fabric color. Pre-shrunk required.
3	Cotton Rib Knit	Ribbed Cuff Size: All Sizes	Cuff	0.12	m	Vietnam Textile Manufacturing Co., Ltd. Code: VTM-COT-RIB-200	Must match main fabric color.
4	Polyester Core-Spun Thread	Thread Size: 40/2	All Seams	150	m	Global Thread Solutions Code: GTS-PES-40-2-WH	Color to match fabric. High strength for durability.



#	ITEM	PART	PLACE MENT	QT Y	UO M	SUPPLIER	NOTES
5	Plastic 4-Hole Button	Button Size: 18mm	Placket	3	pcs	Button World Manufacturing Code: BWM-PLA-18-4H	Color to match fabric. Must pass pull test (min 50N).
6	Woven Care Label	Label - Main Size: 5cm x 2cm	Side Seam	1	pcs	Label Solutions Inc. Code: LSI-WOV-CARE-001	Must include: Brand name, Size, Care instructions, Country of origin
7	Printed Size Label	Label - Size Size: 3cm x 1.5cm	Back Neck	1	pcs	Label Solutions Inc. Code: LSI-PRN-SIZE-001	Size to be printed as per size chart (S, M, L, XL, XXL)
8	Cardboard Hang Tag	Hang Tag Size: 8cm x 5cm	Attached to garment	1	pcs	Packaging Plus Code: PP-CARD-HT-001	Brand logo, product name, price, barcode. Attach with string.



MATERIALS OVERVIEW

Total materials: **8**

Categories: **1**

With images: **0**

SUPPLIER OVERVIEW

Unique suppliers: **5**

Lead time avg: **—**

MOQ avg: **—**



[object Promise]

BOM IMAGE SHEET

No image provided

Premium Cotton Single Jersey

Part: Main Fabric
Placement: Front Body, Back Body, Sleeves
Supplier: Vietnam Textile Manufacturing Co., Ltd.

No image provided

Cotton Rib Knit

Part: Ribbed Collar
Placement: Collar
Supplier: Vietnam Textile Manufacturing Co., Ltd.

No image provided

Cotton Rib Knit

Part: Ribbed Cuff
Placement: Cuff
Supplier: Vietnam Textile Manufacturing Co., Ltd.

No image provided

Polyester Core-Spun Thread

Part: Thread
Placement: All Seams
Supplier: Global Thread Solutions



No image provided

Plastic 4-Hole Button

Part: Button

Placement: Placket

Supplier: Button World
Manufacturing

No image provided

Woven Care Label

Part: Label - Main

Placement: Side Seam

Supplier: Label Solutions Inc.

No image provided

Printed Size Label

Part: Label - Size

Placement: Back Neck

Supplier: Label Solutions Inc.

No image provided

Cardboard Hang Tag

Part: Hang Tag

Placement: Attached to garment

Supplier: Packaging Plus



43243242 — TRËTTER — 10

Page 1 / 3 — Confidential

[object Promise]



MEASUREMENT / POINT OF MEASURE

CODE	DESCRIPTION	TOLE RANC E	S	M	L	XL	XXL	NOTES
CHEST	Chest Widthssss	-1 / +1	98	104	110	116	122	Measure 2.5cm below armhole, across chest. Garment laid flat.
WAIST	Waist Width	-1.5 / +1.5	90	96	102	108	114	Measure at waist level, garment laid flat.
LENGTH	Body Length	-1 / +1.5	70	72	74	76	78	Measure from highest point of shoulder to bottom hem.
SLEEVE	Sleeve Length	-1 / +1	22	23	24	25	26	Measure from shoulder seam to cuff edge.
SHOULDER	Shoulder Width	-1 / +1	42	44	46	48	50	Measure from shoulder seam



CODE	DESCRIPTION	TOLE RANC E	S	M	L	XL	XXL	NOTES
								to shoulder seam.
ARMHOLE	Armhole Depth	-0.5 / +0.5	22	23	24	25	26	Measure from shoulder seam to armhole bottom.
COLLAR	Collar Height	-0.3 / +0.3	2.5	2.5	2.5	2.5	2.5	Measure height of collar when laid flat.
CUFF	Cuff Opening	-0.5 / +0.5	18	19	20	21	22	Measure circumference of cuff opening.

MEASUREMENT SUMMARY

Total POM: 8

Critical: 0

Groups: 0

SIZE COVERAGE

Range: S – XXL

Size columns: 5

Complete rows: 8



43243242 — TRËTTER — 10

Page 1 / 8 — Confidential

[object Promise]



HOW TO MEASURE

image unavailable

CHEST 1

Measure the chest width of the garmentadsssss

STEP-BY-STEP INSTRUCTIONS

1. Lay the garment flat on a smooth surfaces
2. Smooth out any wrinkles or folds
3. Locate the point 2.5cm below the armhole on both sides
4. Place the measuring tape horizontally across the chest at this point
5. Measure from side seam to side seam
6. Record the measurement in centimeters

TIPS

- Ensure the garment is completely flat before measuring
- Do not stretch the fabric while measuring
- Measure at the widest point of the chest area

COMMON MISTAKES

- Measuring too high or too low on the chest
- Not laying the garment completely flat
- Stretching the fabric while measuring



- Take the measurement twice to ensure accuracy

- Measuring at an angle instead of horizontally

Related POM: WAIST, SHOULDER



No image provided

WAIST 2

Measure the waist width of the garment

STEP-BY-STEP INSTRUCTIONS

1. Lay the garment flat on a smooth surface
2. Locate the waist level (typically at the narrowest point of the body)
3. Place the measuring tape horizontally across the waist
4. Measure from side seam to side seam
5. Record the measurement in centimeters

TIPS

- The waist is usually the narrowest part of the garment
- Ensure the garment is flat and not twisted
- Measure at the natural waistline

COMMON MISTAKES

- Measuring at the wrong level (too high or too low)
- Not keeping the tape horizontal
- Measuring a twisted or folded garment

Related POM: CHEST, LENGTH



No image provided

LENGTH 3

Measure the total length of the garment from shoulder to hem

STEP-BY-STEP INSTRUCTIONS

1. Lay the garment flat on a smooth surface
2. Locate the highest point of the shoulder seam
3. Place the measuring tape at this point
4. Measure vertically down to the bottom hem
5. Follow the center line of the garment (front or back)
6. Record the measurement in centimeters

TIPS

- Measure along the center front or center back
- Keep the tape straight and vertical
- Ensure the hem is fully extended

COMMON MISTAKES

- Measuring from the wrong point on the shoulder
- Not keeping the tape vertical
- Measuring along the side seam instead of center
- Not extending the hem fully



43243242 — TRËTTER — 10

Page 6 / 8 — Confidential

Related POM: SLEEVE, ARMHOLE

Page 6 / 8 — Confidential



No image provided

SLEEVE 4

Measure the length of the sleeve from shoulder to cuff

STEP-BY-STEP INSTRUCTIONS

1. Lay the garment flat with the sleeve extended
2. Locate the shoulder seam
3. Place the measuring tape at the shoulder seam
4. Measure along the sleeve to the edge of the cuff
5. Follow the natural curve of the sleeve
6. Record the measurement in centimeters

TIPS

- Extend the sleeve fully but do not stretch
- Follow the natural curve of the sleeve
- Measure to the edge of the cuff, not the hem

COMMON MISTAKES

- Measuring in a straight line instead of following the curve
- Measuring to the wrong point (hem instead of cuff edge)
- Stretching the sleeve while measuring

Related POM: ARMHOLE, CUFF



No image provided

SHOULDER 5

Measure the width across the shoulders

STEP-BY-STEP INSTRUCTIONS

1. Lay the garment flat on a smooth surface
2. Locate the shoulder seams on both sides
3. Place the measuring tape horizontally from shoulder seam to shoulder seam
4. Measure across the back of the garment
5. Record the measurement in centimeters

TIPS

- Measure across the back for accuracy
- Ensure both shoulder seams are aligned
- Keep the tape horizontal

COMMON MISTAKES

- Measuring at an angle
- Not aligning the shoulder seams properly
- Measuring the front instead of the back

Related POM: CHEST, ARMHOLE



[object Promise]

COLORWAYS

Navy Blue

Code: NAVY-001

DEFAULT

PENDING

Placement	Material Type	Production Status	Supplier
All Over	Fabric	Lab Dip	Vietnam Textile Manufacturing Co., Ltd.
Pantone Code	Hex Color	Season	Collection
PANTONE 19-3832 TCX	#1B365D	SS25	Spring Essentials 2025

Notes: Approved color. Bulk fabric ordered. Delivery expected in 2 weeks.



Classic White

Code: WHITE-001

PENDING

Placement	Material Type	Production Status	Supplier
All Over	Fabric	Lab Dip	Vietnam Textile Manufacturing Co., Ltd.

Pantone Code	Hex Color	Season	Collection
<input type="checkbox"/> PANTONE 11-0601 TCX	#FFFFFF	SS25	Spring Essentials 2025

Notes: Approved color. Bulk fabric ready for production.

Charcoal Gray

Code: GRAY-001

PENDING

Placement	Material Type	Production Status	Supplier
All Over	Fabric	Lab Dip	Vietnam Textile Manufacturing Co., Ltd.

Pantone Code	Hex Color	Season	Collection
<input checked="" type="checkbox"/> PANTONE 19-3908 TCX	#4A4A4A	SS25	Spring Essentials 2025

Notes: Lab dip submitted. Awaiting approval.



[object Promise]

NOTES & REMARKS

DESCRIPTION

Production ready. All materials approved. Target delivery: Q2 2025. Minimum order quantity: 500 units per colorway.

Updated: Nov 23, 2025 00:43

GENERAL NOTES

Production ready. All materials approved. Target delivery: Q2 2025. Minimum order quantity: 500 units per colorway.

Updated: Nov 23, 2025 00:43