

Tech note	
Title:	Configuration ProxLine Mini 5v 9600Cross
Package:	
Category:	Hardware
Created:	On 29/10/2012 12:31 PM by Marc Wyns
Last edited:	On 29/10/2012 12:31 PM, by Marc Wyns

**Keywords:** ProxLine Mini, RS-232

**Comments:** use a USB wire to power up the ProxLine Mini

## Pinconfiguration ProxLine Mini

Yellow (RS-232 TX)

Blue (ground 0V)

Red (power +5V)

## Wiring ProxLine Mini

ProxLine Mini	USB cable	RS-232 (db9 female)
Blue	Black	
Red	Red	
Yellow		PIN2

## Pin layout



Opgepast, dit is het zicht van **binnenuit** (de plaats waar je moet solderen!) (JA)

**Picture**



<b>Reference:</b>	S:\HARDWARE\Reader\Proximity (EV)\Proxtech\Technotes\D.121029.V1.0D (ProxLine Mini).docx	Page 2 of 2
-------------------	---	-------------