

Navigation

Resources

Home

SDK Overview

Download & Install

Getting Started

LibMuse

MuselO

MuseLab

MusePlayer

MuseIO Receiver

Muse Hardware

Muse Data Files

Muse Communication

Protocol

Multi-Muse Setup

Developer FAQ

Intro to BCI and EEG

Release Notes

Forums

Mailing List

Support

MuseLab >

Tutorial

How to Run Muse-Lab

On Mac, with the Finder, navigate to "/Applications/Muse". Double click on the MuseLab icon or "muse-lab.jar".


On Windows, navigate to "C:\Program Files (x86)\Muse". Double click on the MuseLab icon or "muse-lab.jar".

Setup


This tutorial assumes you have muse-io running with one of the listed presets selected. See the <u>muse-io</u> tutorial for more info.

Receiving Data from Muse-IO

Set the receiving port for data then click "Open Port". By default the port number it is tcp:5000 unless you specified otherwise on the muse-io command line:




You should start seeing messages show up in the "Incoming Messages" box:




Setting up a Scrolling Graph Visualizer


Now that you are receiving data, it's time to visualize it. Change to the "Visualizer" tab:




Click on the "New" button:




Choose the "Scrolling Line Graph", then click "Finish":



The left side of the screen should now look something like this:




We will create a graph of your raw brainwaves. In the "Signal Group Options" box, check the "Draw" box for "/muse/eeg/raw":



You will see data start to scroll across the screen. Adjust the amplitude of the signal by going to the "Settings" tab and changing the range from -1250 to +1250 (you can use the up and down arrows to do this):

Scrolling Line Graph Options
Signals Settings Time
Visualizer Name
Scrolling Line Graph
Amplitude
Max Amplitude:
✓ Min Amplitude: -1250.0 Apply
Axes
Show Harizantal


Now when you blink, you should see an obvious signature in the top and bottom line graph:




Let's label this graph "EEG":

Scrolling	Line Graph	Options		
	Signals	Settings	Time	
Visualiz	er Name			
EEG				
Amplitu	ıde			
	A	Amplitude: 50.0		

Let's change the names of the channels that show up on the graph. Go back to the "Signals" tab and double-click on "/muse/eeg/raw (0)":



Change the name to "Left Ear", notice that the name on the graph changes:




You can go ahead and change each of the raw EEG labels with its corresponding English name. See OSC Pathing Scheme to see the

head location for each signal.

Load the Configuration File


Once MuseLab loads up, go to "Configuration -> Load Configuration" and open the file called "preset-14-4ch-acc.json". This file will work if you are running muse-io with the "14" preset. It will take a few seconds to load this file.



Once you do this you should start to see data streaming across the screen.


What the data should look once you are receiving clean EEG

In the screenshot below, the setup has the four EEG channels in the top graph. Channels (1) and (4) show three eye blinks. The middle plot shows the two AUX channels, ECG is visible from auxiliary chest electrodes. The bottom plot shows the three accelerometer axes.




Tricks for using MuseLab

- 1. If you click on a graph (it will highlight in blue). You can change the plot vertical scale and time scale using the arrow keys.
- 2. You can delete / modify / create plots by selecting "Visualizers":



3. Recording of data is available in the recording screen:



4. In the Master Time Panel, frame rate can be adjusted to make the graph update less frequently. Also you can Pause and Fwd / Rev scroll.

Configurat	tion	Cont	rol Ba	ır V	isua	lize	er
Master Ti	me Pa	nel			•	?	
ime Range	Displ	ayed					
+	Hou	ırs:	0				
[-]	Min	utes:	0				
	Sec	onds:	10		ppl	у	
layback							
Refresh Ra	te						
, Q	101010						
1					60		
History							
Scroll Spee	ed						
16 -8 -4 -	2 -1	-0.5 0	0.5	1 2	4	8	16
		Pause	9				

5. In the Markers panel, you can define and add markers into the current recording. Markers are also visible in the plot window.

6. In the DSP Settings panel you can define and apply FIR, IIR, and AX+B filters.

7. In the OSC panel, you can see the incoming messages as well as open and close UDP ports.

Incoming Data Format

For an description of the incoming signals from Muse, click here.

preset-14-4ch-a... Unknown user, ... v.1 **Comments**

You do not have permission to add comments.

Sign in | Recent Site Activity | Report Abuse | Print Page | Powered By Google Sites