Updating Witbox 2 firmware

Option 1: BQ Firmware Updater


- 1. Download the Firmware Updater from the <u>Witbox 2 resources page</u> (Windows or Linux depending on your operating system).
- 2. Follow the instructions on the updater to update your printer.

Option 2: Flashing with Cura

- 1. Download the latest firmware version from the Witbox 2 resources page.
- 2. Download and install Cura version 15.04.6 from here.

Ultimaker	Explore	Products	Stories	Resources	Knowledge	Community	Company	
			Version: 2.3.1 32 bit			Rele	ase date: Nov 8, 2016	
			Versi	ion: 2.3.1 64 bit		Rele	ase date: Nov 8, 2016	
			Versi	ion: 2.3 32 bit		Rele	ase date: Oct 19, 2016	
			Versi	ion: 2.3 64 bit		Rele	ase date: Oct 19, 2016	
			Versi	ion: 2.1.3 32 bit		Rele	ase date: Aug 16, 2016	
			Versi	ion: 2.1.3 64 bit		Rele	ase date: Aug 16, 2016	
			Versi	ion: 2.1.2 32 bit		Rele	ase date: Jun 7, 2016	
			Versi	ion: 2.1.2 64 bit		Rele	ase date: Jun 7, 2016	
			Versi	ion: 15.04.6		Rele	ase date: Jun 7, 2016	
			Versi	ion: 15.04.5		Rele	ase date: Mar 17, 2016	
			Versi	ion: 15.04.4		Rele	ase date: Jan 5, 2016	
			Versi	ion: 15.04.03		Rele	ase date: Nov 4, 2015	
			Versi	ion: 15.04.2		Rele	ase date: Jul 28, 2015	
			Versi	ion: 15.04		Rele	ase date: Apr 15, 2015	
			Versi	ion: 15.02.1		Rele	ase date: Feb 19, 2015	
			Versi	ion: 15.01		Rele	ase date: Jan 30, 2015	
			<u>Versi</u>	ion: 14.12		Rele	ase date: Dec 15, 2014	

- 3. Connect the USB cable from your computer to your Witbox 2
- 4. In the top menu, go to Machine >> Machine settings...
- 5. In the pop-up menu, select the COM port you are using. The AUTO configuration should also work, but can fail to detect the USB port in some cases. Click "OK" to exit.



- 6. In the top menu, go to *Machine >> install custom firmware...* This will open the file explorer.
- 7. Navigate to the location of the *.hex* file you downloaded earlier. Select it and Cura will flash the firmware and show a progress bar. You are done. Enjoy your updated printer!