

User Manual

SKU: AFX00007



Description

Arduino Opta® Analog Expansions are designed to multiply your Opta® micro PLC capabilities with the addition of 8 channels that can be programmed as inputs or outputs for connecting your analog voltage, current, resistive temperature sensors or actuators in addition to 4x dedicated PWM outputs. Designed in partnership with leading relay manufacturer Finder®, it allows professionals to scale up industrial and building automation projects while taking advantage of the Arduino ecosystem.

Target Areas:

Industrial IoT, Building automation, Electrical loads management, Industrial automation

CONTENTS

1 Application Examples	4
2 Features	4
2.1 General Specifications Overview	4
2.2 Inputs	5
2.2.1 Voltage Input Mode	5
2.2.2 Current Input Mode	5
2.2.3 RTD Input Mode	6
2.3 Outputs	7
2.3.1 Voltage Output Mode	7
2.3.2 Current Output Mode	7
2.3.3 PWM Output Channels	8
2.3.4 Status LEDs	8
3 Ratings	8
3.1 Recommended Operating Conditions	8
3.2 Power Specification (Ambient Temperature)	8
3.2.1 Additional Notes	9
4 Functional Overview	9
4.1 Product View	9
4.2 Block Diagram	10
4.3 Input/Output Channels	10
4.4 Expansion Port	11
5 Device Operation	11
5.1 Getting Started - IDE	11
5.2 Getting Started - Arduino Cloud Editor	11
5.3 Getting Started - Arduino PLC IDE	11
5.4 Getting Started - Arduino Cloud	12
5.5 Sample Sketches	12
5.6 Online Resources	12
6 Mechanical Information	12
6.1 Product Dimensions	12
7 Certifications	13
7.1 Certifications Summary	13
7.2 Declaration of Conformity CE DoC (EU)	13

7.3 Declaration of Conformity to EU RoHS & REACH 211	01/19/2021	13
7.4 Conflict Minerals Declaration		14
8 FCC Caution		14
9 Company Information		14
10 Reference Documentation		15
11 Revision History		15

1 Application Examples

The Arduino Opta® Analog Expansion is designed for industrial standard machinery control alongside the Opta® micro PLC. It is readily integrated into the Arduino hardware and software ecosystem.

- **Automated Production Line:** Arduino Opta® can manage the overall flow of goods in manufacturing. For example, by integrating a load cell or a vision system, it can ensure each phase of a packing process is performed correctly, automatically discard faulty parts, ensure the appropriate amount of goods is present within each box and interact with production line printers, also adding timestamp information synchronized via Network Time Protocol (NTP).
- **Real-time Monitoring in Manufacturing:** Production data can be visualized locally via an HMI or even by connecting to the Arduino Opta® via Bluetooth® Low Energy. The simplicity of Arduino Cloud allows to remotely display custom dashboards; this product is also compatible with other major Cloud providers.
- **Automated Anomaly Detection:** Its computing power allows the Arduino Opta® to deploy Machine Learning algorithms that are capable to learn when a process is drifting from its usual behavior on the production line and activating/deactivating processes to prevent equipment damage.

2 Features

2.1 General Specifications Overview

Characteristics	Details
Supply Voltage	12...24 V
Reverse polarity protection	Yes
ESP protection	Yes
Transient overvoltage protection	Yes (up to 40 V)
Maximum Supported Expansion Modules	Up to 5
Channels	8x: I1, I2, I3, I4, O1, I5, I6, O2
Channels functionalities	I1 and I2: Programmable inputs (Voltage, Current, RTD2 wires, RTD3 wires), Programmable outputs (Voltage and current) - I3, I4, O1, I5, I6, O2: Programmable inputs (Voltage, Current, RTD2 wires), Programmable outputs (Voltage and current)
Degree of Protection	IP20
Certifications	FCC, CE, UKCA, cULus, ENEC

Note: Check the inputs and outputs detailed sections below for more information about the Analog Expansion channels use.

2.2 Inputs

Characteristics	Details
Number of channels	8x
Channels programmable as inputs	I1, I2, I3, I4, O1, I5, I6, O2
Type of inputs accepted	Digital Voltage and Analog (Voltage, Current and RTD)
Inputs overvoltage protection	Yes
Antipolarity protection	No
Analog Input resolution	16 bit
Noise Rejection	Optional noise rejection between 50 Hz and 60 Hz

2.2.1 Voltage Input Mode

The Analog Expansion input channels can be configured for digital sensors or 0-10 V analog sensors.

Characteristics	Details
Digital input voltage	0...24 V
Configurable threshold	Yes (for supporting 0...10 V logic level)
Analog input voltage	0...10 V
Analog input LSB value	152.59 uV
Accuracy	+/- 1%
Repeatability	+/- 1%
Input impedance	Min: 175 kΩ (when internal 200 kΩ resistor is enabled)

2.2.2 Current Input Mode

The Analog Expansion input channels can be configured for current loop instrumentation using the 0/4-20 mA standard.

Characteristics	Details
Analog input current	0...25 mA
Analog input LSB value	381.5 nA
Short circuit current limit	Min: 25 mA, Max 35 mA (externally powered).
Programmable current limit	0.5 mA to 24.5 mA (loop powered)
Accuracy	+/- 1%
Repeatability	+/- 1%

2.2.3 RTD Input Mode

The Analog Expansion input channels can be used for temperature metering with **PT100** RTDs.

Characteristics	Details
Input range	0...1 MΩ
Bias voltage	2.5 V

2 wires RTDs can be connected to any of the eight channels.


3 Wires RTD Connection

RTD with 3 wires has generally two wires with the same color.

- Connect the two wires with the same color to the - and the ICx screw terminals respectively.
- Connect the wire with a different color to the + screw terminal.

3 wires RTD can only be measured by channels I1 and I2.

12-24 VDC



3 Wires RTD connection example

2.3 Outputs

Characteristics	Details
Number of channels	8x, (2x used simultaneously recommended)
Channels programmable as outputs	I1, I2, I3, I4, O1, I5, I6, O2
Type of outputs supported	Analog voltage and current
DAC resolution	13 bit
Charge pump for zero voltage output	Yes

All eight analog channels can be used as outputs but due to power dissipation limitations, it is recommended to have up to 2 channels set at output at the same time.

At 25°C of ambient temperature, all the 8 channels set as outputs have been tested at the same time while outputting more than 24 mA at 10 V each (>0.24W per channel).

2.3.1 Voltage Output Mode

This output mode lets you control voltage-driven actuators.

Characteristics	Details
Analog output voltage	0...11 V
Resistive load range	500 Ω...100 kΩ
Maximum capacitive load	2 μF
Short-circuit current per channel (sourcing)	Min: 25 mA, Typ: 29 mA, Max: 32 mA (lower limit bit = 0 (default)), Min: 5.5 mA, Typ: 7 mA, Max: 9 mA (lower limit bit = 1)
Short-circuit current per channel (sinking)	Min: 3.0 mA, Typ: 3.8 mA, Max: 4.5 mA
Accuracy	+/- 1%
Repeatability	+/- 1%

2.3.2 Current Output Mode

This output mode lets you control current-driven actuators.

Characteristics	Details
Analog output current	0...25 mA
Maximum output voltage when sourcing 25 mA	11.9 V ± 20%
Open circuit voltage	16.9 V ± 20%
Output impedance	Min: 1.5 MΩ, Typ: 4 MΩ
Accuracy	1% in 0-10 mA range, 2% in 10-24 mA range
Repeatability	1% in 0-10 mA range, 2% in 10-24 mA range

2.3.3 PWM Output Channels

The Analog Expansion has four PWM output channels (**P1...P4**). They are software configurable and for them to work you must provide the **V_{PWM}** pin with the desired voltage.

V _{PWM} Voltage	Details
Source voltage supported	8...24 VDC
Period	Programmable
Duty-cycle	Programmable (0-100%)

2.3.4 Status LEDs

The Analog Expansion features eight user-programmable LEDs ideal for status reporting in the front panel.

Description	Value
Number of LEDs	8x

3 Ratings

3.1 Recommended Operating Conditions

Description	Value
Temperature Operating Range	-20...50 °C
Protection degree rating	IP20
Pollution degree	2 conforming to IEC 61010

3.2 Power Specification (Ambient Temperature)


Property	Min	Typ	Max	Unit
Supply voltage	12	-	24	V
Permissible range	9.6	-	28.8	V
Power consumption (12V)	1.5	-	-	W
Power consumption (24V)	1.8	-	-	W

3.2.1 Additional Notes

All screw terminals marked with “-” (minus sign) are shorted together. There is no galvanic isolation between the board and its DC power supply.

4 Functional Overview

4.1 Product View




Arduino Opta® Analog Expansion

Item	Feature
3a	Power Supply Terminals 12...24 VDC
3b	P1...P4 PWM Outputs
3c	Power Status LED
3d	Analog Input/Output Terminals I1...I2 (Voltage, Current, RTD 2 wires and RTD 3 wires)
3e	Status LEDs 1...8
3f	Port for communication and connection of auxiliary modules
3g	Analog Input/Output Terminals I3...I6 (Voltage, Current, RTD 2 wires)
3h	Analog Input/Output Terminals O1...O2 (Voltage, Current, RTD 2 wires)

4.2 Block Diagram

The following diagram explains the relation between the main components of the Opta® Analog Expansion:



Block diagram

4.3 Input/Output Channels

The Arduino Opta® Analog Expansion features 8 channels that can be configured as inputs or outputs. When the channels are configured as inputs they can be used as digital ones with a 0-24/0-10 V range, or analog being able to measure voltage from 0 to 10 V, measure current from 0 to 25 mA or temperature leveraging the RTD mode.

The channels **I1** and **I2** can be used for connecting 3-Wires RTDs. Every channel can be used also as an output, be aware that using more than two channels as an output simultaneously may overheat the device. This will depend on the ambient temperature and channel load.

We have tested setting all eight channels as outputs at 25 °C outputting more than 24 mA at 10 V each during a limited timeframe.

Warning: In case the user needs a configuration with a deviation from the suggested one, will need to validate the system performance and stability before a deployment into a production environment.

The PWM outputs are software configurable and for them to work you must provide the **V_{PWM}** pin with the desired voltage between 8 and 24 VDC, you can set the period and duty-cycle by software.

4.4 Expansion Port

The expansion port can be used to daisy-chain several Opta® Expansions and additional modules. To access it, it needs to be freed from its breakable plastic cover, and the connection plug needs to be added between each device.

It supports up to 5 expansion modules. To avoid potential communication issues, ensure the total number of connected modules does not exceed 5.

If any issues occur with module detection or data exchange, double-check the connections and ensure the **Aux connector and clips are securely installed** within the expansion port. If problems persist, inspect for any loose or improperly connected cables.

5 Device Operation

5.1 Getting Started - IDE

If you want to program your Arduino Opta® Analog Expansion while offline you need to install the Arduino® Desktop IDE **[1]** and the Arduino_Opta_Blueprint using the Library Manager. To connect the Arduino Opta® to your computer, you will need a USB-C® cable.

5.2 Getting Started - Arduino Cloud Editor

All Arduino® devices work out-of-the-box on the Arduino® Cloud Editor **[2]** by just installing a simple plugin.

The Arduino® Cloud Editor is hosted online, therefore it will always be up-to-date with the latest features and support for all boards and devices. Follow **[3]** to start coding on the browser and upload your sketches onto your device.

5.3 Getting Started - Arduino PLC IDE

Arduino Opta® Analog Expansion can be also programmed using the industrial-standard **IEC 61131-3** programming languages. Download the Arduino® PLC IDE **[4]** software, attach the Opta® Expansion through the Aux Connector and connect your Arduino Opta® to your computer using a simple USB-C® cable to start creating your own PLC industrial solutions. The PLC IDE will recognize the expansion and will expose the new available I/Os in the resources tree.

5.4 Getting Started - Arduino Cloud

All Arduino® IoT enabled products are supported on Arduino Cloud which allows you to log, graph and analyze sensor data, trigger events, and automate your home or business.

5.5 Sample Sketches


Sample sketches for Arduino Opta® Analog Expansions can be found in the **Arduino_Opta_Blueprint** library “Examples” in the Arduino® IDE or the “Arduino Opta® Documentation” section of Arduino® [5].

5.6 Online Resources

Now that you have gone through the basics of what you can do with the device, you can explore the endless possibilities it provides by checking exciting projects on ProjectHub [6], the Arduino® Library Reference [7] and the online store [8] where you will be able to complement your Arduino Opta® product with additional extensions, sensors and actuators.

6 Mechanical Information

6.1 Product Dimensions



Arduino Opta® Analog Expansion Outline. Dimensions are in mm

Note: Terminals can be used with both solid and stranded core wire (min: 0.5 mm² / 20 AWG).

7 Certifications

7.1 Certifications Summary

Cert	Arduino Opta® Analog Expansion (AFX00007)
CE (EU)	EN IEC 61326-1:2021, EN IEC 61010 (LVD)
CB (EU)	Yes
WEEE (EU)	Yes
REACH (EU)	Yes
UKCA (UK)	EN IEC 61326-1:2021
FCC (US)	Yes
cULus	UL 61010-2-201

7.2 Declaration of Conformity CE DoC (EU)

We declare under our sole responsibility that the products above are in conformity with the essential requirements of the following EU Directives and therefore qualify for free movement within markets comprising the European Union (EU) and European Economic Area (EEA).

7.3 Declaration of Conformity to EU RoHS & REACH 211 01/19/2021

Arduino boards are in compliance with RoHS 2 Directive 2011/65/EU of the European Parliament and RoHS 3 Directive 2015/863/EU of the Council of 4 June 2015 on the restriction of the use of certain hazardous substances in electrical and electronic equipment.

Substance	Maximum limit (ppm)
Lead (Pb)	1000
Cadmium (Cd)	100
Mercury (Hg)	1000
Hexavalent Chromium (Cr6+)	1000
Poly Brominated Biphenyls (PBB)	1000
Poly Brominated Diphenyl ethers (PBDE)	1000
Bis(2-Ethylhexyl) phthalate (DEHP)	1000
Benzyl butyl phthalate (BBP)	1000
Dibutyl phthalate (DBP)	1000
Diisobutyl phthalate (DIBP)	1000

Exemptions: No exemptions are claimed.

Arduino Boards are fully compliant with the related requirements of European Union Regulation (EC) 1907 /2006 concerning the Registration, Evaluation, Authorization and Restriction of Chemicals (REACH). We declare none of the SVHCs (<https://echa.europa.eu/web/guest/candidate-list-table>), the Candidate List of Substances of Very High Concern for authorization currently released by ECHA, is present in all products (and also package) in quantities totaling in a concentration equal or above 0.1%. To the best of our knowledge, we also declare that our products do not contain any of the substances listed on the "Authorization List" (Annex XIV of the REACH regulations) and Substances of Very High Concern (SVHC) in any significant amounts as specified by the Annex XVII of Candidate list published by ECHA (European Chemical Agency) 1907 /2006/EC.

7.4 Conflict Minerals Declaration

As a global supplier of electronic and electrical components, Arduino is aware of our obligations with regards to laws and regulations regarding Conflict Minerals, specifically the Dodd-Frank Wall Street Reform and Consumer Protection Act, Section 1502. Arduino does not directly source or process conflict minerals such as Tin, Tantalum, Tungsten, or Gold. Conflict minerals are contained in our products in the form of solder, or as a component in metal alloys. As part of our reasonable due diligence Arduino has contacted component suppliers within our supply chain to verify their continued compliance with the regulations. Based on the information received thus far we declare that our products contain Conflict Minerals sourced from conflict-free areas.

8 FCC Caution

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

9 Company Information

Company name	Arduino S.r.l
Company Address	Via Andrea Appiani, 25 - 20900 MONZA (Italy)

10 Reference Documentation

Ref	Link
Arduino IDE (Desktop)	https://www.arduino.cc/en/Main/Software
Arduino IDE (Cloud)	https://create.arduino.cc/editor
Arduino Cloud - Getting started	https://docs.arduino.cc/arduino-cloud/getting-started/iot-cloud-getting-started
Arduino PLC IDE	https://www.arduino.cc/en/Main/Software
Arduino Opta® Documentation	https://docs.arduino.cc/hardware/opta
Project Hub	https://create.arduino.cc/projecthub?by=part&part_id=11332&sort=trending
Library Reference	https://www.arduino.cc/reference/en/
Online Store	https://store.arduino.cc/

11 Revision History

Date	Revision	Changes
24/09/2024	4	Expansion port updates
03/09/2024	3	Cloud Editor updated from Web Editor
05/07/2024	2	Block Diagram updated
25/07/2024	1	First Release