NEW CONNECTION

Host   User

request actuator weight →

← send actuator weight

search for available patterns

LOOP
No data found for specified weight

send error notification →

request actuator weight →

← send actuator weight

search for available patterns

send available patterns for specified weight →

← send requested pattern

LOOP
Invalid pattern received

send error notification →

send available patterns for specified weight →

← send requested pattern

request activity time →

← send wanted activity time

LOOP
Invalid activity time received

send error notification →

request activity time →

← send wanted activity time

perform activity