NEW STYLE SPOOL VALVE INSTALLATION



REMOVE THE FLARE ELBOW AND BUSHING FROM BOTH SIDES.

NEW STYLE VALVE ASSEMBLY WILL INSTALL WHERE THE BUSHING CAME OUT



- (1) REMOVE ELBOWS AND BUSHINGS FROM BOTH SIDES
- (2) REMOVE EXISTING VALVE ASSEMBLY FROM DRYER AND DISCARD
- (3) INSTALL NEW VALVE ASSEMBLY INTO FRONT SIDE OF DRYER. (GREASE O-RINGS)
- (4) INSTALL BUSHING INTO THE BACK SIDE OF DRYER



2625 N. ARGYLE AVE. FRESNO, CA. 93727 559-291-1650 800-428-7139 FAX 559-348-9677