


Models FS42, FS42C & FS42B


Pelton & Crane

Centennial 2500 & 2510


Mobile Work Station Technical Data & Dimensional Drawings




Cabinet Wall Template





Cabinet Floor Template




3









Chair Location



*NOTE: Illustrated operatory is equipped with a Spirit[™] 2000 or 1500 Chair. <u>USE THIS DIMENSION</u> to locate Chair on CenterLine shown. [97 " Minimum (from Mounting Surface of FWS Mount to Foot of Base of Chair)]

**NOTE: If your operatory is equipped with other than a Spirit[™] 2000 or 1500 Chair, USE THIS DIMENSION to locate Chair on CenterLine shown from Front of Cabinet to Headrest. (26 ")





045928 R3 **7**

