
Statmatic Set Maintenance Time



To change maintenance time, switch on power while is pressed.

The LED Standby then flashes at .3-second intervals.

Maintenance time is set as follows:

15S	LED 1 illuminates
20S	LED 2 illuminates
30S	LED 3 illuminates
40S	LED 1, 2 & 3 illuminate

The button is used to change the setting. The most recently set valve is automatically

saved after 5 seconds. After saving the unit assumes normal operation (LED

