Hydrim C61 G4 Chamber Seal Removing & Reinstalling Part #01-113300S



Figure 22

Removing & reinstalling the chamber seal

Before pulling the chamber seal, note how the bottom left and right edges touch the bottom of the chamber.

Pull the seal out from the seal recess.

To reinstall:

Place the bottom left and right ends of the new seal into position, ensuring that the ends touch the chamber bottom.

Tuck the corners into the seal recess and push the rest of the seal into place.