

Intra Wire Diagrams



Single exposure button (Fixed Control Panel Only)



Additional remote exposure button (Note! The exposure key on the control panel can be disabled as Installation manual describes.)



Double button exposure (Requires both buttons to be pressed simutaneously for exposure.)

