INSTALLATION INSTRUCTIONS FOR SCANX RIBBON CABLE CLAMP REPLACEMENT KIT P/N 74374

Kit Contents:

<u>P/N</u>	<u>Description</u>	<u>Qty.</u>
43824	Cable Clamp w/ adhesive	1
74375	Instructions	1

INSTRUCTIONS

- 1. Peel Adhesive Protective Cover off of Cable Clamp.
- 2. Locate and orient Cable Clamp as shown and apply onto Transport Assembly.
- 3. Slide Ribbon Cable through Clamp as shown.

