RECYCLER INSTALLATION INSTRUCTIONS

STEP #1

Remove the existing water restrictor (Brass Hex) and install the new plastic one in the kit. Make certain that the water flow arrow is pointing into the Pump.



Remove existing exhaust fittings and install the Recycler Chamber onto the Vacuum Pump.



STEP#3

Remove the pipe plug in the bottom of the intake manifold and install the poly flow elbow into the manifold. Attach the Poly-Flow tube from the bottom of the Recycler Chamber over to the bottom of the intake manifold.

