

Document Title	Modeling Show Cases Report
Document Owner	AUTOSAR
Document Responsibility	AUTOSAR
Document Identification No	789

Document Status	published
Part of AUTOSAR Standard	Classic Platform
Part of Standard Release	R20-11

Document Change History				
Date Release Changed by Description				
2020-11-30	R20-11	AUTOSAR Release Management	No content changes	
2019-11-28	R19-11	AUTOSAR Release Management	 Add Show case Structured Requirement Changed Document Status from Final to published 	
2018-10-31	4.4.0	AUTOSAR Release Management	Editorial Changes	
2017-12-08	4.3.1	AUTOSAR Release Management	Editorial Changes	
2016-11-30	4.3.0	AUTOSAR Release Management	Initial Release	



Disclaimer

This work (specification and/or software implementation) and the material contained in it, as released by AUTOSAR, is for the purpose of information only. AUTOSAR and the companies that have contributed to it shall not be liable for any use of the work.

The material contained in this work is protected by copyright and other types of intellectual property rights. The commercial exploitation of the material contained in this work requires a license to such intellectual property rights.

This work may be utilized or reproduced without any modification, in any form or by any means, for informational purposes only. For any other purpose, no part of the work may be utilized or reproduced, in any form or by any means, without permission in writing from the publisher.

The work has been developed for automotive applications only. It has neither been developed, nor tested for non-automotive applications.

The word AUTOSAR and the AUTOSAR logo are registered trademarks.



Table of Contents

1	Introduction	6
2	Overview	7
3	Measurement and Calibration	8
	3.1 Introductory Show Case 3.1.1 Physical System 3.1.1.1 Components Overview 3.1.1.2 The Environment 3.1.1.3 The Plant 3.1.1.4 The Controller 3.1.2 AUTOSAR Modeling	9 10 11 12 13 15
	3.1.3 RTE Generation, Measurement and Calibration	16
	3.1.3.1 FlatMap	17
	3.1.3.2 ECU Documentation, Measurement and Calibration	17
	3.1.4 A2L File	17
	3.1.5 Implementation in C	19
	3.1.6 A walk with T_Plant through the Show Case	22
	3.1.6.1 Physical System	22
	3.1.6.2 AUTOSAR Modeling	23
	3.1.6.3 System	35
	3.1.6.4 ECU Configuration	36
	3.1.6.5 RTE Generation	38
	3.1.6.6 Implementation in C	41
	3.1.6.7 A2L File	42
	3.1.6.8 Measurement and Calibration Tool	43
	3.1.7 Show cases in the Example	44
	3.1.7.1 CompositionSwComponentTypes	44
	3.1.7.2 ParameterSwComponentTypes	45
	3.1.7.3 ApplicationSwComponentTypes	46
	3.1.7.4 ParameterInterfaces	52
	3.1.7.5 SenderReceiverInterfaces	55 56
	3.1.7.6 ApplicationDataTypes, Category VALUE	56
		60
	3.1.7.8 PhysicalDimensions	62
	3.1.7.9 SwAddrMethods	65
	3.2 Advanced Show Case	66
	3.2.1 General Objectives of the Model Structure	66
	3.2.1.1 The Ecu Description	66 66
		66 67
	3.2.1.3 Data Types and Data Objects	
	3.2.1.4 Axis, Curves and Maps	68
	3.2.1.5 Axis, Curves and Maps on ApplicationDataType level	68



70
75
76
78
78
84
86
89
92
93
95
96
00
101
102
103
104
105
106
108
110
12
112
112
115
116
117
20
1



References

- [1] Methodology AUTOSAR_TR_Methodology
- [2] Modeling Show Cases Examples AUTOSAR_EXP_ModelingShowCases
- [3] Software Component Template
 AUTOSAR_TPS_SoftwareComponentTemplate
- [4] Standardization Template AUTOSAR_TPS_StandardizationTemplate
- [5] Specification of Platform Types AUTOSAR_SWS_PlatformTypes
- [6] System Template
 AUTOSAR TPS SystemTemplate



1 Introduction

The objective of this report is the illustration and execution of AUTOSAR modeling and the AUTOSAR methodology (see [1]) for selected show cases.

Each show case focuses on a few specific topics and gives an overview of their basic usage and their application in the field. Where appropriate, the show cases are based on real world applications of the AUTOSAR standard.

It contains

- explanatory background on the functional use case for which the specific part of the AUTOSAR modeling is applied.
- illustration of the AUTOSAR model content in form of interlinked tables
- explanation of the processing results of these AUTOSAR models (e.g. C code, A2L files, ...)
- snippets of the full-blown examples. The complete examples are provided in the archive AUTOSAR_EXP_ModelingShowCases.zip [2].



2 Overview

The report is organized in chapters according to the main focus of the contained show cases. Each chapter contains a topic specific overview and at least one show case. Each chapter is self contained and understandable without reading any other chapter.

The technical report on the AUTOSAR Methodology [1] deserves a special mentioning as accompanying document for going through the show cases.

In the first version of the technical report, the show cases are targeting the topic of measurement and calibration, involving the creation of A2L files based on AUTOSAR models. For these show cases, also the specification of the SoftwareComponent-Template [3] is a good accompanying document.

This updated version is extended by an additional show case targeting the topic of Structured Requirements. For these show cases, also the specification of the StandardizationTemplate [4] is a good accompanying document.



3 Measurement and Calibration

Measurements and Calibration (short: MC) is a major step in the development of electronic control units (ECUS). Measurement and Calibration systems (MC systems), involving software tools (MC tools) as well as the hardware to access an ECU (not in focus here), enable the developer to measure variables and to adapt calibration parameters (or "characteristics") during the run-time of the ECU.

For instance, the following tasks are regularly done by "Measurement and Calibration"

- Adaptation to real hardware (e.g. inserting the electrical characteristics of a sensor)
- Calibration of controllers (e.g. adjusting the parameters of a closed loop controller)
- Tuning of ECU internal environment models (e.g. for "virtual sensors")
- Validation of ECU functions
- Tracking of development errors
- Collecting data for automated optimization of parameters

The "Introductory Show Case" (see 3.1), illustrates all basic artifacts on the way from a physical system that is to be controlled by an ECU until measuring and calibrating with a MC system.

As didactic simplification only a few data types were used, e.g. neither ${\tt CURVES}^1$ nor ${\tt MAPS}^2$ were chosen, nor any ${\tt ApplicationCompositeDataType}$.

However, those advanced topics, their modeling in AUTOSAR as well as their transfer to a MC tool, is of particular interest: they are regularly needed and used the field. Therefore, the "Advanced Show Case" in chapter 3.2 especially highlights these topics. This show case is directly derived from the real world modeling and structuring approach of a major Tier 1 in the powertrain domain. So it also illustrates "good practices" in the field for designing AUTOSAR systems which are to be measured and calibrated later on in their development.

¹CURVES are two dimensional functions defined via axis points and the corresponding function values. Interpolation or extrapolation is used to calculate function values that are not directly defined.

²MAPs are similar to CURVES but three dimensional



3.1 Introductory Show Case

As introduction to measurement and calibration with AUTOSAR a simple, artificial closed-loop control system was chosen. This allows interesting feedback of the system when using a \mbox{MC} tool. At the same time, the model, the source code and generated files are still comprehensible.

A drawback is, that not all typical "real world" data types are featured, for instance. Such topics are covered in the "Advanced Show Case", chapter 3.2.

3.1.1 Physical System

This section contains a description of the physical system setup. It can safely be skipped, if only the AUTOSAR modeling itself is of interest to the reader.




Figure 3.1: Physical Overview

Figure 3.1 shows the major physical values and entities of our system. The control task is the following: The plant is a sensor in an airstream that requires heating. The temperature T_{Plant} is to be controlled by the ECU. However, there is no direct way to measure T_{Plant} .

For the estimation of T_{Plant} the following properties of the system are used:

• T_{Plant} depends on the temperature of the environment T_{Env} , i.e. the temperature of the air stream. T_{Env} can be measured directly.



- ullet T_{Plant} depends on the current $I_{Controller}$ which is output by the ECU and controlled by the controller and therefore known.
- The plant itself acts as a thermal energy storage. So T_{Plant} also depends on the heat quantity that is currently stored within the plant.
- All other influences on T_{Plant} are considered to be insignificant. So they can safely be ignored for this control task.

An estimation of T_{Plant} can be calculated by a plant model, which uses T_{Env} and $I_{Controller}$ as inputs and has the stored heat quantity as internal state.

3.1.1.1 Components Overview




Figure 3.2: Component Overview

For this show case, the interaction with a real physical environment is completely left out, i.e. there is no Heating Power Output component and the profile of T_{Env} is randomly generated inside the component Environment. This cuts off a lot of complexity from the example, and allows to run the software system on a PC without complex environment simulations.

For completeness: The plant model is calculated inside the component Plant and the controller inside the component Controller.

As typical for ECUs the calculations happen in a time-discrete manner, i.e. the calculations in the components are executed periodically at discrete in time steps. In the following, the index $n \in \{1,2,...\}$ denotes the current time step. The previous time step is denoted by the index n-1. The index 0 denotes the initialization value. This also means that time step 1 is the first, that is actually calculated by the ECU.

Furthermore Δt denotes the time in seconds, that elapsed between the calculation of the previous time step and the current time step. In case of time step 1, Δt denotes the time that elapsed between initialization of the system and time step 1. For setting



the actual value of Δt the frequency bandwidth of the physical properties in the system has to be taken into account. Decreasing the value of Δt usually increases the quality of the sampling of physical signals up to a certain point where the costs of further decreasing the value of Δt outweighs the benefit gained in terms of signal quality.

3.1.1.2 The Environment




Figure 3.3: Environment

The modeling and implementation of the environment is not in the focus of this show case. The temperature $Tenv_n[^{\circ}C]$ is generated (pseudo) randomly. This is done in order to see the controller and the plant model "in action" during run-time of the system.

The generated profile is a random walk limited by an upper and a lower boundary, with saturation at these boundaries.

The random walk is configurable via $T_{\texttt{LowLimit}}$ [°C] and $T_{\texttt{HighLimit}}$ [°C], for the boundaries, and $T_{\texttt{StepSize}}$ [K], for the change of the temperature during one time step.

Assuming $rand_n$ [-] $\in \{-1, 0, 1\}$ and $n \in \{1, 2, 3, ...\}$ then $Tenv_n$ is characterized by this equation (with $Tenv_0$ [°C] = -273.15 [°C]):

$$Tenv_{n}\left[^{\circ}\mathbf{C}\right] \ = \ Tenv_{n-1}\left[^{\circ}\mathbf{C}\right] + \mathbf{T_{StepSize}}\left[\mathbf{K}\right] \cdot rand_{n}\left[\text{-}\right]$$

if and only if $Tenv_n$ would be inside the boundaries, i.e.

$$T_{LowLimit} < Tenv_n < T_{HighLimit}$$

If $Tenv_n$ would be outside one of the boundaries, it is set to the value of that boundary.



3.1.1.3 The Plant




Figure 3.4: Plant

The plant is an electrically heated mass that is exposed to the air flow in the environment. The heat quantity Qplant that is stored inside the plant is considered to always be directly proportional to the temperature T with constant proportionality factor. Neither the mass of the plant, nor the specific heat capacity changes during the run-time of our system.

For simplicity, this proportionality factor is considered to be $1 \left[\frac{J}{K} \right]$. For the calculations inside the Plant component, we are always using [K] as unit for temperatures, so the conversion from and to $[^{\circ}C]$ only happens at the interface of the component.

With this, we have the following:

$$\begin{array}{rcl} Qplant_{n}\left[\mathbf{J}\right] & = & T_{n}\left[\mathbf{K}\right]\cdot\mathbf{1}\left[\frac{\mathbf{J}}{\mathbf{K}}\right] \\ \\ T_{n}\left[\mathbf{K}\right] & = & \frac{Qplant_{n}\left[\mathbf{J}\right]}{\mathbf{1}\left[\frac{\mathbf{J}}{\mathbf{K}}\right]} \end{array}$$

This also means, that $Qplant_n[J] = 0[J]$ corresponds $T_n[K] = 0[K]$, i.e. absolute zero. So $Qplant_n[J] \ge 0[J]$ shall always be true.

In each time step, there are two heat flows: One from the electrical heater to the plant and one from the plant to the environment. A negative heat flow means that heat energy is flowing away from the plant. Respectively, a positive heat flow means that heat energy is stored in the plant.

The heat flow $Qheater_n[\mathtt{J}]$ from the electrical heater to the plant in one time step is considered to be proportional to the current $I_n[\mathtt{m}\mathtt{A}]$ through the plant during this time step. The proportionality factor is $\mathtt{h}_{\mathtt{Heater}}[\frac{\mathtt{J}}{\mathtt{m}\mathtt{A}\,\mathtt{s}}]$. Of course, the plant can only be heated up by the electrical heater, i.e. a "negative" current I_n would not cool down the plant, but causes the same heat up as $-I_n$. So we have

$$Qheater_{n}\left[\mathtt{J}\right] \ = \ \mid I_{n} \mid \ [\mathtt{mA}] \cdot \mathtt{h}_{\mathtt{Heater}} \left[\frac{\mathtt{J}}{\mathtt{mA}\,\mathtt{s}} \right] \cdot \Delta t \left[\mathtt{s}\right]$$

The cool down of the plant can only happen via the second heat flow, i.e. the heat flow $Qenv_n[J]$ from the plant to the environment. The flow in one time step is considered



to be proportional to the difference between the temperature of the plant (calculated from the stored heat quantity during the last time step) and the temperature of the environment (received in this time step, but actually "measured" during the last time step). With the proportionality factor $h_{\text{Env}}\left[\frac{J}{K}\right]$, we have:

$$Qenv_{n}\left[\mathbf{J}\right] \ = \ \left(Tenv_{n}\left[\mathbf{K}\right] - T_{n-1}\left[\mathbf{K}\right]\right) \cdot \mathbf{h}_{\mathtt{Env}}\left[\frac{\mathbf{J}}{\mathbf{K}}\right] \cdot \Delta t\left[\mathbf{s}\right]$$

The heat quantity that was stored in the plant in last time step $Qplant_{n-1}$ is now modified by these two heat flows. This results in the stored heat quantity in the current time step. With $Qplant_0[J] = 0[J]$, we have

$$Qplant_n[J] = Qplant_{n-1}[J] + Qheater_n[J] + Qenv_n[J]$$

3.1.1.4 The Controller



Figure 3.5: Controller

For the closed loop control an I controller (by and large) was chosen for component Controller. This means that the amplification of the input signal is proportional to the integral of the errors, i.e. the deviation between measured variable and setpoint. Because the controller cannot actively cool down the temperature of the plant, the output $I_n>=0$ for all n.

Again, all temperatures are converted to and from $[^{\circ}C]$ at the interface of the component. All internal calculation are done in [K].

The error during the current time step is the difference between $T_{\tt SetPoint}[K]$ and the measured variable $T_n[K]$:

$$e_n[K] = T_{SetPoint}[K] - T_n[K]$$

The integral part of the controller is calculated via summing up all errors from the previous steps. With $eSum_n$ [Ks] = 0 [Ks] we have:

$$eSum_n [Ks] = eSum_{n-1} [Ks] + e_n [K] \cdot \Delta t$$

A further design decision for the controller was, to limit the integral and to saturate at the limits. This has the benefit that it limits the current I_n that is output by the controller. Furthermore, it enables the controller to react faster after long deviations.



The lower limit is $0\,[{\rm Ks}]$. So if $eSum_n$ would fall below zero in time step n, we set $eSum_n[{\rm Ks}] = 0\,[{\rm Ks}]$. The upper limit is ${\rm L_{MaxESum}}\,[{\rm Ks}]$. If $eSum_n$ would exceed $L_{MaxESum}$ in time step n we set $eSum_n[{\rm Ks}] = {\rm L_{MaxESum}}\,[{\rm Ks}]$.

The integral state $eSum_n$ of the controller is then amplified by $\mathbf{k} \begin{bmatrix} \frac{\mathbf{m} \mathbf{A}}{\mathbf{K} \mathbf{s}} \end{bmatrix}$ to calculate the current $I_n [\mathbf{m} \mathbf{A}]$, i.e. the output of the controller:

$$I_n\left[\mathtt{mA}\right] = eSum_n\left[\mathtt{Ks}\right] \cdot \mathtt{k}\left[\frac{\mathtt{mA}}{\mathtt{Ks}}\right]$$

So the limitations of the $eSum_n$ guarantee, that

$$0\,[\mathrm{mA}] \, \leq \, I_n\,[\mathrm{mA}] \, \leq \, \mathrm{L}_{\mathtt{MaxESum}}\,[\mathrm{Ks}] \cdot \mathrm{k}\left[\tfrac{\mathrm{mA}}{\mathrm{Ks}}\right]$$



3.1.2 AUTOSAR Modeling

This section gives a brief overview of the AUTOSAR modeling. More insight can be gained by browsing through the hyper-linked tables in section 3.1.7. These tables are generated from the AUTOSAR model of this show case. If this is still not sufficient, the complete model is available in .arxml format in AUTOSAR_EXP_ModelingShowCases.zip [2].




Figure 3.6: Example Composition

In this show case the components specified in section 3.1.1.1 are modeled as ApplicationSwComponentTypeS.

- Environment
- Plant
- Controller

To keep the example simple, no SwcImplementations were modeled. For some tasks, like generation of a MemMap for an embedded controller, this would be needed.

The in- and outputs of the ApplicationSwComponentTypes are modeled as SenderReceiverInterface. The internal state is realized as implicitInter-RunnableVariables. Besides the illustrative aspect, the rationale for this design decision was that the internal state is likely to be used by more than one runnable in ApplicationSwComponentTypes (at least "outside" of an introductory show case).



For variables that should just be available for measurement in a MC tool, arTyped-PerInstanceMemorys are used. For this use case, no synchronization of access to the variable needs to be implemented, so the way with the least overhead was chosen.

All parameters in the specification of the components were put in a fourth SwComponentType, in the ParameterSwComponentType "Parameters".

A distinct ParameterInterface was defined for the parameters of each of the three ApplicationSwComponentTypes. The respective PPortPrototypes of the ParameterSwComponentType hold the initValue for each ParameterDataPrototype in the PortPrototypes. Each value is specified in a ValueSpecification aggregated by a ParameterProvideComSpec.

The component types are instantiated in the CompositionSwComponentType "Composition".

This Composition is the type of the rootSoftwareComposition of the ECU_Extract. This also implies that all SwComponentPrototypes of Composition are mapped to one EcuInstance.

Some information on the FlatMap can be found in section 3.1.3.1.

3.1.3 RTE Generation, Measurement and Calibration

The McSupport file is an interface between the RTE generator and the A2L generator. A RTE generator provides a McDataInstance for each calibrateable or measurable object. From logical view the generation of McSupport could be seen in two steps:

- 1. Provide unique names for all parameters, measurements, component prototypes which are instantiated one or multiple times. This is done by the used AUTOSAR Authoring Tool.
- 2. Generate the McSupport itself. This is usually done by the RTE generator. A2L supports only one global namespace, while AUTOSAR defines own namespaces within each ARPackage. This means, that on the one hand unique names are needed for all objects which are to be accessible during measurement and calibration (parameters, measurements, component prototypes). But on the other hand, unique names are needed for all other things that will appear in A2L, e.g. CompuMethods, Units. For them the RTE generator will create unique names.

AUTOSAR specifies additionally an AliasNameSet to override names which is not used here.

See AUTOSAR_EXP_ModelingShowCases.zip [2] for the generated Rte_McSupportData.arxml file.



3.1.3.1 FlatMap

In this show case, the FlatMap gives unique names to the

- dataElementS
- implicitInterRunnableVariableS
- arTypedPerInstanceMemoryS

The RTE-Generator uses this information for the generation of the McSupport file as well as for generation of the .c and .h files.

The FlatMap consists of a FlatInstanceDescriptor for each instance of these VariableDataPrototypes.

The flat map for this use case can be found in AUTOSAR_EXP_ModelingShowCases.zip [2].

3.1.3.2 ECU Documentation, Measurement and Calibration

When developing an ECU one usual requirement is, that objects described in A2L can be easily found in the documentation of the ECU. This is a challenge since documentation is on the level of SwComponentTypes while A2L is defined on the level of a System of category "ECU_EXTRACT".

- The names of SwComponentPrototypes are potentially different to the names of SwComponentTypes
- The names of McDataInstances are potentially different to the names of DataPrototypes

The challenge gets bigger, if types are instantiated multiple times. This issue needs to be solved by proper architecture, modeling conventions and clever generation of the FlatMap.

In this show case, this topic is only slightly touched by instantiating $\mathtt{TemperatureSRIF}$ two times, for the interface transporting T_{Env} as well as for the interface transporting T_{Plant} .

It is demonstrated that the FlatMap can be used to solve the issue. However, we manually crafted our FlatMap, which is usually not possible in the field. FlatMaps are usually automatically generated by customizable, "clever", not standardized tools.

3.1.4 A2L File

With the information in the McSupport file an A2L file is generated. However, for this generation the memory addresses for the variables and characteristics are needed. They are usually extracted from the map file that is output by the linker of the ECU



executable. The exact process as well as the tool for the ${\tt A2L}$ file generation is not standardized.

An example A2L file is provided in AUTOSAR_EXP_ModelingShowCases.zip.



3.1.5 Implementation in C

The implementation in C is a straight forward realization of the physical specification within the AUTOSAR modeling (see section 3.1.1.1 and 3.1.2). Therefore, the listings are presented without further explanation besides the comments in the source code.

A remark on the (pseudo) random numbers generated in line 22 of Environment.c (Listing 3.1): The numbers don't have good "pseudo randomness" properties but are sufficient for this show case, nevertheless. This way of generation was only chosen, because it fits in one line of C code without introducing a dependency to a library.

Listing 3.1: Environment.c

```
1 #include "Rte Environment.h"
3 #define envRE_START_SEC_CODE
4 #include "Environment_MemMap.h"
6 FUNC (void, Environment CODE) envRE func (void)
7
      /* read parameters for simulation of the temperature profile
8
     float32 lLowLimit = Rte_Prm_EnvParamsRPP_env_TLowLimit();
9
     float32 lStepSize = Rte_Prm_EnvParamsRPP_env_TStepSize();
10
11
     /* retrieve internal state
                                                                      */
     uint32 lSeed = Rte_IrvIRead_envRE_Seed();
13
     float32 lTEnv
                      = Rte_IrvIRead_envRE_TEnv();
14
     float32 direction = (float32)(lSeed % 3) - 1.0;
16
     /* calc high limit with parameter, store for measurement
17
     *Rte_Pim_THighLimit()
18
         = lLowLimit + Rte_Prm_EnvParamsRPP_env_THighLimitDistance();
     /* update state for pseudo random number generation
21
                                                                      */
     1Seed = (8253729 * 1Seed + 2396403);
22
     /* calculate environment temperature
24
     lTEnv += lStepSize * direction;
25
     /* saturating environment temperature at the bounds
     if( lTEnv < lLowLimit) { lTEnv = lLowLimit; }</pre>
28
     if( lTEnv > *Rte_Pim_THighLimit())
29
                             { lTEnv = *Rte_Pim_THighLimit(); }
30
     /* Store internal state
32
                                                                      */
     Rte_IrvIWrite_envRE_Seed(lSeed);
33
    Rte_IrvIWrite_envRE_TEnv(lTEnv);
     /* write output
                                                                      */
36
     Rte_IWrite_envRE_EnvTemperaturePPP_T(lTEnv);
37
39 #define envRE_STOP_SEC_CODE
40 #include "Environment_MemMap.h"
```



Listing 3.2: Plant.c

```
1 #include "Rte_Plant.h"
3 #define plantRE_START_SEC_CODE
4 #include "Plant_MemMap.h"
6 FUNC (void, Plant_CODE) plantRE_func (void)
      /* read input
8
     float32 lTenv = Rte_IRead_plantRE_EnvTemperatureRPP_T();
float32 lI = Rte_IRead_plantRE_CurrentRPP_I();
9
10
11
     /* retrieve internal state
     float32 lQPlant = Rte_IrvIRead_plantRE_QPlant();
14
      /* read parameters
                                                                         */
15
     float32 lDt = Rte_Prm_DtRPP_Dt();
16
      float32 lEFactor = Rte Prm PlantParamsRPP plnt EnvFactor();
     float32 lHFactor = Rte Prm PlantParamsRPP plnt HeaterFactor();
18
     /* heat capacity of 1 assumed
                                                                         */
     float32 lTPlant = lQPlant;
21
22
     /\star calculate heat flows, store in PIM to make them measurable \star/
23
      *Rte_Pim_QEnv() = (lTenv - lTPlant) * lEFactor * lDt;
     *Rte_Pim_QHeater() = lI * lHFactor * lDt;
25
26
27
      /* update heat quantity in plant
                                                                         */
     lQPlant = lQPlant + *Rte_Pim_QHeater() + *Rte_Pim_QEnv();
29
      /* limit heat quantity to absolute zero
                                                                         */
30
     lQPlant = lQPlant < 0 ? 0 : lQPlant;</pre>
     /* heat capacity of 1 assumed
                                                                         */
     lTPlant = lQPlant;
     /* store internal state of plant: stored heat quantity
     Rte IrvIWrite plantRE QPlant(lQPlant);
37
      /* Write output of plant: temerature of plant
      Rte IWrite plantRE PlantTemperaturePPP T(lTPlant);
40
41 }
42 #define plantRE_STOP_SEC_CODE
43 #include "Plant_MemMap.h"
```



Listing 3.3: Controller.c

```
1 #include "Rte_Controller.h"
3 #define ControllerRE_START_SEC_CODE
4 #include "Controller_MemMap.h"
6 FUNC (void, Controller_CODE) controllerRE_func (void)
     /* read input, define output variable
8
     float32 lT = Rte_IRead_ControllerRE_TemperatureRPP_T();
9
     float32 lI;
10
11
    /* retrieve internal state: Sum of errors until last time step */
    float32 lESum = Rte_IrvIRead_ControllerRE_ESum();
14
     /* read parameters
                                                                   */
15
     float32 lDt = Rte_Prm_DtRPP_Dt();
16
     float32 lSetPoint = Rte Prm ControllerParamsRPP ctrl SetPoint();
     float32 lK = Rte Prm ControllerParamsRPP ctrl K();
18
     float32 lMaxESum = Rte_Prm_ControllerParamsRPP_ctrl_MaxESum();
19
     /* store current error in PIM to make it measurable
21
                                                                   */
     *Rte_Pim_E() = lSetPoint - lT;
22
23
      /* update eSum
     lESum += *Rte_Pim_E() * lDt;
25
26
     /* limit eSum
     if(lESum > lMaxESum) { lESum = lMaxESum; }
     if(lESum < 0) { lESum = 0; }
29
30
     /* Controller equation: Calculation of manipulated variable
     lI = lESum * lK;
33
     /* Store internal state
                                                                   */
    Rte_IrvIWrite_ControllerRE_ESum(lESum);
     /* Write output of controller
                                                                   */
     Rte_IWrite_ControllerRE_CurrentPPP_I(11);
38
39 }
40 #define ControllerRE STOP SEC CODE
41 #include "Controller_MemMap.h"
```



3.1.6 A walk with T_Plant through the Show Case

This section revisits the complete show case, but focuses on one physical value: T_{Plant} . It visits all artifacts and highlights all places that relate to T_{Plant} to illustrate the dependencies between all artifacts.

3.1.6.1 Physical System

Our journey begins at the physical system, where the value of the physical system outside of the ECU is identified with a software value inside the ECU.




Figure 3.7: Physical Overview

3.1.6.1.1 Components

It was located at the interface between two architectural components, sent by the Plant and received by the Controller. Furthermore a sequencing was introduced³, i.e. in one time step the Plant is calculated before the Controller.

³Please note that this sequencing is a design decision. As there is also a data flow from the Plant to the Controller one could also argue for another calculation sequence.






Figure 3.8: Component Overview

3.1.6.1.2 **Equations**

The functional behavior is defined by the equations for the Plant

$$Qplant_{n}[J] = T_{n}[K] 1 \begin{bmatrix} \frac{J}{K} \end{bmatrix}$$

$$T_{n}[K] = \frac{Qplant_{n}[J]}{1 \begin{bmatrix} \frac{J}{K} \end{bmatrix}}$$

Figure 3.9: Dependency between Q_{Plant} and T_{Plant}

$$Qenv_{n}\left[\mathbf{J}\right] \ = \ \left(Tenv_{n}\left[\mathbf{K}\right] - T_{n-1}\left[\mathbf{K}\right]\right) \cdot \mathbf{h}_{\mathbf{Env}}\left[\frac{\mathbf{J}}{\mathbf{K}}\right] \cdot \Delta t\left[\mathbf{s}\right]$$

Figure 3.10: Heat flow from the Plant to the Environment

 T_{Plant} is also used by the physical equations in the component Controller:

$$e_n\left[\mathtt{K}
ight] \,=\, \mathtt{T}_{\mathtt{SetPoint}}\left[\mathtt{K}
ight] - T_n\left[\mathtt{K}
ight]$$

Figure 3.11: Calculation of the control error in the Controller

Furthermore, calculations inside the components are done in Kelvin [K]. The conversion from and to $[^{\circ}C]$ happens at the interface level.

3.1.6.2 AUTOSAR Modeling

This architecture, i.e. the layout of the physical system, is modeled in AUTOSAR. The functional behavior defined by the equations will be implemented in C Code later on.



3.1.6.2.1 Physical Dimension and Unit

A Physical Dimension is defined: T_{Plant} is a temperature.

nortName	Temperature
currentExp	0
lengthExp	0
luminousIntensity- Exp	0
massExp	0
molarAmountExp	0
temperatureExp	1
timeExp	0

Table 3.1: PhysicalDimension Temparature

The corresponding ARXML description is:

Listing 3.4: Physical Dimension of Temperature

 T_{Plant} shall have the Unit DegreeCelsius:

C	Common Unit attributes	
S	hortName	DegreeCelsius
	displayName	°C
	offsetSiToUnit	-273.15
	factorSiToUnit	1.0
	physicalDimension	Temparature

Table 3.2: Unit DegreeCelsius

The corresponding ARXML description is:

Listing 3.5: Unit Degree Celsius

```
<UNIT>
     <SHORT-NAME>DegreeCelsius</SHORT-NAME>
     <DISPLAY-NAME>°C</DISPLAY-NAME>
     <FACTOR-SI-TO-UNIT>1.0</FACTOR-SI-TO-UNIT>
```



```
<OFFSET-SI-TO-UNIT>-273.15/OFFSET-SI-TO-UNIT>
<PHYSICAL-DIMENSION-REF DEST="PHYSICAL-DIMENSION">
    /McInt/PhysicalDimensions/Temparature
</PHYSICAL-DIMENSION-REF>
</UNIT>
```

The following is presented for completeness, although not directly needed for T_{Plant} . It is possible to link more than one unit to a physical dimension. So in the model, there is also a definition for the unit Kelvin:

С	Common Unit attributes	
s	shortName Kelvin	
	displayName	K
	offsetSiToUnit	0.0
	factorSiToUnit	1.0
	physicalDimension	Temperature

Table 3.3: Unit Kelvin

The corresponding ARXML Code is:

Listing 3.6: Unit Kelvin

3.1.6.2.2 Application Data Type

A new ApplicationDataType is defined for temperatures in degree Celsius:



С	Common ApplicationDataType attributes			
S	hortName	rtName Temperature_C		
C	ategory	VALUE		
d	lesc	Type for a temp	erature in [°C]	
S	wCalibrationAccess	readOnly		
u	mit	DegreeCelsi	us	
R	lange			
С	Conversion			
	category	LINEAR		
	direction	compuIntern	alToPhys	
	desc	lowerLimit	upperLimit	compuNumerator/ compuDenominator
	-	-	-	$Phys = \frac{-273.15 + 1 * Internal}{1}$

Table 3.4: ApplicationDataType Temperature_C

The corresponding ARXML Code is split between the definition of the Application-DataType:

Listing 3.7: Datatype

```
<APPLICATION-PRIMITIVE-DATA-TYPE>
 <SHORT-NAME>Temperature_C
 <DESC>
 <L-2 L="EN">Type for a temperature in [°C]</L-2>
 <CATEGORY>VALUE</CATEGORY>
 <SW-DATA-DEF-PROPS>
 <SW-DATA-DEF-PROPS-VARIANTS>
   <SW-DATA-DEF-PROPS-CONDITIONAL>
   <SW-CALIBRATION-ACCESS>READ-ONLY/SW-CALIBRATION-ACCESS>
   <COMPU-METHOD-REF DEST="COMPU-METHOD">
     /McInt/CompuMethods/Temperature_C
   </COMPU-METHOD-REF>
   <UNIT-REF DEST="UNIT">/McInt/Units/DegreeCelsius
   </SW-DATA-DEF-PROPS-CONDITIONAL>
 </sw-data-def-props-variants>
  </SW-DATA-DEF-PROPS>
</APPLICATION-PRIMITIVE-DATA-TYPE>
```

and the CompuMethod, which is referenced by the ApplicationDataType:

Listing 3.8: Conversion

```
<COMPU-METHOD>
  <SHORT-NAME>Temperature_C</SHORT-NAME>
  <DESC>
  <L-2 L="EN">Conversion from [°C] to [K]</L-2>
  </DESC>
```



```
<CATEGORY>LINEAR</CATEGORY>
 <DISPLAY-FORMAT>%.1f
 <UNIT-REF DEST="UNIT">/McInt/Units/DegreeCelsius
 <COMPU-INTERNAL-TO-PHYS>
 <COMPU-SCALES>
   <COMPU-SCALE>
   <COMPU-RATIONAL-COEFFS>
     <COMPU-NUMERATOR>
     <v>-273.15</v>
     <V>1</V>
     </COMPU-NUMERATOR>
     <COMPU-DENOMINATOR>
     <V>1</V>
     </COMPU-DENOMINATOR>
   </COMPU-RATIONAL-COEFFS>
   </COMPU-SCALE>
 </COMPU-SCALES>
 </COMPU-INTERNAL-TO-PHYS>
</COMPU-METHOD>
```

This ApplicationDataType is mapped to the ImplementationDataType float32. The DataTypeMappingSet that contains this DataTypeMap is referenced inside the SwcInternalBehaviors of the ApplicationSwComponentTypes presented later on.

Listing 3.9: Type Mapping

For completeness, also the ARXML containing the definition of float32 is inserted here:

Listing 3.10: Implementation Type and Base Type



```
<SW-DATA-DEF-PROPS>
     <SW-DATA-DEF-PROPS-VARIANTS>
       <SW-DATA-DEF-PROPS-CONDITIONAL>
       <BASE-TYPE-REF DEST="SW-BASE-TYPE">/AUTOSAR_PlatformTypes/
           SwBaseTypes/float32</BASE-TYPE-REF>
       </SW-DATA-DEF-PROPS-CONDITIONAL>
     </SW-DATA-DEF-PROPS-VARIANTS>
     </SW-DATA-DEF-PROPS>
   </IMPLEMENTATION-DATA-TYPE>
   </ELEMENTS>
 </AR-PACKAGE>
 <AR-PACKAGE>
   <SHORT-NAME>SwBaseTypes
   <ELEMENTS>
   <SW-BASE-TYPE>
     <SHORT-NAME>float32
     <CATEGORY>FIXED_LENGTH</CATEGORY>
     <BASE-TYPE-SIZE>32</BASE-TYPE-SIZE>
     <BASE-TYPE-ENCODING>IEEE754/BASE-TYPE-ENCODING>
   </SW-BASE-TYPE>
   </ELEMENTS>
 </AR-PACKAGE>
</AR-PACKAGE>
```

3.1.6.2.3 Port Interface

The Temperature_C is used to define the SenderReceiverInterface which is used to type the "transport" of a temperature in degree Celsius between SwComponentTypes. Please note that in the show case, this PortInterface is not only used to type the "transport" of T_{Plant} , but also to type the "transport" of T_{Env} .

Common SenderReceiverInterface attributes	
shortName	TemperatureSRIF
desc	Interface type for transferring temperatures in [°C]
properties of the dataEleme	entsS
properties of VariableDataPrototype	
shortName	Т
type	Temperature_C
swImplPolicy	standard
swCalibrationAccess	readOnly
swAddrMethod	VAR

Table 3.5: SenderReceiverInterface TemperatureSRIF

In ARXML:



Listing 3.11: Port Interface

```
<SENDER-RECEIVER-INTERFACE>
  <SHORT-NAME>TemperatureSRIF</SHORT-NAME>
  <DESC>
  <L-2 L="EN">Interface type for transferring temperatures in [°C]</L-2
  </DESC>
  <IS-SERVICE>false</IS-SERVICE>
  <DATA-ELEMENTS>
  <VARIABLE-DATA-PROTOTYPE>
    <SHORT-NAME>T</SHORT-NAME>
   <SW-DATA-DEF-PROPS>
   <SW-DATA-DEF-PROPS-VARIANTS>
      <SW-DATA-DEF-PROPS-CONDITIONAL>
      <SW-ADDR-METHOD-REF DEST="SW-ADDR-METHOD">/McInt/SwAddrMethods/
         VAR</SW-ADDR-METHOD-REF>
      <SW-CALIBRATION-ACCESS>READ-ONLY</SW-CALIBRATION-ACCESS>
      <SW-IMPL-POLICY>STANDARD</SW-IMPL-POLICY>
      </SW-DATA-DEF-PROPS-CONDITIONAL>
    </SW-DATA-DEF-PROPS-VARIANTS>
    </SW-DATA-DEF-PROPS>
    <TYPE-TREF DEST="APPLICATION-PRIMITIVE-DATA-TYPE">/McInt/
       ApplicationDataTypes/Temperature_C</TYPE-TREF>
  </VARIABLE-DATA-PROTOTYPE>
  </DATA-ELEMENTS>
</SENDER-RECEIVER-INTERFACE>
```

For completeness, also the referenced SwAddrMethod is described here:

C	Common SwAddrMethod attributes	
s	hortName	VAR
d	esc	Memory section for variables
	sectionType	var
	memoryAllocation- KeywordPolicy	addrMethodShortName
	sectionInitializa- tionPolicy	-
	option	safetyQM

Table 3.6: SwAddrMethod VAR

In ARXML:

Listing 3.12: Software Address Method

```
<SW-ADDR-METHOD>
     <SHORT-NAME>VAR</SHORT-NAME>
     <DESC>
     <L-2 L="EN">Memory section for variables</L-2>
     </DESC>
     <OPTIONS>
     <OPTION>> safetyQM</OPTION>
     </OPTIONS>
```



</SW-ADDR-METHOD>

3.1.6.2.4 Software Components

The two ApplicationSwComponentTypes Controller and Plant are using T_{Plant} .

In Plant a PPortPrototype, typed by TemperatureSRIF, is defined for sending out T_{Plant} .

Furthermore dataWriteAccess is granted to the single RunnableEntity in this ApplicationSwComponentType. You also see the symbol, i.e. the name of the implementing C function, as well as the TimingEvent that triggers the execution of the RunnableEntity. These two are of further interest for tying together the system.

Common ApplicationSwComponentType attributes		
shortName Plant		
properties of the ports		
properties of PPortPr	ototype	
shortName	PlantTemperaturePPP	
desc	Port for sending out the estimated temperature of the plant	
providedInterface	TemperatureSRIF	
[]		
internalBehavior	PlantInternalBehavior	
[]		
properties of the runnab	leS	
properties of Runnabl	eEntity	
shortName	plantRE	
symbol	plantRE_func	
properties of the events		
properties of TimingEvent		
shortName	plant100ms	
startOnEvent	plantRE	
period	0.1	

Table 3.7: ApplicationSwComponentType Plant

In ARXML:

Listing 3.13: Plant

```
<APPLICATION-SW-COMPONENT-TYPE>
    <SHORT-NAME>Plant
<PORTS>
    <P-PORT-PROTOTYPE>
    <SHORT-NAME>PlantTemperaturePPP</SHORT-NAME>
```



```
<DESC>
   <L-2 L="EN">Port for sending out the estimated temperature of the
      plant</L-2>
   </DESC>
   <PROVIDED-INTERFACE-TREF DEST="SENDER-RECEIVER-INTERFACE">
    /McInt/PortInterfaces/TemperatureSRIF
   </PROVIDED-INTERFACE-TREF>
 </P-PORT-PROTOTYPE>
 </PORTS>
 <INTERNAL-BEHAVIORS>
 <SWC-INTERNAL-BEHAVIOR>
   <SHORT-NAME>PlantInternalBehavior
   <DATA-TYPE-MAPPING-REFS>
   <DATA-TYPE-MAPPING-REF DEST="DATA-TYPE-MAPPING-SET">
     /McInt/DataTypeMappings/DataTypeMappingSet
   </DATA-TYPE-MAPPING-REF>
   </DATA-TYPE-MAPPING-REFS>
   <EVENTS>
   <TIMING-EVENT>
     <SHORT-NAME>plant100ms
     <START-ON-EVENT-REF DEST="RUNNABLE-ENTITY">
      /McInt/SwComponents/Plant/PlantInternalBehavior/plantRE
     </START-ON-EVENT-REF>
     <PERIOD>0.1</PERIOD>
   </TIMING-EVENT>
   </EVENTS>
   <RUNNABLES>
   <RUNNABLE-ENTITY>
     <SHORT-NAME>plantRE
     <DATA-WRITE-ACCESSS>
     <VARIABLE-ACCESS>
       <SHORT-NAME>DWA_PlantTemperature
       <ACCESSED-VARIABLE>
       <AUTOSAR-VARIABLE-IREF>
         <PORT-PROTOTYPE-REF DEST="P-PORT-PROTOTYPE">
            /McInt/SwComponents/Plant/PlantTemperaturePPP
         </PORT-PROTOTYPE-REF>
         <TARGET-DATA-PROTOTYPE-REF DEST="VARIABLE-DATA-PROTOTYPE">
           /McInt/PortInterfaces/TemperatureSRIF/T
         </TARGET-DATA-PROTOTYPE-REF>
       </AUTOSAR-VARIABLE-IREF>
       </ACCESSED-VARIABLE>
     </VARIABLE-ACCESS>
     </DATA-WRITE-ACCESSS>
     . . .
   </RUNNABLE-ENTITY>
   </RUNNABLES>
 </SWC-INTERNAL-BEHAVIOR>
 </INTERNAL-BEHAVIORS>
</APPLICATION-SW-COMPONENT-TYPE>
```

In Controller a RPortPrototype, typed by TemperatureSRIF, is defined for receiving T_{Plant} .



Furthermore dataReadAccess is granted to the single RunnableEntity in this ApplicationSwComponentType. You also see the symbol, i.e. the name of the implementing C function, as well as the TimingEvent that triggers the execution of the RunnableEntity. These two are of further interest for tying together the system.

Common ApplicationSwComponentType attributes			
s	hortName	Controller	
properties of the ports			
	properties of RPortPrototype		
	shortName	TemperatureRPP	
	desc	Port to receive the temperature of the plant	
	requiredInterface	TemperatureSRIF	
	[]		
i	nternalBehavior	ControllerInternalBehavior	
[[]		
properties of the runnables			
	properties of RunnableEntity		
	shortName	ControllerRE	
	symbol	controllerRE_func	
properties of the events			
	properties of TimingEvent		
	shortName	controller100ms	
	startOnEvent	ControllerRE	
	period	0.1	

Table 3.8: ApplicationSwComponentType Controller

In ARXML:

Listing 3.14: Controller

```
<APPLICATION-SW-COMPONENT-TYPE>
 <SHORT-NAME>Controller
 <PORTS>
 <R-PORT-PROTOTYPE>
   <SHORT-NAME>TemperatureRPP</SHORT-NAME>
   <L-2 L="EN">Port to receive the temperature of the plant</L-2>
   </DESC>
   <REQUIRED-INTERFACE-TREF DEST="SENDER-RECEIVER-INTERFACE">
     /McInt/PortInterfaces/TemperatureSRIF
    </REQUIRED-INTERFACE-TREF>
 </R-PORT-PROTOTYPE>
 </PORTS>
 <INTERNAL-BEHAVIORS>
  <SWC-INTERNAL-BEHAVIOR>
   <SHORT-NAME>ControllerInternalBehavior
   <DATA-TYPE-MAPPING-REFS>
```



```
<DATA-TYPE-MAPPING-REF DEST="DATA-TYPE-MAPPING-SET">
       /McInt/DataTypeMappings/DataTypeMappingSet
    </DATA-TYPE-MAPPING-REF>
    </DATA-TYPE-MAPPING-REFS>
    <EVENTS>
    <TIMING-EVENT>
      <SHORT-NAME>controller100ms</SHORT-NAME>
      <START-ON-EVENT-REF DEST="RUNNABLE-ENTITY">
       /McInt/SwComponents/Controller/ControllerInternalBehavior/
          ControllerRE
      </START-ON-EVENT-REF>
      <PERIOD>0.1</PERIOD>
    </TIMING-EVENT>
    </EVENTS>
    . . .
    <RUNNABLES>
    <RUNNABLE-ENTITY>
      <SHORT-NAME>ControllerRE</SHORT-NAME>
      <DATA-READ-ACCESSS>
      <VARIABLE-ACCESS>
        <SHORT-NAME>DRA_temperature
        <ACCESSED-VARIABLE>
        <AUTOSAR-VARIABLE-IREF>
          <PORT-PROTOTYPE-REF DEST="R-PORT-PROTOTYPE">
           /McInt/SwComponents/Controller/TemperatureRPP
          </PORT-PROTOTYPE-REF>
          <TARGET-DATA-PROTOTYPE-REF DEST="VARIABLE-DATA-PROTOTYPE">
          /McInt/PortInterfaces/TemperatureSRIF/T
          </TARGET-DATA-PROTOTYPE-REF>
        </AUTOSAR-VARIABLE-IREF>
        </ACCESSED-VARIABLE>
      </VARIABLE-ACCESS>
      </DATA-READ-ACCESSS>
    </RUNNABLE-ENTITY>
    </RUNNABLES>
  </SWC-INTERNAL-BEHAVIOR>
  </INTERNAL-BEHAVIORS>
</APPLICATION-SW-COMPONENT-TYPE>
```

The two ApplicationSwComponentTypes are then used to type SwComponent-Prototypes in the Composition. The PortPrototypes of the SwComponent-Prototypes are connected by an AssemblySwConnector:



hortName	Composition	
roperties of the comp	onents	
properties of SwComponentPrototype		
shortName	CPT_Controller	
type	Controller	
properties of SwCor	ponentPrototype	
shortName	CPT_Plant	
type	Plant	

Table 3.9: CompositionSwComponentType Composition

In ARXML:

Listing 3.15: Composision

```
<COMPOSITION-SW-COMPONENT-TYPE>
 <SHORT-NAME>Composition
 <COMPONENTS>
 <SW-COMPONENT-PROTOTYPE>
   <SHORT-NAME>CPT_Controller
   <TYPE-TREF DEST="APPLICATION-SW-COMPONENT-TYPE">/McInt/SwComponents
       /Controller</TYPE-TREF>
 </SW-COMPONENT-PROTOTYPE>
   <SHORT-NAME>CPT Plant
   <TYPE-TREF DEST="APPLICATION-SW-COMPONENT-TYPE">/McInt/SwComponents
       /Plant</TYPE-TREF>
 </SW-COMPONENT-PROTOTYPE>
 </COMPONENTS>
 <CONNECTORS>
  <ASSEMBLY-SW-CONNECTOR>
   <SHORT-NAME>
       ASC_CPT_Plant_TemperaturePPP_CPT_Controller_TemperatureRPP
       SHORT-NAME>
   <PROVIDER-IREF>
   <CONTEXT-COMPONENT-REF DEST="SW-COMPONENT-PROTOTYPE">/McInt/
       SwComponents/Composition/CPT_Plant</CONTEXT-COMPONENT-REF>
   <TARGET-P-PORT-REF DEST="P-PORT-PROTOTYPE">/McInt/SwComponents/
       Plant/PlantTemperaturePPP</TARGET-P-PORT-REF>
   </PROVIDER-IREF>
    <REQUESTER-IREF>
   <CONTEXT-COMPONENT-REF DEST="SW-COMPONENT-PROTOTYPE">/McInt/
       SwComponents/Composition/CPT_Controller</CONTEXT-COMPONENT-REF>
   <TARGET-R-PORT-REF DEST="R-PORT-PROTOTYPE">/McInt/SwComponents/
       Controller/TemperatureRPP</TARGET-R-PORT-REF>
    </REQUESTER-IREF>
 </ASSEMBLY-SW-CONNECTOR>
  </CONNECTORS>
</COMPOSITION-SW-COMPONENT-TYPE>
```



3.1.6.3 System

In the ECU_Extract, i.e. a System with category ECU_EXTRACT, the Composition is used to type the rootSoftwareComposition. All SwComponentPrototypes in Composition are mapped to the single EcuInstance in this show case.

Listing 3.16: System and Eculnstance

```
<ECU-TNSTANCE>
 <SHORT-NAME>EcuInstance
</ECU-INSTANCE>
<SYSTEM>
 <SHORT-NAME>EcuExtract
  <CATEGORY>ECU_EXTRACT</CATEGORY>
 <SYSTEM-MAPPING>
   <SHORT-NAME>SystemMapping
   <SW-MAPPINGS>
   <SWC-TO-ECU-MAPPING>
     <SHORT-NAME>SwcToEcuMapping/SHORT-NAME>
     <COMPONENT-IREFS>
     <COMPONENT-IREF>
       <CONTEXT-COMPOSITION-REF DEST="ROOT-SW-COMPOSITION-PROTOTYPE">
         /McInt/System/EcuExtract/RootSwCompositionPrototype
       </CONTEXT-COMPOSITION-REF>
       <TARGET-COMPONENT-REF DEST="SW-COMPONENT-PROTOTYPE">
         /McInt/SwComponents/Composition/CPT_Controller
        </TARGET-COMPONENT-REF>
     </COMPONENT-IREF>
     <COMPONENT-IREF>
       <CONTEXT-COMPOSITION-REF DEST="ROOT-SW-COMPOSITION-PROTOTYPE">
        /McInt/System/EcuExtract/RootSwCompositionPrototype
       </CONTEXT-COMPOSITION-REF>
       <TARGET-COMPONENT-REF DEST="SW-COMPONENT-PROTOTYPE">
        /McInt/SwComponents/Composition/CPT_Plant
       </TARGET-COMPONENT-REF>
     </COMPONENT-IREF>
     </COMPONENT-IREFS>
     <ECU-INSTANCE-REF DEST="ECU-INSTANCE">/McInt/System/EcuInstance
         ECU-INSTANCE-REF>
   </SWC-TO-ECU-MAPPING>
   </SW-MAPPINGS>
 </SYSTEM-MAPPING>
  </MAPPINGS>
  <ROOT-SOFTWARE-COMPOSITIONS>
 <ROOT-SW-COMPOSITION-PROTOTYPE>
   <SHORT-NAME>RootSwCompositionPrototype
   <FLAT-MAP-REF DEST="FLAT-MAP">/McInt/System/FlatMap</FLAT-MAP-REF>
   <SOFTWARE-COMPOSITION-TREF DEST="COMPOSITION-SW-COMPONENT-TYPE">
       /McInt/SwComponents/Composition
   </SOFTWARE-COMPOSITION-TREF>
 </ROOT-SW-COMPOSITION-PROTOTYPE>
  </ROOT-SOFTWARE-COMPOSITIONS>
</SYSTEM>
```



The FlatMap that is referenced in the ECU_Extract, gives the name TPlant to a dataElement (see ecuExtractReference below). The name TPlant is later on displayed in the MC Tool.

Listing 3.17: FlatMap

```
<FLAT-MAP>
 <SHORT-NAME>FlatMap</SHORT-NAME>
 <INSTANCES>
 <FLAT-INSTANCE-DESCRIPTOR>
   <SHORT-NAME>TPlant
   <ECU-EXTRACT-REFERENCE-IREF>
   <CONTEXT-ELEMENT-REF DEST="ROOT-SW-COMPOSITION-PROTOTYPE">/McInt/
       System/EcuExtract/RootSwCompositionPrototype</CONTEXT-ELEMENT-
   <CONTEXT-ELEMENT-REF DEST="SW-COMPONENT-PROTOTYPE">/McInt/
       SwComponents/Composition/CPT_Plant</CONTEXT-ELEMENT-REF>
   <CONTEXT-ELEMENT-REF DEST="P-PORT-PROTOTYPE">/McInt/SwComponents/
       Plant/PlantTemperaturePPP</CONTEXT-ELEMENT-REF>
   <TARGET-REF DEST="VARIABLE-DATA-PROTOTYPE">/McInt/PortInterfaces/
       TemperatureSRIF/T</TARGET-REF>
    </ECU-EXTRACT-REFERENCE-IREF>
 </FLAT-INSTANCE-DESCRIPTOR>
 </INSTANCES>
</FLAT-MAP>
```

3.1.6.4 ECU Configuration

There are further things that need to be defined before the RTE and the OS can be generated. For instance, the order in which the RTEEvents for the RunnableEntitys are invoked and the assignment to an OsTask. This is done via EcucModuleConfigurationValues. The interesting parts of the RTE configuration are:

Listing 3.18: RTE Config

```
<ECUC-CONTAINER-VALUE>
 <SHORT-NAME>controller100ms</SHORT-NAME>
 <DEFINITION-REF ...>.../RteEventToTaskMapping/DEFINITION-REF>
 <PARAMETER-VALUES>
  <ECUC-NUMERICAL-PARAM-VALUE>
    <DEFINITION-REF ...>.../RtePositionInTask//DEFINITION-REF>
    <VALUE>3</VALUE>
 </ECUC-NUMERICAL-PARAM-VALUE>
 </PARAMETER-VALUES>
 <REFERENCE-VALUES>
 <ECUC-REFERENCE-VALUE>
   <DEFINITION-REF ...>.../RteMappedToTaskRef/DEFINITION-REF>
    <VALUE-REF ...>.../OS/OS_CFG/task_100ms</VALUE-REF>
 </ECUC-REFERENCE-VALUE>
 <ECUC-REFERENCE-VALUE>
   <DEFINITION-REF ...>.../RteEventRef
```



```
<VALUE-REF DEST="TIMING-EVENT">.../controller100ms</VALUE-REF>
 </ECUC-REFERENCE-VALUE>
 </REFERENCE-VALUES>
</ECUC-CONTAINER-VALUE>
<ECUC-CONTAINER-VALUE>
 <SHORT-NAME>plant100ms
 <DEFINITION-REF ...>.../RteEventToTaskMapping/DEFINITION-REF>
 <PARAMETER-VALUES>
  <ECUC-NUMERICAL-PARAM-VALUE>
   <DEFINITION-REF ...>.../RtePositionInTask//DEFINITION-REF>
   <VALUE>2</VALUE>
 </ECUC-NUMERICAL-PARAM-VALUE>
 </PARAMETER-VALUES>
 <REFERENCE-VALUES>
 <ECUC-REFERENCE-VALUE>
   <DEFINITION-REF ...>.../RteMappedToTaskRef/DEFINITION-REF>
   <VALUE-REF ...>.../OS/OS_CFG/task_100ms</value-REF>
 </ECUC-REFERENCE-VALUE>
 <ECUC-REFERENCE-VALUE>
   <DEFINITION-REF ...>.../RteEventRef
    <VALUE-REF DEST="TIMING-EVENT">.../plant100ms
 </ECUC-REFERENCE-VALUE>
  </REFERENCE-VALUES>
</ECUC-CONTAINER-VALUE>
```

This part of the OS configuration defines the name of the OSTask, that we see later on in the generated C code:

Listing 3.19: OsConfig

These configurations are tied to the ECU_Extract by an EcucValueCollection:

Listing 3.20: EcuC Value Collection

```
<ECUC-VALUE-COLLECTION>
     <SHORT-NAME>EcucValueCollection/SHORT-NAME>
```



```
<ECU-EXTRACT-REF DEST="SYSTEM">/McInt/System/EcuExtract
REF>

<ECUC-VALUES>
<ECUC-MODULE-CONFIGURATION-VALUES-REF-CONDITIONAL>
<ECUC-MODULE-CONFIGURATION-VALUES-REF DEST="ECUC-MODULE-CONFIGURATION-VALUES">/McInt/RTE/RTE_CFG</ECUC-MODULE-CONFIGURATION-VALUES-REF>

</ECUC-MODULE-CONFIGURATION-VALUES-REF-CONDITIONAL>
<ECUC-MODULE-CONFIGURATION-VALUES-REF-CONDITIONAL>
<ECUC-MODULE-CONFIGURATION-VALUES-REF DEST="ECUC-MODULE-CONFIGURATION-VALUES-REF DEST="ECUC-MODULE-CONFIGURATION-VALUES">/McInt/OS/OS_CFG</ECUC-MODULE-CONFIGURATION-VALUES-REF-CONDITIONAL>
</ECUC-MODULE-CONFIGURATION-VALUES-REF-CONDITIONAL>
</ECUC-MODULE-CONFIGURATION-VALUES-REF-CONDITIONAL>
</ECUC-VALUES>
</ECUC-VALUE-COLLECTION>
```

This completes the presentation of the AUTOSAR modeling in our walk through.

3.1.6.5 RTE Generation

In the following, some snippets of the generated RTE are presented. However, they are examples only and may differ if different RTE generators are used.

Among other things, the OsTask is generated as defined in the ECU configuration above:

Listing 3.21: Rte.c

```
2 #define RTE START SEC VAR
3 #include "MemMap.h" /*lint !e537 permit multiple inclusion */
5 VAR(float32, RTE DATA) TPlant;
7 #define RTE_STOP_SEC_VAR
8 #include "MemMap.h" /*lint !e537 permit multiple inclusion */
10 TASK(task_100ms)
11 {
    Rte_ImplicitBufs.isa_1._task_100ms.sbuf1.value = TPlant;
13
14
    plantRE_func();
16
     . . .
    controllerRE_func();
17
18
    TPlant = Rte_ImplicitBufs.isa_1._task_100ms.sbuf1.value;
20
21 } /* task_100ms */
```

Also a MACRO to write T_{Plant} in the Plant

Listing 3.22: Rte_Plant.h



and to read T_{Plant} in the Controller

Listing 3.23: Rte Controller.h

was generated. Furthermore, the McSupport file is generated as an interface between the "AUTOSAR world" and the "A2L world". As the reader can see, this is a compilation of necessary data from the AUTOSAR model presented before:

Listing 3.24: McSupportData

```
<AR-PACKAGE>
  <SHORT-NAME>BswImplementations
  <ELEMENTS>
   <BSW-IMPLEMENTATION>
    <SHORT-NAME>Rte
    <MC-SUPPORT>
     <MC-VARIABLE-INSTANCES>
       <MC-DATA-INSTANCE>
        <SHORT-NAME>TPlant
          <L-2 L="EN">Type for a temperature in [°C]</L-2>
        </DESC>
        <CATEGORY>VALUE</CATEGORY>
        <FLAT-MAP-ENTRY-REF DEST="FLAT-INSTANCE-DESCRIPTOR">/McInt/
            System/FlatMap/TPlant</FLAT-MAP-ENTRY-REF>
        <RESULTING-PROPERTIES>
          <SW-DATA-DEF-PROPS-VARIANTS>
          <SW-DATA-DEF-PROPS-CONDITIONAL>
            <BASE-TYPE-REF BASE="Rte_MCSD_SwBaseTypes" DEST="SW-BASE-</pre>
                TYPE">float32</BASE-TYPE-REF>
            <SW-CALIBRATION-ACCESS>READ-ONLY</sw-CALIBRATION-ACCESS>
            <COMPU-METHOD-REF BASE="Rte_MCSD_CompuMethods" DEST="COMPU</pre>
               -METHOD">McInt_CompuMethods_Temperature_C</COMPU-
               METHOD-REF>
            <DISPLAY-FORMAT>%.1f
            <UNIT-REF BASE="Rte_MCSD_Units" DEST="UNIT">
                McInt_Units_DegreeCelsius</UNIT-REF>
          </SW-DATA-DEF-PROPS-CONDITIONAL>
          </SW-DATA-DEF-PROPS-VARIANTS>
        </RESULTING-PROPERTIES>
        <SYMBOL>TPlant</SYMBOL>
        </MC-DATA-INSTANCE>
     </MC-VARIABLE-INSTANCES>
```



```
</ELEMENTS>
</AR-PACKAGE>
<AR-PACKAGE>
  <SHORT-NAME>Units
   <ELEMENTS>
   <UNIT>
   <SHORT-NAME>McInt_Units_DegreeCelsius</SHORT-NAME>
    <DISPLAY-NAME>°C</DISPLAY-NAME>
    <FACTOR-SI-TO-UNIT>1.0/FACTOR-SI-TO-UNIT>
    <OFFSET-SI-TO-UNIT>-273.15/OFFSET-SI-TO-UNIT>
    <PHYSICAL-DIMENSION-REF BASE="Rte_MCSD_PhysicalDimensions" DEST="</pre>
       PHYSICAL-DIMENSION">McInt_PhysicalDimensions_Temparature</
       PHYSICAL-DIMENSION-REF>
    </UNIT>
   </ELEMENTS>
</AR-PACKAGE>
<AR-PACKAGE>
  <SHORT-NAME>CompuMethods
   <ELEMENTS>
   <COMPU-METHOD>
   <SHORT-NAME>McInt_CompuMethods_Temperature_C</SHORT-NAME>
      <L-2 L="EN">Conversion from [°C] at an interface to [K] for
         internal computations</L-2>
    </DESC>
    <CATEGORY>LINEAR</CATEGORY>
    <DISPLAY-FORMAT>%f</DISPLAY-FORMAT>
    <UNIT-REF BASE="Rte_MCSD_Units" DEST="UNIT">
       McInt_Units_DegreeCelsius
    <COMPU-INTERNAL-TO-PHYS>
      <COMPU-SCALES>
      <COMPU-SCALE>
       <COMPU-RATIONAL-COEFFS>
       <COMPU-NUMERATOR>
         <v>-273.15</v>
          <V>1</V>
        </COMPU-NUMERATOR>
        <COMPU-DENOMINATOR>
          <V>1</V>
        </COMPU-DENOMINATOR>
        </COMPU-RATIONAL-COEFFS>
      </COMPU-SCALE>
      </COMPU-SCALES>
    </COMPU-INTERNAL-TO-PHYS>
    </COMPU-METHOD>
    . . .
   </ELEMENTS>
</AR-PACKAGE>
<AR-PACKAGE>
   <SHORT-NAME>PhysicalDimensions
   <ELEMENTS>
    <PHYSICAL-DIMENSION>
    <SHORT-NAME>McInt_PhysicalDimensions_Temparature/SHORT-NAME>
    <LENGTH-EXP>0</LENGTH-EXP>
    <MASS-EXP>0</MASS-EXP>
```



```
<TIME-EXP>0</TIME-EXP>
   <CURRENT-EXP>0</CURRENT-EXP>
   <TEMPERATURE-EXP>1</TEMPERATURE-EXP>
   <molar-amount-exp>0</molar-amount-exp>
   <LUMINOUS-INTENSITY-EXP>0</LUMINOUS-INTENSITY-EXP>
   </PHYSICAL-DIMENSION>
</AR-PACKAGE>
<AR-PACKAGE>
  <SHORT-NAME>SwBaseTypes
  <ELEMENTS>
  <SW-BASE-TYPE>
  <SHORT-NAME>float32
  <CATEGORY>FIXED_LENGTH</CATEGORY>
  <BASE-TYPE-SIZE>32</BASE-TYPE-SIZE>
  <BASE-TYPE-ENCODING>IEEE754// BASE-TYPE-ENCODING>
  </SW-BASE-TYPE>
  . . .
  </ELEMENTS>
</AR-PACKAGE>
```

3.1.6.6 Implementation in C

The implementation in C-Code is a direct implementation of the physical equations. The Plant uses the MACRO, generated by the RTE generator, to write T_{Plant} :

Listing 3.25: Plant

```
1 #include "Rte_Plant.h"
3 FUNC (void, Plant_CODE) plantRE_func (void)
  ...
/* heat capacity of 1 assumed
5
                                                                      */
    float32 lTPlant = lQPlant;
     /\star calculate heat flows, store in PIM to make them measurable \star/
8
     *Rte_Pim_QEnv() = (lTenv - lTPlant) * lEFactor * lDt;
9
10
     /* heat capacity of 1 assumed
11
                                                                      */
     lTPlant = lQPlant;
12
     /* Write output of plant: temerature of plant
    Rte_IWrite_plantRE_PlantTemperaturePPP_T(lTPlant);
16 }
```

The Controller uses the MACRO, generated by the RTE generator, to read T_{Plant} :

Listing 3.26: Controller

```
1 #include "Rte_Controller.h"
2 ...
3 FUNC (void, Controller_CODE) controllerRE_func (void)
4 {
```



```
/* read input, define output variable
float32 lT = Rte_IRead_ControllerRE_TemperatureRPP_T();

/* ...

/* store current error in PIM to make it measurable
*/
*Rte_Pim_E() = lSetPoint - lT;
...
}
```

3.1.6.7 A2L File

Using the McSupport file and the map file from the linker, an example A2L file was generated for this show case. The snippet below is an example only and could differ if a different A2L file generator is used:

Listing 3.27: A2L File

```
2 /begin MEASUREMENT TPlant
         "TPlant"
         FLOAT32_IEEE
        McInt_CompuMethods_Temperature_C
6
7
         -1E+32
8
         1E+32
         DISPLAY_IDENTIFIER "TPlant"
10
         ECU_ADDRESS 0xe000001c
11
         FORMAT "%.1f"
12
         PHYS_UNIT "°C"
14 /end MEASUREMENT
15
  /begin UNIT McInt_PhysicalDimensions_Temparature
17
          "McInt_PhysicalDimensions_Temparature"
          "McInt_PhysicalDimensions_Temparature"
18
         EXTENDED SI
19
          SI_EXPONENTS 0 0 0 0 1 0 0
21 /end UNIT
22 /begin UNIT McInt_Units_DegreeCelsius
          "McInt_Units_DegreeCelsius"
23
          "°С"
          DERIVED
25
         REF_UNIT McInt_PhysicalDimensions_Temparature
26
          UNIT_CONVERSION 1 -273.15
27
28 /end UNIT
29 /begin COMPU_METHOD McInt_CompuMethods_Temperature_C
          "McInt_CompuMethods_Temperature_C"
30
         LINEAR
31
          "%f"
32
          "°C"
33
          COEFFS_LINEAR 1 -273.15
         REF_UNIT McInt_Units_DegreeCelsius
36 /end COMPU_METHOD
37 . . .
```



3.1.6.8 Measurement and Calibration Tool

The A2L file is then used by a MC tool to measure T_{Plant} . Of course, in addition to the A2L file a suitable ECU access⁴ must be available, to actually do measurement and calibration with the AUTOSAR system of this show case. However, the ECU access is not presented because this is not in the focus of this show case.

Below is a typical screen shot from a MC tool during an actual measurement and calibration task. You can see T_{Plant} measured and displayed in degree Celsius.




Figure 3.12: Screenshot of a MC Tool

 $^{^4}$ for instance, a measurement and calibration service like XCP or a hardware access to the memory of the micro controller



3.1.7 Show cases in the Example

3.1.7.1 CompositionSwComponentTypes

ommon CompositionSwComponentType attributes			
hortName	Composition		
roperties of the components			
properties of SwCom	properties of SwComponentPrototype		
shortName	CPT_Controller		
type	Controller		
properties of SwCom	mponentPrototype		
shortName	CPT_Parameters		
type	Parameters		
properties of SwCom	properties of SwComponentPrototype		
shortName	CPT_Plant		
type	Plant		
properties of SwComponentPrototype			
shortName	CPT_Environment		
type	Environment		

Table 3.10: CompositionSwComponentType Composition



3.1.7.2 ParameterSwComponentTypes

Common ParameterSwComponentType attributes		
shortName	Parameters	
desc	Type for providing the parameters to the ApplicationSwCompoments	
properties of the ports		
properties of PPortProto	otype	
shortName	ControllerPPP	
desc	Port for providing the parameters for the controller	
providedInterface	ControllerPIF	
properties of PPortProto	properties of PPortPrototype	
shortName	PlantPPP	
desc	Port for providing the parameters for the plant	
providedInterface	PlantPIF	
properties of PPortProto	otype	
shortName	EnvironmentPPP	
desc	Port for providing the parameters for the environment	
providedInterface	EnvironmentPIF	
properties of PPortPrototype		
shortName	DtPPP	
desc	Time of one time step	
providedInterface	DtPIF	

Table 3.11: ParameterSwComponentType Parameters



3.1.7.3 ApplicationSwComponentTypes

Common ApplicationSwComponentType attributes		
shortName	Controller	
properties of the ports		
properties of RPortPrototype		
shortName	TemperatureRPP	
desc	Port to receive the temperature of the plant	
requiredInterface	TemperatureSRIF	
properties of PPortPrototype		
shortName	CurrentPPP	
desc	Port for sending out the current output by this controller	
providedInterface	CurrentSRIF	
properties of RPortPrototype		
shortName	ControllerParamsRPP	
desc	Port to get the parameters for the controller	
requiredInterface	ControllerPIF	
properties of RPortPrototype		
shortName	DtRPP	
desc	Port to get delta t, i.e. time of one time step	
requiredInterface	DtPIF	
internalBehavior	ControllerInternalBehavior	

Table 3.12: ApplicationSwComponentType Controller



t

 Table 3.13: SwcInternalBehavior ControllerInternalBehavior



Common ApplicationSwComponentType attributes		
shortName	Plant	
properties of the ports		
properties of RPortProt	otype	
shortName	CurrentRPP	
desc	Port to receive the current from the controller	
requiredInterface	CurrentSRIF	
properties of PPortProt	otype	
shortName	PlantTemperaturePPP	
desc	Port for sending out the estimated temperature of the plant	
providedInterface	TemperatureSRIF	
properties of RPortProt	otype	
shortName	PlantParamsRPP	
desc	Port to get the parameters for the plant	
requiredInterface	PlantPIF	
properties of RPortProt	otype	
shortName	EnvTemperatureRPP	
desc	Port to receive the tempertature of the environment	
requiredInterface	TemperatureSRIF	
properties of RPortProt	properties of RPortPrototype	
shortName	DtRPP	
desc	Port to get delta t, i.e. time of one time step	
requiredInterface	DtPIF	
internalBehavior	PlantInternalBehavior	
	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	

Table 3.14: ApplicationSwComponentType Plant



Common SwcInternalBehav	vior attributes
shortName	PlantInternalBehavior
properties of implicitInte	erRunnableVariableS / explicitInterRunnableVariableS
properties of VariableDa	ataPrototype
shortName	QPlant
desc	Internal state of the plant: the stored energy quantity in the current time step
type	Energy
swImplPolicy	standard
swCalibrationAccess	readOnly
swAddrMethod	CODE
properties of the arTypedPe	erInstaceMemoryS
properties of VariableDa	
shortName	QHeater
desc	Measurement point for heat flow between the electrical heater and the plant in the current time step.
type	Energy
swImplPolicy	standard
swCalibrationAccess	readOnly
swAddrMethod	VAR
properties of VariableDa	ataPrototype
shortName	QEnv
desc	Measurement point for heat flow between the plant and the environment in the current time step.
type	Energy
swImplPolicy	standard
swCalibrationAccess	readOnly
swAddrMethod	CODE
properties of the runnables	S
properties of RunnableEn	ntity
shortName	plantRE
symbol	plantRE func
properties of the events	1. –
properties of TimingEver	nt
shortName	plant100ms
startOnEvent	plantRE
period	0.1
F	···

Table 3.15: SwcInternalBehavior PlantInternalBehavior



Common ApplicationSwComponentType attributes		
shortName	Environment	
properties of the ports		
properties of PPortPrototype		
shortName	EnvTemperaturePPP	
desc	Port to send out the temperature of the environment	
providedInterface	TemperatureSRIF	
properties of RPortPrototype		
shortName	EnvParamsRPP	
desc	Port to get the parameters for the environment	
requiredInterface	EnvironmentPIF	
properties of RPortProto	properties of RPortPrototype	
shortName	DtRPP	
desc	Port to get delta t, i.e. time of one time step	
requiredInterface	DtPIF	
internalBehavior	EnvironmentInternalBehavior	

Table 3.16: ApplicationSwComponentType Environment



Common SwcInternalBehav	rior attributes
shortName	EnvironmentInternalBehavior
properties of implicitInte	erRunnableVariableS / explicitInterRunnableVariableS
properties of VariableDa	ataPrototype
shortName	Seed
desc	Internal state of the environment: the current seed for the (pseudo) random number generation
type	uint32
swImplPolicy	standard
swCalibrationAccess	notAccessible
swAddrMethod	CODE
properties of VariableDa	ataPrototype
shortName	TEnv
desc	Internal state of the environment: the temperture of the environment
type	Temperature_C
swImplPolicy	standard
swCalibrationAccess	readOnly
swAddrMethod	CODE
proportion of the sufficient of De	To the action of the second
properties of the arTypedPe	-
properties of VariableDa	
shortName	THighLimit
desc	Measurement point for the upper limit of the generated temperature profile
type	Temperature_C
swImplPolicy	standard
swCalibrationAccess	readOnly
swAddrMethod	CODE
properties of the runnables	S
properties of RunnableEr	ntity
shortName	envRE
symbol	envRE_func
properties of the events	
properties of TimingEver	nt
shortName	env100ms
startOnEvent	envRE
period	0.1
	welnternelDeberrier EnrivenmentInternelDeberrier

Table 3.17: SwcInternalBehavior EnvironmentInternalBehavior



3.1.7.4 ParameterInterfaces

hortName	ControllerPIF
lesc	Interface with all parameters for the controller
properties of the parameters	
properties of ParameterI	DataPrototype
shortName	ctrl_SetPoint
desc	Set point for the temperature of the plant
type	Temperature_C
swImplPolicy	standard
swCalibrationAccess	readWrite
swAddrMethod	CALIB
properties of ParameterDataPrototype	
shortName	ctrl_K
desc	Amplification factor for the I-controller
type	Amplification
swImplPolicy	standard
swCalibrationAccess	readWrite
swAddrMethod	CALIB
properties of ParameterI	DataPrototype
shortName	ctrl_MaxESum
desc	Upper limit of the integal part of the I-controller
type	ESum
swImplPolicy	standard
swCalibrationAccess	readWrite
swAddrMethod	CALIB

Table 3.18: ParameterInterface ControllerPIF



Common ParameterInterfa	Common ParameterInterface attributes	
shortName	PlantPIF	
desc	Interface with all parameters for the plant	
properties of the parameters		
properties of Parameter	properties of ParameterDataPrototype	
shortName	plnt_EnvFactor	
desc	Proportionality factor for the heat flow between plant and environment	
type	EnvFactor	
swImplPolicy	standard	
swCalibrationAccess	readWrite	
swAddrMethod	CALIB	
properties of ParameterI	OataPrototype	
shortName	plnt_HeaterFactor	
desc	Proportionality factor for the heat flow between plant and the electrical heater	
type	HeaterFactor	
swImplPolicy	standard	
swCalibrationAccess	readWrite	
swAddrMethod	CALIB	

Table 3.19: ParameterInterface PlantPIF



Common ParameterInterfa	ace attributes	
hortName	EnvironmentPIF	
lesc	Interface with all parameters for the environment	
roperties of the parameters		
properties of ParameterI	DataPrototype	
shortName	env_TLowLimit	
desc	Lower limit of the generated temeprature profile	
type	Temperature_C	
swImplPolicy	standard	
swCalibrationAccess	readWrite	
swAddrMethod	CALIB	
properties of ParameterI	properties of ParameterDataPrototype	
shortName	env_TStepSize	
desc	The maximal temperature diffenrence of the environment in one time step	
type	Temperature_K	
swImplPolicy	standard	
swCalibrationAccess	readWrite	
swAddrMethod	CALIB	
properties of ParameterI	DataPrototype	
shortName	env_THighLimitDistance	
desc	Distance of the upper limit from the lower limit for the generated temeprature profile.	
type	Temperature_K	
swImplPolicy	standard	
swCalibrationAccess	readWrite	
swAddrMethod	CALIB	

Table 3.20: ParameterInterface EnvironmentPIF

Common ParameterInterface attributes		
shortName	DtPIF	
properties of the parameter	properties of the parameters	
properties of ParameterDataPrototype		
shortName	Dt	
desc	Scheduling time of the components	
type	Time	
swImplPolicy	standard	
swCalibrationAccess	readWrite	
swAddrMethod	CALIB	

Table 3.21: ParameterInterface DtPIF



3.1.7.5 SenderReceiverInterfaces

Common SenderReceiverInterface attributes		
shortName	TemperatureSRIF	
desc	Interface type for transferring temperatures in [°C]	
properties of the dataEleme	entsS	
properties of VariableDataPrototype		
shortName	Т	
type	Temperature_C	
swImplPolicy	standard	
swCalibrationAccess	readOnly	
swAddrMethod	VAR	

Table 3.22: SenderReceiverInterface TemperatureSRIF

Common SenderReceiverInterface attributes		
shortName CurrentSRIF		
desc Interface type for transferring a current in [mA]		
properties of the dataElementsS		
properties of VariableDataPrototype		
shortName	I	
type	Current	
swImplPolicy	standard	
swCalibrationAccess	readOnly	
swAddrMethod	VAR	

Table 3.23: SenderReceiverInterface CurrentSRIF



3.1.7.6 ApplicationDataTypes, Category VALUE

Common ApplicationDataType attributes			
shortName	Temperature_C		
category	VALUE		
desc	Type for a temp	erature in [°C]	
swCalibrationAccess	readOnly		
unit	DegreeCelsi	us	
Range			
Conversion			
category	LINEAR		
direction	compuIntern	alToPhys	
desc	lowerLimit	upperLimit	compuNumerator/ compuDenominator
-	-	-	$Phys = \frac{-273.15 + 1 * Internal}{1}$

Table 3.24: ApplicationDataType Temperature_C

Common ApplicationDataType attributes					
shortName		Current			
category		VALUE			
desc		Type for the cur	rent in [mA]		
swCalibrat	ionAccess	readOnly	readOnly		
unit		MilliAmpere			
Range	Range				
Conversion	ı				
category	,	LINEAR			
direction		compuInterna	alToPhys		
desc		lowerLimit	upperLimit	compuNumerator/ compuDenominator	
-		-	-	$Phys = \frac{0 + 1000 * Internal}{1}$	

Table 3.25: ApplicationDataType Current



Common ApplicationDataType attributes		
shortName EnvFactor		
category	VALUE	
desc Type for the environt factor in [J/Ks]		
swCalibrationAccess readOnly		
unit	JoulePerKelvinSecond	
Range		
Conversion		
category	IDENTICAL	
direction	-	

Table 3.26: ApplicationDataType EnvFactor

Common ApplicationDataType attributes		
shortName Temperature_K		
category	VALUE	
desc Type for a temperature in [K]		
swCalibrationAccess readOnly		
unit Kelvin		
Range		
Conversion		
category	IDENTICAL	
direction	-	

Table 3.27: ApplicationDataType Temperature_K

Common ApplicationDataType attributes		
shortName	Amplification	
category	VALUE	
desc Type for an amplification factor in a controller in [mA/Ks]		
<pre>swCalibrationAccess readOnly</pre>		
unit MilliAmperePerKelvinSecond		
Range		
Conversion		
category	IDENTICAL	
direction	-	

Table 3.28: ApplicationDataType Amplification



Common ApplicationDataType attributes		
shortName	DrtName Energy	
category	VALUE	
desc Type for energy [J]		
swCalibrationAccess	readOnly	
unit	Joule	
Range		
Conversion		
category	IDENTICAL	
direction	-	

Table 3.29: ApplicationDataType Energy

Common ApplicationDataType attributes		
shortName	ESum	
category	VALUE	
desc	Type for the sum of control errors of an I controller in [Ks]	
swCalibrationAccess	Access readOnly	
unit	KelvinSecond	
Range		
Conversion		
category IDENTICAL		
direction	-	

Table 3.30: ApplicationDataType ESum

Common ApplicationDataType attributes		
shortName HeaterFactor		
category	VALUE	
Type of a proportionality factor for the heat flow from an electrical heater to a thermal energy storage in [J/mAs]		
swCalibrationAccess readOnly		
unit	JoulePerMilliAmpereSecond	
Range		
Conversion		
category	IDENTICAL	
direction	-	

Table 3.31: ApplicationDataType HeaterFactor



Common ApplicationDataType attributes		
shortName Time		
category	VALUE	
desc Type for time in [s]		
swCalibrationAccess readOnly		
unit	Second	
Range		
Conversion		
category	IDENTICAL	
direction	-	

Table 3.32: ApplicationDataType Time



3.1.7.7 Units

С	Common Unit attributes		
s	shortName DegreeCelsius		
	displayName	°C	
	offsetSiToUnit	-273.15	
	factorSiToUnit	1.0	
	physicalDimension	Temperature	

Table 3.33: Unit DegreeCelsius

С	Common Unit attributes	
s	hortName	Kelvin
	displayName	K
	offsetSiToUnit	0.0
	factorSiToUnit	1.0
	physicalDimension	Temperature

Table 3.34: Unit Kelvin

C	Common Unit attributes	
S	hortName	Joule
	displayName	J
ì	offsetSiToUnit	0.0
	factorSiToUnit	1.0
	physicalDimension	Energy

Table 3.35: Unit Joule

С	Common Unit attributes	
S	hortName	MilliAmpere
	displayName	mA
	offsetSiToUnit	0.0
	factorSiToUnit	1000.0
	physicalDimension	Current

Table 3.36: Unit MilliAmpere

С	Common Unit attributes	
s	hortName	KelvinSecond
	displayName	Ks
	offsetSiToUnit	0.0
	factorSiToUnit	1.0
	physicalDimension	TemperatureTime

Table 3.37: Unit KelvinSecond



С	Common Unit attributes	
s	hortName	JoulePerKelvinSecond
	displayName	J/Ks
	offsetSiToUnit	0.0
	factorSiToUnit	1.0
	physicalDimension	EnergyPerTemperatureTime

Table 3.38: Unit JoulePerKelvinSecond

С	Common Unit attributes	
S	hortName	JoulePerMilliAmpereSecond
	displayName	J/mAs
	offsetSiToUnit	0.0
	factorSiToUnit	0.001
	physicalDimension	EnergyPerCurrentTime

Table 3.39: Unit JoulePerMilliAmpereSecond

С	Common Unit attributes	
S	hortName	MilliAmperePerKelvinSecond
	displayName	mA/Ks
	offsetSiToUnit	0.0
	factorSiToUnit	1000.0
	physicalDimension	CurrentPerTemperatureTime

Table 3.40: Unit MilliAmperePerKelvinSecond

С	Common Unit attributes	
s	hortName	Second
	displayName	s
	offsetSiToUnit	0.0
	factorSiToUnit	1.0
	physicalDimension	Time

Table 3.41: Unit Second



3.1.7.8 PhysicalDimensions

hortName	Energy
currentExp	0
lengthExp	2
luminousIntensity- Exp	0
massExp	1
molarAmountExp	0
temperatureExp	0
timeExp	-2

Table 3.42: PhysicalDimension Energy

С	Common PhysicalDimension attributes	
S	hortName	Current
	currentExp	1
	lengthExp	0
	luminousIntensity- Exp	0
	massExp	0
	molarAmountExp	0
	temperatureExp	0
	timeExp	0

Table 3.43: PhysicalDimension Current

hortName	CurrentPerTemperatureTime
currentExp	1
lengthExp	0
luminousIntensity- Exp	0
massExp	0
molarAmountExp	0
temperatureExp	-1
timeExp	-1

Table 3.44: Physical Dimension Current Per Temperature Time



shortName		EnergyPerCurrentTime
	currentExp	-1
	lengthExp	2
	luminousIntensity- Exp	0
	massExp	1
	molarAmountExp	0
	temperatureExp	0
	timeExp	-3

Table 3.45: PhysicalDimension EnergyPerCurrentTime

С	Common PhysicalDimension attributes		
S	hortName	EnergyPerTemperatureTime	
	currentExp	0	
	lengthExp	2	
	<pre>luminousIntensity- Exp</pre>	0	
	massExp	1	
	molarAmountExp	0	
	temperatureExp	-1	
	timeExp	-3	

Table 3.46: PhysicalDimension EnergyPerTemperatureTime

Common PhysicalDimension attributes		
sho	ortName	Time
-	currentExp	0
	lengthExp	0
	luminousIntensity- Exp	0
r	massExp	0
r	molarAmountExp	0
t	temperatureExp	0
t	timeExp	1

Table 3.47: PhysicalDimension Time



С	Common PhysicalDimension attributes		
s	hortName	Temperature	
	currentExp	0	
	lengthExp	0	
	<pre>luminousIntensity- Exp</pre>	0	
	massExp	0	
	molarAmountExp	0	
	temperatureExp	1	
	timeExp	0	

Table 3.48: PhysicalDimension Temperature

С	Common PhysicalDimension attributes		
S	hortName	TemperatureTime	
	currentExp	0	
	lengthExp	0	
	<pre>luminousIntensity- Exp</pre>	0	
	massExp	0	
	molarAmountExp	0	
	temperatureExp	1	
	timeExp	1	

Table 3.49: PhysicalDimension TemperatureTime



3.1.7.9 SwAddrMethods

С	Common SwAddrMethod attributes		
s	hortName	VAR	
d	esc	Memory section for variables	
	sectionType	var	
	memoryAllocation- KeywordPolicy	addrMethodShortName	
	sectionInitializa- tionPolicy	-	
	option	safetyQM	

Table 3.50: SwAddrMethod VAR

С	Common SwAddrMethod attributes	
S	hortName	CALIB
d	esc	Memory section for calibration parameters
	sectionType	var
	memoryAllocation- KeywordPolicy	addrMethodShortName
	sectionInitializa- tionPolicy	-
	option	safetyQM

Table 3.51: SwAddrMethod CALIB

С	Common SwAddrMethod attributes	
s	hortName	CODE
d	esc	Memory section for code
	sectionType	var
	memoryAllocation- KeywordPolicy	addrMethodShortName
	sectionInitializa- tionPolicy	-
	option	safetyQM

Table 3.52: SwAddrMethod CODE



3.2 Advanced Show Case

3.2.1 General Objectives of the Model Structure

3.2.1.1 The Ecu Description

calibra-Since the show is focusina and case on measurement tion only a minimal system model is provided. Hereby the file Pprj_EcuDescr_U_SystemNodeStub.arxml defines the System temU EcuDescr of category ECU SYSTEM DESCRIPTION which contains only the RootSwCompositionPrototype. The file Pprj_EcuDescr_U.arxml contains the according CompositionSwComponentType describing the hierarchical top-level-composition of software components shown in table SystemURootComposition EcuDescr.

3.2.1.2 The Ecu Extract

The file Pprj_EcuExtract_U_SystemNodeStub.arxml defines the System SystemU_System of category ECU_EXTRACT which contains only the RootSwCompositionPrototype SystemU referencing the ECU Flat Map and the flat top-level-compositionSystemU_Root. The file Pprj_EcuExtract_U.arxml contains the according CompositionSwComponentType describing the flat top-level-composition of software components shown in table SystemU_Root.

Please note that the flat top-level-composition uses the identical software component types as the hierarchical top-level-composition. Therefore an identification of component and data instances in the hierarchical software component structure or in the flat structure requires the correct iteration from the according System nodes.

3.2.1.2.1 The ECU Flat Map

The file Pprj_EcuExtract_U_FlatMap.arxml contains the ECU Flat Map.

The ECU Flat Map is utilized to assign unique and comprehensible names to all DataPrototypes representing measurements and characteristics. This is important for the calibration engineers⁵

The applied strategy for the creation of a FlatInstanceDescriptor.shortName is to shorten it to the shortName of the DataPrototype when only a single instance of the DataPrototype is used.

⁵Calibration engineers in this context means the engineers working with measurement and calibration tooling e.g. to determine the correct calibration parameter values in order to adopt functionality in the software components to the mechanical components in the vehicle.



3.2.1.3 Data Types and Data Objects

The components are designed top down coming from the physical function down to the implementation in the target programming language C. Hereby the interfaces of Software Components are typically typed with ApplicationDataTypes in order to describe the physical meaning of the DataPrototypes. The only exceptions are the interfaces to AUTOSAR Services which are typed by ImplementationDataTypes directly as those are standardized. ApplicationPrimitiveDataTypes are mainly of category

- BOOLEAN
- VALUE
- CURVE
- MAP
- COM AXIS

and the most important CompuMethod categorys are

- LINEAR
- TEXTTABLE

In case of LINEAR conversions it is supported to differentiate the Unit used for the implemented calculations and an additional Unit used in the MCD system. This relationship of such Units are expressed with Unit-Groups. The ARElements are structured in a way to support the common usage of elements relevant for the interface description up to the level of PortInterfaces by several Component Descriptions. Those elements are located under Tier1/ARPlatform1/DataDictionary/<KindPackage> in the file Pprj_DataDictionary.arxml.

The CompuMethods and DataConstrs are exclusively used by one Application—PrimitiveDataType. The possible reuse between ApplicationPrimitive—DataTypes supported by AUTOSAR is not used in this model structure. When such a ApplicationDataType is defined the intended mapping to the reasonable Imple—mentationDataType is already considered in order to get an optimal usage of the possible range of the ImplementationDataType. Nevertheless, the several physical meanings are not reflected by the definition of individual ImplementationDataType but only the standardized Platform Types [5] are used to describe primitives on implementation level. This has the effect that the RTE APIs are typed by the standardized Platform Types in cases of primitives and arrays of primitives. Only structure types are getting observable in the types of RTE APIs. This approach allows the direct usage of data read from RTE in mathematical or interpolation libraries without any type cast.

The memory allocation of the data objects is controlled by the usage of SwAddrMethods. Those are defined for ParameterDataPrototypes and Variable-DataPrototypes on level of the PortInterfaces. A few examples are shown in



the chapter 3.2.2.17 for the basic uses cases like calibration parameter, normal data and code.

3.2.1.4 Axis, Curves and Maps

The show case contains description for axis, curves and maps which are in AUTOSAR so called compound primitives. In order to understand the structure and the defined attributes in the example it is helpful to understand how such objects are described in AUTOSAR. For this it is necessary to look at the hierarchy of ApplicationDataTypes, DataPrototypes, PortPrototypes, SwComponentTypes and FlatMap.

3.2.1.5 Axis, Curves and Maps on ApplicationDataType level

Figure 3.13 is based on the example of the ApplicationPrimitiveDataType Map_Time_Lnr_s_uint16. It shows the relationships between the Application-PrimitiveDataTypes describing the

- MAP itself
- its axis being a group axis
- in turn the properties of a matching working point




Figure 3.13: ApplicationPrimitiveDataType of category MAP and its group axes



The ApplicationPrimitiveDataType Map_Time_Lnr_s_uint16 defines a data type for a MAP with group axes. The physical meaning and range of the contained values is described with the ApplicationPrimitiveDataType s_Lnr_-0_8191d875_0_FFFF_uint16. It is referenced with the valueAxisDataType attribute. This means it's a value in the range 0 .. 8191.875 [second] with the resolution of 0.125 [second].

The referenced ApplicationPrimitiveDataType in the role valueAxis—DataType represents the primitive data type of the value axis within a compound primitive (e.g. CURVE, MAP). It supersedes CompuMethod, Unit, and BaseType. In the particular example, the valueAxisDataType provides the properties of the primitive elements of the CURVE or MAP via a valueAxisDataType reference to an ApplicationPrimitiveDataType. This in turn defines the attributes:

- dataConstr
- compuMethod
- displayFormat
- unit
- swCalibrationAccess

Thereby, despite being set, the value of swCalibrationAccess of the referenced ApplicationPrimitiveDataType is meaningless for the using CURVE and MAP. Note: The referenced data type needs to be a real primitive (typically of category VALUE. Category BOOLEAN is also supported).

The ApplicationPrimitiveDataType of the CURVE and MAP can additionally define SwDataDefProps which are relevant for the whole compound primitive. Currently the following attributes are used in the example:

- swCalprmAxisSet
- swRecordLayout
- swCalibrationAccess (but will be refined on DataPrototype level)

Further on, via the dataTypeMapping of the using software component, the properties of ImplementationDataType and SwBaseType are described.

As axes of the MAP two group axes are used. The properties of the group axes are described by two ApplicationPrimitiveDataTypes of category COM_AXIS. The attribute swAxisIndex indicates for which dimension the group axis applies (1 = X, 2 = Y). With the attribute sharedAxisType the reference to the ApplicationPrimitiveDataType describing the axis is defined.

In the example, the group axis <code>ComAxis_Temp_Lin_K_uint16</code> defines the the applicable minimum and maximum number of axis points. Additionally the <code>in-putVariableType</code> reference to the <code>ApplicationPrimitiveDataType</code> <code>K_Celsius Lnr 0 511d9921875 0 FFFF uint16</code> defines the properties of the input



value for the axis. This in turn corresponds to the values stored as axis point. The same principle applies for the group axis ComAxis_Mass_Lnr_Kg_uint8.

Please note, the above mentioned properties are defined on the level of ApplicationDataTypes and so far not any data instance implementing such properties exists. This requires an instantiation of such ApplicationDataTypes.

3.2.1.6 Axis, Curves and Maps on DataPrototype and SwComponentPrototype level

3.2.1.6.1 Instantiation of Axis, Curves and Maps




Figure 3.14: Instantiation of a MAP and its group axes

Figure 3.14 shows the instantiation of the ApplicationPrimitiveDataType Co-mAxis_Temp_Lin_K_uint16, ComAxis_Mass_Lnr_Kg_uint8, and Map_Time_-Lnr_s_uint16 up to the level of the CompositionSwComponentType Pcpt_CM-scB.

Thereby ParameterDataPrototypes are typed by the mentioned Application—PrimitiveDataTypes. Each ParameterDataPrototype is owned by an own ParameterInterface. This offers the most flexibility to instantiate the map and axes independently from each other. On the level of the ParameterDataPrototype additionally the swCalibrationAccess and the swAddrMethod is defined.



Further on, the ParameterSwComponentType CMscB_par defines three PPort-Prototypes typed by the ParameterInterfaces.

Please note that a group axes of a curve or map are not necessarily provided by the same ParameterSwComponentType as the one providing the curve or map. This case is illustrated with the map ArrldMap_Time_Lnr_s_uint16 using the group axes ArrldComAxis_Temp_Lin_K_uint16 provided by CMscD_par and ComAxis_Mass_Lnr_Kg_uint8 provided by CMscB_par.

3.2.1.6.2 Usage of Axis, Curves and Maps by Software Components

3.2.1.6.3 Linking map and curve instances to its axes instances

Consider a software component that uses curves and maps with group axes. It is than required to denote which instance of curve and map uses which instance of a group axis as axis of abscissae and, in case of a map, as axis of ordinate.

The AUTOSAR meta model provides hereby two possibilities:

- RunnableEntity.parameterAccess.swDataDefPropsor
- SwcInternalBehavior.instantiationDataDefProps.swDataDef-Props.

Inside one software component it's very unlikely, that the same curve or map is used with different axes by different RunnableEntitys (note that this cannot be expressed by ASAM MCD-2MC, also). Therefore, in this show case the second ability is used. This avoids the risk of inconsistencies when several RunnableEntitys are defining parameterAccesses to the same curve or map instance.

The according instantiationDataDefProps.parameterInstance references the map instance in the scope of the SwComponentType and the swDataDefProps. swCalprmAxisSet.swCalprmAxis.swCalprmAxisTypeProps.swCalprmRef references the applied group axes with the according SwCalprmAxis.swAxisIndex

Listing 3.28: Example of an InstantiationDataDefProps for an map



```
<SW-DATA-DEF-PROPS-CONDITIONAL>
        <SW-CALPRM-AXIS-SET>
          <SW-CALPRM-AXIS>
            <SW-AXIS-INDEX>1</SW-AXIS-INDEX>
            <SW-AXIS-GROUPED>
              <AR-PARAMETER>
                <AUTOSAR-PARAMETER-IREF>
                  <PORT-PROTOTYPE-REF DEST="R-PORT-PROTOTYPE">/Tier1/
                     ARPlatform1/Pcpt_CMscB/CMscB/
                     R_ComAxis_Temp_Lin_K_uint16</port-PROTOTYPE-REF>
                  <TARGET-DATA-PROTOTYPE-REF DEST="PARAMETER-DATA-
                     PROTOTYPE">/Tier1/ARPlatform1/DataDictionary/
                     PortInterfaces/V1_0_0/ComAxis_Temp_Lin_K_uint16/
                     ComAxis_Temp_Lin_K_uint16</TARGET-DATA-PROTOTYPE-
                     REF>
                </AUTOSAR-PARAMETER-IREF>
              </AR-PARAMETER>
            </SW-AXIS-GROUPED>
          </SW-CALPRM-AXIS>
          <SW-CALPRM-AXIS>
            <SW-AXIS-INDEX>2</SW-AXIS-INDEX>
            <SW-AXIS-GROUPED>
              <AR-PARAMETER>
                <AUTOSAR-PARAMETER-IREF>
                  <PORT-PROTOTYPE-REF DEST="R-PORT-PROTOTYPE">/Tier1/
                     ARPlatform1/Pcpt_CMscB/CMscB/
                     R_ComAxis_Mass_Lnr_Kg_uint8</port-prototype-REF>
                  <TARGET-DATA-PROTOTYPE-REF DEST="PARAMETER-DATA-
                     PROTOTYPE">/Tier1/ARPlatform1/DataDictionary/
                     PortInterfaces/V1_0_0/ComAxis_Mass_Lnr_Kg_uint8/
                     ComAxis_Mass_Lnr_Kg_uint8</TARGET-DATA-PROTOTYPE-
                </AUTOSAR-PARAMETER-IREF>ARPlat.form1
              </AR-PARAMETER>
            </SW-AXIS-GROUPED>
          </SW-CALPRM-AXIS>
        </SW-CALPRM-AXIS-SET>
      </SW-DATA-DEF-PROPS-CONDITIONAL>
    </SW-DATA-DEF-PROPS-VARIANTS>
  </SW-DATA-DEF-PROPS>
</INSTANTIATION-DATA-DEF-PROPS>
```

3.2.1.6.4 Linking axes instances to its working point instances

When a software component uses compound primitives containing axes (e.g. curves, maps, or group axes) it's beneficial to indicate which data is used as input for the according axis. This enables the measurement and calibration tool to display the current working point. Like explained in section 3.2.1.6.3, this information can be provided

- at the ParameterAccess.swDataDefProps of the compound primitives containing the axis or
- by means of instantiationDataDefProps.swDataDefProps.



In this show case the second ability is used for the same reasons as discussed in section 3.2.1.6.3.

The according instantiationDataDefProps.parameterInstance references the axes instance in the scope of the SwComponentType CMscB. The swDataDef-Props.swCalprmAxisSet.swCalprmAxis.swCalprmAxisTypeProps.swVariableRef references the applied working point variable (in this case, a dataElement in a RPortPrototype) with the according SwCalprmAxis.swAxisIndex.

Listing 3.29: Example of an InstantiationDataDefProps for an axis

```
<INSTANTIATION-DATA-DEF-PROPS>
  <PARAMETER-INSTANCE>
    <AUTOSAR-PARAMETER-IREF>
      <PORT-PROTOTYPE-REF DEST="R-PORT-PROTOTYPE">/Tier1/ARPlatform1/
         Pcpt_CMscB/CMscB/R_ComAxis_Temp_Lin_K_uint16</PORT-PROTOTYPE-
      <TARGET-DATA-PROTOTYPE-REF DEST="PARAMETER-DATA-PROTOTYPE">/Tier1
         /ARPlatform1/DataDictionary/PortInterfaces/V1 0 0/
         ComAxis Temp Lin K uint16/ComAxis Temp Lin K uint16</TARGET-
         DATA-PROTOTYPE-REF>
    </AUTOSAR-PARAMETER-IREF>
  </PARAMETER-INSTANCE>
  <SW-DATA-DEF-PROPS>
    <SW-DATA-DEF-PROPS-VARIANTS>
      <SW-DATA-DEF-PROPS-CONDITIONAL>
        <SW-CALPRM-AXIS-SET>
          <SW-CALPRM-AXIS>
            <SW-AXIS-INDEX>1</SW-AXIS-INDEX>
            <SW-AXIS-INDIVIDUAL>
              <SW-VARIABLE-REFS>
                <AUTOSAR-VARIABLE>
                  <AUTOSAR-VARIABLE-IREF>
                    <PORT-PROTOTYPE-REF DEST="R-PORT-PROTOTYPE">/Tier1/
                       ARPlatform1/Pcpt_CMscB/CMscB/
                       R_PrimData_Temperature_Lin_K_C_uint16</PORT-
                       PROTOTYPE-REF>
                    <TARGET-DATA-PROTOTYPE-REF DEST="VARIABLE-DATA-
                       PROTOTYPE">/Tier1/ARPlatform1/DataDictionary/
                       PortInterfaces/V1 0 0/
                       PrimData_Temperature_Lin_K_C_uint16/
                       PrimData_Temperature_Lin_K_C_uint16</TARGET-
                       DATA-PROTOTYPE-REF>
                  </AUTOSAR-VARIABLE-IREF>
                </AUTOSAR-VARIABLE>
              </SW-VARIABLE-REFS>
            </SW-AXIS-INDIVIDUAL>
          </SW-CALPRM-AXIS>
        </SW-CALPRM-AXIS-SET>
      </SW-DATA-DEF-PROPS-CONDITIONAL>
    </SW-DATA-DEF-PROPS-VARIANTS>
  </SW-DATA-DEF-PROPS>
</INSTANTIATION-DATA-DEF-PROPS>
```



3.2.1.6.5 Axis, Curves and Maps in the ECU Flat Map

The ECU Flat Map contains entries for all curves, maps, axes and working point variables. The used naming patterns are described in 3.2.1.2.1.

Listing 3.30: Example of a FlatInstanceDescriptor for map axis and working point variable

```
<FLAT-INSTANCE-DESCRIPTOR>
  <SHORT-NAME>Map_Time_Lnr_s_uint16</SHORT-NAME>
  <ECU-EXTRACT-REFERENCE-IREF>
   <CONTEXT-ELEMENT-REF DEST="ROOT-SW-COMPOSITION-PROTOTYPE">/Tier1/
       ARPlatform1/System/SystemU_SystemU</CONTEXT-ELEMENT-REF>
    <CONTEXT-ELEMENT-REF DEST="SW-COMPONENT-PROTOTYPE">/Tier1/
       ARPlatform1/System/CompositionSwComponentTypes/SystemU_Root/
       CMscB_par</CONTEXT-ELEMENT-REF>
   <CONTEXT-ELEMENT-REF DEST="P-PORT-PROTOTYPE">/Tier1/ARPlatform1/
       Pcpt_CMscB/CMscB_par/P_Map_Time_Lnr_s_uint16</CONTEXT-ELEMENT-
   <TARGET-REF DEST="PARAMETER-DATA-PROTOTYPE">/Tier1/ARPlatform1/
       DataDictionary/PortInterfaces/V1_0_0/Map_Time_Lnr_s_uint16/
       Map Time Lnr s uint16</TARGET-REF>
 </ECU-EXTRACT-REFERENCE-IREF>
</FLAT-INSTANCE-DESCRIPTOR>
<FLAT-INSTANCE-DESCRIPTOR>
  <SHORT-NAME>ComAxis_Temp_Lin_K_uint16</SHORT-NAME>
  <ECU-EXTRACT-REFERENCE-IREF>
   <CONTEXT-ELEMENT-REF DEST="ROOT-SW-COMPOSITION-PROTOTYPE">/Tier1/
       ARPlatform1/System/SystemU_SystemU</CONTEXT-ELEMENT-REF>
   <CONTEXT-ELEMENT-REF DEST="SW-COMPONENT-PROTOTYPE">/Tier1/
       ARPlatform1/System/CompositionSwComponentTypes/SystemU_Root/
       CMscB_par</CONTEXT-ELEMENT-REF>
    <CONTEXT-ELEMENT-REF DEST="P-PORT-PROTOTYPE">/Tier1/ARPlatform1/
       Pcpt_CMscB/CMscB_par/P_ComAxis_Temp_Lin_K_uint16</CONTEXT-
       ELEMENT-REF>
   <TARGET-REF DEST="PARAMETER-DATA-PROTOTYPE">/Tier1/ARPlatform1/
       DataDictionary/PortInterfaces/V1 0 0/ComAxis Temp Lin K uint16/
       ComAxis_Temp_Lin_K_uint16</TARGET-REF>
 </ECU-EXTRACT-REFERENCE-IREF>
</FLAT-INSTANCE-DESCRIPTOR>
<FLAT-INSTANCE-DESCRIPTOR>
 <SHORT-NAME>PrimData_Temperature_Lin_K_C_uint16</SHORT-NAME>
 <ECU-EXTRACT-REFERENCE-IREF>
   <CONTEXT-ELEMENT-REF DEST="ROOT-SW-COMPOSITION-PROTOTYPE">/Tier1/
       ARPlatform1/System/SystemU_SystemU</CONTEXT-ELEMENT-REF>
   <CONTEXT-ELEMENT-REF DEST="SW-COMPONENT-PROTOTYPE">/Tier1/
       ARPlatform1/System/CompositionSwComponentTypes/SystemU_Root/
       CMscA</CONTEXT-ELEMENT-REF>
   <CONTEXT-ELEMENT-REF DEST="P-PORT-PROTOTYPE">/Tier1/ARPlatform1/
       Pcpt_CMscA/CMscA/P_PrimData_Temperature_Lin_K_C_uint16</CONTEXT
       -ELEMENT-REF>
    <TARGET-REF DEST="VARIABLE-DATA-PROTOTYPE">/Tier1/ARPlatform1/
       DataDictionary/PortInterfaces/V1_0_0/
       PrimData_Temperature_Lin_K_C_uint16/
       PrimData_Temperature_Lin_K_C_uint16</TARGET-REF>
  </ECU-EXTRACT-REFERENCE-IREF>
```



</FLAT-INSTANCE-DESCRIPTOR>

3.2.1.7 Arrays of Maps and Axes

The ability of curves, maps and cuboids is usually used to describe the physical dependency of a characteristic on other physical input values. Hereby each input value is described by an orthogonal axis. In contrast to this, arrays are used to group a set of values of the same nature which can be handled by the same algorithm. Typically, in this case the algorithm iterates over the array with an index. Nevertheless, each array element may represent a particular part of the vehicle, e.g. a specific cylinder or a specific sensor. It's possible to combine these design principles. This ends up in the need to describe arrays of curves, maps, cuboids and the according axes.

The show case illustrates the model of those objects by the following elements:

- ArrldMap_Time_Lnr_s_uint16
- Arr1dComAxis_Temp_Lin_K_uint16
- Arr1dPrimData_Temperature_Lin_K_C_uint16

Hereby, the array of the map Arr1dMap_Time_Lnr_s_uint16 uses for the x-axis an array of group axes Arr1dComAxis_Temp_Lin_K_uint16 which in turn uses an array of primitive values as working points Arr1dPrimData_Temperature_Lin_-K_C_uint16. In this case, the n'th map uses the n'th x-axes which uses the n'th value as working point. In contrast, the map uses one group axis ComAxis_Mass_-Lnr_Kg_uint8 for the y-axis. In this case all maps in the array are using the same y-axis.

3.2.1.7.1 Arrays of Maps and Axes in the ECU Flat Map

In the ECU Flat Map the ability to reference ApplicationCompositeElementDataPrototypes is used to express the specific meaning of each array element in the array of map and group axis.

For instance, each element in the array Arr1dMap_Time_Lnr_s_uint16 is named in a way to indicate the specific meaning:

- ArrldMap_Time_Lnr_s_uint16_FrontLeft
- ArrldMap_Time_Lnr_s_uint16_FrontRight
- ArrldMap_Time_Lnr_s_uint16_RearLeft
- ArrldMap_Time_Lnr_s_uint16_RearRight

The following listing shows the structure of such an FlatInstanceDescriptior on one example:



Listing 3.31: Example of a FlatInstanceDescriptor for an ApplicationCompositeElementDataPrototype

```
<FLAT-INSTANCE-DESCRIPTOR>
  <SHORT-NAME>Arr1dMap_Time_Lnr_s_uint16_FrontLeft/SHORT-NAME>
  <ECU-EXTRACT-REFERENCE-IREF>
    <CONTEXT-ELEMENT-REF DEST="ROOT-SW-COMPOSITION-PROTOTYPE">/Tier1/
       ARPlatform1/System/SystemU_SystemU</CONTEXT-ELEMENT-REF>
    <CONTEXT-ELEMENT-REF DEST="SW-COMPONENT-PROTOTYPE">/Tier1/
       ARPlatform1/System/CompositionSwComponentTypes/SystemU_Root/
       CMscD_par</CONTEXT-ELEMENT-REF>
    <CONTEXT-ELEMENT-REF DEST="P-PORT-PROTOTYPE">/Tier1/ARPlatform1/
       Pcpt_CMscD/CMscD_par/P_Arr1dMap_Time_Lnr_s_uint16</CONTEXT-
       ELEMENT-REF>
    <CONTEXT-ELEMENT-REF DEST="PARAMETER-DATA-PROTOTYPE">/Tier1/
       ARPlatform1/DataDictionary/PortInterfaces/V1_0_0/
       Arr1dMap_Time_Lnr_s_uint16/Arr1dMap_Time_Lnr_s_uint16</CONTEXT-
       ELEMENT-REF>
    <TARGET-REF DEST="APPLICATION-ARRAY-ELEMENT" INDEX="0">/Tier1/
       ARPlatform1/DataDictionary/ApplicationDataTypes/
       Map_Time_Lnr_s_uint16_ScNoOfWheels/
       Map_Time_Lnr_s_uint16_ScNoOfWheels</TARGET-REF>
  </ECU-EXTRACT-REFERENCE-IREF>
</FLAT-INSTANCE-DESCRIPTOR>
```

Please note the usage of the index attribute in the target reference.

3.2.1.8 Measurement of Modes

3.2.1.8.1 Enabling Measurement of Modes

The measurement of a mode is enabled in the software-component description by setting the ModeDeclarationGroupPrototype.swCalibrationAccess to read-Only. See ModeDirection.

3.2.1.8.2 Modes in the ECU Flat Map

AUTOSAR supports the measurement of the current mode, the previous mode and the next mode. Hereby the last two are useful when the mode is measured during a ongoing transition to identify the kind of transition. In this show case only the measurement of the current mode is illustrated. For this, the FlatMap contains a FlatInstanceDescriptor pointing to the ModeDeclarationGroupPrototype which is to be measured. The role attribute of the FlatInstanceDescriptor is set to CURRENT_MODE

Listing 3.32: Example of a FlatInstanceDescriptor for a ModeDeclarationGroup-Prototype

```
<FLAT-INSTANCE-DESCRIPTOR>
  <SHORT-NAME>ModeDirection
<ROLE>CURRENT MODE
```



<ECU-EXTRACT-REFERENCE-IREF>

- <CONTEXT-ELEMENT-REF DEST="SW-COMPONENT-PROTOTYPE">/Tier1/
 ARPlatform1/System/CompositionSwComponentTypes/SystemU_Root/
 CMscA</CONTEXT-ELEMENT-REF>
- <CONTEXT-ELEMENT-REF DEST="P-PORT-PROTOTYPE">/Tier1/ARPlatform1/
 Pcpt_CMscA/CMscA/P_ModeDirection/CONTEXT-ELEMENT-REF>
- <TARGET-REF DEST="MODE-DECLARATION-GROUP-PROTOTYPE">/Tier1/
 ARPlatform1/DataDictionary/PortInterfaces/V1_0_0/ModeDirection/
 ModeDirection
- </ECU-EXTRACT-REFERENCE-IREF>
 </FLAT-INSTANCE-DESCRIPTOR>



3.2.2 Show cases in the Example

3.2.2.1 CompositionSwComponentTypes

Common CompositionSwComponentType attributes		
shortName	Pcpt_CMscA	
desc	Modeling show case for primitive measurement and calculation.	
properties of the ports		
properties of PPortProt	otype	
shortName	P_ModeDirection	
desc	Mode to indicate a direction	
providedInterface	ModeDirection	
properties of PPortProt	otype	
shortName	P_PrimCal_Mass_Lnr_Kg	
desc	Primitive calibration parameter for minimum egg mass.	
providedInterface	PrimCal_Mass_Lnr_Kg	
properties of PPortProt	otype	
shortName	P_PrimData_Mass_Lnr_Kg_uint8	
desc	Mass in kilogram	
providedInterface	PrimData_Mass_Lnr_Kg_uint8	
properties of PPortProt	otype	
shortName	P_PrimData_StepsSpeed_Txt_sint8	
desc	Stepwise speed indication	
providedInterface	PrimData_StepsSpeed_Txt_sint8	
properties of PPortProt	otype	
shortName	P_PrimData_Temperature_Lin_K_C_uint16	
desc	Temperature 1 in Kelvin but displayed as degree Celsius	
providedInterface	PrimData_Temperature_Lin_K_C_uint16	
properties of RPortPrototype		
shortName	R_PrimData_StepsSpeed_Txt_sint8	
desc	Stepwise speed indication	
requiredInterface	PrimData_StepsSpeed_Txt_sint8	
properties of the components		
properties of SwComponentPrototype		
shortName	CMscA	
type	CMscA	
properties of SwComponentPrototype		
shortName	CMscA_par	
type	CMscA_par	

Table 3.53: CompositionSwComponentType Pcpt_CMscA



Common CompositionSwComponentType attributes		
ShortName SystemU_Root		
properties of the component	s	
properties of SwComponen	tPrototype	
shortName	CMscA	
type	CMscA	
properties of SwComponen	tPrototype	
shortName	CMscA_par	
type	CMscA_par	
properties of SwComponen	tPrototype	
shortName	CMscB	
type	CMscB	
properties of SwComponen	tPrototype	
shortName	CMscB_par	
type	CMscB_par	
properties of SwComponen	tPrototype	
shortName	CMscC_nvm	
type	CMscC_nvm	
properties of SwComponentPrototype		
shortName	CMscD	
type	CMscD	
properties of SwComponentPrototype		
shortName	CMscD_par	
type	CMscD_par	

Table 3.54: CompositionSwComponentType SystemU_Root

Common CompositionSwComponentType attributes		
shortName SystemURootComposition_EcuDescr		
properties of the components		
properties of SwComponentPrototype		
shortName	CMscC	
type	Pcpt_CMscC	

Table 3.55: CompositionSwComponentType SystemURootComposition_EcuDescr



shortName Pcpt_CMscD		
esc	Modeling show case for arrays of axes and mapes.	
roperties of the ports		
properties of RPortProt	cotype	
shortName	R_ComAxis_Mass_Lnr_Kg_uint8	
desc	Shared axis for mass	
requiredInterface	ComAxis_Mass_Lnr_Kg_uint8	
properties of RPortProt	totype	
shortName	R_PrimData_MassCorrected_Lnr_Kg_uint8	
desc	Primitve data for the corrected mass in kg.	
requiredInterface	PrimData_MassCorrected_Lnr_Kg_uint8	
roperties of the components		
properties of SwCompone	entPrototype	
shortName	CMscD	
type	CMscD	
properties of SwComponentPrototype		
shortName	CMscD_par	
type	CMscD par	

Table 3.56: CompositionSwComponentType Pcpt_CMscD



hortName	Pcpt CMscC
esc	Composit of modeling show case C
roperties of the ports	Composit of modeling show date o
properties of PPortProt	
· · ·	P PrimData Time Lnr s uint16
shortName	
desc	Primitve data holding a time value.
providedInterface	PrimData_Time_Lnr_s_uint16
properties of PPortProt	cotype
shortName	P_PrimData_ValidState_Txt_noUnit_boolean
desc	Boolean representing the data validity
providedInterface	PrimData_ValidState_Txt_noUnit_boolean
ranartias of the	+0
roperties of the componer	
properties of SwComponentPrototype	
shortName	CMscA
type	Pcpt_CMscA
properties of SwCompone	entPrototype
shortName	CMscB
type	Pcpt_CMscB
properties of SwComponentPrototype	
shortName	CMscC_nvm
type	CMscC_nvm
properties of SwComponentPrototype	
	014 5
shortName	CMscD

Table 3.57: CompositionSwComponentType Pcpt_CMscC

 ∇



Common CompositionSwComponentType attributes		
shortName	Pcpt_CMscB	
desc	Modeling show case for axes, curves and mapes.	
properties of the ports		
properties of PPortProto	type	
shortName	P_ComAxis_Mass_Lnr_Kg_uint8	
desc	Shared axis for mass	
providedInterface	ComAxis_Mass_Lnr_Kg_uint8	
properties of PPortProto	type	
shortName	P_PrimData_MassCorrected_Lnr_Kg_uint8	
desc	Primitve data for the corrected mass in kg.	
providedInterface	PrimData_MassCorrected_Lnr_Kg_uint8	
properties of PPortProto	type	
shortName	P_PrimData_Time_Lnr_s_uint16	
desc	Primitve data holding a time value.	
providedInterface	PrimData_Time_Lnr_s_uint16	
properties of PPortProto	type	
shortName	P_PrimData_ValidState_Txt_noUnit_boolean	
desc	Boolean representing the data validity	
providedInterface	PrimData_ValidState_Txt_noUnit_boolean	
properties of RPortProto	type	
shortName	R_ModeDirection	
desc	Mode to indicate a direction	
requiredInterface	ModeDirection	
properties of RPortProto		
shortName	R_PrimData_Mass_Lnr_Kg_uint8	
desc	Mass in kilogram	
requiredInterface	PrimData_Mass_Lnr_Kg_uint8	
properties of RPortProto		
shortName	R_PrimData_StepsSpeed_Txt_sint8	
desc	Stepwise speed indication	
requiredInterface	PrimData_StepsSpeed_Txt_sint8	
properties of RPortProto	type	
shortName	R_PrimData_Temperature_Lin_K_C_uint16	
desc	Temperature 1 in Kelvin but displayed as degree Celsius	
requiredInterface	PrimData_Temperature_Lin_K_C_uint16	
properties of the components		
properties of SwComponen	tPrototype	
shortName	CMscB	
type	CMscB	
properties of SwComponentPrototype		





 \triangle

shortName	CMscB_par
type	CMscB_par

Table 3.58: CompositionSwComponentType Pcpt_CMscB



3.2.2.2 ParameterSwComponentTypes

С	Common ParameterSwComponentType attributes		
S	hortName	CMscA_par	
d	esc	Modeling show case for primitive measurement and calculation.	
р	properties of the ports		
	properties of PPortPrototype		
	shortName	P_PrimCal_Mass_Lnr_Kg	
	desc	Primitive calibration parameter for minimum egg mass.	
	providedInterface	PrimCal_Mass_Lnr_Kg	

Table 3.59: ParameterSwComponentType CMscA_par

Common ParameterSwComponentType attributes		
shortName	CMscD_par	
desc	Modeling show case for arrays of axes and mapes.	
properties of the ports		
properties of PPortPrototype		
shortName	P_Arr1dComAxis_Temp_Lin_K_uint16	
desc	Array of shared axis for temperature	
providedInterface	ArrldComAxis_Temp_Lin_K_uint16	
properties of PPortPrototype		
shortName	P_Arr1dMap_Time_Lnr_s_uint16	
desc	Map to get time dependent on temperature and mass.	
providedInterface	ArrldMap_Time_Lnr_s_uint16	

Table 3.60: ParameterSwComponentType CMscD_par



Modeling show case for axes, curves and mapes. Properties of the ports	Common ParameterSwComponentType attributes		
properties of the ports properties of PPortPrototype shortName	shortName	CMscB_par	
properties of PPortPrototype shortName	desc	Modeling show case for axes, curves and mapes.	
shortName P_ComAxis_Mass_Lnr_Kg_uint8 desc Shared axis for mass providedInterface ComAxis_Mass_Lnr_Kg_uint8 properties of PPortPrototype shortName P_ComAxis_Steps_Txt_sint8 desc Shared axis for speed steps properties of PPortPrototype shortName P_ComAxis_Temp_Lin_K_uint16 desc Shared axis for temperature providedInterface ComAxis_Temp_Lin_K_uint16 properties of PPortPrototype shortName P_Curve_Mass_Lnr_Kg_uint8 desc Curve to get mass according differnt speed steps. providedInterface Curve_Mass_Lnr_Kg_uint8 properties of PPortPrototype shortName P_Map_Time_Lnr_s_uint16	properties of the ports		
desc Shared axis for mass providedInterface ComAxis_Mass_Lnr_Kg_uint8 properties of PPortPrototype shortName P_ComAxis_Steps_Txt_sint8 desc Shared axis for speed steps providedInterface ComAxis_Steps_Txt_sint8 properties of PPortPrototype shortName P_ComAxis_Temp_Lin_K_uint16 desc Shared axis for temperature providedInterface ComAxis_Temp_Lin_K_uint16 properties of PPortPrototype shortName P_Curve_Mass_Lnr_Kg_uint8 desc Curve to get mass according differnt speed steps. providedInterface Curve_Mass_Lnr_Kg_uint8 properties of PPortPrototype shortName P_Map_Time_Lnr_s_uint16	properties of PPortProt	otype	
providedInterface	shortName	P_ComAxis_Mass_Lnr_Kg_uint8	
properties of PPortPrototype shortName	desc	Shared axis for mass	
shortName P_ComAxis_Steps_Txt_sint8 desc Shared axis for speed steps providedInterface ComAxis_Steps_Txt_sint8 properties of PPortPrototype shortName P_ComAxis_Temp_Lin_K_uint16 desc Shared axis for temperature providedInterface ComAxis_Temp_Lin_K_uint16 properties of PPortPrototype shortName P_Curve_Mass_Lnr_Kg_uint8 desc Curve to get mass according differnt speed steps. providedInterface Curve_Mass_Lnr_Kg_uint8 properties of PPortPrototype shortName P_Map_Time_Lnr_s_uint16	providedInterface	ComAxis_Mass_Lnr_Kg_uint8	
desc Shared axis for speed steps providedInterface ComAxis_Steps_Txt_sint8 properties of PPortPrototype shortName P_ComAxis_Temp_Lin_K_uint16 desc Shared axis for temperature providedInterface ComAxis_Temp_Lin_K_uint16 properties of PPortPrototype shortName P_Curve_Mass_Lnr_Kg_uint8 desc Curve to get mass according differnt speed steps. providedInterface Curve_Mass_Lnr_Kg_uint8 properties of PPortPrototype shortName P_Map_Time_Lnr_s_uint16	properties of PPortProt	otype	
providedInterface	shortName	P_ComAxis_Steps_Txt_sint8	
properties of PPortPrototype shortName	desc	Shared axis for speed steps	
shortName P_ComAxis_Temp_Lin_K_uint16 desc Shared axis for temperature providedInterface ComAxis_Temp_Lin_K_uint16 properties of PPortPrototype shortName P_Curve_Mass_Lnr_Kg_uint8 desc Curve to get mass according differnt speed steps. providedInterface Curve_Mass_Lnr_Kg_uint8 properties of PPortPrototype shortName P_Map_Time_Lnr_s_uint16	providedInterface	ComAxis_Steps_Txt_sint8	
desc Shared axis for temperature providedInterface ComAxis_Temp_Lin_K_uint16 properties of PPortPrototype shortName P_Curve_Mass_Lnr_Kg_uint8 desc Curve to get mass according differnt speed steps. providedInterface Curve_Mass_Lnr_Kg_uint8 properties of PPortPrototype shortName P_Map_Time_Lnr_s_uint16	properties of PPortProt	otype	
providedInterface ComAxis_Temp_Lin_K_uint16 properties of PPortPrototype shortName P_Curve_Mass_Lnr_Kg_uint8 desc Curve to get mass according differnt speed steps. providedInterface Curve_Mass_Lnr_Kg_uint8 properties of PPortPrototype shortName P_Map_Time_Lnr_s_uint16	shortName	P_ComAxis_Temp_Lin_K_uint16	
properties of PPortPrototype shortName	desc	Shared axis for temperature	
shortName P_Curve_Mass_Lnr_Kg_uint8 desc Curve to get mass according differnt speed steps. providedInterface Curve_Mass_Lnr_Kg_uint8 properties of PPortPrototype shortName P_Map_Time_Lnr_s_uint16	providedInterface	ComAxis_Temp_Lin_K_uint16	
desc Curve to get mass according differnt speed steps. providedInterface Curve_Mass_Lnr_Kg_uint8 properties of PPortPrototype shortName P_Map_Time_Lnr_s_uint16	properties of PPortProt	otype	
providedInterface Curve_Mass_Lnr_Kg_uint8 properties of PPortPrototype shortName P_Map_Time_Lnr_s_uint16	shortName	P_Curve_Mass_Lnr_Kg_uint8	
properties of PPortPrototype shortName P_Map_Time_Lnr_s_uint16	desc	Curve to get mass according differnt speed steps.	
shortName P_Map_Time_Lnr_s_uint16	providedInterface	Curve_Mass_Lnr_Kg_uint8	
	properties of PPortPrototype		
Man to get time dependent on temperature and mass	shortName	P_Map_Time_Lnr_s_uint16	
iviap to get time dependent on temperature and mass.	desc	Map to get time dependent on temperature and mass.	
<pre>providedInterface</pre>	providedInterface	Map_Time_Lnr_s_uint16	

Table 3.61: ParameterSwComponentType CMscB_par



3.2.2.3 ApplicationSwComponentTypes

Common ApplicationSwComponentType attributes			
shortName	CMscD		
desc	Modeling show case for arrays of axes and mapes.		
properties of the ports			
properties of PPortProto	otype		
shortName	P_Arr1dPrimData_Temperature_Lin_K_C_uint16		
desc	Temperature 1 in Kelvin but displayed as degree Celsius		
providedInterface	ArrldPrimData_Temperature_Lin_K_C_uint16		
properties of RPortProto	otype		
shortName	R_Arr1dComAxis_Temp_Lin_K_uint16		
desc	Array of shared axis for temperature		
requiredInterface	ArrldComAxis_Temp_Lin_K_uint16		
properties of RPortProto	otype		
shortName	R_Arr1dMap_Time_Lnr_s_uint16		
desc	Map to get time dependent on temperature and mass.		
requiredInterface	ArrldMap_Time_Lnr_s_uint16		
properties of RPortProto	otype		
shortName	R_Arr1dPrimData_Temperature_Lin_K_C_uint16		
desc	Temperature 1 in Kelvin but displayed as degree Celsius		
requiredInterface	ArrldPrimData_Temperature_Lin_K_C_uint16		
properties of RPortProto	otype		
shortName	R_ComAxis_Mass_Lnr_Kg_uint8		
desc	Shared axis for mass		
requiredInterface	ComAxis_Mass_Lnr_Kg_uint8		
properties of RPortPrototype			
shortName	R_PrimData_MassCorrected_Lnr_Kg_uint8		
desc	Primitve data for the corrected mass in kg.		
requiredInterface	PrimData_MassCorrected_Lnr_Kg_uint8		
internalBehavior	internalBehavior CMscD		

Table 3.62: ApplicationSwComponentType CMscD

Common SwcInternalBehavior attributes		
shortName	CMscD	
properties of the runnables		
properties of RunnableEntity		
shortName	CMscD_Process	
symbol	CMscD_Process	

Table 3.63: SwcInternalBehavior CMscD



hortName	CMscB	
esc	Modeling show case for axes, curves and mapes.	
roperties of the ports		
properties of PPortProt	otype	
shortName	P_PrimData_MassCorrected_Lnr_Kg_uint8	
desc	Primitve data for the corrected mass in kg.	
providedInterface	PrimData_MassCorrected_Lnr_Kg_uint8	
properties of PPortProt		
shortName	P_PrimData_Time_Lnr_s_uint16	
desc	Primitve data holding a time value.	
providedInterface	PrimData_Time_Lnr_s_uint16	
properties of PPortProt	otype	
shortName	P_PrimData_ValidState_Txt_noUnit_boolean	
desc	Boolean representing the data validity	
providedInterface	PrimData_ValidState_Txt_noUnit_boolean	
properties of RPortProt	otype	
shortName	R_ComAxis_Mass_Lnr_Kg_uint8	
desc	Shared axis for mass	
requiredInterface	ComAxis_Mass_Lnr_Kg_uint8	
properties of RPortPrototype		
shortName	R_ComAxis_Steps_Txt_sint8	
desc	Shared axis for speed steps	
requiredInterface	ComAxis_Steps_Txt_sint8	
properties of RPortPrototype		
shortName	R_ComAxis_Temp_Lin_K_uint16	
desc	Shared axis for temperature	
requiredInterface	ComAxis_Temp_Lin_K_uint16	
properties of RPortProt		
shortName	R_Curve_Mass_Lnr_Kg_uint8	
desc	Curve to get mass according differnt speed steps.	
requiredInterface	Curve_Mass_Lnr_Kg_uint8	
properties of RPortProt	-	
shortName	R_Map_Time_Lnr_s_uint16	
desc	Map to get time dependent on temperature and mass.	
requiredInterface	Map_Time_Lnr_s_uint16	
properties of RPortProt	-	
shortName	R ModeDirection	
desc	Mode to indicate a direction	
requiredInterface	ModeDirection	
properties of RPortProt	otype	



 \triangle

desc	Mass in kilogram	
requiredInterface	PrimData_Mass_Lnr_Kg_uint8	
properties of RPortProto	otype	
shortName	R_PrimData_MassCorrected_Lnr_Kg_uint8	
desc	Primitve data for the corrected mass in kg.	
requiredInterface	PrimData_MassCorrected_Lnr_Kg_uint8	
properties of RPortProto	otype	
shortName	R_PrimData_StepsSpeed_Txt_sint8	
desc	Stepwise speed indication	
requiredInterface	PrimData_StepsSpeed_Txt_sint8	
properties of RPortPrototype		
shortName	R_PrimData_Temperature_Lin_K_C_uint16	
desc	Temperature 1 in Kelvin but displayed as degree Celsius	
requiredInterface	PrimData_Temperature_Lin_K_C_uint16	
properties of RPortProto	properties of RPortPrototype	
shortName	R_PrimData_Time_Lnr_s_uint16	
desc	Primitve data holding a time value.	
requiredInterface	PrimData_Time_Lnr_s_uint16	
properties of RPortProto	otype	
shortName	R_PrimData_ValidState_Txt_noUnit_boolean	
desc	Boolean representing the data validity	
requiredInterface	PrimData_ValidState_Txt_noUnit_boolean	
internalBehavior	CMscB	

Table 3.64: ApplicationSwComponentType CMscB

Common SwcInternalBehavior attributes	
shortName	CMscB
properties of the runnables	
properties of RunnableEntity	
shortName	CMscB_Process
desc	cyclic process for calculation
symbol	CMscB_Process

Table 3.65: SwcInternalBehavior CMscB



3.2.2.4 ParameterInterfaces

Common ParameterInterface attributes	
shortName	Arr1dComAxis_Temp_Lin_K_uint16
desc	Array of shared axis for temperature
properties of the parameters	
properties of ParameterDataPrototype	
shortName	Arr1dComAxis_Temp_Lin_K_uint16
desc	Array of shared axis for temperature
type	ComAxis_Temp_Lin_K_uint16_ScNoOfWheels
swImplPolicy	standard
swCalibrationAccess	readWrite
swAddrMethod	CAL

Table 3.66: ParameterInterface Arr1dComAxis_Temp_Lin_K_uint16

Common ParameterInterface attributes		
shortName	Arr1dMap_Time_Lnr_s_uint16	
desc	Map to get time dependent on temperature and mass.	
properties of the parameter	properties of the parameters	
properties of ParameterDataPrototype		
shortName	Arr1dMap_Time_Lnr_s_uint16	
desc	Map to get time dependent on temperature and mass.	
type	Map_Time_Lnr_s_uint16_ScNoOfWheels	
swImplPolicy	standard	
swCalibrationAccess	readWrite	
swAddrMethod	CAL	

Table 3.67: ParameterInterface Arr1dMap_Time_Lnr_s_uint16

Common ParameterInterface attributes		
shortName	ComAxis_Mass_Lnr_Kg_uint8	
desc	Shared axis for mass	
properties of the parameter	properties of the parameters	
properties of ParameterDataPrototype		
shortName	ComAxis_Mass_Lnr_Kg_uint8	
desc	Shared axis for mass	
type	ComAxis_Mass_Lnr_Kg_uint8	
swImplPolicy	standard	
swCalibrationAccess	readWrite	
swAddrMethod	CAL	

Table 3.68: ParameterInterface ComAxis_Mass_Lnr_Kg_uint8



Common ParameterInterface attributes	
shortName	ComAxis_Steps_Txt_sint8
desc	Shared axis for speed steps
properties of the parameters	
properties of ParameterDataPrototype	
shortName	ComAxis_Steps_Txt_sint8
desc	Shared axis for speed steps
type	ComAxis_Steps_Txt_sint8
swImplPolicy	standard
swCalibrationAccess	readWrite
swAddrMethod	CAL

Table 3.69: ParameterInterface ComAxis_Steps_Txt_sint8

Common ParameterInterface attributes	
hortName	ComAxis_Temp_Lin_K_uint16
esc	Shared axis for temperature
properties of the parameters	
properties of ParameterDataPrototype	
shortName	ComAxis_Temp_Lin_K_uint16
desc	Shared axis for temperature
type	ComAxis_Temp_Lin_K_uint16
swImplPolicy	standard
swCalibrationAccess	readWrite
swAddrMethod	CAL

Table 3.70: ParameterInterface ComAxis_Temp_Lin_K_uint16

Common ParameterInterface attributes	
shortName	Curve_Mass_Lnr_Kg_uint8
desc	Curve to get mass according differnt speed steps.
properties of the parameters	
properties of ParameterDataPrototype	
shortName	Curve_Mass_Lnr_Kg_uint8
desc	Curve to get mass according differnt speed steps.
type	Curve_Mass_Lnr_Kg_uint8
swImplPolicy	standard
swCalibrationAccess	readWrite
swAddrMethod	CAL

Table 3.71: ParameterInterface Curve_Mass_Lnr_Kg_uint8



Common ParameterInterface attributes	
shortName	Map_Time_Lnr_s_uint16
desc	Map to get time dependent on temperature and mass.
properties of the parameters	
properties of ParameterDataPrototype	
shortName	Map_Time_Lnr_s_uint16
desc	Map to get time dependent on temperature and mass.
type	Map_Time_Lnr_s_uint16
swImplPolicy	standard
swCalibrationAccess	readWrite
swAddrMethod	CAL

Table 3.72: ParameterInterface Map_Time_Lnr_s_uint16

C	Common ParameterInterface attributes	
sl	hortName	PrimCal_Mass_Lnr_Kg
de	esc	Primitive calibration parameter for minimum egg mass.
рі	properties of the parameters	
	properties of ParameterDataPrototype	
	shortName	PrimCal_Mass_Lnr_Kg
	desc	Primitive calibration parameter for minimum egg mass.
	type	kg_Lnr_0_0d25_0_C8_uint8
	swImplPolicy	standard
	swCalibrationAccess	readWrite
	swAddrMethod	CAL

Table 3.73: ParameterInterface PrimCal_Mass_Lnr_Kg



3.2.2.5 ModeSwitchInterfaces

Common ModeSwitchInterface attributes		
shortName ModeDirection		
desc	Mode to indicate a direction	
properties of the modeGroupS		
shortName	ModeDirection	
swCalibrationAccess	readOnly	
type	Direction	

Table 3.74: ModeSwitchInterface ModeDirection



3.2.2.6 SenderReceiverInterfaces

Common SenderReceiverInterface attributes			
hortName	Arr1dPrimData_Temperature_Lin_K_C_uint16		
esc	Temperature 1 in Kelvin but displayed as degree Celsius		
roperties of the dataEleme	entsS		
properties of VariableDataPrototype			
shortName	Arr1dPrimData_Temperature_Lin_K_C_uint16		
desc	Temperature 1 in Kelvin but displayed as degree Celsius		
type	K_Celsius_Lnr_0_511d9921875_0_FFFF_uint16 ScNoOfWheels		
swImplPolicy	standard		
swCalibrationAccess	readOnly		
swAddrMethod	DATA		

Table 3.75: SenderReceiverInterface Arr1dPrimData_Temperature_Lin_K_C_uint16

Common SenderReceiverInterface attributes			
shortName PrimData_Mass_Lnr_Kg_uint8			
desc Mass in kilogram			
properties of the dataEleme	entsS		
properties of VariableDa	ataPrototype		
shortName	PrimData_Mass_Lnr_Kg_uint8		
desc	Mass in kilogram		
type	kg_Lnr_0_0d25_0_C8_uint8		
swImplPolicy	standard		
swCalibrationAccess	readOnly		
swAddrMethod	DATA		

Table 3.76: SenderReceiverInterface PrimData_Mass_Lnr_Kg_uint8

Common SenderReceiverInterface attributes			
shortName	shortName PrimData_MassCorrected_Lnr_Kg_uint8		
desc	Primitve data for the corrected mass in kg.		
properties of the dataEleme	entsS		
properties of VariableDa	taPrototype		
shortName PrimData_MassCorrected_Lnr_Kg_uint8			
desc	Primitve data for the corrected mass in kg.		
type	kg_Lnr_0_0d25_0_C8_uint8		
swImplPolicy	standard		
swCalibrationAccess	readOnly		
swAddrMethod	DATA		

Table 3.77: SenderReceiverInterface PrimData_MassCorrected_Lnr_Kg_uint8



Common SenderReceiverInterface attributes				
shortName	PrimData_Temperature_Lin_K_C_uint16			
desc	Temperature 1 in Kelvin but displayed as degree Celsius			
properties of the dataEleme	ntsS			
properties of VariableDa	taPrototype			
shortName	PrimData_Temperature_Lin_K_C_uint16			
desc	Temperature 1 in Kelvin but displayed as degree Celsius			
type	K_Celsius_Lnr_0_511d9921875_0_FFFF_uint16			
swImplPolicy	standard			
swCalibrationAccess	readOnly			
swAddrMethod	DATA			

Table 3.78: SenderReceiverInterface PrimData_Temperature_Lin_K_C_uint16

Common SenderReceiverInterface attributes			
shortName	PrimData_Time_Lnr_s_uint16		
desc Primitve data holding a time value.			
properties of the dataEleme	entsS		
properties of VariableDa	ataPrototype		
shortName	PrimData_Time_Lnr_s_uint16		
desc	Primitve data holding a time value.		
type	s_Lnr_0_8191d875_0_FFFF_uint16		
swImplPolicy	standard		
swCalibrationAccess	readOnly		
swAddrMethod	DATA		

Table 3.79: SenderReceiverInterface PrimData_Time_Lnr_s_uint16

Common SenderReceiverInterface attributes				
shortName	PrimData_ValidState_Txt_noUnit_boolean			
desc	Boolean representing the data validity			
properties of the dataEleme	ntsS			
properties of VariableDa	taPrototype			
shortName	PrimData_ValidState_Txt_noUnit_boolean Boolean representing the data validity			
desc				
type	DataValidityType			
swImplPolicy	standard			
swCalibrationAccess	readOnly			
swAddrMethod DATA				

Table 3.80: SenderReceiverInterface PrimData_ValidState_Txt_noUnit_boolean



3.2.2.7 ApplicationDataTypes, Category BOOLEAN

C	Common ApplicationDataType attributes					
S	hortName	DataValidityTyp	DataValidityType			
C	ategory	BOOLEAN				
d	lesc	Boolean to repr	esent the data va	alidity		
S	wCalibrationAccess	notAccessib	le			
υ	mit	NoUnit				
F	lange					
		lowerLimit		upperLimit		
	physConstrs	0		1		
C	Conversion					
	category	TEXTTABLE				
	direction	compuInternalToPhys				
	desc	lowerLimit upperLimit vt symbol			symbol	
	-	0	0 0			
	-	1 Valid				

Table 3.81: ApplicationDataType DataValidityType



3.2.2.8 ApplicationDataTypes, Category VALUE

Common ApplicationDataType attributes					
shortName	K_Celsius_Lnr	_0_511d9921875	_0_FFFF_uint16		
category	VALUE				
desc	Temperature				
swCalibrationAccess	notAccessib	le			
unit	K				
Range					
	lowerLimit		upperLimit		
physConstrs	0 511.9921875				
Conversion					
category	LINEAR				
direction	compuIntern	alToPhys			
desc	lowerLimit upperLimit		compuNumerator/ compuDenominator		
-	-	-	$Phys = \frac{0 + 0.0078125 * Internal}{1}$		

Table 3.82: ApplicationDataType K_Celsius_Lnr_0_511d9921875_0_FFFF_uint16

Common ApplicationDataType attributes				
shortName	kg_Lnr_0_0d25	5_0_C8_uint8		
category	VALUE			
desc	Mass			
swCalibrationAccess	notAccessib	le		
unit	kg			
Range				
	lowerLimit upperLimit			
physConstrs	0 0.25			
Conversion				
category	LINEAR			
direction	compuIntern	alToPhys		
desc	lowerLimit upperLimit		compuNumerator/ compuDenominator	
-	-	-	$Phys = \frac{0 + 0.00125 * Internal}{1}$	

Table 3.83: ApplicationDataType kg_Lnr_0_0d25_0_C8_uint8



shortName	NoUnit_Lnr_1_	4_1_4_uint8		
category	VALUE			
swCalibrationAccess	notAccessib	le		
unit	NoUnit			
Range				
	lowerLimit		upperLimit	
physConstrs	1	1 4		
Conversion				
category	LINEAR			
direction	compuIntern	alToPhys		
desc	lowerLimit	upperLimit	compuNumerator/ compuDenominator	
-	-	-	$Phys = \frac{0 + 1 * Internal}{1}$	

Table 3.84: ApplicationDataType NoUnit_Lnr_1_4_1_4_uint8

C	Common ApplicationDataType attributes					
S	hortName	NoUnit_Lnr_1_65535_1_FFFF_uint16				
C	ategory	VALUE				
s	wCalibrationAccess	notAccessib	le			
u	nit	NoUnit				
R	ange					
		lowerLimit	lowerLimit upperLimit			
	physConstrs	1		65535		
С	Conversion					
	category	LINEAR				
	direction	compuIntern	alToPhys			
	desc	lowerLimit upperLimit		compuNumerator/ compuDenominator		
	-	-	-	$Phys = \frac{0 + 1 * Internal}{1}$		

Table 3.85: ApplicationDataType NoUnit_Lnr_1_65535_1_FFFF_uint16



Common ApplicationDataType attributes				
shortName	s_Lnr_0_8191c	1875_0_FFFF_uir	nt16	
category	VALUE			
desc	cooking time in	seconds		
swCalibrationAccess	notAccessib	le		
unit	S			
Range				
	lowerLimit upperLimit			
physConstrs	0 8191.875			
Conversion				
category	LINEAR			
direction	compuInterna	alToPhys		
desc	lowerLimit upperLimit		compuNumerator/ compuDenominator	
-	-	-	$Phys = \frac{0 + 0.125 * Internal}{1}$	

Table 3.86: ApplicationDataType s_Lnr_0_8191d875_0_FFFF_uint16

Common ApplicationDataType attributes				
nortName	speedSteps			
ategory	VALUE			
esc	Possible speed	steps		
wCalibrationAccess	notAccessib	le		
nit	NoUnit			
ange				
	lowerLimit		upperLimit	
physConstrs	-1		2	
onversion				
category	TEXTTABLE			
direction	compuInternalToPhys			
desc	lowerLimit	upperLimit	vt	symbol
-	-1	-1	Stop	
-	0	0	LightSpeed	
-	1	1	RidiculousSpeed	
-	2	2	LudicrousSpeed	
	nortName ategory esc wCalibrationAccess nit ange physConstrs onversion category direction	nortName speedSteps VALUE Possible speed wCalibrationAccess notAccessib nit NoUnit ange lowerLimit physConstrs onversion category TEXTTABLE direction compuInternate 0 - 1	speedSteps VALUE Possible speed steps wCalibrationAccess notAccessible nit NoUnit ange lowerLimit physConstrs onversion category TEXTTABLE direction desc lowerLimit upperLimit 0 0 0 - 1 1 1	speedSteps Ategory VALUE Possible speed steps Accessible NoUnit Ange lowerLimit upperLimit physConstrs -1 2 conversion category TEXTTABLE direction compuInternalToPhys desc lowerLimit upperLimit vt - -1 -1 Stop - 0 0 LightSpeed - 1 RidiculousSpeed

Table 3.87: ApplicationDataType speedSteps



C	Common ApplicationDataType attributes				
s	hortName	TxWheelName	TxWheelNames		
C	ategory	VALUE			
d	lesc	Wheel names			
s	wCalibrationAccess	notAccessib	le		
u	nit	NoUnit			
R	ange				
		lowerLimit		upperLimit	
	physConstrs	0		3	
С	conversion	<u> </u>			
	category	TEXTTABLE			
	direction	compuIntern	alToPhys		
	desc	lowerLimit	upperLimit	vt	symbol
	-	0	0	FrontLeft	
	-	1	1	FrontRight	
	-	2	2	RearLeft	
	-	3	3	RearRight	

Table 3.88: ApplicationDataType TxWheelNames



3.2.2.9 ApplicationDataTypes, Category COM_AXIS

Common ApplicationDataType attributes		
shortName	ComAxis_Temp_Lin_K_uint16	
category	COM_AXIS	
swCalibrationAccess	notAccessible	
swRecordLayout	RL20_ME_Axis	
properties of the axes (swCa	lprmAxisSet)	
properties of SwAxisIndi	vidual (swCalprmAxis and swCalprmAxisTypeProps)	
swAxisIndex	1	
category	COM_AXIS	
inputVariableType	K_Celsius_Lnr_0_511d9921875_0_FFFF_uint16	
swMaxAxisPoints	6	
swMinAxisPoints	6	

Table 3.89: ApplicationDataType ComAxis_Temp_Lin_K_uint16

Common ApplicationDataType attributes		
shortName	ComAxis_Steps_Txt_sint8	
category	COM_AXIS	
swCalibrationAccess	notAccessible	
swRecordLayout	RL20_ME_Axis	
properties of the axes (swCa	lprmAxisSet)	
properties of SwAxisIndi	ividual (swCalprmAxis and swCalprmAxisTypeProps)	
swAxisIndex	1	
category	COM_AXIS	
inputVariableType	speedSteps	
swMaxAxisPoints	4	
swMinAxisPoints	4	

Table 3.90: ApplicationDataType ComAxis_Steps_Txt_sint8

Common ApplicationDataType attributes		
shortName	ComAxis_Mass_Lnr_Kg_uint8	
category	COM_AXIS	
swCalibrationAccess	notAccessible	
swRecordLayout	RL20_ME_Axis	
properties of the axes (swCa	lprmAxisSet)	
properties of SwAxisIndi	vidual (swCalprmAxis and swCalprmAxisTypeProps)	
swAxisIndex	1	
category	COM_AXIS	
inputVariableType	kg_Lnr_0_0d25_0_C8_uint8	
swMaxAxisPoints	4	
swMinAxisPoints	4	

Table 3.91: ApplicationDataType ComAxis_Mass_Lnr_Kg_uint8



3.2.2.10 ApplicationDataTypes, Category CURVE

Common ApplicationDataType attributes			
shortName	Curve_Mass_Lnr_Kg_uint8		
category	CURVE		
swCalibrationAccess	notAccessible		
swRecordLayout	RL20_ME_1DimMap		
valueAxisDataType	valueAxisDataType kg_Lnr_0_0d25_0_C8_uint8		
properties of the axes (swCalprmAxisSet)			
properties of SwAxisGrou	properties of SwAxisGrouped (swCalprmAxis and swCalprmAxisTypeProps)		
swAxisIndex	1		
category	COM_AXIS		
sharedAxisType	ComAxis_Steps_Txt_sint8		

Table 3.92: ApplicationDataType Curve_Mass_Lnr_Kg_uint8



3.2.2.11 ApplicationDataTypes, Category MAP

Common ApplicationDataType attributes			
shortName	shortName Map_Time_Lnr_s_uint16		
category	MAP		
swCalibrationAccess	notAccessible		
swRecordLayout	RL20_ME_2DimMap		
valueAxisDataType	s_Lnr_0_8191d875_0_FFFF_uint16		
properties of the axes (swo	alprmAxisSet)		
properties of SwAxisGro	ouped (swCalprmAxis and swCalprmAxisTypeProps)		
swAxisIndex	1		
category	COM_AXIS		
sharedAxisType	ComAxis_Temp_Lin_K_uint16		
properties of SwAxisGro	properties of SwAxisGrouped (swCalprmAxis and swCalprmAxisTypeProps)		
swAxisIndex	2		
category	COM_AXIS		
sharedAxisType	ComAxis_Mass_Lnr_Kg_uint8		
	1		

Table 3.93: ApplicationDataType Map_Time_Lnr_s_uint16



3.2.2.12 ApplicationArrayDataTypes

Common ApplicationArrayDataType attributes	
shortName	ComAxis_Temp_Lin_K_uint16_ScNoOfWheels
category	ARRAY
swCalibrationAccess	notAccessible
properties of the elements	
properties of Application	onArrayElement
shortName	ComAxis_Temp_Lin_K_uint16_ScNoOfWheels
category	COM_AXIS
type	ComAxis_Temp_Lin_K_uint16
arraySizeSemantics	fixedSize
maxNumberOfElements	

Table 3.94: ApplicationArrayDataType ComAxis_Temp_Lin_K_uint16_ScNoOfWheels

Common ApplicationArrayDataType attributes			
shortName	K_Celsius_Lnr_0_511d9921875_0_FFFF_uint16_ScNoOfWheels		
category	ARRAY		
swCalibrationAccess	notAccessible		
properties of the elements			
properties of Application	properties of ApplicationArrayElement		
shortName	K_Celsius_Lnr_0_511d9921875_0_FFFF_uint16_ScNoOfWheels		
category	VALUE		
type	K_Celsius_Lnr_0_511d9921875_0_FFFF_uint16		
arraySizeSemantics	fixedSize		
maxNumberOfElements			

Table 3.95: ApplicationArrayDataType K_Celsius_Lnr_0_511d9921875_0_FFFF_uint16_ScNoOfWheels

Common ApplicationArrayDataType attributes			
shortName	Map_Time_Lnr_s_uint16_ScNoOfWheels		
category	ARRAY		
swCalibrationAccess	notAccessible		
properties of the elements	perties of the elements		
properties of Application	onArrayElement		
shortName	Map_Time_Lnr_s_uint16_ScNoOfWheels		
category	MAP		
type	Map_Time_Lnr_s_uint16		
arraySizeSemantics	fixedSize		
maxNumberOfElements			

Table 3.96: ApplicationArrayDataType Map_Time_Lnr_s_uint16_ScNoOfWheels



3.2.2.13 ApplicationRecordDataTypes

Common ApplicationRecordDataType attributes		
shortName	CMscC_nvm_NvBlockATyp	
category	STRUCTURE	
swCalibrationAccess	notAccessible	
properties of the elements		
properties of ApplicationRecordElement		
shortName	PrimData_StepsSpeed_Txt_sint8	
category	VALUE	
type	speedSteps	

Table 3.97: ApplicationRecordDataType CMscC_nvm_NvBlockATyp



3.2.2.14 ModeDeclarationGroups

Common ModeDeclarationGroup attributes		
shortName	Direction	
category	EXPLICIT_ORDER	
initialMode	Halt	
properties of the modeDecla	aration S	
properties of ModeDeclar	cation	
shortName	Backward	
desc	Backward direction	
value	2	
properties of ModeDeclar	ration	
shortName	Forward	
desc	Forward direction	
value	1	
properties of ModeDeclaration		
shortName	Halt	
desc	Standstill	
value	0	

Table 3.98: ModeDeclarationGroup Direction



3.2.2.15 Units

С	Common Unit attributes	
s	hortName	Celsius
d	esc	Degrees Celsius
	displayName	°C
	offsetSiToUnit	-273.15
	factorSiToUnit	1.0
	physicalDimension	PD_K

Table 3.99: Unit Celsius

С	Common Unit attributes	
S	hortName	K
d	esc	Temperature
	displayName	К
	offsetSiToUnit	0.0
	factorSiToUnit	1.0
	physicalDimension	PD_K

Table 3.100: Unit K

С	Common Unit attributes	
S	hortName	kg
d	esc	Mass
	displayName	kg
	offsetSiToUnit	0.0
	factorSiToUnit	1.0
	physicalDimension	PD_kg

Table 3.101: Unit kg

C	Common Unit attributes	
s	hortName	NoUnit
d	esc	No Unit
	displayName	-
	offsetSiToUnit	0.0
	factorSiToUnit	1.0
	physicalDimension	PD_NoUnit

Table 3.102: Unit NoUnit



С	Common Unit attributes	
s	hortName	s
d	esc	Time
	displayName	s
	offsetSiToUnit	0.0
	factorSiToUnit	1.0
	physicalDimension	PD_s

Table 3.103: Unit s



3.2.2.16 PhysicalDimensions

С	Common PhysicalDimension attributes	
s	hortName	PD_K
	currentExp	0
	lengthExp	0
	luminousIntensity- Exp	0
	massExp	0
	molarAmountExp	0
	temperatureExp	1
	timeExp	0

Table 3.104: PhysicalDimension PD_K

С	Common PhysicalDimension attributes	
S	hortName	PD_kg
	currentExp	0
	lengthExp	0
	luminousIntensity- Exp	0
	massExp	1
	molarAmountExp	0
	temperatureExp	0
	timeExp	0

Table 3.105: PhysicalDimension PD_kg

S	shortName	PD_NoUnit
	currentExp	0
	lengthExp	0
	luminousIntensity- Exp	0
	massExp	0
	molarAmountExp	0
	temperatureExp	0
	timeExp	0

Table 3.106: PhysicalDimension PD_NoUnit



shortName PD_s	
currentExp	0
lengthExp	0
luminousIntensity- Exp	0
massExp	0
molarAmountExp	0
temperatureExp	0
timeExp	1

Table 3.107: PhysicalDimension PD_s



3.2.2.17 SwAddrMethods

С	Common SwAddrMethod attributes					
S	shortName CAL					
O.	esc	Calibratable constants; safety level QM. Constants will be located in different memory sections depending on the alignment of the constant.				
	sectionType	calprm				
	memoryAllocation- KeywordPolicy	addrMethodShortNameAndAlignment				
	sectionInitializa- tionPolicy	-				
	option	safetyQM				

Table 3.108: SwAddrMethod CAL

С	Common SwAddrMethod attributes					
S	shortName CODE_10MS					
d	esc	Code of ECU-functions called every 10 ms; safety level QM.				
	sectionType	code				
	memoryAllocation- KeywordPolicy	addrMethodShortName				
	sectionInitializa- tionPolicy	-				
	option	safetyQM				

Table 3.109: SwAddrMethod CODE_10MS

C	Common SwAddrMethod attributes					
s	shortName CONST_SLOW					
d	esc	Non calibratable constants of ECU-functions called seldom; safety level QM.				
	sectionType	const				
	memoryAllocation- KeywordPolicy	addrMethodShortName				
	sectionInitializa- tionPolicy	-				
	option	safetyQM				

Table 3.110: SwAddrMethod CONST_SLOW



С	ommon SwAddrMethod att:	n SwAddrMethod attributes			
s	hortName	DATA			
d	esc	Variables of ECU-functions; safety level QM. Variables will be located in different memory sections depending on the alignment of the variable.			
	sectionType	var			
	memoryAllocation- KeywordPolicy	addrMethodShortNameAndAlignment			
	sectionInitializa- tionPolicy	INIT			
	option	safetyQM			

Table 3.111: SwAddrMethod DATA

С	Common SwAddrMethod attributes					
shortName DATA_NVDAT						
d	esc	Variables stored in non-volatile memory; safety level QM.				
	sectionType	var				
	memoryAllocation- KeywordPolicy	addrMethodShortName				
	sectionInitializa- tionPolicy	NO-INIT				
	option	nvData, safetyQM				

Table 3.112: SwAddrMethod DATA_NVDAT



4 Structured Requirements

Structured Requirements are available at different sections in the meta model. There exists a clear definition of the elements of StructuredReq. Based on these elements a variety of possible use cases can be applied. The following show cases shall illustrate this:

- provide additional information for configuration
- provide specification items as requirements
- provide diagnostical requirements
- provide decomposition of requirements

4.1 Introductory Show Case

An OEMs e.g. can specify additional unmapped Ecu Configuration information using Structured Requirements. They are serialized using standardized ARXML. This would ensure a consistent processing of these data by a suitable tooling solution on supplier side. In addition, further validation can be applied to data and lead to a high quality of the exchanged information. No new and additional elements have to be introduced in the meta model because StructuredReg still provides all needed entities.

4.1.1 Additional information (M1 parameter)

The System Template [6] defines upstream mappings for a variety of M1 parameters. They are transported by the System Extract or Diagnostic Extract and presented in figure 4.1 as importable parameters.

The show case that an OEM needs to specify a value for not importable M1 parameters (no full mapping specified in AUTOSAR templates) to determine a dedicated behavior, e.g. CanDevErrorDetect which can be enabled by true or disabled by false is illustrated in figure 4.1 as processable parameters. A tool based processing of these information can increase efficiency and minimize error-proneness. This show case is targeting to solve this by using the StructuredReq.






Figure 4.1: Types of Parameters

The figure 4.1 shows further type of parameters; calculated and adjusted parameters; which exist but are not in the scope of show case.

In listing 4.1 the StructuredReg for CanDevErrorDetect is illustrated.

Listing 4.1: Example 1 for StructuredReq

```
<STRUCTURED-REQ SI="UNMAPPED_ECUC">
  <SHORT-NAME>CAN_0001
  <LONG-NAME>
    <L-4 L="EN">CanDevErrorDetect</L-4>
  </LONG-NAME>
  <CATEGORY>REQUIREMENT_ITEM</CATEGORY>
 <DATE>2018-03-19</DATE>
 <ISSUED-BY>OEM</ISSUED-BY>
  <TYPE>valid</TYPE>
 <IMPORTANCE>High</IMPORTANCE>
  <DESCRIPTION>
    <LIST>
      <ITEM SI="Guideline">
        <P>
          <L-1 L="EN">Switches the development error detection and
             notification on or off. true: detection and notification is
             enabled. false: detection and notification is disabled.</L-1>
        </P>
      </ITEM>
      <ITEM SI="SupplierSetting">
          <L-1 L="FOR-ALL">FALSE</L-1>
        </P>
      </ITEM>
      <ITEM SI="ARVersion">
        <P>
          <L-1 L="FOR-ALL">4.2.2</L-1>
        </P>
        <P>
          <L-1 L="FOR-ALL">4.3.0</L-1>
        </P>
          <L-1 L="FOR-ALL">4.4.0</L-1>
        </P>
      </ITEM>
```



```
<ITEM SI="ValueRange">
          <L-1 L="FOR-ALL">TRUE</L-1>
        </P>
        <P>
          <L-1 L="FOR-ALL">FALSE</L-1>
        </P>
      </ITEM>
    </LIST>
  </DESCRIPTION>
  <RATIONALE>
    <P>
      <L-1 L="EN">The feature development error detection shall be
         disabled for production code else it has to be ensured that there
          will be no side effects from this code.</L-1>
    </P>
  </RATIONALE>
  <USE-CASE>
    <P>
      <L-1 L="EN">preconfigured/default</L-1>
    </P>
  </USE-CASE>
</STRUCTURED-REQ>
```

For illustrative reasons the following listing 4.2 only contains a subset of the example where the ValueRange is specified using a DataConstr.

Listing 4.2: Example 2 for ValueRange in StructuredReq

The corresponding DataConstr is shown in the listing 4.3.

Listing 4.3: Example 2 for DataConstr

```
<DATA-CONSTR>
  <SHORT-NAME>Range_Boolean
<DATA-CONSTR-RULES>
  <DATA-CONSTR-RULE>
  <PHYS-CONSTRS>
    <LOWER-LIMIT>TRUE</LOWER-LIMIT>
    <UPPER-LIMIT>FALSE</UPPER-LIMIT>
    </PHYS-CONSTRS>
  </DATA-CONSTR-RULE>
  </DATA-CONSTR-RULES>
</DATA-CONSTR-RULES></DATA-CONSTR></DATA-CONSTR></DATA-CONSTR></DATA-CONSTR></DATA-CONSTR></DATA-CONSTR></DATA-CONSTR></DATA-CONSTR>
```

The same data can also be rendered in the table 4.1.



ReqID	CAN_00001	CanDevErrorDetect	Setting	FALSE
Use Case	preconfigured/default	4.2.2, 4.3.0, 4.4.0	Range	FALSE, TRUE
Descrip- tion	Switches the development error detection and notification on or off. true: detection and notification is enabled. false: detection and notification is disabled.	Rational	The feature developm shall be disabled for p has to be ensured that effects from this code.	roduction code else it t there will be no side

Table 4.1: StructuredReq Of CanDevErrorDetect

4.1.2 Specification items as requirements

AUTOSAR uses StructuredReq within AUTOSAR RS documents [TPS_STDT_-00060]. They are automatically generated based on the specification generation process. Theses specification items use the attributes of StructuredReq including Traceable, to realize the up tracing. A dedicated example is illustrated in 4.4 this.

Listing 4.4: Example for StructuredReq in RS AUTOSAR Specification

```
<STRUCTURED-REQ>
  <SHORT-NAME>RS_SYST_00020
    <L-4 L="EN">Exclusion of signals from a specific physical line</L-4>
  </LONG-NAME>
  <CATEGORY>REQUIREMENT_ITEM</CATEGORY>
  <TRACE-REFS>
    <TRACE-REF BASE="ArTrace" DEST="TRACEABLE">RS_Main_00150/TRACE-REF>
    <TRACE-REF BASE="ArTrace" DEST="TRACEABLE">RS_Main_00030/TRACE-REF>
  </TRACE-REFS>
  <DATE>2004-10-29</DATE>
  <ISSUED-BY>WP Methodology&amp;Templates</ISSUED-BY>
  <TYPE>valid</TYPE>
  <IMPORTANCE>medium</IMPORTANCE>
  <DESCRIPTION>
    <P>
      <L-1 L="EN">The System Constraint Description shall be able to
         describe that signals have not to be mapped to a specific
         physical line.</L-1>
    </P>
  </DESCRIPTION>
  <RATIONALE>
      <L-1 L="EN">Some physical lines can result unsuitable (too slow,
         unsafe communication protocol, etc.) for the transmission of
         some specific signals.</L-1>
    </P>
  </RATIONALE>
  <USE-CASE>
    <P>
      <L-1 L="EN">Most of power train signals cannot be mapped to a low
         speed CAN bus, due to their timing requirements.</L-1>
    </P>
  </USE-CASE>
```



The Traceable is realized by the tags <TRACE-REF>s in inside <TRACE-REFS>. In the specification the up traces appear as links below the table.

[RS_SYST_00020] Exclusion of signals from a specific physical line [

Туре:	valid
Description:	The System Constraint Description shall be able to describe that signals have not to be mapped to a specific physical line.
Rationale:	Some physical lines can result unsuitable (too slow, unsafe communication protocol, etc.) for the transmission of some specific signals.
Dependencies:	None identified.
Use Case:	Most of power train signals cannot be mapped to a low speed CAN bus, due to their timing requirements.
Supporting Material:	-

(RS_Main_00150, RS_Main_00030)

Figure 4.2: Spec item represented by StructuredReg

Using StructuredReg a complete requirements description and tracing is available.

4.1.3 Diagnostic requirements

In this context the StructuredReq is embedded in DiagnosticAccessPermission. Mainly the description of the two conditions are shown here.

Listing 4.5: Example for the definition of pre- and run-conditions for DiagnosticAccessPermission



```
<CATEGORY>DIAG ACCESS PERM PRE COND</CATEGORY>
            <DESCRIPTION>
                <P>
                    <L-1 L="EN">This is a textual description of a pre-
                       condition</L-1>
                </P>
            </DESCRIPTION>
        </STRUCTURED-REQ>
        <STRUCTURED-REQ>
            <SHORT-NAME>runcondition
            <CATEGORY>DIAG_ACCESS_PERM_RUN_COND</CATEGORY>
            <DESCRIPTION>
                <P>
                    <L-1 L="EN">This is a textual description of a run-
                       condition</L-1>
                </P>
            </DESCRIPTION>
        </STRUCTURED-REQ>
    </INTRODUCTION>
    <DIAGNOSTIC-SESSION-REFS>
        <DIAGNOSTIC-SESSION-REF DEST="DIAGNOSTIC-SESSION">/AUTOSAR/
           UseCase 230/ExampleSession</DIAGNOSTIC-SESSION-REF>
    </DIAGNOSTIC-SESSION-REFS>
    <SECURITY-LEVEL-REFS>
        <SECURITY-LEVEL-REF DEST="DIAGNOSTIC-SECURITY-LEVEL">/AUTOSAR/
           UseCase_230/ExampleSecurityLevel</SECURITY-LEVEL-REF>
    </SECURITY-LEVEL-REFS>
</DIAGNOSTIC-ACCESS-PERMISSION>
```

4.1.4 Decomposition of requirements

The StructuredReg can also be used for decomposition of requirements.




Figure 4.3: Decomposition of StructuredReq

In figure 4.3 the StructuredReqB has an upstream requirement to StructuredReqA realized by Traceable using <TRACE-REF>. The StructuredReqB itself is decomposed by StructuredReqB1 and StructuredReqB2. This is realized by the



attribute dependencies of StructuredReq. It contains two <TRACE>s which in turn use <TRACE-REF> again.

Listing 4.6: Example for decomposition of StructuredReq

```
<STRUCTURED-REO>
  <SHORT-NAME>A</SHORT-NAME>
  <CATEGORY>REQUIREMENT_ITEM</CATEGORY>
  <DATE>2019-07-19</DATE>
  <ISSUED-BY>OEM</ISSUED-BY>
 <TYPE>valid</TYPE>
  <IMPORTANCE>High</IMPORTANCE>
</STRUCTURED-REQ>
<STRUCTURED-REQ>
  <SHORT-NAME>B</SHORT-NAME>
  <CATEGORY>REQUIREMENT ITEM</CATEGORY>
  <TRACE-REFS>
    <TRACE-REF DEST="STRUCTURED-REO">OEM/Documentation/
       DecompositionExample/A</TRACE-REF>
  </TRACE-REFS>
  <DATE>2019-07-19</DATE>
  <ISSUED-BY>OEM</ISSUED-BY>
  <TYPE>valid</TYPE>
  <IMPORTANCE>High</IMPORTANCE>
  <DEPENDENCIES>
   <TRACE>
     <SHORT-NAME>DECOMPB1
     <LONG-NAME>
       <L-4 L="EN">Decomposition element 1</L-4>
     </LONG-NAME>
     <CATEGORY>DECOMPOSITION</CATEGORY>
     <TRACE-REFS>
       <TRACE-REF DEST="STRUCTURED-REQ">OEM/Documentation/
          DecompositionExample/B1</TRACE-REF>
     </TRACE-REFS>
   </TRACE>
   <TRACE>
     <SHORT-NAME>DECOMPB2</SHORT-NAME>
     <LONG-NAME>
       <L-4 L="EN">Decomposition element 2</L-4>
     <CATEGORY>DECOMPOSITION</CATEGORY>
     <TRACE-REFS>
       <TRACE-REF DEST="STRUCTURED-REO">OEM/Documentation/
          DecompositionExample/B2</TRACE-REF>
     </TRACE-REFS>
   </TRACE>
  </DEPENDENCIES>
</STRUCTURED-REQ>
<STRUCTURED-REQ>
  <SHORT-NAME>B1</SHORT-NAME>
  <CATEGORY>REQUIREMENT ITEM</CATEGORY>
 <DATE>2019-07-19</DATE>
  <ISSUED-BY>OEM</ISSUED-BY>
  <TYPE>valid</TYPE>
  <IMPORTANCE>High</IMPORTANCE>
```



- </STRUCTURED-REQ>
- <STRUCTURED-REQ>
 - <SHORT-NAME>B2</SHORT-NAME>
 - <CATEGORY>REQUIREMENT_ITEM</CATEGORY>
 - **<DATE>**2019-07-19**</DATE>**
 - <ISSUED-BY>OEM</ISSUED-BY>
 - <TYPE>valid</TYPE>
 - <IMPORTANCE>High</IMPORTANCE>
- </STRUCTURED-REQ>



A Mentioned Class Tables

For the sake of completeness, this chapter contains a set of class tables representing meta-classes mentioned in the context of this document but which are not contained directly in the scope of describing specific meta-model semantics.

Class	ARElement (abstract)			
Package	M2::AUTOSARTemplates:	:GenericS	Structure::	GeneralTemplateClasses::ARPackage
Note	An element that can be de packages of course).	fined star	nd-alone,	.e. without being part of another element (except for
Base	ARObject, CollectableElei	ment, <mark>Ide</mark>	ntifiable, I	MultilanguageReferrable, PackageableElement, Referrable
Subclasses	Type, BaseType, Blueprint Entry, BuildActionManifest BswModuleEntryBlueprint Specification, ConstantSp Descriptor, CpSoftwareClt CryptoServiceKey, Crypto TransformationSet, DataTy DiagnosticContributionSet EcucDestinationUriDefSet ToEndProtectionSet, EthIp FMFeatureMap, FMFeatur Category, HwElement, Hw Design, Implementation, In CycleInfoSet, LifeCycleSta DeclarationMappingSet, P MappingSet, PortPrototyp PredefinedVariant, RapidF ClientEventGroupTimingC TimingConfig, SomeipSdS Type, SwRecordLayout, S SystemSignal, SystemSig	Mappings t, Calibrat Mapping, ecification usterMapp ServiceP / PeMappi , Docume , EcucMo Props, Ei reModel, I / Type, IPS nterpolatio thysicalDine eBlueprin onfig, Son ServerSer wSystemenalGroup	Set, BswEionParam Collection MappingSet, CongSet, Dia Con	cclRole, AliasNameSet, ApplicationPartition, AutosarData ntryRelationshipSet, BswModuleDescription, BswModule eterValueSet, ClientIdDefinitionSet, ClientServerInterfaceTon, CompuMethod, ConsistencyNeedsBlueprintSet, Constant Set, CpSoftwareCluster, CpSoftwareClusterBinaryManifest pSoftwareClusterResourcePool, CryptoServiceCertificate, ryptoServiceQueue, DataConstr, DataExchangePoint, Data agnosticCommonElement, DiagnosticConnection, 2EProfileCompatibilityProps, EcucDefinitionCollection, gurationValues, EcucModuleDef, EcucValueCollection, End npProps, EthTcplpProps, EvaluatedVariantSet, FMFeature, eselectionSet, FlatMap, GeneralPurposeConnection, Hw Props, IPv6ExtHeaderFilterSet, IdsCommonElement, Ids MappingSet, J1939ControllerApplication, KeywordSet, Life McFunction, McGroup, ModeDeclarationGroup, Mode PhysicalDimensionMappingSet, PortInterface, PortInterface IdVariantCriterion, PostBuildVariantCriterionValueSet, SdgDef, SignalServiceTranslationPropsSet, SomeipSd tentServiceInstanceConfig, SomeipSdServerEventGroup aceConfig, SwAddrMethod, SwAxisType, SwComponent SystemconstantValueSet, SwcBswMapping, System, ftwareClusterMappingSet, TcpOptionFilterSet, Timing ationPropsSet, Unit, UnitGroup, ViewMapSet
Attribute	Туре	Mult.	Kind	Note
_	_		<u> </u>	_

Table A.1: ARElement

Class	ARPackage	ARPackage				
Package	M2::AUTOSARTemplates::G	M2::AUTOSARTemplates::GenericStructure::GeneralTemplateClasses::ARPackage				
Note	AUTOSAR package, allowin	AUTOSAR package, allowing to create top level packages to structure the contained ARElements.				
		ARPackages are open sets. This means that in a file based description system multiple files can be used to partially describe the contents of a package.				
	This is an extended version of MSR's SW-SYSTEM.					
Base	ARObject, AtpBlueprint, Atp Referrable	ARObject, AtpBlueprint, AtpBlueprintable, CollectableElement, Identifiable, MultilanguageReferrable, Referrable				
Attribute	Туре					





Class	ARPackage			
arPackage	ARPackage	*	aggr	This represents a sub package within an ARPackage, thus allowing for an unlimited package hierarchy.
				Stereotypes: atpSplitable; atpVariation Tags: atp.Splitkey=arPackage.shortName, arPackage.variation Point.shortLabel vh.latestBindingTime=blueprintDerivationTime xml.sequenceOffset=30
element	PackageableElement	*	aggr	Elements that are part of this package
				Stereotypes: atpSplitable; atpVariation Tags: atp.Splitkey=element.shortName, element.variation Point.shortLabel vh.latestBindingTime=systemDesignTime xml.sequenceOffset=20
referenceBase	ReferenceBase	*	aggr	This denotes the reference bases for the package. This is the basis for all relative references within the package. The base needs to be selected according to the base attribute within the references.
				Stereotypes: atpSplitable Tags: atp.Splitkey=referenceBase.shortLabel xml.sequenceOffset=10

Table A.2: ARPackage

Class	AliasNameSet					
Package	M2::AUTOSARTemplates::CommonStructure::FlatMap					
Note	This meta-class represents a set of AliasNames. The AliasNameSet can for example be an input to the A2L-Generator.					
	Tags:atp.recommendedPackage=AliasNameSets					
Base	ARElement, ARObject, AtpBlueprint, AtpBlueprintable, CollectableElement, Identifiable, Multilanguage Referrable, PackageableElement, Referrable					
Attribute	Туре	Mult.	Kind	Note		
aliasName	AliasNameAssignment	1*	aggr	AliasNames contained in the AliasNameSet.		
				Stereotypes: atpSplitable; atpVariation		

Table A.3: AliasNameSet

Class	AnylnstanceRef	AnyInstanceRef				
Package	M2::AUTOSARTemplates:	M2::AUTOSARTemplates::GenericStructure::GeneralTemplateClasses::AnyInstanceRef				
Note		Describes a reference to any instance in an AUTOSAR model. This is the most generic form of an instance ref. Refer to the superclass notes for more details.				
Base	ARObject, AtpInstanceRe	ARObject, AtplnstanceRef				
Attribute	Туре	Mult.	Kind	Note		





Class	AnylnstanceRef			
base	AtpClassifier	1	ref	This is the base from which navigation path begins.
				Stereotypes: atpDerived
contextElement	AtpFeature	*	ref	This is one step in the navigation path specified by the instance ref.
target	AtpFeature	1	ref	This is the target of the instance ref.

Table A.4: AnyInstanceRef

Class	ApplicationArrayDataT	ApplicationArrayDataType				
Package	M2::AUTOSARTemplate	s::SWCom _l	oonentTer	nplate::Datatype::Datatypes		
Note	An application data type	which is ar	array, ea	ch element is of the same application data type.		
	Tags:atp.recommended	Package=A	pplication	DataTypes		
Base	Blueprintable, AtpClassi	ARElement, ARObject, ApplicationCompositeDataType, ApplicationDataType, AtpBlueprint, Atp Blueprintable, AtpClassifier, AtpType, AutosarDataType, CollectableElement, Identifiable, Multilanguage Referrable, PackageableElement, Referrable				
Attribute	Туре	Type Mult. Kind Note				
dynamicArray SizeProfile	String	01	attr	Specifies the profile which the array will follow if it is a variable size array.		
element	ApplicationArray Element	01	aggr	This association implements the concept of an array element. That is, in some cases it is necessary to be able to identify single array elements, e.g. as input values for an interpolation routine.		

Table A.5: ApplicationArrayDataType

Class	ApplicationArrayElement					
Package	M2::AUTOSARTemplates::SWComponentTemplate::Datatype::DataPrototypes					
Note	Describes the properties	of the elen	nents of a	n application array data type.		
Base	ARObject, ApplicationCollidentifiable, Multilanguage			aPrototype, AtpFeature, AtpPrototype, DataPrototype, able		
Attribute	Туре	Type Mult. Kind Note				
arraySize Handling	ArraySizeHandling Enum	01	attr	The way how the size of the array is handled.		
arraySize Semantics	ArraySizeSemantics Enum	01	attr	This attribute controls how the information about the array size shall be interpreted.		
indexDataType	ApplicationPrimitive DataType	01	ref	This reference can be taken to assign a CompuMethod of category TEXTTABLE to the array. The texttable entries associate a textual value to an index number such that the element with that index number is represented by a symbolic name.		
maxNumberOf Elements	PositiveInteger	01	attr	The maximum number of elements that the array can contain.		
				Stereotypes: atpVariation Tags:vh.latestBindingTime=preCompileTime		

Table A.6: ApplicationArrayElement



Class	ApplicationCompositeD.	ApplicationCompositeDataType (abstract)				
Package	M2::AUTOSARTemplates:	M2::AUTOSARTemplates::SWComponentTemplate::Datatype::Datatypes				
Note	Abstract base class for all	Abstract base class for all application data types composed of other data types.				
Base		ARElement, ARObject, ApplicationDataType, AtpBlueprint, AtpBlueprintable, AtpClassifier, AtpType, AutosarDataType, CollectableElement, Identifiable, MultilanguageReferrable, PackageableElement, Referrable				
Subclasses	ApplicationArrayDataType	ApplicationArrayDataType, ApplicationRecordDataType				
Attribute	Туре	Mult.	Kind	Note		
_	_	_	_	-		

Table A.7: ApplicationCompositeDataType

Class	ApplicationCompositeE	ApplicationCompositeElementDataPrototype (abstract)				
Package	M2::AUTOSARTemplates	::SWCom	onentTer	nplate::Datatype::DataPrototypes		
Note	This class represents a data prototype which is aggregated within a composite application data type (record or array). It is introduced to provide a better distinction between target and context in instance Refs.					
Base	ARObject, AtpFeature, A	ARObject, AtpFeature, AtpPrototype, DataPrototype, Identifiable, MultilanguageReferrable, Referrable				
Subclasses	ApplicationArrayElement,	ApplicationArrayElement, ApplicationRecordElement				
Attribute	Туре	Mult.	Kind	Note		
type	ApplicationDataType	ApplicationDataType 01 tref This represents the corresponding data type.				
				Stereotypes: isOfType		

Table A.8: ApplicationCompositeElementDataPrototype

Class	ApplicationDataType (abstract)				
Package	M2::AUTOSARTemplates::SWComponentTemplate::Datatype::Datatypes				
Note	ApplicationDataType defines a data type from the application point of view. Especially it should be used whenever something "physical" is at stake.				
	An ApplicationDataType represents a set of values as seen in the application model, such as measurement units. It does not consider implementation details such as bit-size, endianess, etc.				
	It should be possible to model the application level aspects of a VFB system by using ApplicationData Types only.				
Base	ARElement, ARObject, AtpBlueprint, AtpBlueprintable, AtpClassifier, AtpType, AutosarDataType, CollectableElement, Identifiable, MultilanguageReferrable, PackageableElement, Referrable				
Subclasses	ApplicationCompositeDataType, ApplicationPrimitiveDataType				
Attribute	Type Mult. Kind Note				
_	- - -				

Table A.9: ApplicationDataType

Class	ApplicationPrimitiveDataType
Package	M2::AUTOSARTemplates::SWComponentTemplate::Datatype::Datatypes
Note	A primitive data type defines a set of allowed values.
	Tags:atp.recommendedPackage=ApplicationDataTypes
Base	ARElement, ARObject, ApplicationDataType, AtpBlueprint, AtpBlueprintable, AtpClassifier, AtpType, AutosarDataType, CollectableElement, Identifiable, MultilanguageReferrable, PackageableElement, Referrable





Class	ApplicationPrimitiveDataType					
Attribute	Туре	Mult.	Kind	Note		
_	-	-	-	-		

Table A.10: ApplicationPrimitiveDataType

Class	ApplicationRecordData	ApplicationRecordDataType				
Package	M2::AUTOSARTemplate	s::SWCom	onentTer	mplate::Datatype::Datatypes		
Note	An application data type	which can	be decom	posed into prototypes of other application data types.		
	Tags:atp.recommended	Package=A	pplication	DataTypes		
Base	Blueprintable, AtpClassi	ARElement, ARObject, ApplicationCompositeDataType, ApplicationDataType, AtpBlueprint, Atp Blueprintable, AtpClassifier, AtpType, AutosarDataType, CollectableElement, Identifiable, Multilanguage Referrable, PackageableElement, Referrable				
Attribute	Туре	Mult.	Kind	Note		
element	ApplicationRecord	*	aggr	Specifies an element of a record.		
(ordered)	Element			The aggregation of ApplicationRecordElement is subject to variability with the purpose to support the conditional existence of elements inside a ApplicationrecordData Type.		
				Stereotypes: atpVariation Tags:vh.latestBindingTime=preCompileTime		

Table A.11: ApplicationRecordDataType

Class	ApplicationRecordElem	ApplicationRecordElement				
Package	M2::AUTOSARTemplates:	::SWComp	onentTer	nplate::Datatype::DataPrototypes		
Note	Describes the properties	of one par	ticular ele	ment of an application record data type.		
Base		ARObject, ApplicationCompositeElementDataPrototype, AtpFeature, AtpPrototype, DataPrototype, Identifiable, MultilanguageReferrable, Referrable				
Attribute	Туре	Mult.	Kind	Note		
isOptional	Boolean	01	attr	This attribute represents the ability to declare the enclosing ApplicationRecordElement as optional. This means the that, at runtime, the ApplicationRecord Element may or may not have a valid value and shall therefore be ignored.		
				The underlying runtime software provides means to set the ApplicationRecordElement as not valid at the sending end of a communication and determine its validity at the receiving end.		

Table A.12: ApplicationRecordElement

Class	ApplicationSwComponentType					
Package	M2::AUTOSARTemplates::SWComponentTemplate::Components					
Note	The ApplicationSwComponentType is used to represent the application software.					
	Tags:atp.recommendedPackage=SwComponentTypes					
Base	ARElement, ARObject, AtomicSwComponentType, AtpBlueprint, AtpBlueprintable, AtpClassifier, Atp Type, CollectableElement, Identifiable, MultilanguageReferrable, PackageableElement, Referrable, Sw ComponentType					





Class	ApplicationSwComponentType				
Attribute	Type Mult. Kind Note				
_	-	-	-	-	

Table A.13: ApplicationSwComponentType

Enumeration	ArraySizeSemanticsEnum						
Package	M2::AUTOSARTemplates::CommonStructure::ImplementationDataTypes						
Note	This type controls how the information about the number of elements in an ApplicationArrayDataType is to be interpreted.						
Literal	Description						
fixedSize	This means that the ApplicationArrayDataType will always have a fixed number of elements.						
	Tags:atp.EnumerationLiteralIndex=0						
variableSize	This implies that the actual number of elements in the ApplicationArrayDataType might vary at run-time. The value of arraySize represents the maximum number of elements in the array.						
	Tags:atp.EnumerationLiteralIndex=1						

Table A.14: ArraySizeSemanticsEnum

Class	AssemblySwConnector	AssemblySwConnector				
Package	M2::AUTOSARTemplates	s::SWCom _l	ponentTer	mplate::Composition		
Note	1	AssemblySwConnectors are exclusively used to connect SwComponentPrototypes in the context of a CompositionSwComponentType.				
Base	ARObject, AtpClassifier, Referrable, SwConnecto	,	e, AtpStru	uctureElement, Identifiable, MultilanguageReferrable,		
Attribute	Туре	Type Mult. Kind Note				
provider	AbstractProvidedPort Prototype	01	iref	Instance of providing port. InstanceRef implemented by:PPortInComposition InstanceRef		
requester	AbstractRequiredPort Prototype	01	iref	Instance of requiring port. InstanceRef implemented by:RPortInComposition InstanceRef		

Table A.15: AssemblySwConnector

Class	AtomicSwComponentTyp	AtomicSwComponentType (abstract)				
Package	M2::AUTOSARTemplates::	SWCom	oonentTer	nplate::Components		
Note		An atomic software component is atomic in the sense that it cannot be further decomposed and distributed across multiple ECUs.				
Base		ARElement, ARObject, AtpBlueprint, AtpBlueprintable, AtpClassifier, AtpType, CollectableElement, Identifiable, MultilanguageReferrable, PackageableElement, Referrable, SwComponentType				
Subclasses	ApplicationSwComponentType, ComplexDeviceDriverSwComponentType, EcuAbstractionSwComponent Type, NvBlockSwComponentType, SensorActuatorSwComponentType, ServiceProxySwComponent Type, ServiceSwComponentType					
Attribute	Туре	Mult.	Kind	Note		





Class	AtomicSwComponentType (abstract)			
internalBehavior	SwcInternalBehavior	01	aggr	The SwcInternalBehaviors owned by an AtomicSw ComponentType can be located in a different physical file. Therefore the aggregation is < <atpsplitable>>>.</atpsplitable>
				Stereotypes: atpSplitable; atpVariation Tags: atp.Splitkey=internalBehavior.shortName, internal Behavior.variationPoint.shortLabel vh.latestBindingTime=preCompileTime
symbolProps	SymbolProps	01	aggr	This represents the SymbolProps for the AtomicSw ComponentType.
				Stereotypes: atpSplitable Tags:atp.Splitkey=symbolProps.shortName

Table A.16: AtomicSwComponentType

Class	AutosarDataPrototype (a	AutosarDataPrototype (abstract)				
Package	M2::AUTOSARTemplates:	:SWComp	onentTen	nplate::Datatype::DataPrototypes		
Note	Base class for prototypica	I roles of a	an Autosa	rDataType.		
Base	ARObject, AtpFeature, At	ARObject, AtpFeature, AtpPrototype, DataPrototype, Identifiable, MultilanguageReferrable, Referrable				
Subclasses	ArgumentDataPrototype,	Paramete	DataProte	otype, VariableDataPrototype		
Attribute	Туре	Mult.	Kind	Note		
type	AutosarDataType	AutosarDataType 01 tref This represents the corresponding data type.				
				Stereotypes: isOfType		

Table A.17: AutosarDataPrototype

Class	CompositionSwCompon	CompositionSwComponentType			
Package	M2::AUTOSARTemplates:	:SWComp	onentTer	nplate::Composition	
Note	ComponentTypes) as well each others and towards t structures of software-com	A CompositionSwComponentType aggregates SwComponentPrototypes (that in turn are typed by Sw ComponentTypes) as well as SwConnectors for primarily connecting SwComponentPrototypes among each others and towards the surface of the CompositionSwComponentType. By this means hierarchical structures of software-components can be created. Tags:atp.recommendedPackage=SwComponentTypes			
Base		ARElement, ARObject, AtpBlueprint, AtpBlueprintable, AtpClassifier, AtpType, CollectableElement, Identifiable, MultilanguageReferrable, PackageableElement, Referrable, SwComponentType			
Attribute	Туре	Type Mult. Kind Note			
component	SwComponent Prototype	*	aggr	The instantiated components that are part of this composition. The aggregation of SwComponentPrototype is subject to variability with the purpose to support the conditional existence of a SwComponentPrototype. Please be aware: if the conditional existence of Sw ComponentPrototypes is resolved post-build the deselected SwComponentPrototypes are still contained in the ECUs build but the instances are inactive in in that they are not scheduled by the RTE. The aggregation is marked as atpSplitable in order to allow the addition of service components to the ECU extract during the ECU integration.	





Class	CompositionSwCompor	nentType		
				△ The use case for having 0 components owned by the CompositionSwComponentType could be to deliver an empty CompositionSwComponentType to e.g. a supplier for filling the internal structure.
				Stereotypes: atpSplitable; atpVariation Tags: atp.Splitkey=component.shortName, component.variation Point.shortLabel vh.latestBindingTime=postBuild
connector	SwConnector	*	aggr	SwConnectors have the principal ability to establish a connection among PortPrototypes. They can have many roles in the context of a CompositionSwComponentType. Details are refined by subclasses.
				The aggregation of SwConnectors is subject to variability with the purpose to support variant data flow.
				The aggregation is marked as atpSplitable in order to allow the extension of the ECU extract with AssemblySw Connectors between ApplicationSwComponentTypes and ServiceSwComponentTypes during the ECU integration.
				Stereotypes: atpSplitable; atpVariation Tags: atp.Splitkey=connector.shortName, connector.variation Point.shortLabel vh.latestBindingTime=postBuild
constantValue Mapping	ConstantSpecification MappingSet	*	ref	Reference to the ConstantSpecificationMapping to be applied for initValues of PPortComSpecs and RPortCom Spec.
				Stereotypes: atpSplitable Tags:atp.Splitkey=constantValueMapping
dataType Mapping	DataTypeMappingSet	*	ref	Reference to the DataTypeMapping to be applied for the used ApplicationDataTypes in PortInterfaces.
				Background: when developing subsystems it may happen that ApplicationDataTypes are used on the surface of CompositionSwComponentTypes. In this case it would be reasonable to be able to also provide the intended mapping to the ImplementationDataTypes. However, this mapping shall be informal and not technically binding for the implementors mainly because the RTE generator is not concerned about the CompositionSwComponent Types.
				Rationale: if the mapping of ApplicationDataTypes on the delegated and inner PortPrototype matches then the mapping to ImplementationDataTypes is not impacting compatibility.
				Stereotypes: atpSplitable Tags:atp.Splitkey=dataTypeMapping
instantiation RTEEventProps	InstantiationRTEEvent Props	*	aggr	This allows to define instantiation specific properties for RTE Events, in particular for instance specific scheduling.
				Stereotypes: atpSplitable; atpVariation Tags: atp.Splitkey=instantiationRTEEventProps.shortLabel, instantiationRTEEventProps.variationPoint.shortLabel vh.latestBindingTime=codeGenerationTime

Table A.18: CompositionSwComponentType



Class	CompuConstTextCon	CompuConstTextContent				
Package	M2::MSR::AsamHdo::C	M2::MSR::AsamHdo::ComputationMethod				
Note	This meta-class represe	This meta-class represents the textual content of a scale.				
Base	ARObject, CompuCons	ARObject, CompuConstContent				
Attribute	Туре	Type Mult. Kind Note				
vt	VerbatimString	01	attr	This represents a textual constant in the computation method.		

Table A.19: CompuConstTextContent

Class	CompuMethod						
Package	M2::MSR::AsamHdo::Co	M2::MSR::AsamHdo::ComputationMethod					
Note	This meta-class represer mathematical representa		ty to expr	ess the relationship between a physical value and the			
	Note that this is still inder formula how the internal			ical implementation in data types. It only specifies the o its physical pendant.			
	Tags:atp.recommendedF	ackage=C	ompuMet	hods			
Base	ARElement, ARObject, A Referrable, Packageable			eprintable, CollectableElement, Identifiable, Multilanguage			
Attribute	Туре	Type Mult. Kind Note					
compulnternal ToPhys	Compu	01	aggr	This specifies the computation from internal values to physical values.			
				Tags:xml.sequenceOffset=80			
compuPhysTo Internal	Compu	01	aggr	This represents the computation from physical values to the internal values.			
				Tags:xml.sequenceOffset=90			
displayFormat	DisplayFormatString	01	attr	This property specifies, how the physical value shall be displayed e.g. in documents or measurement and calibration tools.			
				Tags:xml.sequenceOffset=20			
unit	Unit	01	ref	This is the physical unit of the Physical values for which the CompuMethod applies.			
				Tags:xml.sequenceOffset=30			

Table A.20: CompuMethod

Class	CompuRationalCoeffs	CompuRationalCoeffs				
Package	M2::MSR::AsamHdo::Cor	nputationN	/lethod			
Note		This meta-class represents the ability to express a rational function by specifying the coefficients of nominator and denominator.				
Base	ARObject	ARObject				
Attribute	Туре	Mult.	Kind	Note		
compu	CompuNominator	01	aggr	This is the denominator of the expression.		
Denominator	Denominator			Tags:xml.sequenceOffset=30		
compu	CompuNominator	01	aggr	This is the numerator of the rational expression.		
Numerator	Denominator			Tags:xml.sequenceOffset=20		

Table A.21: CompuRationalCoeffs



Class	CompuScale			
Package	M2::MSR::AsamHdo::Com	nputation	Method	
Note	This meta-class represent	s the abili	ty to spec	ify one segment of a segmented computation method.
Base	ARObject			
Attribute	Туре	Mult.	Kind	Note
compulnverse Value	CompuConst	01	aggr	This is the inverse value of the constraint. This supports the case that the scale is not reversible per se.
				Tags:xml.sequenceOffset=60
compuScale	CompuScaleContents	01	aggr	This represents the computation details of the scale.
Contents				Tags: xml.roleElement=false xml.roleWrapperElement=false xml.sequenceOffset=70 xml.typeElement=false xml.typeWrapperElement=false
desc	MultiLanguageOverview Paragraph	01	aggr	<desc> represents a general but brief description of the object in question.</desc>
				Tags:xml.sequenceOffset=30
lowerLimit	Limit	01	attr	This specifies the lower limit of the scale.
				Stereotypes: atpVariation Tags: vh.latestBindingTime=preCompileTime xml.sequenceOffset=40
mask	PositiveInteger	01	attr	In difference to all the other computational methods every COMPU-SCALE will be applied including the bit MASK. Therefore it is allowed for this type of COMPU-METHOD, that COMPU-SCALES overlap.
				To calculate the string reverse to a value, the string has to be split and the according value for each substring has to be summed up. The sum is finally transmitted.
				The processing has to be done in order of the COMPU-SCALE elements.
				Tags:xml.sequenceOffset=35
shortLabel	Identifier	01	attr	This element specifies a short name for the particular scale. The name can for example be used to derive a programming language identifier.
				Tags:xml.sequenceOffset=20
symbol	Cldentifier	01	attr	The symbol, if provided, is used by code generators to get a C identifier for the CompuScale. The name will be used as is for the code generation, therefore it needs to be unique within the generation context.
				Tags:xml.sequenceOffset=25
upperLimit	Limit	01	attr	This specifies the upper limit of a of the scale.
				Stereotypes: atpVariation Tags: vh.latestBindingTime=preCompileTime xml.sequenceOffset=50

Table A.22: CompuScale



Class	DataConstr					
Package	M2::MSR::AsamHdo::Con	straints::C	BlobalCon	straints		
Note	This meta-class represent	s the abili	ty to spec	ify constraints on data.		
	Tags:atp.recommendedPa	Tags:atp.recommendedPackage=DataConstrs				
Base	ARElement, ARObject, AtpBlueprint, AtpBlueprintable, CollectableElement, Identifiable, Multilanguage Referrable, PackageableElement, Referrable					
Attribute	Туре	Mult.	Kind	Note		
dataConstrRule	DataConstrRule	*	aggr	This is one particular rule within the data constraints.		
				Tags: xml.roleElement=true xml.roleWrapperElement=true xml.sequenceOffset=30 xml.typeElement=false xml.typeWrapperElement=false		

Table A.23: DataConstr

Class	DataConstrRule				
Package	M2::MSR::AsamHdo::Constraints::GlobalConstraints				
Note	This meta-class represer	nts the abili	ity to expr	ess one specific data constraint rule.	
Base	ARObject				
Attribute	Туре	Type Mult. Kind Note			
constrLevel	Integer	01	attr	This attribute describes the category of a constraint. One of its functions is in the area of constraint violation, where it can be used from a certain level, to produce error messages.	
				The lower the level, the more stringent the check.	
				Used to distinguish hard or soft limits.	
				Tags:xml.sequenceOffset=20	
internalConstrs	InternalConstrs	01	aggr	Describes the limitations applicable on the internal domain (as opposed to the physical domain).	
				Tags:xml.sequenceOffset=40	
physConstrs	PhysConstrs	01	aggr	Describes the limitations applicable on the physical domain (as opposed to the internal domain).	
				Tags:xml.sequenceOffset=30	

Table A.24: DataConstrRule

Class	DataPrototype (abstrac	DataPrototype (abstract)				
Package	M2::AUTOSARTemplate	M2::AUTOSARTemplates::SWComponentTemplate::Datatype::DataPrototypes				
Note	Base class for prototypic	Base class for prototypical roles of any data type.				
Base	ARObject, AtpFeature, A	ARObject, AtpFeature, AtpPrototype, Identifiable, MultilanguageReferrable, Referrable				
Subclasses	ApplicationCompositeEle	ementData	Prototype	, AutosarDataPrototype		
Attribute	Туре	Mult.	Kind	Note		
swDataDef Props	SwDataDefProps	01	aggr	This property allows to specify data definition properties which apply on data prototype level.		

Table A.25: DataPrototype



Class	DataTypeMap				
Package	M2::AUTOSARTemplates:	:SWCom	onentTer	mplate::Datatype::Datatypes	
Note	This class represents the relationship between ApplicationDataType and its implementing Abstract ImplementationDataType.				
Base	ARObject	ARObject			
Attribute	Туре	Mult.	Kind	Note	
applicationData Type	ApplicationDataType	01	ref	This is the corresponding ApplicationDataType	
implementation DataType	AbstractImplementation DataType	01	ref	This is the corresponding AbstractImplementationData Type.	

Table A.26: DataTypeMap

Class	DataTypeMappingSet					
Package	M2::AUTOSARTemplates:	:SWComp	onentTer	nplate::Datatype::Datatypes		
Note	This class represents a list of mappings between ApplicationDataTypes and ImplementationDataTypes. In addition, it can contain mappings between ImplementationDataTypes and ModeDeclarationGroups.					
	Tags:atp.recommendedPage	Tags:atp.recommendedPackage=DataTypeMappingSets				
Base	ARElement, ARObject, AtpBlueprint, AtpBlueprintable, CollectableElement, Identifiable, Multilanguage Referrable, PackageableElement, Referrable					
Attribute	Туре	Mult.	Kind	Note		
dataTypeMap	DataTypeMap	*	aggr	This is one particular association between an Application DataType and its AbstractImplementationDataType.		
modeRequest TypeMap	ModeRequestTypeMap	*	aggr	This is one particular association between an Mode DeclarationGroup and its AbstractImplementationData Type.		

Table A.27: DataTypeMappingSet

Class	DiagnosticAccessPermission					
Package	M2::AUTOSARTemplates:	:Diagnost	icExtract:	Dcm		
Note		This represents the specification of whether a given service can be accessed according to the existence of meta-classes referenced by a particular DiagnosticAccessPermission.				
	In other words, this meta-class acts as a mapping element between several (otherwise unrelated) pieces of information that are put into context for the purpose of checking for access rights.					
	Tags:atp.recommendedPackage=DiagnosticAccessPermissions					
Base	ARElement, ARObject, C Referrable, PackageableE			DiagnosticCommonElement, Identifiable, Multilanguage		
Attribute	Туре	Mult.	Kind	Note		
diagnostic Session	DiagnosticSession	*	ref	This represents the associated DiagnosticSessions		
environmental Condition	Diagnostic EnvironmentalCondition	01	ref	This represents the environmental conditions associated with the access permission.		
securityLevel	DiagnosticSecurityLevel	*	ref	This represents the associated DiagnosticSecurityLevels		

Table A.28: DiagnosticAccessPermission



Class	Eculnstance							
Package	M2::AUTOSARTemplates	::SystemTe	emplate::l	Fibex::FibexCore::CoreTopology				
Note	ECUInstances are used to define the ECUs used in the topology. The type of the ECU is defined by a reference to an ECU specified with the ECU resource description.							
	Tags:atp.recommendedPackage=EcuInstances							
Base	ARObject, CollectableElement, FibexElement, Identifiable, MultilanguageReferrable, Packageable Element, Referrable							
Attribute	Туре	Mult.	Kind	Note				
associatedCom IPduGroup	ISignallPduGroup	*	ref	With this reference it is possible to identify which ISignal IPduGroups are applicable for which Communication Connector/ ECU.				
				Only top level ISignallPduGroups shall be referenced by an EcuInstance. If an ISignallPduGroup contains other ISignallPduGroups than these contained ISignallPduGroups shall not be referenced by the EcuInstance. Contained ISignallPduGroups are associated to an Ecu Instance via the top level ISignallPduGroup.				
associated Consumed Provided	ConsumedProvided ServiceInstanceGroup	*	ref	With this reference it is possible to identify which ConsumedProvidedServiceInstanceGroups are applicable for which ECUInstance.				
ServiceInstance Group				Stereotypes: atpVariation Tags:vh.latestBindingTime=postBuild				
associatedPdur IPduGroup	PdurlPduGroup	*	ref	With this reference it is possible to identify which PduR IPdu Groups are applicable for which Communication Connector/ ECU.				
clientIdRange	ClientIdRange	01	aggr	Restriction of the Client Identifier for this Ecu to an allowed range of numerical values. The Client Identifier of the transaction handle is generated by the client RTE for inter-Ecu Client/Server communication.				
com Configuration GwTimeBase	TimeValue	01	attr	The period between successive calls to Com_Main FunctionRouteSignals of the AUTOSAR COM module in seconds.				
com ConfigurationRx TimeBase	TimeValue	01	attr	The period between successive calls to Com_Main FunctionRx of the AUTOSAR COM module in seconds.				
com ConfigurationTx TimeBase	TimeValue	01	attr	The period between successive calls to Com_Main FunctionTx of the AUTOSAR COM module in seconds.				
comEnable MDTForCyclic Transmission	Boolean	01	attr	Enables for the Com module of this Eculnstance the minimum delay time monitoring for cyclic and repeated transmissions (TransmissionModeTiming has cyclic Timing assigned or eventControlledTiming with numberOf Repetitions > 0).				
commController	Communication	1*	aggr	CommunicationControllers of the ECU.				
	Controller			Stereotypes: atpVariation Tags:vh.latestBindingTime=postBuild				
connector	Communication	*	aggr	All channels controlled by a single controller.				
	Connector			Stereotypes: atpVariation Tags:vh.latestBindingTime=postBuild				
dltConfig	DltConfig	01	aggr	Describes the Dlt configuration on this Eculnstance.				
dolpConfig	DolpConfig	01	aggr	Dolp configuration on this Eculnstance.				
				Tags:atp.Status=draft				





Class	Eculnstance			
ethSwitchPort Group Derivation	Boolean	01	attr	Defines whether the derivation of SwitchPortGroups based on VLAN and/or CouplingPort.pncMapping shall be performed for this Eculnstance. If not defined the derivation shall not be done.
partition	EcuPartition	*	aggr	Optional definition of Partitions within an Ecu.
pncPrepare SleepTimer	TimeValue	01	attr	Time in seconds the PNC state machine shall wait in PNC_PREPARE_SLEEP.
pnc Synchronous Wakeup	Boolean	01	attr	If this parameter is available and set to true then all available PNCs will be woken up as soon as a channel wakeup occurs. This is ensured by adding all PNCs to all channel wakeup sources during upstream mapping.
pnResetTime	TimeValue	01	attr	Specifies the runtime of the reset timer in seconds. This reset time is valid for the reset of PN requests in the EIRA and in the ERA.
sleepMode Supported	Boolean	1	attr	Specifies whether the ECU instance may be put to a "low power mode"
				true: sleep mode is supported
				false: sleep mode is not supported
				Note: This flag may only be set to "true" if the feature is supported by both hardware and basic software.
tcplplcmpProps	EthTcplplcmpProps	01	ref	Eculnstance specific ICMP (Internet Control Message Protocol) attributes
tcplpProps	EthTcplpProps	01	ref	EcuInstance specific TcpIp Stack attributes.
v2xSupported	V2xSupportEnum	01	attr	This attribute is used to control the existence of the V2X stack on the given EcuInstance.
wakeUpOver BusSupported	Boolean	1	attr	Driver support for wakeup over Bus.

Table A.29: EcuInstance

Class	EcucModuleConfiguration	EcucModuleConfigurationValues						
Package	M2::AUTOSARTemplates::	M2::AUTOSARTemplates::ECUCDescriptionTemplate						
Note	Head of the configuration of Infrastructure.	Head of the configuration of one Module. A Module can be a BSW module as well as the RTE and ECU Infrastructure.						
	As part of the BSW modul roles:	As part of the BSW module description, the EcucModuleConfigurationValues element has two different roles:						
	The recommendedConfigu	The recommendedConfiguration contains parameter values recommended by the BSW module vendor.						
		The preconfiguredConfiguration contains values for those parameters which are fixed by the implementation and cannot be changed.						
		nese two EcucModuleConfigurationValues are used when the base EcucModuleConfigurationValues s part of the base ECU configuration) is created to fill parameters with initial values.						
	Tags:atp.recommendedPa	Tags:atp.recommendedPackage=EcucModuleConfigurationValuess						
Base	ARElement, ARObject, Co Element, Referrable	ARElement, ARObject, CollectableElement, Identifiable, MultilanguageReferrable, Packageable Element, Referrable						
Attribute	Туре	Mult.	Kind	Note				





Class	EcucModuleConfigurati	ionValues		
container	EcucContainerValue	*	aggr	Aggregates all containers that belong to this module configuration.
				atpVariation: [RS_ECUC_00078]
				Stereotypes: atpSplitable; atpVariation Tags: atp.Splitkey=container.definition, container.shortName, container.variationPoint.shortLabel vh.latestBindingTime=postBuild xml.sequenceOffset=10
definition	EcucModuleDef	01	ref	Reference to the definition of this EcucModule ConfigurationValues element. Typically, this is a vendor specific module configuration.
				Stereotypes: atpldentityContributor Tags:xml.sequenceOffset=-10
ecucDefEdition	RevisionLabelString	01	attr	This is the version info of the ModuleDef ECUC Parameter definition to which this values conform to / are based on.
				For the Definition of ModuleDef ECUC Parameters the AdminData shall be used to express the semantic changes. The compatibility rules between the definition and value revision labels is up to the module's vendor.
implementation ConfigVariant	EcucConfiguration VariantEnum	01	attr	Specifies the kind of deliverable this EcucModule ConfigurationValues element provides. If this element is not used in a particular role (e.g. preconfigured Configuration or recommendedConfiguration) then the value shall be one of VariantPreCompile, VariantLink Time, VariantPostBuild.
module Description	BswImplementation	01	ref	Referencing the BSW module description, which this EcucModuleConfigurationValues element is configuring. This is optional because the EcucModuleConfiguration Values element is also used to configure the ECU infrastructure (memory map) or Application SW-Cs. However in case the EcucModuleConfigurationValues are used to configure the module, the reference is mandatory in order to fetch module specific "common" published information.
postBuildVariant Used	Boolean	01	attr	Indicates whether a module implementation has or plans to have (i.e., introduced at link or post-build time) new post-build variation points. TRUE means yes, FALSE means no. If the attribute is not defined, FALSE semantics shall be assumed.

Table A.30: EcucModuleConfigurationValues

Class	EcucValueCollection	EcucValueCollection				
Package	M2::AUTOSARTemplates:	M2::AUTOSARTemplates::ECUCDescriptionTemplate				
Note	This represents the ancho	This represents the anchor point of the ECU configuration description.				
	Tags:atp.recommendedPa	Tags:atp.recommendedPackage=EcucValueCollections				
Base	ARElement, ARObject, C Element, Referrable	ARElement, ARObject, CollectableElement, Identifiable, MultilanguageReferrable, Packageable Element, Referrable				
Attribute	Туре	Mult.	Kind	Note		





Class	EcucValueCollection			
ecucValue	EcucModule ConfigurationValues	*	ref	References to the configuration of individual software modules that are present on this ECU.
				atpVariation: [RS_ECUC_00079]
				Stereotypes: atpVariation Tags:vh.latestBindingTime=preCompileTime
ecuExtract	System	01	ref	Represents the extract of the System Configuration that is relevant for the ECU configured with that ECU Configuration Description.

Table A.31: EcucValueCollection

Class	FlatInstanceDescriptor						
Package	M2::AUTOSARTemplates	M2::AUTOSARTemplates::CommonStructure::FlatMap					
Note	software system. The pur	rpose of th	is elemen	ent instance or data element) of the instance tree of a t is to map the various nested representations of this unique name (shortName) to it.			
	Use cases:						
	Specify unique n	ames of m	easurable	e data to be used by MCD tools			
	Specify unique n	ames of ca	alibration o	data to be used by MCD tool			
	 Specify a unique system description 		an instand	ce of a component prototype in the ECU extract of the			
	Note that in addition it is	possible to	assign al	ias names via AliasNameAssignment.			
Base	ARObject, Identifiable, M	lultilanguag	geReferra	ble, Referrable			
Attribute	Туре	Mult.	Kind	Note			
ecuExtract Reference	AtpFeature	01	iref	Refers to the instance in the ECU extract. This is valid only, if the FlatMap is used in the context of an ECU extract.			
				The reference shall be such that it uniquely defines the object instance. For example, if a data prototype is declared as a role within an SwcInternalBehavior, it is not enough to state the SwcInternalBehavior as context and the aggregated data prototype as target. In addition, the reference shall also include the complete path identifying instance of the component prototype and the Atomic SoftwareComponentType, which is refered by the particular SwcInternalBehavior.			
				Tags:xml.sequenceOffset=40 InstanceRef implemented by:AnyInstanceRef			
role	Identifier	01	attr	The role denotes the particular role of the downstream memory location described by this FlatInstanceDescriptor.			
				It applies to use case where one upstream object results in multiple downstream objects, e.g. ModeDeclaration GroupPrototypes which are measurable. In this case the RTE will provide locations for current mode, previous mode and next mode.			
rtePluginProps	RtePluginProps	01	aggr	The properties of a communication graph with respect to the utilization of RTE Implementation Plug-in.			
				Stereotypes: atpSplitable Tags:atp.Splitkey=rtePluginProps			
swDataDef Props	SwDataDefProps	01	aggr	The properties of this FlatInstanceDescriptor.			





Class	FlatInstanceDescri	ptor		
upstream Reference	AtpFeature	01	iref	Refers to the instance in the context of an "upstream" descriptions, wich could be the system or system extract description, the basic software module description or (if a flat map is used in preliminary context) a description of an atomic component or composition. This reference is optional in case the flat map is used in ECU context.
				The reference shall be such that it uniquely defines the object instance in the given context. For example, if a data prototype is declared as a role within an SwcInternal Behavior, it is not enough to state the SwcInternal Behavior as context and the aggregated data prototype as target. In addition, the reference shall also include the complete path identifying the instance of the component prototype that contains the particular instance of Swc InternalBehavior.
				Tags:xml.sequenceOffset=20 InstanceRef implemented by:AnyInstanceRef

Table A.32: FlatInstanceDescriptor

Class	FlatMap				
Package	M2::AUTOSARTemplates::CommonStructure::FlatMap				
Note	Contains a flat list of references to software objects. This list is used to identify instances and to resolve name conflicts. The scope is given by the RootSwCompositionPrototype for which it is used, i.e. it can be applied to a system, system extract or ECU-extract.				
				preliminary context, e.g. in the scope of a software n this case it is not referred by a RootSwComposition	
	Tags:atp.recommendedPa	ackage=Fl	latMaps		
Base	ARElement, ARObject, AtpBlueprint, AtpBlueprintable, CollectableElement, Identifiable, Multilanguage Referrable, PackageableElement, Referrable				
Attribute	Туре	Type Mult. Kind Note			
instance	FlatInstanceDescriptor	1*	aggr	A descriptor instance aggregated in the flat map.	
				The variation point accounts for the fact, that the system in scope can be subject to variability, and thus the existence of some instances is variable.	
				The aggregation has been made splitable because the content might be contributed by different stakeholders at different times in the workflow. Plus, the overall size might be so big that eventually it becomes more manageable if it is distributed over several files.	
				Stereotypes: atpSplitable; atpVariation Tags: atp.Splitkey=instance.shortName, instance.variation Point.shortLabel vh.latestBindingTime=postBuild	

Table A.33: FlatMap



Class	Identifiable (abstract)		Identifiable (abstract)						
Package	M2::AUTOSARTemplates:	:GenericS	Structure::	GeneralTemplateClasses::Identifiable					
Note	this, Identifiables are object	Instances of this class can be referred to by their identifier (within the namespace borders). In addition to this, Identifiables are objects which contribute significantly to the overall structure of an AUTOSAR description. In particular, Identifiables might contain Identifiables.							
Base	ARObject, Multilanguagel	Referrable	, Referral	ple					
Subclasses	AbstractSecurityEventFilte Endpoint, ApplicationError Point, AtpBlueprint, AtpBl AutosarVariableInstance, ManifestResource, Binary ModuleDependency, Build Node, Chapter, ClassCon Element, ComManageme Controller, Compiler, Con Element, CpSoftwareClus SoftwareClusterToEcuInst Mapping, DataPrototypeG Algorithm, DiagnosticCon DiagnosticRoutineSubfund Address, DolpRoutingActi ContainerValue, EcucDefi Query, EcucValidationCor ExclusiveArea, Executable MapCondition, FMFeature FlatInstanceDescriptor, FI Pool, Frame Triggering, Ge HeapUsage, HwAttributeE FilterList, ISignalToIPduM AddressCluster, J1939Tpl MulticastGroup, McDatalr SwitchPoint, NetworkEndp ParameterAccess, PduTol ElementToCommunicatior ResourceConsumption, R Entity, RptExecutableEntii Group, SdgAttribute, Sdgf FreshnessProps, Security ElementProps, SignalServ SomeipTpChannel, Speci GenericAxisParamType, S SwcToEcuMapping, SwcT SoftwareClusterResource Description, TimingExtens TraceableTable, Traceable VariableAccess, Variation	er, Abstract, Applicative printable Binary Main Binary Main Manifest Fold Action Entent Condition in the Mapping sistence Application, Ditalent Condition, Ditalent Condition, Ditalent Condition, Ditalent Condition, Entent Condition, Entent Condition, Entent Condition, Entent Condition, Condition, Entent Condition, Condition, Entent Condition, Condition, Entent Condition,	ctSecurity ionPartitic e, AtpClas nifestAddi ResourceE tity, Build, g, Commo eeds, Cor rce, CpSo oing, CpS aTransfor icator, Dia rgument, Ecur dToEndPr vecutionTr eent, FMFe pholog, Fle ameter, Gl ributeLite ignalTrigg rword, Life lemorySe Cluster, N pping, Pdu Mapping, mpositionI ptExecution textProps ationEven eference, Arg, Swcs ping, Sys TcpOption rce, Timir edFailure, r, ViewMa	T					
Attribute	Type Admin Data	Mult.	Kind	Note					
adminData	AdminData	01	aggr	This represents the administrative data for the identifiable object. Tags:xml.sequenceOffset=-40					
annetetie:-	Annatation	*		<u> </u>					
annotation	Annotation	*	aggr	Possibility to provide additional notes while defining a model element (e.g. the ECU Configuration Parameter Values). These are not intended as documentation but					
				are mere design notes.					





Identifiable (abstract)			
CategoryString	01	attr	The category is a keyword that specializes the semantics of the Identifiable. It affects the expected existence of attributes and the applicability of constraints.
			Tags:xml.sequenceOffset=-50
MultiLanguageOverview Paragraph	01	aggr	This represents a general but brief (one paragraph) description what the object in question is about. It is only one paragraph! Desc is intended to be collected into overview tables. This property helps a human reader to identify the object in question.
			More elaborate documentation, (in particular how the object is built or used) should go to "introduction".
			Tags:xml.sequenceOffset=-60
DocumentationBlock	01	aggr	This represents more information about how the object in question is built or is used. Therefore it is a DocumentationBlock.
			Tags:xml.sequenceOffset=-30
String	01	attr	The purpose of this attribute is to provide a globally unique identifier for an instance of a meta-class. The values of this attribute should be globally unique strings prefixed by the type of identifier. For example, to include to DCE UUID as defined by The Open Group, the UUID would be preceded by "DCE:". The values of this attribute may be used to support merging of different AUTOSAR models. The form of the UUID (Universally Unique Identifier) is taken from a standard defined by the Open Group (was Open Software Foundation). This standard is widely used, including by Microsoft for COM (GUIDs) and by many companies for DCE, which is based on CORBA The method for generating these 128-bit IDs is published in the standard and the effectiveness and uniqueness of the IDs is not in practice disputed. If the id namespace is omitted, DCE is assumed. An example is "DCE:2fac1234-31f8-11b4-a222-08002b34c003". The uuid attribute has no semantic meaning for an AUTOSAF model and there is no requirement for AUTOSAR tools to manage the timestamp. Tags:xml.attribute=true
	CategoryString MultiLanguageOverview Paragraph DocumentationBlock	CategoryString 01 MultiLanguageOverview Paragraph DocumentationBlock 01	CategoryString 01 attr MultiLanguageOverview Paragraph 01 aggr DocumentationBlock 01 aggr

Table A.34: Identifiable

Class	ImplementationDataType				
Package	M2::AUTOSARTemplates:	::Common	Structure	::ImplementationDataTypes	
Note	Describes a reusable data type on the implementation level. This will typically correspond to a typedef in C-code.				
	Tags:atp.recommendedPage	Tags:atp.recommendedPackage=ImplementationDataTypes			
Base	ARElement, ARObject, AbstractImplementationDataType, AtpBlueprint, AtpBlueprintable, AtpClassifier, AtpType, AutosarDataType, CollectableElement, Identifiable, MultilanguageReferrable, Packageable Element, Referrable				
Attribute	Туре	Type Mult. Kind Note			
dynamicArray SizeProfile	String	01	attr	Specifies the profile which the array will follow in case this data type is a variable size array.	





Class	ImplementationDataTyp	е		
isStructWith Optional	Boolean	01	attr	This attribute is only valid if the attribute category is set to STRUCTURE.
Element				If set to True, this attribute indicates that the ImplementationDataType has been created with the intention to define at least one element of the structure as optional.
subElement (ordered)	ImplementationData TypeElement	*	aggr	Specifies an element of an array, struct, or union data type.
				The aggregation of ImplementionDataTypeElement is subject to variability with the purpose to support the conditional existence of elements inside a Implementation DataType representing a structure.
				Stereotypes: atpVariation Tags:vh.latestBindingTime=preCompileTime
symbolProps	SymbolProps	01	aggr	This represents the SymbolProps for the Implementation DataType.
				Stereotypes: atpSplitable Tags:atp.Splitkey=symbolProps.shortName
typeEmitter	NameToken	01	attr	This attribute is used to control which part of the AUTOSAR toolchain is supposed to trigger data type definitions.

Table A.35: ImplementationDataType

Class	InstantiationDataDefPro	ps				
Package	M2::AUTOSARTemplates::SWComponentTemplate::SwcInternalBehavior::InstantiationDataDefProps					
Note	This is a general class allowing to apply additional SwDataDefProps to particular instantiations of a Data Prototype.					
	Typically the accessibility and further information like alias names for a particular data is modeled on the level of DataPrototypes (especially VariableDataPrototypes, ParameterDataPrototypes). But due to the recursive structure of the meta-model concerning data types (a composite (data) type consists out of data prototypes) a part of the MCD information is described in the data type (in case of Application CompositeDataType).					
	This is a strong restriction in the reuse of data typed because the data type should be re-used for different VariableDataPrototypes and ParameterDataPrototypes to guarantee type compatibility on C-implementation level (e.g. data of a Port is stored in PIM or a ParameterDataPrototype used as ROM Block and shall be typed by the same data type as NVRAM Block).					
	This class overcomes suc	ch a restric	tion if app	olied properly.		
Base	ARObject					
Attribute	Туре	Mult.	Kind	Note		
parameter Instance	AutosarParameterRef	01	aggr	This is the particular ParameterDataPrototypes on which the swDataDefProps shall be applied.		
swDataDef Props	SwDataDefProps	01	aggr	These are the particular data definition properties which shall be applied		
variableInstance	AutosarVariableRef	01	aggr	This is the particular VariableDataPrototypes on which the swDataDefProps shall be applied.		

Table A.36: InstantiationDataDefProps



Class	InternalBehavior (abstra	act)					
Package	M2::AUTOSARTemplates	::Commor	Structure	::InternalBehavior			
Note	Common base class (abs modules/clusters.	Common base class (abstract) for the internal behavior of both software components and basic software modules/clusters.					
Base	ARObject, AtpClassifier, AtpFeature, AtpStructureElement, Identifiable, MultilanguageReferrable, Referrable						
Subclasses	BswInternalBehavior, Sw	cInternalB	ehavior				
Attribute	Туре	Mult.	Kind	Note			
constant Memory	ParameterData Prototype	*	aggr	Describes a read only memory object containing characteristic value(s) implemented by this Internal Behavior.			
				The shortName of ParameterDataPrototype has to be equal to the "C' identifier of the described constant.			
				The characteristic value(s) might be shared between Sw ComponentPrototypes of the same SwComponentType.			
				The aggregation of constantMemory is subject to variability with the purpose to support variability in the software component or module implementations. Typically different algorithms in the implementation are requiring different number of memory objects.			
				Stereotypes: atpSplitable; atpVariation Tags: atp.Splitkey=constantMemory.shortName, constant Memory.variationPoint.shortLabel vh.latestBindingTime=preCompileTime			
constantValue Mapping	ConstantSpecification MappingSet	*	ref	Reference to the ConstanSpecificationMapping to be applied for the particular InternalBehavior			
				Stereotypes: atpSplitable Tags:atp.Splitkey=constantValueMapping			
dataType Mapping	DataTypeMappingSet	*	ref	Reference to the DataTypeMapping to be applied for the particular InternalBehavior			
				Stereotypes: atpSplitable Tags:atp.Splitkey=dataTypeMapping			
exclusiveArea	ExclusiveArea	*	aggr	This specifies an ExclusiveArea for this InternalBehavior. The exclusiveArea is local to the component resp. module. The aggregation of ExclusiveAreas is subject to variability. Note: the number of ExclusiveAreas might varidue to the conditional existence of RunnableEntities or BswModuleEntities.			
				Stereotypes: atpSplitable; atpVariation Tags: atp.Splitkey=exclusiveArea.shortName, exclusive Area.variationPoint.shortLabel vh.latestBindingTime=preCompileTime			
exclusiveArea NestingOrder	ExclusiveAreaNesting Order	*	aggr	This represents the set of ExclusiveAreaNestingOrder owned by the InternalBehavior.			
				Stereotypes: atpSplitable; atpVariation Tags: atp.Splitkey=exclusiveAreaNestingOrder.shortName, exclusiveAreaNestingOrder.variationPoint.shortLabel vh.latestBindingTime=preCompileTime			





Class	InternalBehavior (abstract	InternalBehavior (abstract)							
staticMemory	VariableDataPrototype	*	aggr	Describes a read and writeable static memory object representing measurerment variables implemented by this software component. The term "static" is used in the meaning of "non-temporary" and does not necessarily specify a linker encapsulation. This kind of memory is only supported if supportsMultipleInstantiation is FALSE.					
				The shortName of the VariableDataPrototype has to be equal with the "C' identifier of the described variable.					
				The aggregation of staticMemory is subject to variability with the purpose to support variability in the software component's implementations.					
				Typically different algorithms in the implementation are requiring different number of memory objects.					
				Stereotypes: atpSplitable; atpVariation Tags: atp.Splitkey=staticMemory.shortName, static Memory.variationPoint.shortLabel vh.latestBindingTime=preCompileTime					

Table A.37: InternalBehavior

Class	McDataInstance				
Package	M2::AUTOSARTemplates	::Common	Structure	::MeasurementCalibrationSupport	
Note	Describes the specific properties of one data instance in order to support measurement and/or calibration of this data instance.				
	The most important attrib	utes are:			
	 Its shortName is for display by the 			U Flat map (if applicable) and will be used as identifier and	
	,			esponding data type (ApplicationDataType if defined, as far as applicable.	
	,			ogramming language. It will be used to find out the actual ion tool with the help of linker generated information.	
	exception of the Flat Map McAccessDetails) are cor	and the re npletely go uMethod is	eferences enerated t s only use	nd all the aggregated and referred elements (with the from ImplementationElementInParameterInstanceRef and from "upstream" information. This means, that even if an d via reference here, it will be copied into the M1 artifact a given Implementation.	
Base	ARObject, Identifiable, M	ultilangua	geReferra	ble, Referrable	
Attribute	Туре	Mult.	Kind	Note	
arraySize	PositiveInteger	01	attr	The existence of this attribute turns the data instance into an array of data. The attribute determines the size of the array in terms of number of elements.	
displayIdentifier	Mcdldentifier	01	attr	An optional attribute to be used to set the ASAM ASAP2 DISPLAY_IDENTIFIER attribute.	
flatMapEntry	FlatInstanceDescriptor	01	ref	Reference to the corresponding entry in the ECU Flat Map. This allows to trace back to the original specification of the generated data instance. This link shall be added by the RTE generator mainly for documentation purposes.	
				The reference is optional because ▽	





Class	McDataInstance			
instanceIn Memory	ImplementationElement InParameterInstance Ref	01	aggr	measurement access. Reference to the corresponding data instance in the description of calibration data structures published by the RTE generator. This is used to support emulation methods inside the ECU, it is not required for A2L generation.
mcDataAccess Details	McDataAccessDetails	01	aggr	Refers to "upstream" information on how the RTE uses this data instance. Use Case: Rapid Prototyping
mcData Assignment	RoleBasedMcData Assignment	*	aggr	An assignment between McDataInstances. This supports the indication of related McDataElement implementing the of "RP global buffer", "RP global measurement buffer", "RP enabler flag".
resulting Properties	SwDataDefProps	01	aggr	These are the generated properties resulting from decisions taken by the RTE generator for the actually implemented data instance. Only those properties are relevant here, which are needed for the measurement and calibration system.
resultingRptSw Prototyping Access	RptSwPrototyping Access	01	aggr	Describes the implemented accessibility of data and modes by the rapid prototyping tooling.
role	Identifier	01	attr	An optional attribute to be used for additional information on the role of this data instance, for example in the context of rapid prototyping.
rptImplPolicy	RptImplPolicy	01	aggr	Describes the implemented code preparation for rapid prototyping at data accesses for a hook based bypassing
subElement (ordered)	McDataInstance	*	aggr	This relation indicates, that the target element is part of a "struct" which is given by the source element. This information will be used by the final generator to set up the correct addressing scheme.
				Stereotypes: atpVariation Tags:vh.latestBindingTime=preCompileTime
symbol	SymbolString	01	attr	This String is used to determine the memory address during final generation of the MC configuration data (e.g. "A2L" file) . It shall be the name of the element in the programming language such that it can be identified in linker generated information.
				In case the McDataInstance is part of composite data in the programming language, the symbol String may include parts denoting the element context, unless the context is given by the symbol attribute of an enclosing McDataInstance. This means in particular for the C language that the "." character shall be used as a separator between the name of a "struct" variable the name of one of its elements.
				The symbol can differ from the shortName in case of generated C data declarations.
				∇





Class	McDataInstance	
		It is an optional attribute since it may be missing in case the instance represents an element (e.g. a single array element) which has no name in the linker map.
		Stereotypes: atpSplitable Tags:atp.Splitkey=symbol

Table A.38: McDataInstance

Enumeration	MemoryAllocationKeywordPolicyType		
Package	M2::MSR::DataDictionary::AuxillaryObjects		
Note	Enumeration to specify the name pattern of the Memory Allocation Keyword.		
Literal	Description		
addrMethodShort Name	The MemorySection shortNames of referring MemorySections and therefore the belonging Memory Allocation Keywords in the code are build with the shortName of the SwAddrMethod. This is the default value if the attribute does not exist.		
	Tags:atp.EnumerationLiteralIndex=0		
addrMethodShort NameAndAlignment	The MemorySection shortNames of referring MemorySections and therefore the belonging Memory Allocation Keywords in the code are build with the shortName of the SwAddrMethod and a variable alignment postfix.		
	Thereby the alignment postfix needs to be consistent with the alignment attribute of the related MemorySection.		
	Tags:atp.EnumerationLiteralIndex=1		

Table A.39: MemoryAllocationKeywordPolicyType

Enumeration	MemorySectionType			
Package	M2::MSR::DataDictionary::AuxillaryObjects			
Note	Enumeration to specify the essential nature of the data which can be allocated in a common memory class by the means of the AUTOSAR Memory Mapping.			
Literal	Description			
calibrationVariables	This memory section is reserved for "virtual variables" that are computed by an MCD system during a measurement session but do not exist in the ECU memory.			
	Tags:atp.EnumerationLiteralIndex=2			
calprm	To be used for calibratable constants of ECU-functions.			
	Tags:atp.EnumerationLiteralIndex=3			
code	To be used for mapping code to application block, boot block, external flash etc.			
	Tags:atp.EnumerationLiteralIndex=4			
configData	Constants with attributes that show that they reside in one segment for module configuration.			
	Tags:atp.EnumerationLiteralIndex=5			
const	To be used for global or static constants.			
	Tags:atp.EnumerationLiteralIndex=6			





Enumeration	MemorySectionType	
excludeFromFlash	This memory section is reserved for "virtual parameters" that are taken for computing the values of so-called dependent parameter of an MCD system. Dependent Parameters that are not at the same time "virtual parameters" are allocated in the ECU memory.	
	Virtual parameters, on the other hand, are not allocated in the ECU memory. Virtual parameters exist in the ECU Hex file for the purpose of being considered (for computing the values of dependent parameters) during an offline-calibration session.	
	Tags:atp.EnumerationLiteralIndex=7	
var	To be used for global or static variables. The expected initialization is specified with the attribute sectionInitializationPolicy.	
	Tags:atp.EnumerationLiteralIndex=9	

Table A.40: MemorySectionType

Class	ModeDeclaration	ModeDeclaration		
Package	M2::AUTOSARTemplate	M2::AUTOSARTemplates::CommonStructure::ModeDeclaration		
Note	Declaration of one Mod	Declaration of one Mode. The name and semantics of a specific mode is not defined in the meta-model.		
Base	ARObject, AtpClassifie Referrable	ARObject, AtpClassifier, AtpFeature, AtpStructureElement, Identifiable, MultilanguageReferrable, Referrable		
Attribute	Туре	Mult.	Kind	Note
value	PositiveInteger	01	attr	The RTE shall take the value of this attribute for generating the source code representation of this Mode Declaration.

Table A.41: ModeDeclaration

Class	ModeDeclarationGroup				
Package	M2::AUTOSARTemplates::CommonStructure::ModeDeclaration				
Note	A collection of Mode Declarations. Also, the initial mode is explicitly identified.				
	Tags:atp.recommendedPackage=ModeDeclarationGroups				
Base	ARElement, ARObject, AtpBlueprint, AtpBlueprintable, AtpClassifier, AtpType, CollectableElement, Identifiable, MultilanguageReferrable, PackageableElement, Referrable				
Attribute	Туре	Mult.	Kind	Note	
initialMode	ModeDeclaration	01	ref	The initial mode of the ModeDeclarationGroup. This mode is active before any mode switches occurred.	
mode Declaration	ModeDeclaration	*	aggr	The ModeDeclarations collected in this ModeDeclaration Group.	
				Stereotypes: atpVariation Tags:vh.latestBindingTime=blueprintDerivationTime	
modeManager ErrorBehavior	ModeErrorBehavior	01	aggr	This represents the ability to define the error behavior expected by the mode manager in case of errors on the mode user side (e.g. terminated mode user).	
modeTransition	ModeTransition	*	aggr	This represents the avaliable ModeTransitions of the ModeDeclarationGroup	
modeUserError Behavior	ModeErrorBehavior	01	aggr	This represents the definition of the error behavior expected by the mode user in case of errors on the mode manager side (e.g. terminated mode manager).	
onTransition Value	PositiveInteger	01	attr	The value of this attribute shall be taken into account by the RTE generator for programmatically representing a value used for the transition between two statuses.	

Table A.42: ModeDeclarationGroup



Class	ModeDeclarationGroupF	ModeDeclarationGroupPrototype				
Package	M2::AUTOSARTemplates:	:Common	Structure	::ModeDeclaration		
Note	The ModeDeclarationGroupPrototype specifies a set of Modes (ModeDeclarationGroup) which is provided or required in the given context.					
Base	ARObject, AtpFeature, AtpPrototype, Identifiable, MultilanguageReferrable, Referrable					
Attribute	Туре	Type Mult. Kind Note				
swCalibration Access	SwCalibrationAccess Enum	01	attr	This allows for specifying whether or not the enclosing ModeDeclarationGroupPrototype can be measured at run-time.		
type	ModeDeclarationGroup	01	tref	The "collection of ModeDeclarations" (= ModeDeclaration Group) supported by a component		
				Stereotypes: isOfType		

Table A.43: ModeDeclarationGroupPrototype

Class	ModeSwitchInterface			
Package	M2::AUTOSARTemplates:	:SWComp	onentTer	nplate::PortInterface
Note	A mode switch interface declares a ModeDeclarationGroupPrototype to be sent and received.			
	Tags:atp.recommendedPackage=PortInterfaces			
Base	ARElement, ARObject, AtpBlueprint, AtpBlueprintable, AtpClassifier, AtpType, CollectableElement, Identifiable, MultilanguageReferrable, PackageableElement, PortInterface, Referrable			
Attribute	Туре	Mult.	Kind	Note
modeGroup	ModeDeclarationGroup Prototype	01	aggr	The ModeDeclarationGroupPrototype of this mode interface.

Table A.44: ModeSwitchInterface

Class	NumericalValueSpecif	NumericalValueSpecification				
Package	M2::AUTOSARTemplate	es::Commor	Structure	::Constants		
Note	A numerical ValueSpecification which is intended to be assigned to a Primitive data element. Note that the numerical value is a variant, it can be computed by a formula.					
Base	ARObject, ValueSpecifi	cation				
Attribute	Туре	Mult.	Kind	Note		
value	Numerical	01	attr	This is the value itself.		
				Stereotypes: atpVariation Tags:vh.latestBindingTime=preCompileTime		

Table A.45: NumericalValueSpecification

Class	PPortPrototype				
Package	M2::AUTOSARTemplates	M2::AUTOSARTemplates::SWComponentTemplate::Components			
Note	Component port providing	Component port providing a certain port interface.			
Base	ARObject, AbstractProvidedPortPrototype, AtpBlueprintable, AtpFeature, AtpPrototype, Identifiable, MultilanguageReferrable, PortPrototype, Referrable				
Attribute	Туре	Mult.	Kind	Note	
provided	PortInterface 01 tref The interface that this port provides.				
Interface				Stereotypes: isOfType	

Table A.46: PPortPrototype



Class	ParameterAccess				
Package	M2::AUTOSARTemplates	M2::AUTOSARTemplates::SWComponentTemplate::SwcInternalBehavior::DataElements			
Note	The presence of a ParameterAccess implies that a RunnableEntity needs access to a ParameterData Prototype.				
Base		ARObject, AbstractAccessPoint, AtpClassifier, AtpFeature, AtpStructureElement, Identifiable, MultilanguageReferrable, Referrable			
Attribute	Туре	Mult.	Kind	Note	
accessed Parameter	AutosarParameterRef	01	aggr	Refernce to the accessed calibration parameter.	
swDataDef Props	SwDataDefProps	01	aggr	This allows denote instance and access specific properties, mainly input values and common axis.	

Table A.47: ParameterAccess

Class	ParameterDataPrototy	ParameterDataPrototype			
Package	M2::AUTOSARTemplate	M2::AUTOSARTemplates::SWComponentTemplate::Datatype::DataPrototypes			
Note		A parameter element used for parameter interface and internal behavior, supporting signal like parameter and characteristic value communication patterns and parameter and characteristic value definition.			
Base	ARObject, AtpFeature, A Referrable, Referrable	ARObject, AtpFeature, AtpPrototype, AutosarDataPrototype, DataPrototype, Identifiable, Multilanguage Referrable, Referrable			
Attribute	Туре	Type Mult. Kind Note			
initValue	ValueSpecification	01	aggr	Specifies initial value(s) of the ParameterDataPrototype	

Table A.48: ParameterDataPrototype

Class	ParameterInterface	ParameterInterface				
Package	M2::AUTOSARTemplates:	::SWCom	onentTer	nplate::PortInterface		
Note	A parameter interface declares a number of parameter and characteristic values to be exchanged between parameter components and software components.					
	Tags:atp.recommendedPackage=PortInterfaces					
Base				eprintable, AtpClassifier, AtpType, CollectableElement, errable, PackageableElement, PortInterface, Referrable		
Attribute	Туре	Type Mult. Kind Note				
parameter	ParameterData Prototype	*	aggr	The ParameterDataPrototype of this ParameterInterface.		

Table A.49: ParameterInterface

Class	ParameterProvideCon	ParameterProvideComSpec				
Package	M2::AUTOSARTemplate	s::SWCom	oonentTer	mplate::Communication		
Note	"Communication" specif	"Communication" specification that applies to parameters on the provided side of a connection.				
Base	ARObject, PPortComSp	ARObject, PPortComSpec				
Attribute	Туре	Mult.	Kind	Note		
initValue	ValueSpecification	01	aggr	The initial value applicable for the corresponding ParameterDataPrototype.		
parameter	ParameterData Prototype	01	ref	The ParameterDataPrototype to which the Parameter ComSpec applies.		

 Table A.50: ParameterProvideComSpec



Class	ParameterSwComponer	ntType					
Package	M2::AUTOSARTemplates::SWComponentTemplate::Components						
Note	The ParameterSwComponentType defines parameters and characteristic values accessible via provided Ports. The provided values are the same for all connected SwComponentPrototypes						
	Tags:atp.recommendedP	Tags:atp.recommendedPackage=SwComponentTypes					
Base	ARElement, ARObject, AtpBlueprint, AtpBlueprintable, AtpClassifier, AtpType, CollectableElement, Identifiable, MultilanguageReferrable, PackageableElement, Referrable, SwComponentType						
Attribute	Type Mult. Kind Note			Note			
constant Mapping	ConstantSpecification MappingSet	*	ref	Reference to the ConstanSpecificationMapping to be applied for the particular ParameterSwComponentType			
				Stereotypes: atpSplitable Tags:atp.Splitkey=constantMapping			
dataType Mapping	DataTypeMappingSet	*	ref	Reference to the DataTypeMapping to be applied for the particular ParameterSwComponentType			
				Stereotypes: atpSplitable Tags:atp.Splitkey=dataTypeMapping			
instantiation DataDefProps	InstantiationDataDef Props	*	aggr	The purpose of this is that within the context of a given SwComponentType some data def properties of individual instantiations can be modified.			
				The aggregation of InstantiationDataDefProps is subject to variability with the purpose to support the conditional existence of PortPrototypes			
				Stereotypes: atpVariation Tags:vh.latestBindingTime=preCompileTime			

Table A.51: ParameterSwComponentType

Class	PhysConstrs	PhysConstrs				
Package	M2::MSR::AsamHdo::C	M2::MSR::AsamHdo::Constraints::GlobalConstraints				
Note		This meta-class represents the ability to express physical constraints. Therefore it has (in opposite to InternalConstrs) a reference to a Unit.				
Base	ARObject					
Attribute	Туре	Mult.	Kind	Note		
lowerLimit	Limit	01	attr	This specifies the lower limit of the constraint.		
				Stereotypes: atpVariation Tags: vh.latestBindingTime=preCompileTime xml.sequenceOffset=20		
maxDiff	Numerical	01	attr	Maximum difference that is permitted between two consecutive values if the constraint is applied to an axis.		
				Tags:xml.sequenceOffset=60		
maxGradient	Numerical	01	attr	This element specifies the maximum slope that may be used in curves and maps.		
				Tags:xml.sequenceOffset=50		
monotony	MonotonyEnum	01	attr	This specifies the monotony constraints on the data object. Note that this applies only to curves and maps.		
				Tags:xml.sequenceOffset=70		





Class	PhysConstrs			
scaleConstr (ordered)	ScaleConstr	*	aggr	This is one particular scale which contributes to the data constraints.
				Tags: xml.roleElement=true xml.roleWrapperElement=true xml.sequenceOffset=40 xml.typeElement=false xml.typeWrapperElement=false
unit	Unit	01	ref	This is the unit to which the physical constraints relate to. In particular, it is the physical unit of the specified limits.
				Tags:xml.sequenceOffset=80
upperLimit	Limit	01	attr	This specifies the upper limit of the constraint.
				Stereotypes: atpVariation Tags: vh.latestBindingTime=preCompileTime xml.sequenceOffset=30

Table A.52: PhysConstrs

Class	PhysicalDimension					
Package	M2::MSR::AsamHdo::Units					
Note				f the physical dimension of two units is identical, then a enversion between units is related to the definition of the		
	Note that the equivalence and Torque share the sa			oes not per se define the convertibility. For example Energy		
	Please note further the value of an exponent does not necessarily have to be an integer number. It is also possible that the value yields a rational number, e.g. to compute the square root of a given physical quantity. In this case the exponent value would be a rational number where the numerator value is 1 are the denominator value is 2.					
	Tags:atp.recommendedPackage=PhysicalDimensions					
Base	ARElement, ARObject, Element, Referrable	Collectable	Element,	Identifiable, MultilanguageReferrable, Packageable		
Attribute	Туре	Mult.	Kind	Note		
currentExp	Numerical	01	attr	This attribute represents the exponent of the physical dimension "electric current".		
				Tags:xml.sequenceOffset=50		
lengthExp	Numerical	01	attr	The exponent of the physical dimension "length".		
				Tags:xml.sequenceOffset=20		
luminous IntensityExp	Numerical	01	attr	The exponent of the physical dimension "luminous intensity".		
				Tags:xml.sequenceOffset=80		
massExp	Numerical	01	attr	The exponent of the physical dimension "mass".		
				Tags:xml.sequenceOffset=30		
molarAmount Exp	Numerical	01	attr	The exponent of the physical dimension "quantity of substance".		
				Tags:xml.sequenceOffset=70		
temperatureExp	Numerical	01	attr	The exponent of the physical dimension "temperature".		
				Tags:xml.sequenceOffset=60		





Class	PhysicalDimension			
timeExp	Numerical	01	attr	The exponent of the physical dimension "time".
				Tags:xml.sequenceOffset=40

Table A.53: PhysicalDimension

Class	PortInterface (abstract)	PortInterface (abstract)				
Package	M2::AUTOSARTemplates	::SWComp	onentTer	mplate::PortInterface		
Note	Abstract base class for ar	interface	that is eit	her provided or required by a port of a software component.		
Base				eprintable, AtpClassifier, AtpType, CollectableElement, geableElement, Referrable		
Subclasses	ClientServerInterface, Da	taInterface	e, ModeSv	witchInterface, TriggerInterface		
Attribute	Туре	Mult.	Kind	Note		
isService	Boolean	01	attr	This flag is set if the PortInterface is to be used for communication between an		
		ApplicationSwComponentType or				
				 ServiceProxySwComponentType or 		
				 SensorActuatorSwComponentType or 		
				 ComplexDeviceDriverSwComponentType 		
				 ServiceSwComponentType 		
				EcuAbstractionSwComponentType		
	and a ServiceSwComponentType (namely an AUTOSA Service) located on the same ECU. Otherwise the flag not set.					
serviceKind	ServiceProviderEnum	01	attr	This attribute provides further details about the nature of the applied service.		

Table A.54: PortInterface

Class	PortPrototype (abstract)				
Package	M2::AUTOSARTemplates:	:SWComp	onentTer	nplate::Components	
Note	Base class for the ports of	f an AUTC	SAR soft	ware component.	
	The aggregation of PortPr existence of ports.	ototypes i	s subject	to variability with the purpose to support the conditional	
Base	ARObject, AtpBlueprintab	le, AtpFea	ature, Atp	Prototype, Identifiable, MultilanguageReferrable, Referrable	
Subclasses	AbstractProvidedPortPrototype, AbstractRequiredPortPrototype				
Attribute	Type Mult. Kind Note				
clientServer Annotation	ClientServerAnnotation	*	aggr	Annotation of this PortPrototype with respect to client/ server communication.	
delegatedPort Annotation	DelegatedPort Annotation	01	aggr	Annotations on this delegated port.	
ioHwAbstraction Server Annotation	IoHwAbstractionServer Annotation	*	aggr	Annotations on this IO Hardware Abstraction port.	
modePort Annotation	ModePortAnnotation	*	aggr	Annotations on this mode port.	
nvDataPort Annotation	NvDataPortAnnotation	*	aggr	Annotations on this non voilatile data port.	





Class	PortPrototype (abstract)			
parameterPort Annotation	ParameterPort Annotation	*	aggr	Annotations on this parameter port.
senderReceiver Annotation	SenderReceiver Annotation	*	aggr	Collection of annotations of this ports sender/receiver communication.
triggerPort Annotation	TriggerPortAnnotation	*	aggr	Annotations on this trigger port.

Table A.55: PortPrototype

Class	RPortPrototype				
Package	M2::AUTOSARTemplates:	M2::AUTOSARTemplates::SWComponentTemplate::Components			
Note	Component port requiring	Component port requiring a certain port interface.			
Base	ARObject, AbstractRequiredPortPrototype, AtpBlueprintable, AtpFeature, AtpPrototype, Identifiable, MultilanguageReferrable, PortPrototype, Referrable				
Attribute	Туре	Mult.	Kind	Note	
required	PortInterface 01 tref The interface that this port requires.				
Interface				Stereotypes: isOfType	

Table A.56: RPortPrototype

Class	RTEEvent (abstract)	RTEEvent (abstract)			
Package	M2::AUTOSARTemplates:	:SWComp	onentTer	nplate::SwcInternalBehavior::RTEEvents	
Note	Abstract base class for all	RTE-rela	ted events	3	
Base	ARObject, AbstractEvent, Referrable, Referrable	AtpClass	ifier, AtpF	Feature, AtpStructureElement, Identifiable, Multilanguage	
Subclasses	AsynchronousServerCallReturnsEvent, BackgroundEvent, DataReceiveErrorEvent, DataReceivedEvent, DataSendCompletedEvent, DataWriteCompletedEvent, ExternalTriggerOccurredEvent, InitEvent, InternalTriggerOccurredEvent, ModeSwitchedAckEvent, OperationInvokedEvent, OsTaskExecutionEvent, SwcModeManagerErrorEvent, SwcModeSwitchEvent, TimingEvent, TransformerHardErrorEvent				
Attribute	Туре	Mult.	Kind	Note	
disabledMode	ModeDeclaration	*	iref	Reference to the Modes that disable the Event.	
				Stereotypes: atpSplitable Tags:atp.Splitkey=disabledMode.contextModeDeclaration GroupPrototype, disabledMode.contextPort, disabled Mode.targetModeDeclaration InstanceRef implemented by:RModeInAtomicSwc InstanceRef	
startOnEvent	RunnableEntity	01	ref	RunnableEntity starts when the corresponding RTEEvent occurs.	

Table A.57: RTEEvent

Primitive	Ref
Package	M2::AUTOSARTemplates::GenericStructure::GeneralTemplateClasses::PrimitiveTypes





Primitive	Ref	Ref					
Note	This primitive denotes a n	ame base	d referen	ce. For detailed syntax see the xsd.pattern.			
	first slash (relative)	first slash (relative or absolute reference) [optional]					
	Identifier [required]	d]					
	a sequence of sla	shes and	Identifiers	s [optional]			
	This primitive is used by the	ne meta-m	nodel tools	s to create the references.			
	Tags: xml.xsd.customType=REF xml.xsd.pattern=/?[a-zA-Z][a-zA-Z0-9_]{0,127}(/[a-zA-Z][a-zA-Z0-9_]{0,127})* xml.xsd.type=string						
Attribute	Туре	Mult.	Kind	Note			
base	Identifier	01	attr	This attribute reflects the base to be used for this reference.			
				Tags:xml.attribute=true			
blueprintValue	String	01	attr	This represents a description that documents how the value shall be defined when deriving objects from the blueprint.			
				Tags: atp.Status=draft xml.attribute=true			
index	PositiveInteger	01	attr	This attribute supports the use case to point on specific elements in an array. This is in particular required if arrays are used to implement particular data objects.			
				Tags:xml.attribute=true			

Table A.58: Ref

Class	Referrable (abstract)					
Package	M2::AUTOSARTemplates:	:GenericS	Structure::	GeneralTemplateClasses::Identifiable		
Note	Instances of this class car	be referr	ed to by the	heir identifier (while adhering to namespace borders).		
Base	ARObject					
Subclasses	AtpDefinition, BswDistinguishedPartition, BswModuleCallPoint, BswModuleClientServerEntry, Bsw VariableAccess, CouplingPortTrafficClassAssignment, DiagnosticDebounceAlgorithmProps, Diagnostic EnvModeElement, EthernetPriorityRegeneration, EventHandler, ExclusiveAreaNestingOrder, Hw DescriptionEntity, ImplementationProps, LinSlaveConfigldent, ModeTransition, MultilanguageReferrable, PduActivationRoutingGroup, PncMappingIdent, SingleLanguageReferrable, SoConlPduIdentifier, Socket ConnectionBundle, TimeSyncServerConfiguration, TpConnectionIdent					
Attribute	Туре	Mult.	Kind	Note		
shortName	Identifier	1	attr	This specifies an identifying shortName for the object. It needs to be unique within its context and is intended for humans but even more for technical reference.		
				Stereotypes: atpldentityContributor Tags: xml.enforceMinMultiplicity=true xml.sequenceOffset=-100		
shortName Fragment	ShortNameFragment	*	aggr	This specifies how the Referrable.shortName is composed of several shortNameFragments.		
				Tags:xml.sequenceOffset=-90		

Table A.59: Referrable



Class	RootSwCompositionPro	totype			
Package	M2::AUTOSARTemplates::SystemTemplate				
Note	The RootSwCompositionPrototype represents the top-level-composition of software components within a given System.				
		,		may for example be a more or less complete VFB or the software of a flat ECU Extract with only atomic SWCs.	
	Therefore the RootSwComposition will only occasionally contain all atomic software components that are used in a complete VFB System. The OEM is primarily interested in the required functionality and the interfaces defining the integration of the Software Component into the System. The internal structure of such a component contains often substantial intellectual property of a supplier. Therefore a top-level software composition will often contain empty compositions which represent subsystems.				
	The contained SwComponentPrototypes are fully specified by their SwComponentTypes (including Port Prototypes, PortInterfaces, VariableDataPrototypes, SwcInternalBehavior etc.), and their ports are interconnected using SwConnectorPrototypes.				
Base	ARObject, AtpFeature, A	pPrototyp	e, Identifia	able, MultilanguageReferrable, Referrable	
Attribute	Туре	Mult.	Kind	Note	
calibration ParameterValue	CalibrationParameter ValueSet	*	ref	Used CalibrationParameterValueSet for instance specific initialization of calibration parameters.	
Set				Stereotypes: atpSplitable Tags:atp.Splitkey=calibrationParameterValueSet	
flatMap	FlatMap	01	ref	The FlatMap used in the scope of this RootSw CompositionPrototype.	
	Stereotypes: atpSplitable Tags:atp.Splitkey=flatMap				
software Composition	CompositionSw ComponentType	1	tref	We assume that there is exactly one top-level composition that includes all Component instances of the system	
				Stereotypes: isOfType	

Table A.60: RootSwCompositionPrototype

Class	RunnableEntity					
Package	M2::AUTOSARTemplates	M2::AUTOSARTemplates::SWComponentTemplate::SwcInternalBehavior				
Note	Type and are executed ur	A RunnableEntity represents the smallest code-fragment that is provided by an AtomicSwComponent Type and are executed under control of the RTE. RunnableEntities are for instance set up to respond to data reception or operation invocation on a server.				
Base	ARObject, AtpClassifier, AtpFeature, AtpStructureElement, ExecutableEntity, Identifiable, Multilanguage Referrable, Referrable					
Attribute	Туре	Type Mult. Kind Note				
argument (ordered)	RunnableEntity Argument	*	aggr	This represents the formal definition of a an argument to a RunnableEntity.		
asynchronous ServerCall			aggr	The server call result point admits a runnable to fetch the result of an asynchronous server call.		
ResultPoint				The aggregation of AsynchronousServerCallResultPoint is subject to variability with the purpose to support the conditional existence of client server PortPrototypes and the variant existence of server call result points in the implementation.		
	implementation. Stereotypes: atpSplitable; atpVariation Tags: atp.Splitkey=asynchronousServerCallResultPoint.sho Name, asynchronousServerCallResultPoint.variation Point.shortLabel vh.latestBindingTime=preCompileTime					





Class	RunnableEntity			
canBelnvoked Concurrently	Boolean	01	attr	If the value of this attribute is set to "true" the enclosing RunnableEntity can be invoked concurrently (even for one instance of the corresponding AtomicSwComponent Type). This implies that it is the responsibility of the implementation of the RunnableEntity to take care of this form of concurrency. Note that the default value of this attribute is set to "false".
dataRead Access	VariableAccess	*	aggr	RunnableEntity has implicit read access to dataElement of a sender-receiver PortPrototype or nv data of a nv data PortPrototype.
				The aggregation of dataReadAccess is subject to variability with the purpose to support the conditional existence of sender receiver ports or the variant existence of dataReadAccess in the implementation.
				Stereotypes: atpSplitable; atpVariation Tags: atp.Splitkey=dataReadAccess.shortName, dataRead Access.variationPoint.shortLabel vh.latestBindingTime=preCompileTime
dataReceive PointBy Argument	VariableAccess	*	aggr	RunnableEntity has explicit read access to dataElement of a sender-receiver PortPrototype or nv data of a nv data PortPrototype. The result is passed back to the application by means of an argument in the function signature.
				The aggregation of dataReceivePointByArgument is subject to variability with the purpose to support the conditional existence of sender receiver PortPrototype or the variant existence of data receive points in the implementation.
				Stereotypes: atpSplitable; atpVariation Tags:
				atp.Splitkey=dataReceivePointByArgument.shortName, dataReceivePointByArgument.variationPoint.shortLabel vh.latestBindingTime=preCompileTime
dataReceive PointByValue	VariableAccess	*	aggr	RunnableEntity has explicit read access to dataElement of a sender-receiver PortPrototype or nv data of a nv data PortPrototype.
				The result is passed back to the application by means of the return value. The aggregation of dataReceivePointBy Value is subject to variability with the purpose to support the conditional existence of sender receiver ports or the variant existence of data receive points in the implementation.
				Stereotypes: atpSplitable; atpVariation Tags: atp.Splitkey=dataReceivePointByValue.shortName, data ReceivePointByValue.variationPoint.shortLabel vh.latestBindingTime=preCompileTime
dataSendPoint	VariableAccess	*	aggr	RunnableEntity has explicit write access to dataElement of a sender-receiver PortPrototype or nv data of a nv data PortPrototype.
				The aggregation of dataSendPoint is subject to variability with the purpose to support the conditional existence of sender receiver PortPrototype or the variant existence of data send points in the implementation.





Class	RunnableEntity			
				☐ Stereotypes: atpSplitable; atpVariation Tags: atp.Splitkey=dataSendPoint.shortName, dataSend Point.variationPoint.shortLabel vh.latestBindingTime=preCompileTime
dataWrite Access	VariableAccess	*	aggr	RunnableEntity has implicit write access to dataElement of a sender-receiver PortPrototype or nv data of a nv data PortPrototype. The aggregation of dataWriteAccess is subject to variability with the purpose to support the conditional existence of sender receiver ports or the variant existence of dataWriteAccess in the implementation. Stereotypes: atpSplitable; atpVariation Tags: atp.Splitkey=dataWriteAccess.shortName, dataWriteAccess.variationPoint.shortLabel vh.latestBindingTime=preCompileTime
external TriggeringPoint	ExternalTriggeringPoint	*	aggr	The aggregation of ExternalTriggeringPoint is subject to variability with the purpose to support the conditional existence of trigger ports or the variant existence of external triggering points in the implementation. Stereotypes: atpSplitable; atpVariation Tags: atp.Splitkey=externalTriggeringPoint.ident.shortName, externalTriggeringPoint.variationPoint.shortLabel vh.latestBindingTime=preCompileTime
internal TriggeringPoint	InternalTriggeringPoint	*	aggr	The aggregation of InternalTriggeringPoint is subject to variability with the purpose to support the variant existence of internal triggering points in the implementation. Stereotypes: atpSplitable; atpVariation Tags: atp.Splitkey=internalTriggeringPoint.shortName, internal TriggeringPoint.variationPoint.shortLabel vh.latestBindingTime=preCompileTime
modeAccess Point	ModeAccessPoint	*	aggr	The runnable has a mode access point. The aggregation of ModeAccessPoint is subject to variability with the purpose to support the conditional existence of mode ports or the variant existence of mode access points in the implementation. Stereotypes: atpSplitable; atpVariation Tags: atp.Splitkey=modeAccessPoint.ident.shortName, mode AccessPoint.variationPoint.shortLabel vh.latestBindingTime=preCompileTime
modeSwitch Point	ModeSwitchPoint	*	aggr	The runnable has a mode switch point. The aggregation of ModeSwitchPoint is subject to variability with the purpose to support the conditional existence of mode ports or the variant existence of mode switch points in the implementation. Stereotypes: atpSplitable; atpVariation Tags: atp.Splitkey=modeSwitchPoint.shortName, modeSwitch Point.variationPoint.shortLabel vh.latestBindingTime=preCompileTime





Class	RunnableEntity			
parameter Access	ParameterAccess	*	aggr	The presence of a ParameterAccess implies that a RunnableEntity needs read only access to a Parameter DataPrototype which may either be local or within a Port Prototype.
				The aggregation of ParameterAccess is subject to variability with the purpose to support the conditional existence of parameter ports and component local parameters as well as the variant existence of Parameter Access (points) in the implementation.
				Stereotypes: atpSplitable; atpVariation Tags: atp.Splitkey=parameterAccess.shortName, parameter Access.variationPoint.shortLabel vh.latestBindingTime=preCompileTime
readLocal Variable	VariableAccess	*	aggr	The presence of a readLocalVariable implies that a RunnableEntity needs read access to a VariableData Prototype in the role of implicitInterRunnableVariable or explicitInterRunnableVariable.
				The aggregation of readLocalVariable is subject to variability with the purpose to support the conditional existence of implicitInterRunnableVariable and explicit InterRunnableVariable or the variant existence of read LocalVariable (points) in the implementation.
				Stereotypes: atpSplitable; atpVariation
				Tags: atp.Splitkey=readLocalVariable.shortName, readLocal Variable.variationPoint.shortLabel vh.latestBindingTime=preCompileTime
serverCallPoint	ServerCallPoint	*	aggr	The RunnableEntity has a ServerCallPoint. The aggregation of ServerCallPoint is subject to variability with the purpose to support the conditional existence of client server PortPrototypes or the variant existence of server call points in the implementation.
				Stereotypes: atpSplitable; atpVariation
				Tags: atp.Splitkey=serverCallPoint.shortName, serverCall Point.variationPoint.shortLabel vh.latestBindingTime=preCompileTime
symbol	Cldentifier	01	attr	The symbol describing this RunnableEntity's entry point. This is considered the API of the RunnableEntity and is required during the RTE contract phase.
waitPoint	WaitPoint	*	aggr	The WaitPoint associated with the RunnableEntity.
writtenLocal Variable	VariableAccess	*	aggr	The presence of a writtenLocalVariable implies that a RunnableEntity needs write access to a VariableData Prototype in the role of implicitInterRunnableVariable or explicitInterRunnableVariable.
				The aggregation of writtenLocalVariable is subject to variability with the purpose to support the conditional existence of implicitInterRunnableVariable and explicit InterRunnableVariable or the variant existence of written LocalVariable (points) in the implementation.
				Stereotypes: atpSplitable; atpVariation Tags: atp.Splitkey=writtenLocalVariable.shortName, written LocalVariable.variationPoint.shortLabel vh.latestBindingTime=preCompileTime

Table A.61: RunnableEntity



Class	SenderReceiverInterface					
Package	M2::AUTOSARTemplates	::SWCom	onentTer	mplate::PortInterface		
Note	A sender/receiver interfac	A sender/receiver interface declares a number of data elements to be sent and received.				
	Tags:atp.recommendedP	Tags:atp.recommendedPackage=PortInterfaces				
Base	ARElement, ARObject, AtpBlueprint, AtpBlueprintable, AtpClassifier, AtpType, CollectableElement, DataInterface, Identifiable, MultilanguageReferrable, PackageableElement, PortInterface, Referrable					
Attribute	Туре	Mult.	Kind	Note		
dataElement	VariableDataPrototype	*	aggr	The data elements of this SenderReceiverInterface.		
invalidation Policy	InvalidationPolicy	*	aggr	InvalidationPolicy for a particular dataElement		
metaDataItem Set	MetaDataItemSet	*	aggr	This aggregation defines fixed sets of meta-data items associated with dataElements of the enclosing Sender ReceiverInterface		

Table A.62: SenderReceiverInterface

Class	StructuredReq	StructuredReq					
Package	M2::MSR::Documentation	n::BlockEle	ments::R	equirementsTracing			
Note	This represents a structured requirement. This is intended for a case where specific requirements for features are collected.						
	Note that this can be ren	dered as a	labeled li	st.			
Base	ARObject, DocumentVie Traceable	ewSelectabl	le, Identifi	able, MultilanguageReferrable, Paginateable, Referrable,			
Attribute	Туре	Mult.	Kind	Note			
appliesTo	standardNameEnum	*	attr	This attribute represents the platform the requirement is assigned to.			
				Tags: xml.namePlural=APPLIES-TO-DEPENDENCIES xml.sequenceOffset=25			
conflicts	DocumentationBlock	01	aggr	This represents an informal specification of conflicts.			
				Tags:xml.sequenceOffset=40			
date	DateTime	1	attr	This represents the date when the requirement was initiated.			
				Tags:xml.sequenceOffset=5			
dependencies	DocumentationBlock	01	aggr	This represents an informal specifiaction of dependencies. Note that upstream tracing should be formalized in the property trace provided by the superclass Traceable.			
				Tags:xml.sequenceOffset=30			
description	DocumentationBlock	01	aggr	Ths represents the general description of the requirement.			
				Tags:xml.sequenceOffset=10			
importance	String	1	attr	This allows to represent the importance of the requirement.			
				Tags:xml.sequenceOffset=8			
issuedBy	String	1	attr	This represents the person, organization or authority which issued the requirement.			
				Tags:xml.sequenceOffset=6			
rationale	DocumentationBlock	01	aggr	This represents the rationale of the requirement.			
				Tags:xml.sequenceOffset=20			



Class	StructuredReq			
remark	DocumentationBlock	01	aggr	This represents an informal remark. Note that this is not modeled as annotation, since these remark is still essential part of the requirement.
				Tags:xml.sequenceOffset=60
supporting Material	DocumentationBlock	01	aggr	This represents an informal specifiaction of the supporting material.
				Tags:xml.sequenceOffset=50
testedItem	Traceable	*	ref	This assocation represents the ability to trace on the same specification level. This supports for example the of acceptance tests.
				Tags:xml.sequenceOffset=70
type	String	1	attr	This attribute allows to denote the type of requirement to denote for example is it an "enhancement", "new feature" etc.
				Tags:xml.sequenceOffset=7
useCase	DocumentationBlock	01	aggr	This describes the relevant use cases. Note that formal references to use cases should be done in the trace relation.
				Tags:xml.sequenceOffset=35

Table A.63: StructuredReq

Class	SwAddrMethod					
Package	M2::MSR::DataDictionary::AuxillaryObjects					
Note	Used to assign a common addressing method, e.g. common memory section, to data or code objects. These objects could actually live in different modules or components.					
	Tags:atp.recommendedP	ackage=S	wAddrMe	thods		
Base	ARElement, ARObject, A Referrable, Packageable			eprintable, CollectableElement, Identifiable, Multilanguage		
Attribute	Туре	Mult.	Kind	Note		
memory Allocation KeywordPolicy	MemoryAllocation KeywordPolicyType	01	attr	Enumeration to specify the name pattern of the Memory Allocation Keyword.		
option	Identifier	*	attr	This attribute introduces the ability to specify further intended properties of the MemorySection in with the related objects shall be placed.		
				These properties are handled as to be selected. The intended options are mentioned in the list.		
				In the Memory Mapping configuration, this option list is used to determine an appropriate MemMapAddressing ModeSet.		
section Initialization Policy	SectionInitialization PolicyType	01	attr	Specifies the expected initialization of the variables (inclusive those which are implementing VariableData Prototypes). Therefore this is an implementation constraint for initialization code of BSW modules (especially RTE) as well as the start-up code which initializes the memory segment to which the AutosarData Prototypes referring to the SwAddrMethod's are later on mapped.		
				If the attribute is not defined it has the identical semantic as the attribute value "INIT"		





Class	SwAddrMethod			
sectionType	MemorySectionType	01	attr	Defines the type of memory sections which can be associated with this addresssing method.

Table A.64: SwAddrMethod

Class	SwAxisGrouped	SwAxisGrouped				
Package	M2::MSR::DataDictionary::Axis					
Note	An SwAxisGrouped is an	axis which	n is share	d between multiple calibration parameters.		
Base	ARObject, SwCalprmAxi	sTypeProp	s			
Attribute	Туре	Mult.	Kind	Note		
sharedAxisType	ApplicationPrimitive DataType	01	ref	This is the datatype of the calibration parameter providing the shared axis.		
swAxisIndex	AxisIndexType	01	attr	Describes which axis of the referenced calibration parameter provides the values for the group axis. The index satisfies the following convention:		
				 0 = value axis. in this case, the interpolation result of the referenced parameter is used as a base point index. 		
				The index should only be specified if the parameter under swCalprm contains more than one axis. It is standard practice for the axis index of parameters with more than one axis, to be set to 1, if data has not been assigned to swAxis Index.		
				Tags:xml.sequenceOffset=20		
swCalprmRef	SwCalprmRefProxy	1	aggr	This property specifes the calibration parameter which serves as the input axis. In AUTOSAR, the type of the referenced Calibration parameter shall be compatible to the type specified by sharedAxisType.		
				Tags: xml.roleElement=false xml.roleWrapperElement=false xml.sequenceOffset=30 xml.typeElement=false xml.typeWrapperElement=false		

Table A.65: SwAxisGrouped

Class	SwAxisIndividual	SwAxisIndividual			
Package	M2::MSR::DataDictiona	ary::Axis			
Note	This meta-class describes an axis integrated into a parameter (field etc.). The integration makes this individual to each parameter. The so-called grouped axis represents the counterpart to this. It is conceived as an independent parameter (see class SwAxisGrouped).				
Base	ARObject, SwCalprmA	xisTypeProp	s		
Attribute	Туре	Mult.	Kind	Note	
compuMethod	CompuMethod	CompuMethod 01 ref This is the compuMethod which is expected for the axis. It is used in early stages if the particular input-value is not yet available.			
				Tags:xml.sequenceOffset=30	





			Δ	
Class	SwAxisIndividual			
dataConstr	DataConstr	01	ref	Refers to constraints, e.g. for plausibility checks.
				Tags:xml.sequenceOffset=80
inputVariable Type	ApplicationPrimitive DataType	01	ref	This is the datatype of the input value for the axis. This allows to define e.g. a type of curve, where the input value is finalized at the access point.
swAxisGeneric	SwAxisGeneric	01	aggr	this specifies the properties of a generic axis if applicable Tags:xml.sequenceOffset=90
swMaxAxis Points	Integer	01	attr	Maximum number of base points contained in the axis of a map or curve.
Tomos				Stereotypes: atpVariation Tags: vh.latestBindingTime=preCompileTime xml.sequenceOffset=60
swMinAxis Points	Integer	01	attr	Minimum number of base points contained in the axis of map or curve.
				Stereotypes: atpVariation Tags: vh.latestBindingTime=preCompileTime xml.sequenceOffset=70
swVariableRef (ordered)	SwVariableRefProxy	*	aggr	Refers to input variables of the axis. It is possible to specify more than one variable. Here the following is valid:
				 The variable with the highest priority shall be given first. It is used in the generation of the cod and is also displayed first in the application system.
				 All variables referenced shall be of the same physical nature. This is usually detected in that the conversion formulae affected refer back to the same SI-units.
				In AUTOSAR this ensured by the constraint, that the referenced input variables shall use a type compatible to "inputVariableType".
				 This multiple referencing allows a base point distribution for more than one input variable to be used. One example of this are the temperature curves which can depend both on the induction air temperature and the engine temperature.
				These variables can be displayed simultaneously by MCI systems (adjustment systems), enabling operating points to be shown in the curves.
				Tags: xml.roleElement=false xml.roleWrapperElement=true xml.sequenceOffset=20 xml.typeElement=false xml.typeWrapperElement=false
unit	Unit	01	ref	This represents the physical unit of the input value of the axis. It is provided to support the case that the particular input variable is not yet known.
				Tags:xml.sequenceOffset=40

Table A.66: SwAxisIndividual



Class	SwBaseType			
Package	M2::MSR::AsamHdo::Bas	M2::MSR::AsamHdo::BaseTypes		
Note	This meta-class represent	This meta-class represents a base type used within ECU software.		
	Tags:atp.recommendedPa	ackage=B	aseTypes	
Base	ARElement, ARObject, A MultilanguageReferrable,			eprintable, BaseType, CollectableElement, Identifiable, nt, Referrable
Attribute	Туре	Type Mult. Kind Note		
_	_	-	_	-

Table A.67: SwBaseType

Enumeration	SwCalibrationAccessEnum
Package	M2::MSR::DataDictionary::DataDefProperties
Note	Determines the access rights to a data object w.r.t. measurement and calibration.
Literal	Description
notAccessible	The element will not be accessible via MCD tools, i.e. will not appear in the ASAP file.
	Tags:atp.EnumerationLiteralIndex=0
readOnly	The element will only appear as read-only in an ASAP file.
	Tags:atp.EnumerationLiteralIndex=1
readWrite	The element will appear in the ASAP file with both read and write access.
	Tags:atp.EnumerationLiteralIndex=2

Table A.68: SwCalibrationAccessEnum

Class	SwCalprmAxis					
Package	M2::MSR::DataDictionary::CalibrationParameter					
Note	This element specifies ar	n individual	input par	ameter axis (abscissa).		
Base	ARObject					
Attribute	Туре	Type Mult. Kind Note				
category	CalprmAxisCategory	01	attr	This property specifies the category of a particular axis.		
	Enum			Tags:xml.sequenceOffset=30		
displayFormat	DisplayFormatString	01	attr	This property specifies how the axis values shall be displayed e.g. in documents or in measurement and calibration tools.		
				Tags:xml.sequenceOffset=100		
swAxisIndex	AxisIndexType	01	attr	This attribute specifies which axis is specified by the containing SwCalprmAxis.		
				For example in a curve this is usually "1". In a map this is "1" or "2".		
				Tags:xml.sequenceOffset=20		
swCalibration	SwCalibrationAccess	01	attr	Describes the applicability of parameters and variables.		
Access	Enum			Tags:xml.sequenceOffset=90		



Class	SwCalprmAxis			
swCalprmAxis TypeProps	SwCalprmAxisType Props	01	aggr	specific properties depending on the type of the axis. Tags: xml.roleElement=false xml.roleWrapperElement=false xml.sequenceOffset=40 xml.typeElement=true xml.typeWrapperElement=false

Table A.69: SwCalprmAxis

Class	SwCalprmAxisSet					
Package	M2::MSR::DataDiction	ary::Calibration	onParame	eter		
Note	This element specifies the input parameter axes (abscissas) of parameters (and variables, if these are used adaptively).					
Base	ARObject					
Attribute	Type Mult. Kind Note					
swCalprmAxis	SwCalprmAxis * aggr One axis belonging to this SwCalprmAxisSet					
				Tags: xml.roleElement=true xml.roleWrapperElement=false xml.sequenceOffset=20 xml.typeElement=false xml.typeWrapperElement=false		

Table A.70: SwCalprmAxisSet

Class	SwComponentPrototyp	SwComponentPrototype					
Package	M2::AUTOSARTemplate:	M2::AUTOSARTemplates::SWComponentTemplate::Composition					
Note	Role of a software comp	Role of a software component within a composition.					
Base	ARObject, AtpFeature, A	ARObject, AtpFeature, AtpPrototype, Identifiable, MultilanguageReferrable, Referrable					
Attribute	Туре	Mult.	Kind	Note			
type	SwComponentType	SwComponentType 01 tref Type of the instance.					
				Stereotypes: isOfType			

Table A.71: SwComponentPrototype

Class	SwComponentType (abstr	SwComponentType (abstract)					
Package	M2::AUTOSARTemplates::	M2::AUTOSARTemplates::SWComponentTemplate::Components					
Note	Base class for AUTOSAR s	Base class for AUTOSAR software components.					
Base		ARElement, ARObject, AtpBlueprint, AtpBlueprintable, AtpClassifier, AtpType, CollectableElement, Identifiable, MultilanguageReferrable, PackageableElement, Referrable					
Subclasses	AtomicSwComponentType, CompositionSwComponentType, ParameterSwComponentType						
Attribute	Туре						





Class	SwComponentType (at	ostract)		
consistency Needs	ConsistencyNeeds	*	aggr	This represents the collection of ConsistencyNeeds owned by the enclosing SwComponentType.
				Stereotypes: atpSplitable; atpVariation Tags: atp.Splitkey=consistencyNeeds.shortName, consistency Needs.variationPoint.shortLabel vh.latestBindingTime=preCompileTime
port	PortPrototype	*	aggr	The PortPrototypes through which this SwComponent Type can communicate.
				The aggregation of PortPrototype is subject to variability with the purpose to support the conditional existence of PortPrototypes.
				Stereotypes: atpSplitable; atpVariation Tags: atp.Splitkey=port.shortName, port.variationPoint.short Label vh.latestBindingTime=preCompileTime
portGroup	PortGroup	*	aggr	A port group being part of this component.
				Stereotypes: atpVariation Tags:vh.latestBindingTime=preCompileTime
swComponent	SwComponent	01	aggr	This adds a documentation to the SwComponentType.
Documentation	Documentation			Stereotypes: atpSplitable; atpVariation Tags: atp.Splitkey=swComponentDocumentation, sw ComponentDocumentation.variationPoint.shortLabel vh.latestBindingTime=preCompileTime xml.sequenceOffset=-10
unitGroup	UnitGroup	*	ref	This allows for the specification of which UnitGroups are relevant in the context of referencing SwComponentType

Table A.72: SwComponentType

Class	< <atpvariation>> SwDataDefProps</atpvariation>				
Package	M2::MSR::DataDictionary::DataDefProperties				
Note	This class is a collection of properties relevant for data objects under various aspects. One could consider this class as a "pattern of inheritance by aggregation". The properties can be applied to all objects of all classes in which SwDataDefProps is aggregated.				
	Note that not all of the attributes or associated elements are useful all of the time. Hence, the process definition (e.g. expressed with an OCL or a Document Control Instance MSR-DCI) has the task of implementing limitations.				
	SwDataDefProps covers various aspects:				
	 Structure of the data element for calibration use cases: is it a single value, a curve, or a map, but also the recordLayouts which specify how such elements are mapped/converted to the Data Types in the programming language (or in AUTOSAR). This is mainly expressed by properties like swRecordLayout and swCalprmAxisSet 				
	 Implementation aspects, mainly expressed by swImplPolicy, swVariableAccessImplPolicy, sw AddrMethod, swPointerTagetProps, baseType, implementationDataType and additionalNative TypeQualifier 				
	Access policy for the MCD system, mainly expressed by swCalibrationAccess				





Class	< <atpvariation>> SwDataDefProps</atpvariation>						
	 Semantics of the data element, mainly expressed by compuMethod and/or unit, dataConstr, invalidValue 						
	 Code generation policy provided by swRecordLayout 						
	Tags:vh.latestBindingTime=codeGenerationTime						
Base	ARObject						
Attribute	Туре	Mult.	Kind	Note			
additionalNative TypeQualifier	NativeDeclarationString	01	attr	This attribute is used to declare native qualifiers of the programming language which can neither be deduced from the baseType (e.g. because the data object describes a pointer) nor from other more abstract attributes. Examples are qualifiers like "volatile", "strict" or "enum" of the C-language. All such declarations have to be put into one string.			
				Tags:xml.sequenceOffset=235			
annotation	Annotation	*	aggr	This aggregation allows to add annotations (yellow pads) related to the current data object. Tags: xml.roleElement=true xml.roleWrapperElement=true xml.sequenceOffset=20 xml.typeElement=false xml.typeWrapperElement=false			
baseType	SwBaseType	01	ref	Base type associated with the containing data object.			
				Tags:xml.sequenceOffset=50			
compuMethod	CompuMethod	01	ref	Computation method associated with the semantics of this data object.			
				Tags:xml.sequenceOffset=180			
dataConstr	DataConstr	01	ref	Data constraint for this data object.			
				Tags:xml.sequenceOffset=190			
displayFormat	DisplayFormatString	01	attr	This property describes how a number is to be rendered e.g. in documents or in a measurement and calibration system.			
				Tags:xml.sequenceOffset=210			
display Presentation	DisplayPresentation Enum	01	attr	This attribute controls the presentation of the related data for measurement and calibration tools.			
implementation DataType	AbstractImplementation DataType	01	ref	This association denotes the ImplementationDataType of a data declaration via its aggregated SwDataDefProps. It is used whenever a data declaration is not directly referring to a base type. Especially			
				 redefinition of an ImplementationDataType via a "typedef" to another ImplementationDatatype 			
				 the target type of a pointer (see SwPointerTarget Props), if it does not refer to a base type directly 			
				 the data type of an array or record element within an ImplementationDataType, if it does not refer to a base type directly 			
				 the data type of an SwServiceArg, if it does not refer to a base type directly 			
				Tags:xml.sequenceOffset=215			





Class	< <atpvariation>> SwDat</atpvariation>	aDefProps	<u> </u>	
invalidValue	ValueSpecification	01		Optional value to express invalidity of the actual data
ilivalid value	valueopecinication	01	aggr	element. Tags:xml.sequenceOffset=255
-tCi	Floor	0.1	-44	,
stepSize	Float	01	attr	This attribute can be used to define a value which is added to or subtracted from the value of a DataPrototype when using up/down keys while calibrating.
swAddrMethod	SwAddrMethod	01	ref	Addressing method related to this data object. Via an association to the same SwAddrMethod it can be specified that several DataPrototypes shall be located in the same memory without already specifying the memory section itself.
				Tags:xml.sequenceOffset=30
swAlignment	AlignmentType	01	attr	The attribute describes the intended alignment of the DataPrototype. If the attribute is not defined the alignment is determined by the swBaseType size and the memory AllocationKeywordPolicy of the referenced SwAddr Method.
				Tags:xml.sequenceOffset=33
swBit Representation	SwBitRepresentation	01	aggr	Description of the binary representation in case of a bit variable.
				Tags:xml.sequenceOffset=60
swCalibration Access	SwCalibrationAccess Enum	01	attr	Specifies the read or write access by MCD tools for this data object.
				Tags:xml.sequenceOffset=70
swCalprmAxis Set	SwCalprmAxisSet	01	aggr	This specifies the properties of the axes in case of a curve or map etc. This is mainly applicable to calibration parameters.
				Tags:xml.sequenceOffset=90
swComparison	SwVariableRefProxy	*	aggr	Variables used for comparison in an MCD process.
Variable				Tags:
				xml.sequenceOffset=170 xml.typeElement=false
swData Dependency	SwDataDependency	01	aggr	Describes how the value of the data object has to be calculated from the value of another data object (by the MCD system).
				Tags:xml.sequenceOffset=200
swHostVariable	SwVariableRefProxy	01	aggr	Contains a reference to a variable which serves as a host-variable for a bit variable. Only applicable to bit objects.
				Tags: xml.sequenceOffset=220 xml.typeElement=false
swImplPolicy	SwImplPolicyEnum	01	attr	Implementation policy for this data object.
				Tags:xml.sequenceOffset=230
swintended Resolution	Numerical	01	attr	The purpose of this element is to describe the requested quantization of data objects early on in the design process.
				The resolution ultimately occurs via the conversion formula present (compuMethod), which specifies the transition from the physical world to the standardized





 \wedge

Class	< <atpvariation>> SwData</atpvariation>	aDefProps	3	
				In the case of a development phase without a fixed conversion formula, a pre-specification can occur through swIntendedResolution.
				The resolution is specified in the physical domain according to the property "unit".
				Tags:xml.sequenceOffset=240
swInterpolation Method	Identifier	01	attr	This is a keyword identifying the mathematical method to be applied for interpolation. The keyword needs to be related to the interpolation routine which needs to be invoked.
				Tags:xml.sequenceOffset=250
swlsVirtual	Boolean	01	attr	This element distinguishes virtual objects. Virtual objects do not appear in the memory, their derivation is much more dependent on other objects and hence they shall have a swDataDependency.
				Tags:xml.sequenceOffset=260
swPointerTarget Props	SwPointerTargetProps	01	aggr	Specifies that the containing data object is a pointer to another data object.
				Tags:xml.sequenceOffset=280
swRecord	SwRecordLayout	01	ref	Record layout for this data object.
Layout				Tags:xml.sequenceOffset=290
swRefresh Timing	MultidimensionalTime	01	aggr	This element specifies the frequency in which the object involved shall be or is called or calculated. This timing can be collected from the task in which write access processes to the variable run. But this cannot be done by the MCD system.
				So this attribute can be used in an early phase to express the desired refresh timing and later on to specify the real refresh timing.
				Tags:xml.sequenceOffset=300
swTextProps	SwTextProps	01	aggr	the specific properties if the data object is a text object.
				Tags:xml.sequenceOffset=120
swValueBlock	Numerical	01	attr	This represents the size of a Value Block
Size				Stereotypes: atpVariation Tags: vh.latestBindingTime=preCompileTime xml.sequenceOffset=80
swValueBlock SizeMult (ordered)	Numerical	*	attr	This attribute is used to specify the dimensions of a value block (VAL_BLK) for the case that that value block has more than one dimension.
				The dimensions given in this attribute are ordered such that the first entry represents the first dimension, the second entry represents the second dimension, and so on.
				For one-dimensional value blocks the attribute swValue BlockSize shall be used and this attribute shall not exist.
				Stereotypes: atpVariation Tags:vh.latestBindingTime=preCompileTime





Class	< <atpvariation>> SwDataDefProps</atpvariation>			
unit	Unit	01	ref	Physical unit associated with the semantics of this data object. This attribute applies if no compuMethod is specified. If both units (this as well as via compuMethod) are specified the units shall be compatible.
				Tags:xml.sequenceOffset=350
valueAxisData Type	ApplicationPrimitive DataType	01	ref	The referenced ApplicationPrimitiveDataType represents the primitive data type of the value axis within a compound primitive (e.g. curve, map). It supersedes CompuMethod, Unit, and BaseType.
				Tags:xml.sequenceOffset=355

Table A.73: SwDataDefProps

Enumeration	SwImplPolicyEnum
Package	M2::MSR::DataDictionary::DataDefProperties
Note	Specifies the implementation strategy with respect to consistency mechanisms of variables.
Literal	Description
const	forced implementation such that the running software within the ECU shall not modify it. For example implemented with the "const" modifier in C. This can be applied for parameters (not for those in NVRAM) as well as argument data prototypes.
	Tags:atp.EnumerationLiteralIndex=0
fixed	This data element is fixed. In particular this indicates, that it might also be implemented e.g. as in place data, (#DEFINE).
	Tags:atp.EnumerationLiteralIndex=1
measurementPoint	The data element is created for measurement purposes only. The data element is never read directly within the ECU software. In contrast to a "standard" data element in an unconnected provide port is, this unconnection is guaranteed for measurementPoint data elements.
	Tags:atp.EnumerationLiteralIndex=2
queued	The content of the data element is queued and the data element has 'event' semantics, i.e. data elements are stored in a queue and all data elements are processed in 'first in first out' order. The queuing is intended to be implemented by RTE Generator. This value is not applicable for parameters.
	Tags:atp.EnumerationLiteralIndex=3
standard	This is applicable for all kinds of data elements. For variable data prototypes the 'last is best' semantics applies. For parameter there is no specific implementation directive.
	Tags:atp.EnumerationLiteralIndex=4

Table A.74: SwlmplPolicyEnum

Class	SwcImplementation	SwcImplementation				
Package	M2::AUTOSARTemplates	::SWComp	onentTer	nplate::SwcImplementation		
Note		This meta-class represents a specialization of the general Implementation meta-class with respect to the usage in application software.				
	Tags:atp.recommendedP	Tags:atp.recommendedPackage=SwcImplementations				
Base	ARElement, ARObject, C PackageableElement, Re		Element,	Identifiable, Implementation, MultilanguageReferrable,		
Attribute	Туре	Type Mult. Kind Note				
behavior	SwcInternalBehavior					
				I.		





Class	SwcImplementation			
perInstance MemorySize	PerInstanceMemory Size	*	aggr	Allows a definition of the size of the per-instance memory for this implementation. The aggregation of PerInstance MemorySize is subject to variability with the purpose to support variability in the software components implementations. Typically different algorithms in the implementation are requiring different number of memory objects, in this case PerInstanceMemory.
				Stereotypes: atpVariation Tags:vh.latestBindingTime=preCompileTime
required RTEVendor	String	01	attr	Identify a specific RTE vendor. This information is potentially important at the time of integrating (in particular: linking) the application code with the RTE. The semantics is that (if the association exists) the corresponding code has been created to fit to the vendor-mode RTE provided by this specific vendor. Attempting to integrate the code with another RTE generated in vendor mode is in general not possible.

Table A.75: SwcImplementation

Class	SwcInternalBehavior	SwcInternalBehavior						
Package	M2::AUTOSARTemplates	M2::AUTOSARTemplates::SWComponentTemplate::SwcInternalBehavior						
Note				mponentType describes the relevant aspects of the i.e. the RunnableEntities and the RTEEvents they respond				
Base	ARObject, AtpClassifier, Referrable, Referrable	AtpFeatur	e, AtpStru	uctureElement, Identifiable, InternalBehavior, Multilanguage				
Attribute	Туре	Mult.	Kind	Note				
arTypedPer Instance	VariableDataPrototype	*	aggr	Defines an AUTOSAR typed memory-block that needs to be available for each instance of the SW-component.				
Memory				This is typically only useful if supportsMultipleInstantiation is set to "true" or if the component defines NVRAM access via permanent blocks.				
				The aggregation of arTypedPerInstanceMemory is subject to variability with the purpose to support variability in the software component's implementations. Typically different algorithms in the implementation are requiring different number of memory objects.				
				Stereotypes: atpSplitable; atpVariation Tags: atp.Splitkey=arTypedPerInstanceMemory.shortName, ar TypedPerInstanceMemory.variationPoint.shortLabel vh.latestBindingTime=preCompileTime				
event	RTEEvent	*	aggr	This is a RTEEvent specified for the particular Swc InternalBehavior.				
				The aggregation of RTEEvent is subject to variability with the purpose to support the conditional existence of RTE events. Note: the number of RTE events might vary due to the conditional existence of PortPrototypes using Data ReceivedEvents or due to different scheduling needs of algorithms.				



	1			
Class	SwcInternalBehavior	Г	ı	
				Stereotypes: atpSplitable; atpVariation Tags: atp.Splitkey=event.shortName, event.variationPoint.short Label vh.latestBindingTime=preCompileTime
exclusiveArea Policy	SwcExclusiveArea Policy	*	aggr	Options how to generate the ExclusiveArea related APIs. When no SwcExclusiveAreaPolicy is specified for an ExclusiveArea the default values apply. Stereotypes: atpSplitable; atpVariation Tags: atp.Splitkey=exclusiveAreaPolicy, exclusiveArea Policy.variationPoint.shortLabel vh.latestBindingTime=preCompileTime
explicitInter Runnable Variable	VariableDataPrototype	*	aggr	Implement state message semantics for establishing communication among runnables of the same component. The aggregation of explicitInterRunnable Variable is subject to variability with the purpose to support variability in the software components implementations. Typically different algorithms in the implementation are requiring different number of memory objects. Stereotypes: atpSplitable; atpVariation Tags:
handle TerminationAnd Restart	HandleTerminationAnd RestartEnum	01	attr	atp.Splitkey=explicitInterRunnableVariable.shortName, explicitInterRunnableVariable.variationPoint.shortLabel vh.latestBindingTime=preCompileTime This attribute controls the behavior with respect to stopping and restarting. The corresponding AtomicSw ComponentType may either not support stop and restart,
implicitInter Runnable Variable	VariableDataPrototype	*	aggr	or support only stop, or support both stop and restart. Implement state message semantics for establishing communication among runnables of the same component. The aggregation of implicitInterRunnable Variable is subject to variability with the purpose to support variability in the software components implementations. Typically different algorithms in the implementation are requiring different number of memory objects.
				Stereotypes: atpSplitable; atpVariation Tags: atp.Splitkey=implicitInterRunnableVariable.shortName, implicitInterRunnableVariable.variationPoint.shortLabel vh.latestBindingTime=preCompileTime
includedData TypeSet	IncludedDataTypeSet	*	aggr	The includedDataTypeSet is used by a software component for its implementation. Stereotypes: atpSplitable
				Tags:atp.Splitkey=includedDataTypeSet
includedMode Declaration	IncludedMode DeclarationGroupSet	*	aggr	This aggregation represents the included Mode DeclarationGroups
GroupSet				Stereotypes: atpSplitable Tags:atp.Splitkey=includedModeDeclarationGroupSet





Class	SwcInternalBehavior			
instantiation DataDefProps	InstantiationDataDef Props	*	aggr	The purpose of this is that within the context of a given SwComponentType some data def properties of individua instantiations can be modified. The aggregation of InstantiationDataDefProps is subject to variability with the purpose to support the conditional existence of Port Prototypes and component local memories like "per InstanceParameter" or "arTypedPerInstanceMemory".
				Stereotypes: atpSplitable; atpVariation Tags: atp.Splitkey=instantiationDataDefProps, instantiationData DefProps.variationPoint.shortLabel vh.latestBindingTime=preCompileTime
perInstance Memory	PerInstanceMemory	*	aggr	Defines a per-instance memory object needed by this software component. The aggregation of PerInstance Memory is subject to variability with the purpose to support variability in the software components implementations. Typically different algorithms in the implementation are requiring different number of memory objects.
				Stereotypes: atpSplitable; atpVariation Tags: atp.Splitkey=perInstanceMemory.shortName, perInstance Memory.variationPoint.shortLabel vh.latestBindingTime=preCompileTime
perInstance Parameter	ParameterData Prototype	*	aggr	Defines parameter(s) or characteristic value(s) that needs to be available for each instance of the software-component. This is typically only useful if supportsMultipleInstantiation is set to "true". The aggregation of perInstanceParameter is subject to variability with the purpose to support variability in the software components implementations. Typically different algorithms in the implementation are requiring different number of memory objects.
				Stereotypes: atpSplitable; atpVariation Tags: atp.Splitkey=perInstanceParameter.shortName, per InstanceParameter.variationPoint.shortLabel vh.latestBindingTime=preCompileTime
portAPIOption	PortAPIOption	*	aggr	Options for generating the signature of port-related calls from a runnable to the RTE and vice versa. The aggregation of PortPrototypes is subject to variability with the purpose to support the conditional existence of ports.
				Stereotypes: atpSplitable; atpVariation Tags: atp.Splitkey=portAPIOption, portAPIOption.variation Point.shortLabel vh.latestBindingTime=preCompileTime
runnable	RunnableEntity	*	aggr	This is a RunnableEntity specified for the particular Swc InternalBehavior. The aggregation of RunnableEntity is subject to variability with the purpose to support the conditional existence of RunnableEntities. Note: the number of RunnableEntities might vary due to the conditional existence of Port Prototypes using DataReceivedEvents or due to different scheduling needs of algorithms.





Class	SwcInternalBehavior	T		
				Stereotypes: atpSplitable; atpVariation Tags: atp.Splitkey=runnable.shortName, runnable.variation Point.shortLabel vh.latestBindingTime=preCompileTime
service Dependency	SwcService Dependency	*	aggr	Defines the requirements on AUTOSAR Services for a particular item. The aggregation of SwcServiceDependency is subject to variability with the purpose to support the conditional existence of ports as well as the conditional existence of ServiceNeeds.
				The SwcServiceDependency owned by an SwcInternal Behavior can be located in a different physical file in order to support that SwcServiceDependency might be provided in later development steps or even by different expert domain (e.g OBD expert for Obd related Service Needs) tools. Therefore the aggregation is < <atp>splitable>>.</atp>
				Stereotypes: atpSplitable; atpVariation Tags: atp.Splitkey=serviceDependency.shortName, service Dependency.variationPoint.shortLabel vh.latestBindingTime=preCompileTime
shared Parameter	ParameterData Prototype	*	aggr	Defines parameter(s) or characteristic value(s) shared between SwComponentPrototypes of the same Sw ComponentType The aggregation of sharedParameter is subject to variability with the purpose to support variability in the software components implementations. Typically different algorithms in the implementation are requiring different number of memory objects.
				Stereotypes: atpSplitable; atpVariation Tags: atp.Splitkey=sharedParameter.shortName, shared Parameter.variationPoint.shortLabel vh.latestBindingTime=preCompileTime
supports Multiple Instantiation	Boolean	01	attr	Indicate whether the corresponding software-component can be multiply instantiated on one ECU. In this case the attribute will result in an appropriate component API on programming language level (with or without instance handle).
variationPoint Proxy	VariationPointProxy	*	aggr	Proxy of a variation points in the C/C++ implementation. Stereotypes: atpSplitable Tags:atp.Splitkey=variationPointProxy.shortName

Table A.76: SwcInternalBehavior

Class	System		
Package	M2::AUTOSARTemplates::SystemTemplate		





Class	System							
Note				tion. The System description defines five major elements: g and Mapping Constraints.				
	The System element directly aggregates the elements describing the Software, Mapping and Mapping Constraints; it contains a reference to an ASAM FIBEX description specifying Communication and Topology.							
	Tags:atp.recommendedF	Package=S	ystems					
Base		ARElement, ARObject, AtpClassifier, AtpFeature, AtpStructureElement, CollectableElement, Identifiable, MultilanguageReferrable, PackageableElement, Referrable						
Attribute	Туре	Mult.	Kind	Note				
clientId DefinitionSet	ClientIdDefinitionSet	*	ref	Set of Client Identifiers that are used for inter-ECU client-server communication in the System.				
containerlPdu HeaderByte Order	ByteOrderEnum	01	attr	Defines the byteOrder of the header in ContainerlPdus.				
ecuExtract Version	RevisionLabelString	01	attr	Version number of the Ecu Extract.				
fibexElement	FibexElement	*	ref	Reference to ASAM FIBEX elements specifying Communication and Topology.				
				All Fibex Elements used within a System Description shall be referenced from the System Element.				
				atpVariation: In order to describe a product-line, all Fibex Elements can be optional.				
				Stereotypes: atpVariation Tags:vh.latestBindingTime=postBuild				
interpolation Routine MappingSet	InterpolationRoutine MappingSet	*	ref	This reference identifies the InterpolationRoutineMapping Sets that are relevant in the context of the enclosing System.				
j1939Shared AddressCluster	J1939SharedAddress Cluster	*	aggr	Collection of J1939Clusters that share a common address space for the routing of messages.				
				Stereotypes: atpSplitable; atpVariation				
				Tags: atp.Splitkey=j1939SharedAddressCluster.shortName, j1939SharedAddressCluster.variationPoint.shortLabel vh.latestBindingTime=postBuild				
mapping	SystemMapping	*	aggr	Aggregation of all mapping aspects (mapping of SW components to ECUs, mapping of data elements to signals, and mapping constraints).				
				In order to support OEM / Tier 1 interaction and shared development for one common System this aggregation is atpSplitable and atpVariation. The content of System Mapping can be provided by several parties using different names for the SystemMapping.				
				This element is not required when the System description is used for a network-only use-case.				
				Stereotypes: atpSplitable; atpVariation				
				Tags: atp.Splitkey=mapping.shortName, mapping.variation Point.shortLabel vh.latestBindingTime=postBuild				
pncVector Length	PositiveInteger	01	attr	Length of the partial networking request release information vector (in bytes).				





Class	System			
pncVectorOffset	PositiveInteger	01	attr	Absolute offset (with respect to the NM-PDU) of the partial networking request release information vector that is defined in bytes as an index starting with 0.
rootSoftware Composition	RootSwComposition Prototype	01	aggr	Aggregation of the root software composition, containing all software components in the System in a hierarchical structure. This element is not required when the System description is used for a network-only use-case.
				atpVariation: The RootSwCompositionPrototype can vary.
				Stereotypes: atpSplitable; atpVariation Tags: atp.Splitkey=rootSoftwareComposition.shortName, root SoftwareComposition.variationPoint.shortLabel vh.latestBindingTime=systemDesignTime
swCluster	CpSoftwareCluster	*	ref	CP Software Clusters of this System
				Stereotypes: atpSplitable; atpVariation Tags: atp.Splitkey=swCluster.cpSoftwareCluster, sw Cluster.variationPoint.shortLabel atp.Status=draft vh.latestBindingTime=systemDesignTime
system Documentation	Chapter	*	aggr	Possibility to provide additional documentation while defining the System. The System documentation can be composed of several chapters.
				Stereotypes: atpSplitable; atpVariation Tags: atp.Splitkey=systemDocumentation.shortName, system Documentation.variationPoint.shortLabel vh.latestBindingTime=systemDesignTime xml.sequenceOffset=-10
systemVersion	RevisionLabelString	1	attr	Version number of the System Description.

Table A.77: System

Class	TimingEvent	TimingEvent				
Package	M2::AUTOSARTemplates	::SWComp	onentTer	nplate::SwcInternalBehavior::RTEEvents		
Note	TimingEvent references to	he Runnab	oleEntity t	hat need to be started in response to the TimingEvent		
Base	ARObject, AbstractEvent Referrable, RTEEvent, R		sifier, Atpl	Feature, AtpStructureElement, Identifiable, Multilanguage		
Attribute	Туре	Type Mult. Kind Note				
offset	TimeValue	01	attr	The value makes an assumption about the time offset of the first activation of the RunnableEntity triggered by the mapped TimingEvent relative to the periodic activation of the time base of this TimingEvent. Unit: second.		
period	TimeValue	01	attr	Period of timing event in seconds. The value of this attribute shall be greater than zero.		

Table A.78: TimingEvent



Class	Traceable (abstract)	Traceable (abstract)				
Package	M2::MSR::Documentation	::BlockEle	ments::R	equirementsTracing		
Note	This meta class represent	s the abili	ty to be su	ubject to tracing within an AUTOSAR model.		
	Identifiable. Nevertheless	Note that it is expected that its subclasses inherit either from MultilanguageReferrable or from Identifiable. Nevertheless it also inherits from MultilanguageReferrable in order to provide a common reference target for all Traceables.				
Base	ARObject, Multilanguage	Referrable	, Referral	ple		
Subclasses	StructuredReq, TimingCo	nstraint, T	raceableT	able, TraceableText		
Attribute	Туре	Mult.	Kind	Note		
trace	Traceable	*	ref	This assocation represents the ability to trace to upstream requirements / constraints. This supports for example the bottom up tracing		
		ProjectObjectives <- MainRequirements <- Features <- RequirementSpecs <- BSW/AI				
				Tags:xml.sequenceOffset=20		

Table A.79: Traceable

Class	Unit	Unit					
Package	M2::MSR::AsamHdo::Units						
Note	This is a physical measure convert one unit into anoth			that might be defined should stem from SI units. In order to t are defined.			
		For the calculation from SI-unit to the defined unit the factor (factorSiToUnit) and the offset (offsetSiTo Unit) are applied as follows:					
	x [{unit}] := y * [{siUnit}] * f	actorSiTo	Unit [[unit]	/{siUnit}] + offsetSiToUnit [{unit}]			
	For the calculation from a the offset (offsetSiToUnit)			eciprocal of the factor (factorSiToUnit) and the negation of			
	$y \{siUnit\} := (x*\{unit\} - offs)$	etSiToUni	t [{unit}]) /	(factorSiToUnit [[unit]/{siUnit}]			
	Tags:atp.recommendedPa	ackage=U	nits				
Base	ARElement, ARObject, CollectableElement, Identifiable, MultilanguageReferrable, Packageable Element, Referrable						
Attribute	Туре	Mult.	Kind	Note			
displayName	SingleLanguageUnit Names	01	aggr	This specifies how the unit shall be displayed in documents or in user interfaces of tools. The displayName corresponds to the Unit. Display in an ASAM MCD-2MC file.			
				Tags:xml.sequenceOffset=20			
factorSiToUnit	Float	01	attr	This is the factor for the conversion from SI Units to units.			
				The inverse is used for conversion from units to SI Units.			
				Tags:xml.sequenceOffset=30			
offsetSiToUnit	Float	01	attr	This is the offset for the conversion from and to siUnits.			
				Tags:xml.sequenceOffset=40			
physical Dimension	PhysicalDimension	01	ref	This association represents the physical dimension to which the unit belongs to. Note that only values with units of the same physical dimensions might be converted.			
				Tags:xml.sequenceOffset=50			

Table A.80: Unit



Class	UnitGroup	UnitGroup				
Package	M2::MSR::AsamHdo::Unit	M2::MSR::AsamHdo::Units				
Note	This meta-class represents the ability to specify a logical grouping of units. The category denotes the unit system that the referenced units are associated to.					
	In this way, e.g. country-specific unit systems (CATEGORY="COUNTRY") can be defined as well as specific unit systems for certain application domains.					
	In the same way a group of equivalent units, can be defined which are used in different countri setting CATEGORY="EQUIV_UNITS". KmPerHour and MilesPerHour could such be combined group named "vehicle_speed". The unit MeterPerSec would not belong to this group because normally not used for vehicle speed. But all of the mentioned units could be combined to one gnamed "speed".					
	Note that the UnitGroup does not ensure the physical compliance of the units. This is maintained by the physical dimension.					
	Tags:atp.recommendedPackage=UnitGroups					
Base	ARElement, ARObject, C Element, Referrable	ARElement, ARObject, CollectableElement, Identifiable, MultilanguageReferrable, Packageable Element, Referrable				
Attribute	Туре	Mult.	Kind	Note		
unit	Unit	*	ref	This represents one particular unit in the UnitGroup.		
				Tags:xml.sequenceOffset=20		

Table A.81: UnitGroup

Class	ValueSpecification (abstract)				
Package	M2::AUTOSARTemplates::CommonStructure::Constants				
Note	Base class for expressions leading to a value which can be used to initialize a data object.				
Base	ARObject				
Subclasses	AbstractRuleBasedValueSpecification, ApplicationValueSpecification, CompositeValueSpecification, ConstantReference, NotAvailableValueSpecification, NumericalValueSpecification, ReferenceValue Specification, TextValueSpecification				
Attribute	Туре	Mult.	Kind	Note	
shortLabel	Identifier	01	attr	This can be used to identify particular value specifications for human readers, for example elements of a record type.	

Table A.82: ValueSpecification

Class	VariableDataPrototype					
Package	M2::AUTOSARTemplate	M2::AUTOSARTemplates::SWComponentTemplate::Datatype::DataPrototypes				
Note	A VariableDataPrototype is used to contain values in an ECU application. This means that most likely a VariableDataPrototype allocates "static" memory on the ECU. In some cases optimization strategies might lead to a situation where the memory allocation can be avoided.					
	In particular, the value of a VariableDataPrototype is likely to change as the ECU on which it is used executes.					
Base	ARObject, AtpFeature, AtpPrototype, AutosarDataPrototype, DataPrototype, Identifiable, Multilanguage Referrable, Referrable					
Attribute	Туре	Mult.	Kind	Note		
initValue	ValueSpecification	01	aggr	Specifies initial value(s) of the VariableDataPrototype		

Table A.83: VariableDataPrototype