

MICROSAR vlpc

Technical Reference

Inter Processor Communication Version 0.1.0

Authors	David Zentner
Status	Not Released



Document Information

History

Author	Date	Version	Remarks
David Zentner	2017-08-01	0.0.0	Creation
David Zentner	2017-08-09	0.1.0	STORYC-1454

Reference Documents

No.	Source	Title	Version
[1]	AUTOSAR	AUTOSAR_SWS_DET.pdf	[version]
[2]	AUTOSAR	AUTOSAR_SWS_DEM.pdf	[version]
[3]	AUTOSAR	AUTOSAR_BasicSoftwareModules.pdf	V1.0.0

Scope of the Document

This technical reference describes the general use of the vlpc basis software.



Caution

We have configured the programs in accordance with your specifications in the questionnaire. Whereas the programs do support other configurations than the one specified in your questionnaire, Vector's release of the programs delivered to your company is expressly restricted to the configuration you have specified in the questionnaire.



Contents

1	Comp	onent Hi	story	6		
2	Introd	duction		7		
	2.1	Archited	cture Overview	8		
3	Funct	tional Des	scription	10		
	3.1	Feature	es	10		
		3.1.1	Supported Features	10		
		3.1.2	Deviations	10		
	3.2	Initializa	ation	10		
	3.3	States .		10		
	3.4	Main Fเ	Main Functions			
	3.5	Error H	andling	11		
		3.5.1	Development Error Reporting	11		
		3.5.2	Production Code Error Reporting	12		
	3.6	Suppor	t of different UL and LL	12		
	3.7	Unsegn	mented and segmented transmission and reception	12		
	3.8	Multiple	exing of up to 256 connections on one channel	12		
	3.9	Tx Queue		13		
		3.9.1	FiFo	14		
		3.9.2	Priority based	14		
	3.10	Bandwi	idth control	14		
4	Integi	ration		15		
	4.1	Scope of	of Delivery	15		
		4.1.1	Static Files	15		
		4.1.2	Dynamic Files	15		
	4.2	Critical	Sections	16		
5	API D	escriptio	n	17		
	5.1	Service	es provided by vlpc			
		5.1.1	vlpc_InitMemory			
		5.1.2	vlpc_Init	17		
		5.1.3	vlpc_GetVersionInfo	18		
		5.1.4	vlpc_MainFunction	18		
		5.1.5	· _ vlpc_Transmit	19		
	5.2	Service	es used by vlpc			
	5.3	Callbac	ck Functions	19		
		5.3.1	vlpc_StartOfReception	19		



8	Cont	act		25
	7.2	Abbrevi	iations	24
	7.1		ry	
7		-	Abbreviations	
7	Class			
	6.1	Configu	uration Variants	23
6	Conf			
		5.3.5	vlpc_TxConfirmation	22
		5.3.4	vlpc_CopyTxData	
		5.3.3	vlpc_RxIndication	
		5.3.2	vlpc_CopyRxData	
		F 2 2	ulas CanuDuData	



Illustrations

Figure 2-1	AUTOSAR 4.2 Architecture Overview	8
Figure 2-2	Interfaces to adjacent modules of the vlpc	
Figure 3-1	Initialization state machine	10
Tables		
Table 1-1	Component history	6
Table 3-1	Supported features	10
Table 3-2	Deviations from standards	10
Table 3-3	Service IDs	11
Table 3-4	Errors reported to DET	12
Table 4-1	Static files	
Table 4-2	Generated files	16
Table 5-1	vlpc_InitMemory	17
Table 5-2	vlpc_Initvlpc_Init	18
Table 5-3	vlpc_GetVersionInfo	
Table 5-4	vlpc_MainFunction	19
Table 5-5	vlpc_Transmit	
Table 5-6	Services used by the vlpc	
Table 5-7	vlpc_StartOfReception	
Table 5-8	vlpc_CopyRxData	
Table 5-9	vlpc_RxIndication	
Table 5-10	vlpc_CopyTxData	
Table 5-11	vlpc_TxConfirmation	
Table 7-1	Glossary	
Table 7-2	Abbreviations	



1 Component History

The component history gives an overview over the important milestones that are supported in the different versions of the component.

Component Version	New Features
0.02.00	Support of segmented and unsegmented transmission and reception.
0.03.00	Support of priority Tx queue.

Table 1-1 Component history



2 Introduction

This document describes the functionality, API and configuration of the AUTOSAR BSW module vlpc.

Supported AUTOSAR Release*:	4	
Supported Configuration Variants:	pre-compile, link-time	
Vendor ID:	VIPC_VENDOR_ID	30 decimal
		(= Vector-Informatik, according to HIS)
Module ID:	VIPC_MODULE_ID 2	255 decimal
		(according to ref. [3])

^{*} For the detailed functional specification please also refer to the corresponding AUTOSAR SWS.

The module vlpc is used for communication between different ECUs via different channels. It establishes a point-to-point connection to its target where multiple connections can share one communication channel. Thus, the connections are multiplexed on one channel. One channel can multiplex up to 256 connections.

A channel is always unidirectional; therefore there is no flow control in vlpc.

vlpc supports communication via bus systems as well as via memory access depending of the configured lower layer.



2.1 **Architecture Overview**

The following figure shows where the vlpc is located in the AUTOSAR architecture.




Figure 2-1 AUTOSAR 4.2 Architecture Overview



The next figure shows the interfaces to adjacent modules of the vlpc. These interfaces are described in chapter 5.




Figure 2-2 Interfaces to adjacent modules of the vlpc



3 Functional Description

3.1 Features

The features listed in the following table cover the complete functionality specified for the vlpc.

3.1.1 Supported Features

The following features are supported:

Supported Features	
Support of different UL and LL.	
Unsegmented and segmented transmission and reception (TP-Interfaces).	
Multiplexing of up to 256 connections on one channel.	
Bandwidth control.	
Tx queue; FiFo	

Table 3-1 Supported features

3.1.2 Deviations

There are no known unsupported features.

Category	Description	Version

Table 3-2 Deviations from standards

3.2 Initialization

The vlpc module is pre-initialized by a call to function vlpc_InitMemory.

The vlpc module is initialized by a call to function vlpc_Init. Initialization of the vlpc must not be done before the used lower layer (e.g. vlpc Memlf) is initialized.

3.3 States

The vlpc has the following state machine:




Figure 3-1 Initialization state machine



In state Uninit vlpc rejects all transmission requests.

After call to vlpc Init the vlpc is initialized and all supported features are available.

3.4 Main Functions

The vlpc provides the vlpc_MainFunction which has to be called cyclically.

The main function triggers transmission on every Tx channel where a transmission request is pending.

3.5 Error Handling

3.5.1 Development Error Reporting

By default, development errors are reported to the DET using the service Det_ReportError() as specified in [1], if development error reporting is enabled (i.e. pre-compile parameter VIPC DEV ERROR DETECT==STD ON).

If another module is used for development error reporting, the function prototype for reporting the error can be configured by the integrator, but must have the same signature as the service <code>Det_ReportError()</code>.

The reported vlpc Module ID is 255.

The reported service IDs identify the services which are described in 5.1. The following table presents the service IDs and the related services:

Service ID	Service
0x00	vlpc_Init
0x01	vlpc_InitMemory
0x02	vlpc_GetVersionInfo
0x03	vlpc_Transmit
0x04	vlpc_RxIndication
0x05	vlpc_TxConfirmation
0x06	vlpc_CopyRxData
0x07	vlpc_CopyTxData
0x08	vlpc_StartOfReception

Table 3-3 Service IDs

The errors reported to DET are described in the following table:

Error Code		Description
0x01	VIPC_E_INV_POINTER	The pointer is invalid and points to NULL.
0x02	VIPC_E_INV_CONFIG	The configuration is invalid; the provided PDU length is invalid.
0x03	VIPC_E_INV_CHANNEL	Invalid channel identifier.
0x04	VIPC_E_INV_PHYS_CHANNEL	Invalid physical channel identifier.
0x05	VIPC_E_INV_SDU_ID	The given SDU (connection) ID is invalid.



Error Code		Description
0x06	VIPC_E_INV_PDU_ID	The given PDU (channel) ID is invalid.
0x10	VIPC_E_NOT_INITIALIZED	vlpc is not initialized, yet.
0x11	VIPC_E_ALREADY_INITIALIZED	vlpc is already initialized.

Table 3-4 Errors reported to DET

3.5.2 Production Code Error Reporting

vlpc does not provide Production Code Error Reporting.

3.6 Support of different UL and LL

The vlpc supports the PduR and a CDD as UL. For this, lpc provides the TP-APIs.

Additionally, the vlpc supports different LL, e.g. the vlpcMemlf. The vlpc also requires the TP-APIs of its LL.

3.7 Unsegmented and segmented transmission and reception

The SDU length of UL (connection) may be larger than the PDU length of the assigned LL (channel), in this case the transmission data in segmented in a FF, optional CFs and a LF.

Otherwise, the transmission data is transmitted in a SF.

In both cases the UL only triggers once the transmission, receives multiple calls to _CopyTxData and one call to its _TxConfirmation after the complete PDU is transmitted.

The same goes for the reception path. The receiving UL receives one call to _StartOfReception, multiple calls to _CopyRxData and one call to _RxIndication after complete PDU is received.

3.8 Multiplexing of up to 256 connections on one channel

A vlpc channel is a unidirectional communication path to another ECU which can hold multiple connections. A connection represents one user of the vlpc.

If multiple connections share one channel, the transmission order is managed according to the buffer implementation. Please refer to chapter 3.9.

For each Tx channel there must be an Rx channel on another ECU. The same goes for Tx connections and Rx connections.

The mapping has to be done manually by referencing the same global PDUs on Tx and Rx side. Additionally, the address of each connection has to be set accordingly. A Tx connection is mapped to a Rx connection if the addresses are equal.



If /MICROSAR/vIpc/vIpcConfig/vIpcTxChannel/vIpcTxConnection/vIpcTxAddress

==

/ MICROSAR/vIpc/vIpcConfig/vIpcRxChannel/vIpcRxConnection/ vIpcRxAddress.



Caution

If there are **n** connections on one Tx channel, on the receiving ECU there has to be an Rx channel also with **n** connections.

The mapping of Tx channel to Rx channel and Tx connection to Rx connection has to be done manually.

For example:

ECU 0

- > Tx Channel 0 -> PDU 0
 - > Tx Connection 0
 - > Address = 0
 - > Tx Connection 1
 - > Address = 1

ECU 1

- > Rx Channel 0 -> PDU 0
 - > Rx Connection 0
 - > Address = 1
 - > Rx Connection 1
 - > Address = 0

In this example the following objects are mapped:

- > Tx Channel 0 is mapped to Rx Channel 0
- > Tx Connection 0 is mapped to Rx Connection 1
- Tx_Connection_1 is mapped to Rx_Connection_0

3.9 Tx Queue

Each Tx channel has its own queue to buffer transmission requests for each connection. Each connection must only be queued once; as long as a connection is queued other transmission requests of this connection are rejected. A queued connection is removed from the queue, when the transmission of the last PDU segment is confirmed.

There are two queue implementations available:

- > FiFo
- Priority based

The queue implementation can be selected with the configuration parameter /MICROSAR/vIpc/vIpcConfig/vIpcTxChannel/vIpcSchedulingAlgorithm.



3.9.1 FiFo

The FiFo queue handles the first occurred transmission request as most important. As soon as the Tx channel becomes ready for next transmission, this transmission request is processed.

3.9.2 Priority based

The priority based queue uses the configured priorities of each Tx Connection to decide in which order the processed.

The priority can be configured with the parameter /MICROSAR/vIpc/vIpcConfig/vIpcTxChannel/vIpcTxConnection/vIpcPriority.

3.10 Bandwidth control

vlpc provides the possibility to reduce the bandwidth by configuration of /MICROSAR/vlpc/vlpcConfig/vlpcTxChannel/vlpcNumSeparationCycles.

If this parameter is set to 0, a pending transmission is triggered on the lower layer as soon as the current transmission is confirmed. This is the burst mode.

If this parameter is greater than 0, then it specifies the number of vlpc_MainFunctions that have to be executed before the next transmission is triggered.



Caution

The parameter /MICROSAR/VIpc/VIpcConfig/VIpcTxChannel/VIpcNumSeparationCycles must be set to greater 0 if the TxConfirmation is called by the LL immediately in context of the VIpc Transmit.

Otherwise, there could be recursion!



4 Integration

This chapter gives necessary information for the integration of the MICROSAR vIpc into an application environment of an ECU.

4.1 Scope of Delivery

The delivery of the vlpc contains the files which are described in the chapters 4.1.1 and 4.1.2:

4.1.1 Static Files

File Name	Description
vlpc.c	This is the source file of the vlpc. It contains the general APIs like the vlpc_Init and the vlpc_MainFunction.
vlpc.h	This is the header file; it contains general data of the vlpc. This file should be included by vlpc's ULs.
vlpc_Cbk.h	This is the callback header; it contains the declarations of callback function. This file should be included by vlpc's LL.
vlpc_PQ.c	This is the source file containing implementation of the transmission queue.
vlpc_PQ.h	This is the header file for the transmission queue. This should not be included from other modules.
vlpc_Priv.h	This is the private header file for internal data. This should not be included from other modules.
vlpc_Rx.c	This is the source file containing implementation of the reception path.
vlpc_Rx.h	This is the header file for the reception path. This should not be included from other modules.
vlpc_Tx.c	This is the source file containing implementation of the transmission path.
vlpc_Tx.h	This is the header file for the transmission path. This should not be included from other modules.
vlpc_XCfgImp I.h	This is the header file containing the implementation of GenData abstraction. This should not be included from other modules.
vlpc_XCfg.h	This is the header file containing the declaration of GenData abstraction. This should not be included from other modules.

Table 4-1 Static files

4.1.2 Dynamic Files

The dynamic files are generated by the configuration tool DaVinci Configurator 5.

File Name	Description
vlpc_Cfg.h	This is the precompile configuration file containing definitions of global GenData.
vlpc_Lcfg.c	This is the link time configuration file containing definitions of global GenData.
vlpc_Lcfg.h	This is the link time configuration header containing declaration of global GenData.



File Name	Description
vlpc_PBcfg.c	This is the post-build configuration file containing definitions of global GenData.
vlpc_PBcfg.h	This is the post-build configuration header containing declaration of global GenData.
vlpc_Types.h	This is the types header defining all global types.

Table 4-2 Generated files

4.2 Critical Sections

The vlpc module uses the following exclusive area:

> VIPC_EXCLUSIVE_AREA_TX_QUEUE

It is entered for every Tx queue access.



5 API Description

For an interfaces overview please see Figure 2-2.

5.1 Services provided by vlpc

5.1.1 vlpc_InitMemory

Prototype		
<pre>void vIpc_InitMemory (void)</pre>		
Parameter		
N/A	N/A	
Return code		
void	N/A	
- 4		

Functional Description

This API pre-initializes the vlpc.

Particularities and Limitations

- > Service ID: see table 'Service IDs'.
- > This function is synchronous.

> This function is non-reentrant.

> This function is reentrant.

Expected Caller Context

> This function shall be called on task or interrupt level.

Table 5-1 vlpc_InitMemory

5.1.2 vlpc_Init

Prototype		
<pre>void vIpc_Init (vIpc_0</pre>	ConfigType * ConfigPtr)	
Parameter		
ConfigPtr	A pointer to the current configuration. If no configuration option exist, it may point to NULL.	
Return code		
void	N/A	
Functional Description		
This function initializes the vlpc module.		
Particularities and Limitations		
> Service ID: see table 'Service IDs'.		
> This function is synchronous.		



Expected Caller Context

> This function can be called on interrupt and task level.

Table 5-2 vlpc_Init

5.1.3 vlpc_GetVersionInfo

Prototype

void vIpc GetVersionInfo (Sdt VersionInfoType * VersionInfo)

Parameter

VersionInfo A pointer to the current version. This must not point to NULL.

Return code

void N/A

Functional Description

This function returns the version information of vlpc.

Particularities and Limitations

- > Service ID: see table 'Service IDs'.
- > This function is synchronous.
- > This function is reentrant.

Expected Caller Context

> This function can be called on interrupt and task level.

Table 5-3 vlpc_GetVersionInfo

5.1.4 vlpc_MainFunction

Prototype

void vIpc MainFunction (void)

Parameter

void N/A

Return code

void N/A

Functional Description

This function is executed cyclically and triggers transmission for pending transmission requests.

Particularities and Limitations

- > Service ID: see table 'Service IDs'.
- > This function is synchronous.
- > This function is non-reentrant.

Expected Caller Context

> This function can be called on interrupt and task level.



Table 5-4 vlpc_MainFunction

5.1.5 vlpc_Transmit

Prototype		
void vIpc_Transmit (Po	<pre>void vIpc_Transmit (PduIdType TxSduId, PduInfoType * PduInfoPtr)</pre>	
Parameter		
TxSduId	Identifier of the connection.	
PduInfoPtr	Pointer to transmission data and its length.	
Return code		
void	N/A	

Functional Description

This function queues the transmission request. If the bus is idle, the transmission request is forwarded to vlpc's LL.

Particularities and Limitations

- > Service ID: see table 'Service IDs'.
- > This function is synchronous.
- > This function is non-reentrant.

Expected Caller Context

> This function can be called on interrupt and task level.

Table 5-5 vlpc_Transmit

5.2 Services used by vlpc

In the following table services provided by other components, which are used by the vlpc are listed. For details about prototype and functionality refer to the documentation of the providing component.

Component	API
DET	Det_ReportError

Table 5-6 Services used by the vlpc

5.3 Callback Functions

This chapter describes the callback functions that are implemented by the vlpc and can be invoked by other modules. The prototypes of the callback functions are provided in the header file $vlpc_Cbk.h$ by the vlpc.

5.3.1 vlpc StartOfReception

Francis Conference		
Prototype		
BufReq_ReturnType vIpc_StartOfReception(PduIdType RxPduId, PduInfoType * PduInfoPtr, PduLengthType TpSduLength, PduLengthType * BufferSizePtr)		
Parameter		
RxPduId	The identifier of the vlpc channel.	



PduInfoPtr	Pointer to the received data and their length. This pointer has to point to valid data and the length must be at least enough to copy the vlpc header (6Byte).	
TpSduLength	The length of received data.	
BufferSizePtr	Indicates to the LL how much buffer is available on the UL in addition to vlpc header data.	
Return code		
BufReq_ReturnType	BUFREQ_OK: Indicates success. BUFREQ_E_NOT_OK: Indicates that copying data failed. BUFREQ_E_BUSY: Indicates that UL has currently not enough buffer.	

Functional Description

This function is called by vlpc's LL to indicate that a PDU is received and ready to be forwarded.

Particularities and Limitations

- > Service ID: see table 'Service IDs'.
- > This function is synchronous.
- > This function is reentrant.

Expected Caller Context

> This function can be called on interrupt and task level.

Table 5-7 vlpc_StartOfReception

5.3.2 vlpc_CopyRxData

Prototype

 $\label{lem:bufkeq_ReturnType} \begin{tabular}{ll} \tt Bufkeq_ReturnType & \tt VIpc_CopyRxData(PduIdType RxPduId, PduInfoType & PduInfoPtr, PduLengthType & BufferSizePtr) \\ \end{tabular}$

radiengenipe Barrererer		
Parameter		
RxPduId	The identifier of the vlpc channel.	
PduInfoPtr	Pointer to the received data and their length.	
BufferSizePtr	Indicates to the LL how much buffer is available on the UL in addition to vlpc header data.	
Return code		
BufReq_ReturnType	BUFREQ_OK: Indicates success.	
	BUFREQ_E_NOT_OK: Indicates that copying data failed.	
	BUFREQ_E_BUSY: Indicates that UL has currently not enough buffer.	

Functional Description

This function is called by vlpc's LL if more data of the current PDU is received.

Particularities and Limitations

- > Service ID: see table 'Service IDs'.
- > This function is synchronous.
- > This function is reentrant.



Expected Caller Context

> This function can be called on interrupt and task level.

Table 5-8 vlpc_CopyRxData

5.3.3 vlpc_RxIndication

Prototype

void vIpc RxIndication (PduIdType RxPduId, Std ReturnType Result)

void vipe_iminated of in (radial ipe ranial at a feet and ipe result)	
Parameter	
RxPduId	The identifier of the vlpc channel.
Result	E_OK: Indicates success. E_NOT_OK: Indicates error during reception sequence.
Return code	
void	N/A

Functional Description

This function is called by vlpc's LL after a successful reception of a PDU.

Particularities and Limitations

- > Service ID: see table 'Service IDs'.
- > This function is synchronous.
- > This function is reentrant.

Expected Caller Context

> This function can be called on interrupt and task level.

Table 5-9 vlpc_RxIndication

5.3.4 vlpc_CopyTxData

Prototype

BufReg ReturnType vIpc CopyTxData(PduIdType TxPduId, PduInfoType * PduInfoPtr

RetryInfoType * RetryPtr, PduLengthType * AvailableDataPtr)		
Parameter		
RxPduId	The identifier of the vlpc channel.	
PduInfoPtr	Pointer to the Tx buffer of vlpc's LL and its length.	
RetryPtr	Indicates if previously transmitted data has to be re-transmitted. This parameter is not supported by vlpc.	
AvailableDataPtr	Indicates to the LL how much buffer is available on the UL in addition to vlpc header data.	
Return code		
BufReq_ReturnType	BUFREQ_OK: Indicates success.	
	BUFREQ_E_NOT_OK: Indicates that copying data failed.	
	BUFREQ_E_BUSY: Indicates that UL has currently not enough buffer.	



Functional Description

This function is called by vIpc's LL if more data of the current PDU can be transmitted.

Particularities and Limitations

- > Service ID: see table 'Service IDs'.
- > This function is synchronous.
- > This function is reentrant.

Expected Caller Context

> This function can be called on interrupt and task level.

Table 5-10 vlpc_CopyTxData

5.3.5 vlpc_TxConfirmation

Prototype		
<pre>void vIpc_TxConfirmation(PduIdType TxPduId, Std_ReturnType Result)</pre>		
Parameter		
TxPduId	The identifier of the vlpc channel.	
Result	E_OK: Indicates success. E_NOT_OK: Indicates error during transmission sequence.	
Return code		
void	N/A	

Functional Description

This function is called by vlpc's LL to confirm the successful transmission of a PDU.

Particularities and Limitations

- > Service ID: see table 'Service IDs'.
- > This function is synchronous.
- > This function is reentrant.

Expected Caller Context

> This function can be called on interrupt and task level.

Table 5-11 vlpc_TxConfirmation



6 Configuration

6.1 Configuration Variants

The vlpc supports the configuration variants

- > VARIANT-PRE-COMPILE
- > VARIANT-LINK-TIME

The configuration classes of the vlpc parameters depend on the supported configuration variants. For their definitions please see the vlpc_bswmd.arxml file.



7 Glossary and Abbreviations

7.1 Glossary

Term	Description
EAD	Embedded Architecture Designer; generation tool for MICROSAR components
SF	Single Frame
FF	First Frame
CF	Consecutive Frame
LF	Last Frame
FiFo	First In First Out
UL	Upper Layer
LL	Lower Layer

Table 7-1 Glossary

7.2 Abbreviations

Abbreviation	Description
API	Application Programming Interface
AUTOSAR	Automotive Open System Architecture
BSW	Basis Software
DEM	Diagnostic Event Manager
DET	Development Error Tracer
EAD	Embedded Architecture Designer
ECU	Electronic Control Unit
HIS	Hersteller Initiative Software
ISR	Interrupt Service Routine
MICROSAR	Microcontroller Open System Architecture (the Vector AUTOSAR solution)
PPORT	Provide Port
RPORT	Require Port
RTE	Runtime Environment
SRS	Software Requirement Specification
SWC	Software Component
SWS	Software Specification

Table 7-2 Abbreviations



8 Contact

Visit our website for more information on

- > News
- > Products
- > Demo software
- Support
- > Training data
- > Addresses

www.vector.com