


Experiment 7:



The screenshot shows the Arduino IDE 2.3.10 interface. The top menu bar includes File, Edit, Sketch, Tools, and Help. The toolbar shows icons for opening files, saving, compiling, and uploading. The sketch is named 'sketch_aug17b.ino' and is targeted to an 'Arduino UNO'. The code in the sketch is as follows:

```
1 int number = 0;
2
3 void setup() {
4   Serial.begin(9600); // Initialize serial communication at 9600 baud
5 }
6
7 void loop() {
8   Serial.print("Number is ");
9   Serial.println(number); // Print current number with a newline
10  delay(500);             // Wait 0.5 seconds
11  number++;               // Increment the number
12 }
13
```

The Output window at the bottom shows the compilation process:

```
Using precompiled core: C:\Users\trish\AppData\Local\arduino\cores\arduino_avr_uno_1854fb47367fe1f0bbc92a1cf35fbde7\core.a
Linking everything together...
"C:\Users\trish\AppData\Local\Arduino15\packages\arduino\tools\avr-gcc\7.3.0-stm13.6.1-arduino7/bin/avr-gcc" -w -Os -g -flto -fuse-linker-plugin -l
"C:\Users\trish\AppData\Local\Arduino15\packages\arduino\tools\avr-gcc\7.3.0-stm13.6.1-arduino7/bin/avr-objcopy" -O ihex -j .eeprom --set-section-
"C:\Users\trish\AppData\Local\Arduino15\packages\arduino\tools\avr-gcc\7.3.0-stm13.6.1-arduino7/bin/avr-objcopy" -O ihex -R .eeprom "C:\Users\tr
"C:\Users\trish\AppData\Local\Arduino15\packages\arduino\tools\avr-gcc\7.3.0-stm13.6.1-arduino7/bin/avr-size" -A "C:\Users\trish\AppData\Local
Sketch uses 1902 bytes (5%) of program storage space. Maximum is 32256 bytes.
Global variables use 200 bytes (9%) of dynamic memory, leaving 1848 bytes for local variables. Maximum is 2048 bytes.
```

The status bar at the bottom indicates 'Ln 12, Col 2' and 'Arduino UNO [not connected]'.

