

The screenshot displays the VSM Studio IDE interface. The top menu bar includes File, Project, Build, Edit, Debug, System, and Help. Below the menu is a toolbar with icons for Schematic Capture, Source Code, and various editing functions. A status bar at the top indicates 'SIMULATION ERROR LOG'. The left sidebar shows the 'Projects' panel with a tree view containing 'AT89C51(U1)' and its 'Source Files' folder, which includes 'main.asm'. The main editor window shows the assembly code for 'main.asm':

```

1 ORG 0000H
2 UP: SETB P2.0
3 ACALL DELAY
4 CLR P2.0
5 ACALL DELAY
6 SJMP UP
7 DELAY: MOV R4, #35
8 H1: MOV R3, #255
9 H2: DJNZ R3, H2
10 DJNZ R4, H1
11 RET
12 END

```

The line containing 'END' (line 12) is highlighted in yellow. The bottom status bar shows 'VSM Studio Output'.

