

- 1 Vin +11 to +14.5v
- 2+12v For Digital I/O
- 3+12v
- 4+12v
- 5+12v
- 6+12v
- 7 EXTGND
- 8 GND (do not connect to external ground
- 9 CANO HI
- 10 ... CANO LO
- 11 ... CAN1HI
- 12 ... CAN1LO

GEVCU AMPSEAL 35 Pinout Middle Row

- 13 EXTGND
- 14 EXTGND
- 15 MOSFET1 (total 2A limit for all mosfets)
- 16 MOSFET2
- 17 MOSFET3
- 18 MOSFET4
- 19 GND (do not connect to external ground)
- 20 Analog0 Throttle (pot 1)
- 21 Analog1 Throttle (pot 2)
- 22 Analog2 Brake Transducer
- 23 Analog3

GEVCU AMPSEAL 35 Pinout Bottom Row

- 24 +5v isolated
- 25 +5v isolated
- 25 +5v isolated
- 26 +5v isolated
- 28 +5v isolated
- 29 GND (do not connect to external ground)
- 30 GND
- 31 GND
- 32 Digital1 Drive Enable
- 33 Digital2
- 34 Digital3
- 34 Digital4

Connection Notes

- 1. Connections shown above are for the current version of GEVCU code (8-21-2013)
- 2. Only connect the mosfet outputs or digital inputs to the +12v provided on the connector. These outputs are protected and fused.
- 3. Do not connect the external power or chassis ground to any GND pin on the connector. The GND is designed as a reference for the isolated +5v supply