
OMEN Alpha

Assembly instructions



1. You will need:



- 2. Solder sockets for integrated circuits. Sockets and pinheaders are not included in the kit!
- 3. Test all soldered connections:
 - ☐ Test if all pins are well connected.
 - ☐ Check if GND is not short connected to Vcc
 - ☐ Check if every IC has properly connected GND and Vcc
- 4. Solder all pasive parts (capacitors, diode, resistors, pushbutton, crystal)
- **5.** Connect the power (+5 V) and check.
- Insert the CPU into the socket and try to power it up. Check the oscillator (CPU pin 37).
- 7. Insert the essential ICs: 74245, 74573, 7400, RAM 62256 and EEPROM 28C256 (programmed)
- 8. Connect the UART 68B50 and the TTL-USB interface (three wires: TxD, RxD and GND)
- 9. Connect the serial USB to your PC and set it (115200 Bd, 8 data bits, no parity, 1 stop bit. Use Teraterm, Putty, or other serial terminal)
- 10. Power the Alpha and check the terminal.