




微處理機系統與介面技術

LAB 2 - UART






#### UART



- Universal Asynchronous Receiver/Transmitter (UART)
- UARTO
  - RXO/GPBO: pin32
  - TX0/GPB1 : pin33
- UART1
  - RX1/GPB4 : pin19
  - TX1/GPB5 : pin20
- · UART2
  - RX2/GPD14 : pin38
  - TX2/GPD15 : pin39

UART with 8 Databits, 1 Stopbit and no Parity







### PL2303

- · 將UART訊號轉成USB訊號
- Pin
  - VCC 不要接
  - GND接到NUC140 GND
  - TxD 接到NUC140 Rx
  - RxD 接到NUC140 Tx








## Putty

- 下載網址 http://www.chiark.greenend.o rg.uk/~sgtatham/putty/downl oad.html
- 記得選 COMPORT
- 記得改 Speed








# Putty

· USB接到PC後,可以點選裝置管理員,就可以看到uart的COM port









## Register Configuration

- UA\_BAUD: Baud Rate Divider Register
- UA\_LCR: Line Control Register
  - · Word length, parity, stop bit
- UA\_IER: Interrupt Enable Register
  - · UART裡面有很多種中斷,請注意使用
- UA\_ISR: Interrupt Status Control Register

31	30	29	28	27	26	25	24
Reserved							
23	22	21	20	19	18	17	16
Reserved							
15	14	13	12	11	10	9	8
DMA_RX_EN	DMA_TX_EN	AUTO_CTS_ EN	AUTO_RTS_ EN	TIME_OUT_E N	Reserved		LIN_RX_BRK _IEN
7	6	5	4	3	2	1	0
Reserved	WAKE_EN	BUF_ERR_IE N	RTO_IEN	MODEM_IEN	RLS_IEN	THRE_IEN	RDA_IEN





### ISR - Interrupt Service Routine


· 在MCU架構下,通常由硬體觸發,ex. 鍵盤送出一個字給MCU→觸

發中斷

Interrupt vector

IRQ\_Handler

理中斷的相關function



CCU@Taiwan 🖽



#### Basic

- · 將鍵盤輸入的字印到putty上面
  - 注意!請輸入enter的時候再把字印出來 ex. 輸入 "Hello" → enter → putty上面印出Hello 中間過程請不要在putty上面印字
  - Enter's ascii code: 0x0D








#### Bonus

- · 輸入字串控制RGB LED
  - Keyboard input "red on" → turn on the red led
  - Keyboard input "red off" → turn off the red led
  - Keyboard input "green on" → turn on the green led
  - Keyboard input "green off" → turn off the green led
  - Keyboard input "blue on" → turn on the blue led
  - Keyboard input "blue off" → turn off the blue led

RGB LED low-active driven

by GPA12 for **blue** color by GPA13 for **green** color by GPA14 for **red** color








## Tips

- 參考範例: UART\_TxRx\_Function
  - 請看懂裡面如何使用uart interrupt, 不要直接照抄
- 相關function:
  - · memset, strcmp(記得include string.h)
- ·請多多參考NUC140的Technical Reference Manual 裡面會清楚說明如何使用那些register
- · RGB LED 記得要設定腳位為Output mode 詳見LAB1 PPT









### Tips

- 要使用GPIO\_SetMode function 要include GPIO.c 到Library
- GPIO.c 路徑 NUC100\_120BSP... -> Library -> StdDriver -> src









#### Demo

- · Place: 創新大樓515 找助教 林子華(進門最後一排最裡面)
- Demo Time: (二)(三)下午三點~五點
- Report deadline: 10/9(五)
- Report title format: LABx\_ID\_Name
- · Demo必須在Report deadline前完成
- · Demo前須先上傳程式碼(上傳main所在的.c檔即可)





### Graded

• Basic : 70%

• Bonus : 15%

• Report & Code: 15%

