
GENDER BENDER PROBABILISTIC TRIGGER GENERATOR



HOLD SHIFT AND ADJUST ENCODER TO CHANGE THE SAME SETTING FOR ALL CHANNELS

TRACK A M X A DENSITY- PROBABILITY CHANCE DIVISION - CLOCK DIVISION FOR FILL VELOCITY - MIDI VELOCITY FOR DURATION - GATE DURATION

TRACK SETTINGS

MULT - MIDI NOTE MULTIPLIER STEP - MIDI NOTE OPERAND NOTE - MIDI NOTE CHAN - MIDI CHANNEL

NOTE + (MULT * STEP)

FILL •I:

INTERVAL - DURATION DURATION - BARS FOR FILL OFFSET -RANDOM - FILL VARIATION SWING - SWING TIME

PARAMETER LFO

WAVE 0-SINE 1-SAW 2-SQUARE 3-RANDOM 5-CV1* 6-CV2*
CLOCK DIVISION
AMPLITUDE
OFFSET
PWM WAVE

*NOT YET IMPLEMENTED