How to access our 3D Printers

- 1. Ensure that the printer you wish to use is powered on
 - 2. Log in to our PC
 - 3. Open 3d.printers.local in the browser
 - 4. Select the printer you wish to use
 - 5. Login using the saved credentials
 - 6. Click Connect
 - **7.** Use the printer!

