


# MAXI Circuit Breakers Model MX5



Direct replacement for "MAXI" automotive style fuses

Permanently eliminates the need to replace blown Maxi fuses



# **Ordering Information**

9146111191111411911					
MX5 — Model Number		Type Reset	Amp Rating		
Automatic Reset (Type I)	⊗ <mark>40</mark>	AUTO RESET	] = A	5 10	35 40
Automatic Reset with L.E.D (Type I)	<b>⊘</b> 40 AMP	AUTO RESET	= L	15 20	45 50
Manual Reset (Type皿)	<b>⊗</b> 40 /	AMP RESET	= M	25 30	55 60

### Automatic Reset (TypeI) = A

-Upon overload the breaker <u>cycles continuosly</u> during an overload condition until the overload is removed or corrected.

#### **L.E.D** Indicator (Type I) = L

-Functions the same as automatic reset. L.E.D is lit when breaker is in the open condition.

#### Manual Reset (Type III) = |

-Upon overload the breaker <u>opens and remains open</u> until the breaker is reset.

# **SPECIFICATIONS**

Amp Ratings: 10,15, 20, 25, 30,

35, 40, 45, 50, 55,60

Voltage Ratings: 14 VDC; 28 VDC

Operating Temperature:

-40 F to 185 F (-40 C to 85 C).

Storage Temperature :

-40 F to 260 F (-40 C to 125 C).

**Housing**: UL Rated 94 VO Thermoplastic

(  $\ensuremath{\mathsf{Non}}$  -  $\ensuremath{\mathsf{Conductive}}$  housing eliminates dangers


of internal parts shorting to case ).

Terminal Type : Compatible with Maxi fuse blocks

**Versions**: Type I Automatic reset, Type I with L.E.D indicator (lights during tripped condition),


Type III Manual reset.

**Approvals**: Meets or exceeds SAE standard J553 Type I and Type III Circuit Breakers.



## MUST HOLD 100 % @ 25 & 70 degrees C

150 % overload = 3.9 - 47 seconds 175 % overload = 2.2 - 9.2 second \* 200 % overload = 1.5 - 3.9 seconds 250 % overload = 0.8 - 1.8 seconds 300 % overload = 0.5 - 1.1 seconds 400 % overload = 0.3 - 0.6 seconds 500 % overload = 0.2 - 0.3 seconds





ACTION INC