# MICROCONTROLLER AND INTERFACING LAB DEPARTMENT OF ELECTRICAL AND ELECTRONIC ENGINEERING, BUET

**Experiment: 9** 

# LCD interface with 8086

# 1.1 Objective

The objective of this experiment are

- ❖ To know the communication protocol with LCD
- Establish the protocol between LCD and 8086
- Test different features of LCD

# 1.2 Learning Outcome

At the end of the experiment students will be able to

- Communicate with LCD
- Can display anything in the LCD

# 1.3 Liquid Crystal Display (LCD) Module

**LCD** is a thin, flat display device made up of pixels arrayed in front of a light source or reflector. Uses very small amounts of electric power, and is therefore suitable for use in battery-powered electronic devices.

#### 1.3.1 Characteristics

Each module contains a CMOS controller and all necessary drivers which have low power consumption. The controller is equipped with an internal character generator ROM, RAM and RAM for display data. All display functions are controllable by instructions making interfacing practical.

#### Register:

The Controller has two 8 bit registers, the Instruction register (IR) and the data register (DR).

The IR is a write only register to store instruction codes like Display Clear or Cursor Shift as well as addresses for the Display Data RAM (DD RAM) or the Character Generator RAM (CG RAM).

The DR is a read/write register used for temporarily storing data to be read/written to/from the DD RAM or CG RAM. Data written into the DR is automatically written into DD RAM or CG RAM by an internal operation of the display controller. The DR is also used to store data when reading out data from DD RAM or CG RAM. When address information is written into IR, data is read out from DD RAM or CG RAM to DR by an internal operation. Data transfer is

Pin Number	Symbol
1	Vss
2	Vcc
3	Vee
4	RS
5	R/W
6	E
7	DB0
8	DB1
9	DB2
10	DB3
11	DB4
12	DB5
13	DB6
14	DB7

then completed by reading the DR. After performing a read from the DR, data in the DD RAM or CG RAM at the next address is sent to the DR for the next read cycle. The register select (RS) signal

RS	R/W	Operation
0	0	IR write, internal operation (Display Clear etc.)
0	1	Busy flag (DB7) and Address Counter (DB0 ~ DB6) read
1	0	DR Write, Internal Operation (DR ~ DD RAM or CG RAM)
1	1	DR Read, Internal Operation (DD RAM or CG RAM)

determines which of these two registers is selected.

# **Busy Flag:**

When the busy flag is high or "1" the module is performing an internal operation and the next instruction will not be accepted. As shown in Table 1.4, the busy flag outputs to DB7 when RS=0 and a read operation is performed. The next instruction must not be written until ensuring that the busy flag is low or "0".

# **Address Counter (AC)**

The address counter (AC) assigns addresses to the DD RAM and the CG RAM. When the address of an instruction is written into the IR, the address information is sent from the IR to the AC. The selection of either DD RAM or CG RAM is also determined concurrently by the same instruction. After writing into or reading from the DD RAM or CG RAM the address counter (AC) is automatically incremented by 1 or decremented by 1 (determined by the I/D bit in the "Entry Mode Set" command.) AC contents are output to DB0  $\sim$  DB7 when RS = 0 and a read operation is performed, as shown in Table.

# **Display Data RAM (DD RAM)**

The Display Data RAM (DD RAM) stores the display data represented in 8 bit character codes. Its capacity is  $80 \times 8$  bits or 80 characters. The Display Data RAM that is not used for the display an be used as a general data RAM.


# **MPU INTERFACING**


Each character display can be operated in either 4 or 8 bit mode. Instructions/Data are written to the display using the signal timing characteristics found below.

When operating in 4 bit mode, data is transferred in two 4 bit operations using data bits DB4 - DB7. DB0 - DB3 are not used and should be tied low. When using 4 bit mode, data is transferred twice before the instruction cycle is complete. First the high order nibble is transferred then the low order nibble. The busy flag should only be checked after both nibbles are transferred. When operating in 8 bit mode, data is transferred using the full 8 bit bus DB0 - DB7.

#### **Software Initialization**


#### **8 - Bit Initialization:**





Function Set (Interface = 8 bits, Set No. of lines and display font)	В1	B2 D	B3 D	B4 D	35 D B0	B6 DE D	7 DE	V DB	R/V	RS
	X	X	F	N	1	1	0	0	0	0
Display OFF	0	0	0	1	0	0	0	0	0	0
Clear Display	1	0	0	0	0	0	0	0	0	0
Entry Mode Set	S	I/D	1	0	0	0	0	0	0	0
Display ON	В	C	1	1	0	0	0	0	0	0

# Initialization Complete, Display Ready.



					ir	nstructi	ion set					
Instruction					C	ode					Description	Execution
Instruction	RS	R/W	DB7	DB6	DB5	DB4	DB3	DB2	DB1	DB0	Description	time**
Clear display	0	0	0	0	0	0	0	0	0	1	Clears display and returns cursor to the home position (address 0).	1.64mS
Cursor home	0	0	0	0	0	0	0	0	1	*	Returns cursor to home position (address 0). Also returns display being shifted to the original position. DDRAM contents remains unchanged.	1.64mS
Entry mode set	0	0	0	0	0	0	0	1	I/D	S	Sets cursor move direction (I/D), specifies to shift the display (S). These operations are performed during data read/write.	40uS
Display On/Off control	0	0	0	0	0	0	1	D	С	В	Sets On/Off of all display (D), cursor On/Off (C) and blink of cursor position character (B).	40uS
Cursor/display shift	0	0	0	0	0	1	S/C	R/L	*	*	Sets cursor- move or display-shift (S/C), shift direction (R/L). DDRAM contents remains unchanged.	40uS
Function set	0	0	0	0	1	DL	N	F	*	*	Sets interface data length	40uS

	instruction set											
Instruction						ode					Description	Execution time**
moti dotion	RS R/W DB7 DB6 DB5 DB4 DE					DB3	DB2	DB1	DB0	_	unie	
											(DL), number of display line (N) and character font(F).	
Set CGRAM address	0	0	0	1	1 CGRAM address						Sets the CGRAM address. CGRAM data is sent and received after this setting.	40uS
Set DDRAM address	0	0	1	1 DDRAM address						Sets the DDRAM address. DDRAM data is sent and received after this setting.	40uS	
Read busy- flag and address counter	0	1	BF	CGRAM / DDRAM address						Reads Busy-flag (BF) indicating internal operation is being performed and reads CGRAM or DDRAM address counter contents (depending on previous instruction).	0uS	
Write to CGRAM or DDRAM	1	0		write data							Writes data to CGRAM or DDRAM.	40uS
Read from CGRAM or DDRAM	1	1				read	data				Reads data from CGRAM or DDRAM.	40uS


# Remarks:

- DDRAM = Display Data RAM.
- CGRAM = Character Generator RAM.
- DDRAM address corresponds to cursor position.
- -\* = Don't care.
- -\*\* = Based on Fosc = 250KHz.

Table: Bit names								
Bit name	Settings							
I/D	0 = Decrement cursor position	1 = Increment cursor position						
S	0 = No display shift	1 = Display shift						
D	0 = Display off	1 = Display on						
С	0 = Cursor off	1 = Cursor on						
В	0 = Cursor blink off	1 = Cursor blink on						
S/C	0 = Move cursor	1 = Shift display						
R/L	0 = Shift left	1 = Shift right						
DL	0 = 4-bit interface	1 = 8-bit interface						
N	0 = 1/8 or 1/11 Duty (1 line)	1 = 1/16 Duty (2 lines)						
F	0 = 5x7  dots	1 = 5x10 dots						
BF	0 = Can accept instruction	1 = Internal operation in progress						


# **Detailed Explanations**

# **Set CG RAM Address**



Sets the address counter to the CG RAM address AAAAAAA. Data is then written/read to from the CG RAM.


#### **Set DD RAM Address**



Sets the address counter to the DD RAM address AAAAAAA. Data is then written/read to from the DD RAM.

For a 1-line display module AAAAAAA is "00"  $\sim$  "4F" (hexadecimal). For 2-line display module AAAAAAA is "00"  $\sim$  "27" (hexadecimal) for the first line and "40"  $\sim$  "67" (hexa decimal) for the second line.

# **Read Busy Flag and Address**



Reads the busy flag (BF) and value of the address counter (AC). BF = 1 indicates that on internal operation is in progress and the next instruction will not be accepted until BF is set to "0". If the display is written while BF = 1, abnormal operation will occur.

The BF status should be checked before each write operation.

At the same time the value of the address counter expressed in binary AAAAAAA is read out. The address counter is used by both CG and DD RAM and its value is determined by the previous instruction.

#### Write Data to CG or DD RAM



Writes binary 8-bit data DDDDDDDD to the CG or DD RAM.

The previous designation determines whether the CG or DD RAM is to be written (CG RAM address set or DD RAM address set). After a write the entry mode will automatically increase or decrease the address by 1. Display shift will also follow the entry mode.

#### Read Data from CG or DD RAM



Reads binary 8-bit data DDDDDDDD from the CG RAM or DD RAM.

The previous designation determines whether the CG or DD RAM is to be read.

Before entering the read instruction, you must execute either the CG RAM or DD RAM address set instruction.

If you don't, the first read data will be invalidated. When serially executing the "read" instruction the next address data is normally read from the second read.

The "address set" instruction need not be executed just before the "read" instruction when shifting the cursor using cursor instruction (when reading DD RAM). The cursor shift instruction operation is the same as that of the DD RAM address set instruction.

After a read, the entry mode automatically increases or decreases the address by 1; however, display shift is not executed no matter what the entry mode is.

Note: The address counter (AC) is automatically incremented or decremented by 1 after a "write" instruction to either CG RAM or DD RAM. RAM data selected by the AC cannot then be read out even if "read" instructions are executed.

The conditions for correct data reads are: (a) Execute either the address set instruction or cursor shift instruction (only with DD RAM) or (b) The execution of the "read data" instruction from the second time when the read instruction is performed multiple times in serial.

# **16 Character x 2 Line Display**

No.	Instruction	Display	Operation
1	Power supply ON (Initialized by Internal reset circuit)  RS R/W DB <sub>7</sub> ~ DB <sub>0</sub>		Module is initialized.
2	Function set    RS   R/W   DB <sub>7</sub>   ~ DB <sub>0</sub>		Sets the interface data length to 8 bits and selects 2-line display and 5 x 7-dot character font.
3	Display ON/OFF Control           RS         R/W         DB <sub>7</sub> ~         DB <sub>0</sub> 0         0         0         0         1         1         1         0	_	Turns on display and cursor.
4	Entry mode set    RS   R/W   DB <sub>7</sub>   ~ DB <sub>0</sub>	_	Sets mode to increment address by one and to shift the cursor to the right at the time of write to internal RAM
5	Write data to CG/DD RAM         RS       R/W       DB <sub>7</sub> ~       DB <sub>0</sub> 1       0       0       1       0       0       1       0       0	L_	Writes "L". Cursor is incremented by one and shifts to the right.
6	Write data to CG/DD RAM           RS         R/W         DB <sub>7</sub> ~         DB <sub>0</sub> 1         0         0         1         0         0         1         1	LC_	Writes "C"
7			
8	Write data to CG/DD RAM           RS         R/W         DB <sub>7</sub> ~         DB <sub>0</sub> 1         0         0         0         1         1         0	LCD MODULE DMC16	Writes "6"

No.	Instruction	Display	Operation
9	Set DD RAM address.           RS         R/W         DB <sub>7</sub> ~         DB <sub>0</sub> 0         0         1         1         0         0         0	LCD MODULE DMC16	Sets RAM address so that the cursor is positioned at the head of the 2 <sup>nd</sup> line.
10	RS   R/W   DB <sub>7</sub>   ~ DB <sub>0</sub>   1   0   0   0   1   1   0   0   1   1	LCD MODULE DMC16 1_	Write "1"
11	Write data to CG/DD RAM         RS       R/W       DB <sub>7</sub> ~       DB <sub>0</sub> 1       0       0       0       1       1       0       0       1	LCD MODULE DMC16 16_	Writes "6"
12			
13	Write data to CG/DD RAM address         RS       R/W       DB <sub>7</sub> ~       DB <sub>0</sub> 1       0       0       0       1       0       1       0	LCD MODULE DMC16 16 DIGITS, 2 LINES_	Writes "S"
14	Set DD/RAM address           RS         R/W         DB <sub>7</sub> ~         DB <sub>0</sub> 0         0         1         0         0         0         0         0	<u>L</u> CD MODULE DMC16 16 DIGITS, 2 LINES	Moves cursor to original position
15	Clear display         RS       R/W       DB <sub>7</sub> ~       DB <sub>0</sub> 0       0       0       0       0       0       0       0		Return both display and cursor to the original position
16			

# **Exercise 1**

```
***********
      LCD Interface EXPERIMENT PROGRAM
                                          *
             8086 Training kit
      EEE Department, BUET
************
;Code for MDA 8086 . NOTE: activate 4 lines below for MDA 8086 if not activated
      STACK
                  EQU
                        0A00H
                                    ; STACK POINTER; A 0 Must be added before A00H
                                    ; USED TO WRITE INSTRUCTION REGISTER
      IR_WR
                  EQU
                        00H
      ST RD
                                    ; USED TO READ STATUS
                  EOU
                        02H
                                    : USED TO WRITE DISPLAY DATA RAM
      DR WR
                  EOU
                        04H
;Code for MTS-86C (Black processor) . NOTE: activate 4 lines below for MTS-86C(Black) if not
;activated
                                    ; USED TO WRITE INSTRUCTION REGISTER
      IR_WR
                  EQU
                        3FF9H
      ST_RD
                  EQU
                        3FFBH
                                    ; USED TO READ STATUS
      DR WR
                  EQU
                        3FFDH
                                    ; USED TO WRITE DISPLAY DATA RAM
      STACK
                  EQU
                        0A00H
                                    ; STACK POINTER; A 0 Must be added before A00H
                        ; because address value starting with non numerical
                        ; value creates error while compiling
;Code for MTS-86C (White Processor) . NOTE: activate 4 lines below for MTS-86C(White) if not
;activated
                  EQU
                                    ; USED TO WRITE INSTRUCTION REGISTER
      IR_WR
                        0FFC1H
      ST_RD
                  EQU
                        0FFC3H
                                    ; USED TO READ STATUS
      DR WR
                  EQU
                        0FFC5H
                                    ; USED TO WRITE DISPLAY DATA RAM
                                    ; STACK POINTER; A 0 Must be added before A00H
      STACK
                  EQU
                        0A00H
                        ; because address value starting with non numerical
                        ; value creates error while compiling
;code common for both MDA and MTS starts from here
CODE SEGMENT
      ASSUME
                  CS:CODE,DS:CODE,ES:CODE,SS:CODE
START:
            ORG
                  0H ; Use 1000H for MDA series
                  AX,CS
            MOV
                  DS,AX; Making the DS (Data Segment) and CS (Code Segment)
            MOV
                              ;value same
            MOV
                  SS,AX; Making the SS (Stack Segment) also same with CS, DS
            MOV
                  SP,STACK
            CALL ALLCLR
            CALL LN11
            MOV
                  SI, OFFSET LINE1
            CALL STRING
            CALL LN21
            MOV
                  SI, OFFSET LINE2
            CALL STRING
            ; Blinks the whole display
BLINK: CALL
            DISPOFF
            CALL TIMER
            CALL DISPON
            CALL TIMER
            JMP
                  BLINK
```

```
LINE1 DB
             'Hi BUET Students !',00H,00H
                    'Make me friend.',00H,00H
LINE2
             DB
      ; LCD instruction
             MOV
                    AH,0000001B; Clears entire display
ALLCLR:
             JMP
                    OUT1
DISPOFF:
                    AH,00001000B; Display off, cursor off, not blink
             MOV
             1MP
DISPON:
             MOV
                    AH,00001111B; Display on, cursor on, cursor blink
             JMP
                    OUT1
             AH,00000010B; Returns to home position
LN11: MOV
             JMP
                    OUT1
LN21: MOV
             AH,11000000B; Sets RAM address so that the cursor is positioned
                       ; at the head of the 2nd line.
             JMP
                    OUT1
      ;To write to instruction register
OUT1: PUSH
                    \mathsf{AX}
             PUSH
                           DX
             CALL
                           BUSY
             MOV
                           AL,AH
                           DX,IR WR
             MOV
             OUT
                           DX,AL
             POP
                           \mathsf{D}\mathsf{X}
                           AX
             POP
      ; busy flag check, must be done before any write operation
BUSY: PUSH
                    \mathsf{DX}
             PUSH
                           AX
             MOV
                           DX,ST_RD
BUSY1:
             IN
                           AL,DX
             AND
                           AL,10000000B
                           BUSY1
             JNZ
             POP
                           AX
             POP
                           DX
             RET
      ;To send a single character
CHAROUT:
             PUSH DX
             PUSH
                           AX
                           BUSY
             CALL
             MOV
                           AL,AH
             MOV
                           DX,DR_WR
             OUT
                           DX,AL
                           AX
             POP
             POP
                           DX
             RET
      ;To out a string line from address CS:[SI]
STRING:
             MOV
                           AH, BYTE PTR CS:[SI]
             CMP
                           AH,00H
             JE
                           STRING1
             CALL
                           BUSY
             CALL
                           CHAROUT
             INC
                           SI
             JMP
                           STRING
STRING1:
             RET
```

;Timer Makes delay

TIMER: PUSH CX

MOV CX,0FFFFH

TIMER1: DEC CX

JNZ TIMER1 POP CX

RET

.

CODE ENDS

END START

# **Exercise 2**

Using the code above make a program that will

- a) display your group no. in the first line and roll no in the second line.
- b) after some delay it will shift the line to right 3 space
- c) after some delay it will shift the line to left 5 space
- d) after some delay it will clear the whole display and cursor to the home position
- e) after some delay it will repeat all of above actions

# **Exercise 3**

Write a program that will count from 0 to 1000 and after counting to 1000 it will repeat it again. Display the results in the LCD.

#### **Home Task:**

- **1.** Complete all the code for exercise 2,3 and explain all the steps done in the program.
- **2.** Write a program that will display your group members name in the first line and roll in the second line and after some delay it will show next member's name and roll and repeatedly do it after finishing all member's task.

Prepared by: RAJIB MIKAIL, Lecturer, EEE, BUET. Date: June' 07