PocketOS

Quick start

Your home, at a glance. Setting up takes about five minutes.

Home Assistant | 2.4 GHz Wi-Fi | Your phone

1. **Charge and switch on**
   Plug PocketOS in with the USB-C cable. To switch it on, hold the Power button for 1 second.

2. **Join PocketOS from your phone**
   Point your phone's camera at the code on PocketOS's screen and tap to join. A setup page opens.

3. **Choose your home Wi-Fi**
   Pick your network and enter its password. PocketOS joins it, and your phone goes back to your Wi-Fi.

4. **Connect Home Assistant**
   On the settings page, open **Smart home** and follow the steps. Your devices appear on PocketOS.

Step-by-step guide
Scan for the full setup guide, with pictures.
pocketos-orpin.vercel.app/start

The side buttons

Power

PRESS
Screen off or on

HOLD 1 SECOND
Switch on

HOLD 6 SECONDS
Switch off

Boot

PRESS
Show the code for the settings page

PRESS TWICE
Back to the home screen

HOLD
Talk to your home, then let go

Help and updates

Help and questions: pocketos-orpin.vercel.app/help
Updates install over Wi-Fi, with security updates until at least **31 December 2029**. Report a security problem, and read our statement of compliance, at pocketos-orpin.vercel.app/security

Safety and care

- PocketOS has a built-in rechargeable lithium battery. Don't open, crush, puncture or heat it.
- Charge with the supplied cable from a USB charger or computer. Don't leave it charging on soft furnishings.
- Keep it dry and away from heat. Clean with a soft, dry cloth.
- If it swells, gets hot, smells or is damaged, stop using it and contact us.

Don't put PocketOS in household rubbish. Take it to an electrical recycling point.
Leeeko LTD, 32 Ferndale Avenue, Newcastle, NE28 7NE, United Kingdom.
Home Assistant is a trademark of its owner. PocketOS is not affiliated with or endorsed by it.

