6. ARRAY PICKER

PROPERTY	DESCRIPTION
value Index (read/write Number)	The current value of the knob control
array (read/write Array)	An array containing Strings or other data types. The elements in the array determine the available options for selection using this control.
	Array elements are displayed as text on a list that pops up on taping the control. The selected element is displayed as a text label in the control.
	Example: ["One","Two","Three"]
format (FormatString, read/ write String)	A format String for texts on the pop up list and the text label displayed by the control. See <u>format specifiers and the format function</u> for a complete discussion on possible values.
	Example: "Option %s"
color Color (read/write String or Number)	The color of the array picker control. See description of the <i>color</i> property on the page object for a discussion on possible values.
linkToPages Array (read/write Array)	An array of strings matching page <i>pageIdentifier</i> . Any change on the array picker value will cause the interface to switch to the page matching the identifier at the value index.
	Example: ["PageOne","PageTwo","PageThree"]
	Upon selecting the first segment (the value property is 0) the interface will switch to page with identifier "PageOne" and so on.

