3. CUSTOM SWITCH

PROPERTY	DESCRIPTION
imageOn ImagePath (read/write String)	Image to show for the 'On' state of the control.
aspectRatioOn (constant Number)	Aspect ratio to be applied to the 'On' image. See description of the *aspectRatio* property for the **page** object for detailed information on possible values.
imageOff ImagePath (read/write String)	Image to show for the 'Off' state of the control.
aspectRatioOff (constant Number)	Aspect ratio to be applied to the 'Off' image. See description of the *aspectRatio* property for the **page** object for detailed information on possible values.