

PLC & Sinamics S210


1. Add Unspecified PLC




2. Detect PLC




3. Verify connection




4. Add Sinamics S210



5. Set up PROFINET




6. Select communication telegram 3




Optional: Enable webserver through


PROFINET port X150




7. Disable Isochronous mode




8. Set up motor (click on motor icon)




9. Upload config to S210




10. Upload config to PLC




Optional: Verify by going online on both devices




11. Verify basic settings




Optional: Parametrization




12. Add technology object: Motion axis




13. Set PROFIdrive




14. Select telegram




15. Set up encoder




Optional: Set up additional parameters




16. Set up homing




17. Upload config to PLC



18. Verify through Commissioning





19. Use Technology object in program

