

Station PC connection guide

Physical setup reference for PC1-RF and PC2-Pointing

Adapted from the local PC setup guide dated 25 October 2023. The photographs show the documented rack connections.

1. Confirm rack power

Confirm the computers receive power from the PDU above them. The source guide identifies the red switch position as on.



2. Connect the selected computer


Connect the labeled HDMI and USB extension cables to whichever computer you intend to use. The rear connections are shown below.



Monitor keyboard and mouse

3. Connect the monitor and keyboard

Connect the HDMI cable to the monitor. Connect the keyboard to the other end of the USB extension cable.



4. Connect the mouse

Plug the mouse into the keyboard USB port shown below.



Computer power and display

5. Power on the selected computer

Use the computer power button on the rack front. This photo shows both computer fronts beneath the PDU.



6. Confirm the display

Confirm that the monitor receives a signal from the selected computer.

If there is no display signal

Check that the monitor is powered on, the correct input is selected, and the HDMI cable is connected. Refer unresolved startup problems to the station lead.

Connection reference

PC1-RF and PC2-Pointing are the labels in the rack drawing. Use the hardware photos to identify the physical computer and cables before changing connections.

Source: Documentation/Ground-Station-PC-Setup-Instructions (1).docx, last modified 25 October 2023. This companion extracts the physical connection steps and basic display checks.